



ECS4650 Series

Software Release  
v1.1.0.9

CLI Reference Guide

# CLI Reference Guide

---

## **ECS4650-54T**

L3 Gigabit Ethernet Switch  
with 48 1000BASE-T RJ-45 ports  
and 6 25G SFP28 ports

## **ECS4650-54P**

L3 Gigabit Ethernet PoE Switch  
with 48 1000BASE-T RJ-45 PoE ports  
and 6 25G SFP28 ports

---

# How to Use This Guide

This guide includes detailed information on the switch software, including how to operate and use the management functions of the switch. To deploy this switch effectively and ensure trouble-free operation, you should first read the relevant sections in this guide so that you are familiar with all of its software features.

**Who Should Read This Guide?** This guide is for network administrators who are responsible for operating and maintaining network equipment. The guide assumes a basic working knowledge of LANs (Local Area Networks), the Internet Protocol (IP), and Simple Network Management Protocol (SNMP).

**How This Guide is Organized** This guide describes the switch's command line interface (CLI). For more detailed information on the switch's key features or information about the web browser management interface refer to the *Web Management Guide*.

The guide includes these sections:

- ◆ Section I "[Getting Started](#)" — Includes information on initial configuration.
- ◆ Section II "[Command Line Interface](#)" — Includes all management options available through the CLI.
- ◆ Section III "[Appendices](#)" — Includes information on troubleshooting switch management access.

**Related Documentation** This guide focuses on switch software configuration through the CLI.

For information on how to manage the switch through the Web management interface, see the following guide:

*Web Management Guide*

For information on how to install the switch, see the following guide:

*Quick Start Guide*

For all safety information and regulatory statements, see the following documents:

*Quick Start Guide*  
*Safety and Regulatory Information*

**Conventions** The following conventions are used throughout this guide to show information:



---

**Note:** Emphasizes important information or calls your attention to related features or instructions.

---



---

**Caution:** Alerts you to a potential hazard that could cause loss of data, or damage the system or equipment.

---

**Documentation Notice** This documentation is provided for general information purposes only. If any product feature details in this documentation conflict with the product datasheet, refer to the datasheet for the latest information.

**Revision History** This section summarizes the changes in each revision of this guide.

Revision	Date	Change Description
v1.1.0.9	02/2024	Initial release

---

# Contents

<b>How to Use This Guide</b>	<b>3</b>
<b>Contents</b>	<b>5</b>
<b>Tables</b>	<b>47</b>

---

<b>Section I</b>	<b>Getting Started</b>	<b>55</b>
	<b>1 Initial Switch Configuration</b>	<b>57</b>
	Connecting to the Switch	57
	Configuration Options	57
	Connecting to the Console Port	58
	Logging Onto the Command Line Interface	59
	Setting Passwords	59
	Remote Connections	60
	Configuring the Switch for Remote Management	61
	Using the Network Interface	61
	Setting an IP Address	61
	Configuring the Switch for Cloud Management	66
	Enabling SNMP Management Access	67
	Managing System Files	69
	Upgrading the Operation Code	70
	Saving or Restoring Configuration Settings	71
	Automatic Installation of Operation Code and Configuration Settings	72
	Downloading Operation Code from a File Server	72
	Specifying a DHCP Client Identifier	75
	Downloading a Configuration File and Other Parameters from a DHCP Server	76
	Setting the System Clock	78
	Setting the Time Manually	79
	Configuring SNTP	79

	Configuring NTP	80
<b>Section II</b>	<b>Command Line Interface</b>	<b>81</b>
<b>2</b>	<b>Using the Command Line Interface</b>	<b>83</b>
	Accessing the CLI	83
	Console Connection	83
	Telnet Connection	84
	Entering Commands	85
	Keywords and Arguments	85
	Minimum Abbreviation	85
	Command Completion	85
	Getting Help on Commands	86
	Partial Keyword Lookup	88
	Negating the Effect of Commands	88
	Using Command History	88
	Understanding Command Modes	88
	Exec Commands	89
	Configuration Commands	90
	Command Line Processing	92
	Showing Status Information	92
	CLI Command Groups	93
<b>3</b>	<b>General Commands</b>	<b>97</b>
	prompt	97
	reload (Global Configuration)	98
	enable	99
	quit	100
	show history	100
	configure	101
	disable	102
	reload (Privileged Exec)	102
	show reload	103
	end	103
	exit	103

<b>4 System Management Commands</b>	<b>105</b>
Cloud Management	106
mgmt	106
mgmt loglevel	107
mgmt setoption	107
mgmt property	109
mgmt upgrade	109
show mgmt status	110
show mgmt version	110
show mgmt log	110
show mgmt option	111
Device Designation	112
hostname	112
Banner Information	113
banner configure	113
banner configure company	115
banner configure dc-power-info	115
banner configure department	116
banner configure equipment-info	117
banner configure equipment-location	117
banner configure ip-lan	118
banner configure lp-number	119
banner configure manager-info	119
banner configure mux	120
banner configure note	121
show banner	121
System Status	122
show access-list tcam-utilization	123
show memory	124
show process cpu	124
show process cpu guard	125
show process cpu task	126
show running-config	126
show startup-config	128

show system	129
show tech-support	130
show users	131
show version	131
show watchdog	132
watchdog software	132
Fan Control	133
fan-speed force-full	133
Frame Size	133
jumbo frame	133
File Management	134
General Commands	136
boot system	136
copy	137
delete	141
dir	141
umount usbdisk	142
whichboot	143
Automatic Code Upgrade Commands	144
upgrade opcode auto	144
upgrade opcode path	145
upgrade opcode reload	146
show upgrade	146
TFTP Configuration Commands	147
ip tftp retry	147
ip tftp timeout	147
show ip tftp	148
Line	148
line	149
databits	150
exec-timeout	150
login	151
parity	152
password	153
password-thresh	153

silent-time	154
speed	155
stopbits	155
timeout login response	156
disconnect	157
terminal	157
show line	158
Event Logging	159
logging command	159
logging facility	160
logging history	160
logging host	161
logging level	162
logging on	163
logging trap	163
clear log	164
show log	164
show logging	165
SMTP Alerts	167
logging sendmail	167
logging sendmail destination-email	168
logging sendmail host	168
logging sendmail level	169
logging sendmail source-email	170
show logging sendmail	170
Time	171
SNTP Commands	172
sntp client	172
sntp poll	173
sntp server	173
show sntp	174
NTP Commands	174
ntp authenticate	174
ntp authentication-key	175
ntp client	176

ntp server	177
show ntp	178
show ntp status	178
show ntp statistics peer	178
show ntp peer-status	179
Manual Configuration Commands	180
clock summer-time (date)	180
clock summer-time (predefined)	181
clock summer-time (recurring)	182
clock timezone	183
clock timezone-predefined	184
calendar set	187
show calendar	187
Time Range	188
time-range	188
absolute	189
periodic	190
show time-range	191
Switch Clustering	191
cluster	192
cluster commander	193
cluster ip-pool	194
cluster member	194
rcommand	195
show cluster	196
show cluster members	196
show cluster candidates	196
Dying Gasp	197
dying-gasp	197
show dying-gasp status	198
show dying-gasp packets	198
<b>5 SNMP Commands</b>	<b>199</b>
General SNMP Commands	201
snmp-server	201

snmp-server community	201
snmp-server contact	202
snmp-server location	203
show snmp	203
<b>SNMP Target Host Commands</b>	<b>204</b>
snmp-server enable traps	204
snmp-server host	205
snmp-server enable port-traps link-up-down	207
snmp-server enable port-traps mac-notification	208
show snmp-server enable port-traps	208
<b>SNMPv3 Commands</b>	<b>209</b>
snmp-server engine-id	209
snmp-server group	210
snmp-server user	211
snmp-server view	213
show snmp engine-id	214
show snmp group	215
show snmp user	216
show snmp view	217
<b>Notification Log Commands</b>	<b>217</b>
nlm	217
snmp-server notify-filter	218
show nlm oper-status	220
show snmp notify-filter	220
<b>Additional Trap Commands</b>	<b>220</b>
memory	220
process cpu	221
process cpu guard	222
<b>6 Remote Monitoring Commands</b>	<b>225</b>
rmon alarm	226
rmon event	227
rmon collection history	228
rmon collection rmon1	229
show rmon alarms	230

show rmon events	230
show rmon history	231
show rmon statistics	231
<b>7 Flow Sampling Commands</b>	<b>233</b>
sflow owner	234
sflow polling instance	235
sflow sampling instance	236
show sflow	237
<b>8 Authentication Commands</b>	<b>239</b>
User Accounts and Privilege Levels	240
enable password	240
username	241
privilege	242
show privilege	243
Authentication Sequence	244
authentication enable	244
authentication login	245
RADIUS Client	246
radius-server acct-port	246
radius-server auth-port	247
radius-server host	247
radius-server key	248
radius-server encrypted-key	249
radius-server retransmit	249
radius-server timeout	250
show radius-server	250
TACACS+ Client	251
tacacs-server host	251
tacacs-server key	252
tacacs-server encrypted-key	253
tacacs-server port	253
tacacs-server retransmit	254
tacacs-server timeout	254
show tacacs-server	255

AAA	255
aaa accounting commands	256
aaa accounting dot1x	257
aaa accounting exec	258
aaa accounting update	259
aaa authorization commands	259
aaa authorization exec	260
aaa group server	261
server	261
accounting dot1x	262
accounting commands	263
accounting exec	263
authorization commands	264
authorization exec	264
show accounting	265
show authorization	266
Web Server	267
ip http authentication	267
ip http port	268
ip http server	268
ip http secure-port	269
ip http secure-server	269
Telnet Server	271
ip telnet max-sessions	271
ip telnet port	272
ip telnet server	272
telnet (client)	273
show ip telnet	273
Secure Shell	274
ip ssh authentication-retries	276
ip ssh server	277
ip ssh timeout	277
delete public-key	278
ip ssh crypto host-key generate	278
ip ssh crypto zeroize	279

ip ssh save host-key	280
show ip ssh	280
show public-key	281
show ssh	281
802.1X Port Authentication	282
General Commands	283
dot1x default	283
dot1x eapol-pass-through	284
dot1x system-auth-control	284
Authenticator Commands	285
dot1x intrusion-action	285
dot1x max-reauth-req	286
dot1x max-req	286
dot1x operation-mode	287
dot1x port-control	288
dot1x re-authentication	288
dot1x timeout quiet-period	289
dot1x timeout re-authperiod	289
dot1x timeout supp-timeout	290
dot1x timeout tx-period	290
dot1x re-authenticate	291
Supplicant Commands	292
dot1x identity profile	292
dot1x max-start	292
dot1x pae supplicant	293
dot1x timeout auth-period	294
dot1x timeout held-period	294
dot1x timeout start-period	295
Information Display Commands	295
show dot1x	295
Management IP Filter	298
management	298
show management	299
PPPoE Intermediate Agent	300
pppoe intermediate-agent	301

pppoe intermediate-agent format-type	301
pppoe intermediate-agent port-enable	302
pppoe intermediate-agent port-format-type	303
pppoe intermediate-agent port-format-type remote-id-delimiter	304
pppoe intermediate-agent trust	305
pppoe intermediate-agent vendor-tag strip	305
clear pppoe intermediate-agent statistics	306
show pppoe intermediate-agent info	306
show pppoe intermediate-agent statistics	307
<b>9 General Security Measures</b>	<b>309</b>
Port Security	310
mac-learning	310
port security	311
port security mac-address sticky	313
port security mac-address-as-permanent	313
show port security	314
Network Access (MAC Address Authentication)	316
network-access aging	317
network-access mac-filter	318
mac-authentication reauth-time	319
network-access dynamic-qos	319
network-access dynamic-vlan	320
network-access guest-vlan	321
network-access link-detection	322
network-access link-detection link-down	322
network-access link-detection link-up	323
network-access link-detection link-up-down	324
network-access max-mac-count	324
network-access mode mac-authentication	325
network-access port-mac-filter	326
mac-authentication intrusion-action	327
mac-authentication max-mac-count	327
clear network-access	328
show network-access	328

show network-access mac-address-table	329
show network-access mac-filter	330
Web Authentication	331
web-auth login-attempts	332
web-auth quiet-period	332
web-auth session-timeout	333
web-auth system-auth-control	333
web-auth	334
web-auth re-authenticate (Port)	334
web-auth re-authenticate (IP)	335
show web-auth	335
show web-auth interface	336
show web-auth summary	336
DHCPv4 Snooping	337
ip dhcp snooping	338
ip dhcp snooping information option	340
ip dhcp snooping information option encode no-subtype	341
ip dhcp snooping information option remote-id	342
ip dhcp snooping information option tr101 board-id	343
ip dhcp snooping information policy	344
ip dhcp snooping verify mac-address	344
ip dhcp snooping vlan	345
ip dhcp snooping information option circuit-id	346
ip dhcp snooping max-number	348
ip dhcp snooping trust	348
clear ip dhcp snooping binding	349
clear ip dhcp snooping database flash	349
ip dhcp snooping database flash	350
show ip dhcp snooping	350
show ip dhcp snooping binding	351
DHCPv6 Snooping	351
ipv6 dhcp snooping	352
ipv6 dhcp snooping option remote-id	354
ipv6 dhcp snooping option remote-id policy	355
ipv6 dhcp snooping vlan	356

ipv6 dhcp snooping max-binding	357
ipv6 dhcp snooping trust	357
clear ipv6 dhcp snooping binding	358
clear ipv6 dhcp snooping statistics	359
show ipv6 dhcp snooping	359
show ipv6 dhcp snooping binding	360
show ipv6 dhcp snooping statistics	360
IPv4 Source Guard	361
ip source-guard binding	361
ip source-guard	363
ip source-guard max-binding	365
ip source-guard mode	366
clear ip source-guard binding blocked	367
show ip source-guard	367
show ip source-guard binding	368
IPv6 Source Guard	369
ipv6 source-guard binding	369
ipv6 source-guard	371
ipv6 source-guard max-binding	372
show ipv6 source-guard	373
show ipv6 source-guard binding	374
ARP Inspection	374
ip arp inspection	375
ip arp inspection filter	376
ip arp inspection log-buffer logs	377
ip arp inspection validate	378
ip arp inspection vlan	379
ip arp inspection limit	380
ip arp inspection trust	380
show ip arp inspection configuration	381
show ip arp inspection interface	381
show ip arp inspection log	382
show ip arp inspection statistics	382
show ip arp inspection vlan	383
Denial of Service Protection	383

dos-protection echo-charge	384
dos-protection smurf	384
dos-protection tcp-flooding	385
dos-protection tcp-null-scan	385
dos-protection tcp-syn-fin-scan	386
dos-protection tcp-udp-port-zero	386
dos-protection tcp-xmas-scan	387
dos-protection udp-flooding	387
dos-protection win-nuke	388
show dos-protection	388
Port-based Traffic Segmentation	389
traffic-segmentation	389
traffic-segmentation session	391
traffic-segmentation uplink/downlink	391
traffic-segmentation uplink-to-uplink	392
show traffic-segmentation	393
<b>10 Access Control Lists</b>	<b>395</b>
IPv4 ACLs	395
access-list ip	396
permit, deny (Standard IP ACL)	396
permit, deny (Extended IPv4 ACL)	397
ip access-group	400
show ip access-group	401
show ip access-list	401
IPv6 ACLs	402
access-list ipv6	402
permit, deny (Standard IPv6 ACL)	403
permit, deny (Extended IPv6 ACL)	404
ipv6 access-group	406
show ipv6 access-group	407
show ipv6 access-list	407
MAC ACLs	408
access-list mac	408
permit, deny (MAC ACL)	409

mac access-group	413
show mac access-group	413
show mac access-list	414
ARP ACLs	414
access-list arp	414
permit, deny (ARP ACL)	415
show access-list arp	416
ACL Information	417
clear access-list hardware counters	417
show access-group	418
show access-list	418
<b>11 Interface Commands</b>	<b>421</b>
Interface Configuration	423
interface	423
alias	424
capabilities	424
description	425
discard	426
flowcontrol	426
history	427
media-type	428
fec	429
negotiation	429
shutdown	430
speed-duplex	430
clear counters	431
show discard	432
show interfaces brief	432
show interfaces counters	433
show interfaces history	437
show interfaces status	439
show interfaces switchport	440
Transceiver Threshold Configuration	442
transceiver-monitor	442

transceiver-threshold-auto	443
transceiver-threshold current	443
transceiver-threshold rx-power	444
transceiver-threshold temperature	445
transceiver-threshold tx-power	446
transceiver-threshold voltage	447
show interfaces transceiver	448
show interfaces transceiver-threshold	449
Cable Diagnostics	450
test cable-diagnostics	450
test loop internal	451
show cable-diagnostics	451
show loop internal	452
Power Savings	453
power-save	453
show power-save	454
<b>12 Link Aggregation Commands</b>	<b>455</b>
Manual Configuration Commands	457
port-channel load-balance	457
channel-group	458
Dynamic Configuration Commands	459
lacp	459
lacp actor/partner mode (Ethernet Interface)	460
lacp admin-key (Ethernet Interface)	461
lacp port-priority	462
lacp system-priority	463
lacp admin-key (Port Channel)	463
lacp timeout	464
Trunk Status Display Commands	465
show lacp	465
show port-channel load-balance	468
MLAG Commands	469
mLAG	470
mLAG domain peer-link	470

mlag group member	471
show mlag	473
show mlag group	473
show mlag domain	473
<b>13 Power over Ethernet Commands</b>	<b>475</b>
power inline	475
power inline maximum allocation	476
power inline priority	477
show power inline status	478
show power inline time-range	479
show power mainpower	480
<b>14 Port Mirroring Commands</b>	<b>481</b>
Local Port Mirroring Commands	481
port monitor	481
show port monitor	483
RSPAN Mirroring Commands	484
rspan source	486
rspan destination	487
rspan remote vlan	488
no rspan session	489
show rspan	490
<b>15 Congestion Control Commands</b>	<b>491</b>
Rate Limit Commands	491
rate-limit	492
Storm Control Commands	493
switchport packet-rate	493
Automatic Traffic Control Commands	494
Threshold Commands	497
auto-traffic-control apply-timer	497
auto-traffic-control release-timer	498
auto-traffic-control	499
auto-traffic-control action	499
auto-traffic-control alarm-clear-threshold	500

auto-traffic-control alarm-fire-threshold	501
auto-traffic-control auto-control-release	502
auto-traffic-control control-release	503
SNMP Trap Commands	503
snmp-server enable port-traps atc broadcast-alarm-clear	503
snmp-server enable port-traps atc broadcast-alarm-fire	504
snmp-server enable port-traps atc broadcast-control-apply	504
snmp-server enable port-traps atc broadcast-control-release	505
snmp-server enable port-traps atc multicast-alarm-clear	505
snmp-server enable port-traps atc multicast-alarm-fire	506
snmp-server enable port-traps atc multicast-control-apply	506
snmp-server enable port-traps atc multicast-control-release	507
ATC Display Commands	507
show auto-traffic-control	507
show auto-traffic-control interface	508
<b>16 Loopback Detection Commands</b>	<b>509</b>
loopback-detection	510
loopback-detection action	510
loopback-detection recover-time	511
loopback-detection transmit-interval	512
loopback detection trap	512
loopback-detection release	513
show loopback-detection	513
<b>17 UniDirectional Link Detection Commands</b>	<b>515</b>
udld detection-interval	515
udld message-interval	516
udld recovery	517
udld recovery-interval	517
udld aggressive	518
udld port	519
show udld	520
<b>18 Address Table Commands</b>	<b>523</b>
mac-address-table aging-time	523

mac-address-table static	524
clear mac-address-table dynamic	525
show mac-address-table	526
show mac-address-table aging-time	527
show mac-address-table count	527
show mac-address-table hash-lookup-depth	528
<b>19 Smart Pair Commands</b>	<b>529</b>
Smart Pair Concept	529
smart-pair	529
smart-pair restore	530
primary-port	531
backup-port	532
wtr-delay	533
show smart-pair	533
<b>20 TWAMP Commands</b>	<b>535</b>
twamp reflector	535
twamp reflector refwait	536
show twamp reflector	536
<b>21 Spanning Tree Commands</b>	<b>537</b>
spanning-tree	538
spanning-tree cisco-prestandard	539
spanning-tree forward-time	539
spanning-tree hello-time	540
spanning-tree max-age	541
spanning-tree mode	541
spanning-tree mst configuration	543
spanning-tree pathcost method	543
spanning-tree priority	544
spanning-tree system-bpdu-flooding	545
spanning-tree tc-prop	545
spanning-tree transmission-limit	546
max-hops	547
mst priority	547

mst vlan	548
name	549
revision	549
spanning-tree bpdu-filter	550
spanning-tree bpdu-guard	551
spanning-tree cost	552
spanning-tree edge-port	553
spanning-tree link-type	554
spanning-tree loopback-detection	555
spanning-tree loopback-detection action	555
spanning-tree loopback-detection release-mode	556
spanning-tree loopback-detection trap	557
spanning-tree restricted-tcn	557
spanning-tree mst cost	558
spanning-tree mst port-priority	559
spanning-tree port-bpdu-flooding	559
spanning-tree port-priority	560
spanning-tree root-guard	561
spanning-tree spanning-disabled	562
spanning-tree tc-prop-stop	562
spanning-tree loopback-detection release	563
spanning-tree protocol-migration	563
show spanning-tree	564
show spanning-tree mst configuration	566
show spanning-tree tc-prop	567
<b>22 VLAN Commands</b>	<b>569</b>
GVRP and Bridge Extension Commands	570
bridge-ext gvrp	570
garp timer	571
switchport forbidden vlan	572
switchport gvrp	573
show bridge-ext	573
show garp timer	574
show gvrp configuration	575

Editing VLAN Groups	576
vlan database	576
vlan	577
Configuring VLAN Interfaces	578
interface vlan	578
switchport acceptable-frame-types	579
switchport allowed vlan	580
switchport ingress-filtering	581
switchport mode	582
switchport native vlan	583
vlan-trunking	584
Displaying VLAN Information	585
show vlan	585
Configuring IEEE 802.1Q Tunneling	586
dot1q-tunnel system-tunnel-control	587
dot1q-tunnel tpid	588
switchport dot1q-tunnel mode	589
switchport dot1q-tunnel priority map	590
switchport dot1q-tunnel service match cvid	590
show dot1q-tunnel service	592
show dot1q-tunnel	593
Configuring L2PT Tunneling	594
l2protocol-tunnel tunnel-dmac	594
switchport l2protocol-tunnel	597
show l2protocol-tunnel	598
Configuring VLAN Translation	598
switchport vlan-translation	598
show vlan-translation	600
Configuring Protocol-based VLANs	601
protocol-vlan protocol-group (Configuring Groups)	602
protocol-vlan protocol-group (Configuring Interfaces)	603
show protocol-vlan protocol-group	604
show interfaces protocol-vlan protocol-group	604
Configuring IP Subnet VLANs	605
subnet-vlan	605

show subnet-vlan	606
Configuring MAC Based VLANs	607
mac-vlan	607
show mac-vlan	608
Configuring Voice VLANs	609
voice vlan	609
voice vlan aging	610
voice vlan mac-address	611
switchport voice vlan	612
switchport voice vlan priority	613
switchport voice vlan rule	613
switchport voice vlan security	614
show voice vlan	615
Configuring Excluded VLANs	616
excluded-vlan	616
show excluded-vlan	617
<b>23 ERPS Commands</b>	<b>619</b>
erps	621
erps node-id	622
erps vlan-group	623
erps ring	623
erps instance	624
ring-port	625
exclusion-vlan	626
enable (ring)	626
enable (instance)	627
meg-level	627
control-vlan	628
rpl owner	629
rpl neighbor	630
wtr-timer	631
guard-timer	631
holdoff-timer	632
major-ring	633

propagate-tc	633
bpdu-tcn-notify	634
non-revertive	634
raps-def-mac	638
raps-without-vc	639
version	641
inclusion-vlan	642
physical-ring	643
erps forced-switch	643
erps manual-switch	645
erps clear	647
clear erps statistics	647
show erps statistics	648
show erps	649
<b>24 Class of Service Commands</b>	<b>653</b>
Priority Commands (Layer 2)	653
queue mode	654
queue weight	655
switchport priority default	656
show queue mode	657
show queue weight	657
Priority Commands (Layer 3 and 4)	658
qos map phb-queue	658
qos map cos-dscp	659
qos map dscp-mutation	661
qos map ip-prec-dscp	662
qos map trust-mode	663
show qos map cos-dscp	664
show qos map dscp-mutation	665
show qos map ip-prec-dscp	665
show qos map phb-queue	666
show qos map trust-mode	667
<b>25 Quality of Service Commands</b>	<b>669</b>
class-map	670

description	671
match	672
rename	673
policy-map	674
class	674
police flow	675
police srtcm-color	677
police trtcm-color	679
set cos	681
set ip dscp	682
set phb	683
service-policy	684
show class-map	684
show policy-map	685
show policy-map interface	686
<b>26 Control Plane Commands</b>	<b>687</b>
control-plane	687
service-policy	688
show policy-map control-plane	688
<b>27 Multicast Filtering Commands</b>	<b>691</b>
IGMP Snooping	691
ip igmp snooping	693
ip igmp snooping mrouter-forward-mode dynamic	694
ip igmp snooping proxy-reporting	694
ip igmp snooping report-suppression	695
ip igmp snooping querier	696
ip igmp snooping router-alert-option-check	696
ip igmp snooping router-port-expire-time	697
ip igmp snooping tcn-flood	697
ip igmp snooping tcn-query-solicit	699
ip igmp snooping unregistered-data-flood	699
ip igmp snooping unsolicited-report-interval	700
ip igmp snooping version	701
ip igmp snooping version-exclusive	701

ip igmp snooping vlan general-query-suppression	702
ip igmp snooping vlan immediate-leave	703
ip igmp snooping vlan last-memb-query-count	704
ip igmp snooping vlan last-memb-query-intvl	704
ip igmp snooping vlan mrd	705
ip igmp snooping vlan proxy-address	706
ip igmp snooping vlan query-interval	707
ip igmp snooping vlan query-resp-intvl	708
ip igmp snooping vlan static	709
clear ip igmp snooping groups dynamic	709
clear ip igmp snooping statistics	710
show ip igmp snooping	710
show ip igmp snooping group	711
show ip igmp snooping mrouter	712
show ip igmp snooping statistics	713
Static Multicast Routing	716
ip igmp snooping vlan mrouter	716
IGMP Filtering and Throttling	717
ip igmp filter (Global Configuration)	718
ip igmp profile	719
permit, deny	719
range	720
ip igmp authentication	720
ip igmp filter (Interface Configuration)	722
ip igmp max-groups	723
ip igmp max-groups action	724
ip igmp query-drop	724
ip multicast-data-drop	725
show ip igmp authentication	725
show ip igmp filter	726
show ip igmp profile	727
show ip igmp query-drop	727
show ip igmp throttle interface	728
show ip multicast-data-drop	729
MLD Snooping	729

ipv6 mld snooping	731
ipv6 mld snooping proxy-reporting	731
ipv6 mld snooping querier	732
ipv6 mld snooping query-interval	732
ipv6 mld snooping query-max-response-time	733
ipv6 mld snooping robustness	733
ipv6 mld snooping router-port-expire-time	734
ipv6 mld snooping unknown-multicast mode	735
ipv6 mld snooping unsolicited-report-interval	735
ipv6 mld snooping version	736
ipv6 mld snooping vlan immediate-leave	736
ipv6 mld snooping vlan mrouter	737
ipv6 mld snooping vlan static	738
clear ipv6 mld snooping groups dynamic	739
clear ipv6 mld snooping statistics	739
show ipv6 mld snooping	740
show ipv6 mld snooping group	741
show ipv6 mld snooping group source-list	741
show ipv6 mld snooping mrouter	742
show ipv6 mld snooping statistics	743
MLD Filtering and Throttling	747
ipv6 mld filter (Global Configuration)	747
ipv6 mld profile	748
permit, deny	749
range	749
ipv6 mld filter (Interface Configuration)	750
ipv6 mld max-groups	751
ipv6 mld max-groups action	751
ipv6 mld query-drop	752
ipv6 multicast-data-drop	753
show ipv6 mld filter	753
show ipv6 mld profile	754
show ipv6 mld query-drop	754
show ipv6 mld throttle interface	755
IGMP (Layer 3)	756

ip igmp	756
ip igmp last-member-query-interval	757
ip igmp max-resp-interval	758
ip igmp query-interval	758
ip igmp static-group	759
ip igmp version	760
clear ip igmp group	761
show ip igmp groups	761
show ip igmp interface	763
MVR for IPv4	764
mvr	766
mvr associated-profile	766
mvr domain	767
mvr profile	767
mvr proxy-query-interval	768
mvr proxy-switching	769
mvr robustness-value	770
mvr source-port-mode	771
mvr upstream-source-ip	772
mvr vlan	772
mvr immediate-leave	773
mvr type	774
mvr vlan group	775
clear mvr groups dynamic	776
clear mvr statistics	776
show mvr	777
show mvr associated-profile	778
show mvr interface	779
show mvr members	780
show mvr profile	782
show mvr statistics	782
MVR for IPv6	788
mvr6 associated-profile	789
mvr6 domain	789
mvr6 profile	790

mvr6 proxy-query-interval	791
mvr6 proxy-switching	792
mvr6 robustness-value	793
mvr6 source-port-mode dynamic	794
mvr6 upstream-source-ip	794
mvr6 vlan	795
mvr6 immediate-leave	796
mvr6 type	797
mvr6 vlan group	798
clear mvr6 groups dynamic	799
clear mvr6 statistics	799
show mvr6	800
show mvr6 associated-profile	801
show mvr6 interface	802
show mvr6 members	802
show mvr6 domain	804
show mvr6 profile	805
show mvr6 statistics	806
<b>28 LLDP Commands</b>	<b>811</b>
lldp	813
lldp holdtime-multiplier	813
lldp med-fast-start-count	814
lldp notification-interval	814
lldp refresh-interval	815
lldp reinit-delay	815
lldp tx-delay	816
lldp admin-status	817
lldp basic-tlv management-ip-address	817
lldp basic-tlv management-ipv6-address	818
lldp basic-tlv port-description	819
lldp basic-tlv system-capabilities	819
lldp basic-tlv system-description	820
lldp basic-tlv system-name	820
lldp dot1-tlv proto-ident	821

lldp dot1-tlv proto-vid	821
lldp dot1-tlv pvid	822
lldp dot1-tlv vlan-name	822
lldp dot3-tlv link-agg	823
lldp dot3-tlv mac-phy	823
lldp dot3-tlv max-frame	824
lldp dot3-tlv poe	824
lldp med-location civic-addr	825
lldp med-notification	827
lldp med-tlv ext-poe	827
lldp med-tlv inventory	828
lldp med-tlv location	829
lldp med-tlv med-cap	829
lldp med-tlv network-policy	830
lldp notification	830
show lldp config	831
show lldp info local-device	832
show lldp info remote-device	833
show lldp info statistics	835
<b>29 CFM Commands</b>	<b>837</b>
Defining CFM Structures	840
ethernet cfm ais level	840
ethernet cfm ais ma	841
ethernet cfm ais period	842
ethernet cfm ais suppress alarm	842
ethernet cfm domain	843
ethernet cfm enable	845
ma index name	846
ma index name-format	847
ethernet cfm mep	848
ethernet cfm port-enable	849
clear ethernet cfm ais mpid	849
show ethernet cfm configuration	850
show ethernet cfm md	852

show ethernet cfm ma	852
show ethernet cfm maintenance-points local	853
show ethernet cfm maintenance-points local detail mep	854
show ethernet cfm maintenance-points remote detail	855
Continuity Check Operations	857
ethernet cfm cc ma interval	857
ethernet cfm cc enable	858
snmp-server enable traps ethernet cfm cc	859
mep archive-hold-time	860
clear ethernet cfm maintenance-points remote	860
clear ethernet cfm errors	861
show ethernet cfm errors	862
Cross Check Operations	863
ethernet cfm mep crosscheck start-delay	863
snmp-server enable traps ethernet cfm crosscheck	863
mep crosscheck mpid	864
ethernet cfm mep crosscheck	865
show ethernet cfm maintenance-points remote crosscheck	866
Link Trace Operations	866
ethernet cfm linktrace cache	866
ethernet cfm linktrace cache hold-time	867
ethernet cfm linktrace cache size	868
ethernet cfm linktrace	869
clear ethernet cfm linktrace-cache	870
show ethernet cfm linktrace-cache	870
Loopback Operations	871
ethernet cfm loopback	871
Fault Generator Operations	873
mep fault-notify alarm-time	873
mep fault-notify lowest-priority	873
mep fault-notify reset-time	875
show ethernet cfm fault-notify-generator	875
Delay Measure Operations	876
ethernet cfm delay-measure two-way	876

<b>30 OAM Commands</b>	<b>879</b>
efm oam	880
efm oam critical-link-event	880
efm oam link-monitor frame	881
efm oam link-monitor frame threshold	882
efm oam link-monitor frame window	882
efm oam mode	<b>883</b>
clear efm oam counters	884
clear efm oam event-log	884
efm oam remote-loopback	885
efm oam remote-loopback test	886
show efm oam counters interface	887
show efm oam event-log interface	887
show efm oam remote-loopback interface	889
show efm oam status interface	889
show efm oam status remote interface	890
<b>31 Domain Name Service Commands</b>	<b>891</b>
DNS Commands	892
ip domain-list	892
ip domain-lookup	893
ip domain-name	894
ip host	894
ip name-server	895
ipv6 host	896
clear dns cache	897
show dns	897
show dns cache	897
show hosts	898
Multicast DNS Commands	899
ip mdns	899
show ip mdns	899
<b>32 DHCP Commands</b>	<b>901</b>
DHCP Client	901

DHCP for IPv4	902
ip dhcp dynamic-provision	902
ip dhcp client class-id	903
ip dhcp inform	905
ip dhcp restart client	906
show ip dhcp dynamic-provision	906
DHCP for IPv6	907
ipv6 dhcp client rapid-commit vlan	907
ipv6 dhcp restart client vlan	907
ipv6 dhcp dynamic-provision	909
show ipv6 dhcp duid	909
show ipv6 dhcp vlan	910
show ipv6 dhcp dynamic-provision	910
DHCP Relay	911
Global DHCP Relay settings	911
ip dhcp relay server	911
ip dhcp restart relay	912
show ip dhcp relay	913
L3 DHCP Relay Option Settings	914
ip dhcp relay information option	914
ip dhcp relay information option encode no-subtype	914
ip dhcp relay information option remote-id	915
ip dhcp relay information policy	915
DHCP Relay for IPv6	916
ipv6 dhcp relay destination	916
show ipv6 dhcp relay destination	918
DHCP Server	918
ip dhcp excluded-address	919
ip dhcp pool	919
service dhcp	920
bootfile	921
client-identifier	921
default-router	922
dns-server	923
domain-name	923

hardware-address	924
host	924
lease	926
netbios-name-server	926
netbios-node-type	927
network	928
next-server	929
option	929
clear ip dhcp binding	930
show ip dhcp binding	931
show ip dhcp	931
show ip dhcp pool	931
<b>33 IP Interface Commands</b>	<b>933</b>
IPv4 Interface	933
Basic IPv4 Configuration	934
ip address	934
ip default-gateway	936
interface loopback	937
ip address (loopback)	937
show ip interface	938
show ip traffic	938
traceroute	939
ping	940
ARP Configuration	942
arp	942
arp timeout	943
ip proxy-arp	944
clear arp-cache	944
show arp	945
UDP Helper Configuration	946
ip forward-protocol udp	946
ip helper	947
ip helper-address	948
show ip helper	949

IPv6 Interface	949
Interface Address Configuration and Utilities	951
ipv6 default-gateway	951
ipv6 address	952
ipv6 address autoconfig	953
ipv6 address dhcp	955
ipv6 address eui-64	956
ipv6 address link-local	958
ipv6 enable	959
ipv6 mtu	960
show ipv6 interface	961
show ipv6 mtu	963
show ipv6 traffic	964
clear ipv6 traffic	968
ping6	969
traceroute6	970
Neighbor Discovery	971
ipv6 hop-limit	971
ipv6 neighbor	972
ipv6 nd dad attempts	973
ipv6 nd managed-config-flag	975
ipv6 nd other-config-flag	975
ipv6 nd ns-interval	976
ipv6 nd rguard	977
show ipv6 nd rguard	978
ipv6 nd reachable-time	979
ipv6 nd prefix	979
ipv6 nd ra interval	981
ipv6 nd ra lifetime	982
ipv6 nd ra router-preference	982
ipv6 nd ra suppress	983
clear ipv6 neighbors	984
show ipv6 neighbors	984
show ipv6 nd prefix	985
ND Snooping	986

ipv6 nd snooping	987
ipv6 nd snooping auto-detect	988
ipv6 nd snooping auto-detect retransmit count	989
ipv6 nd snooping auto-detect retransmit interval	990
ipv6 nd snooping prefix timeout	990
ipv6 nd snooping max-binding	991
ipv6 nd snooping trust	991
clear ipv6 nd snooping binding	992
clear ipv6 nd snooping prefix	992
show ipv6 nd snooping	993
show ipv6 nd snooping binding	993
show ipv6 nd snooping prefix	994
<b>34 VRRP Commands</b>	<b>995</b>
vrrp authentication	996
vrrp ip	996
vrrp preempt	997
vrrp priority	998
vrrp timers advertise	999
show vrrp	1000
show vrrp interface	1002
show vrrp interface counters	1003
show vrrp router counters	1004
<b>35 IP Routing Commands</b>	<b>1005</b>
Global Routing Configuration	1005
IPv4 Commands	1006
ip route	1006
maximum-paths	1007
show ip route	1007
show ip host-route	1009
show ip route database	1010
show ip route summary	1010
show ip traffic	1010
IPv6 Commands	1012
ipv6 route	1012

show ipv6 route	1013
<b>36 RIP Commands</b>	<b>1015</b>
router rip	1016
default-information originate	1016
default-metric	1017
distance	1018
maximum-prefix	1019
neighbor	1019
network	1020
passive-interface	1021
redistribute	1022
timers basic	1023
version	1024
ip rip authentication mode	1025
ip rip authentication string	1026
ip rip receive version	1027
ip rip receive-packet	1027
ip rip send version	1028
ip rip send-packet	1029
ip rip split-horizon	1030
clear ip rip route	1030
show ip protocols rip	1031
show ip rip	1032
<b>37 OSPF Commands</b>	<b>1033</b>
Open Shortest Path First (OSPFv2)	1033
router ospf	1035
area authentication	1036
area default-cost	1037
area nssa	1038
area range	1040
area stub	1040
auto-cost reference-bandwidth	1042
compatible rfc1583	1042
default-information originate	1043

default-metric	1045
passive-interface	1045
redistribute	1046
router-id	1048
summary-address	1048
timers spf	1049
ip ospf area	1050
ip ospf authentication	1051
ip ospf authentication-key	1052
ip ospf cost	1053
ip ospf dead-interval	1054
ip ospf hello-interval	1054
ip ospf message-digest-key	1055
ip ospf network	1056
ip ospf priority	1057
ip ospf retransmit-interval	1058
ip ospf transmit-delay	1058
clear ip ospf process	1059
show ip ospf	1059
show ip ospf border-routers	1060
show ip ospf database	1061
show ip ospf database asbr-summary	1062
show ip ospf database external	1063
show ip ospf database network	1064
show ip ospf database nssa-external	1065
show ip ospf database router	1066
show ip ospf database self-originate	1067
show ip ospf database summary	1068
show ip ospf interface	1070
show ip ospf neighbor	1071
show ip ospf route	1071
Open Shortest Path First (OSPFv3)	1072
router ipv6 ospf	1073
area range	1074
area stub	1075

default-metric	1076
passive-interface	1077
redistribute	1078
router-id	1079
timers spf	1080
ipv6 ospf area	1080
ipv6 ospf cost	1081
ipv6 ospf dead-interval	1082
ipv6 ospf hello-interval	1083
ipv6 ospf priority	1083
ipv6 ospf retransmit-interval	1084
ipv6 ospf transmit-delay	1085
show ipv6 ospf	1086
show ipv6 ospf database	1086
show ipv6 ospf database external	1087
show ipv6 ospf database inter-area-prefix	1088
show ipv6 ospf database inter-area-router	1088
show ipv6 ospf database intra-area-router	1089
show ipv6 ospf database link	1089
show ipv6 ospf database network	1090
show ipv6 ospf database router	1090
show ipv6 ospf database self-originate	1091
show ipv6 ospf interface	1091
show ipv6 ospf neighbor	1092
show ipv6 ospf route	1092
<b>38 BGPv4 Commands</b>	<b>1093</b>
Border Gateway Protocol (BGPv4)	1093
router bgp	1097
bgp as-path access-list	1098
bgp community-list	1099
bgp extcommunity-list	1101
ip prefix-list	1103
aggregate-address	1104
bgp always-compare-med	1106

bgp bestpath as-path ignore	1106
bgp bestpath as-path confed	1107
bgp bestpath compare-routerid	1107
bgp bestpath med	1108
bgp client-to-client reflection	1108
bgp cluster-id	1109
bgp confederation identifier	1110
bgp confederation peers	1111
bgp dampening	1112
bgp default local-preference	1113
bgp deterministic-med	1114
bgp fast-external-failover	1114
bgp log-neighbor-changes	1115
bgp network import-check	1116
bgp router-id	1116
bgp conditional-advertisement timer	1117
clear ip bgp	1117
clear ip bgp ipv4	1119
clear ip bgp dampening	1120
distance	1121
distance bgp	1121
neighbor activate	1123
neighbor advertisement-interval	1123
neighbor allowas-in	1124
neighbor attribute-unchanged	1125
neighbor capability dynamic	1125
neighbor capability orf prefix-list	1126
neighbor default-originate	1127
neighbor description	1128
neighbor distribute-list	1128
neighbor dont-capability-negotiate	1129
neighbor ebgp-multihop	1130
neighbor enforce-first-as	1130
neighbor enforce-multihop	1131
neighbor filter-list	1131

neighbor interface	1132
neighbor maximum-prefix	1133
neighbor next-hop-self	1134
neighbor override-capability	1134
neighbor passive	1135
neighbor password	1136
neighbor peer-group (Creating)	1136
neighbor peer-group (Group Members)	1137
neighbor port	1138
neighbor prefix-list	1138
neighbor remote-as	1139
neighbor remove-private-as	1140
neighbor route-map	1141
neighbor route-reflector-client	1141
neighbor route-server-client	1142
neighbor send-community	1143
neighbor shutdown	1144
neighbor soft-reconfiguration inbound	1144
neighbor strict-capability-match	1145
neighbor timers	1146
neighbor timers connect	1147
neighbor unsuppress-map	1147
neighbor update-source	1148
neighbor weight	1149
network	1149
redistribute	1150
timers bgp	1151
show ip bgp	1152
show ip bgp attribute-info	1153
show ip bgp community	1153
show ip bgp community-info	1154
show ip bgp community-list	1155
show ip bgp dampening	1155
show ip bgp filter-list	1156
show ip bgp neighbors	1157

show ip bgp paths	1157
show ip bgp prefix-list	1158
show ip bgp regexp	1158
show ip bgp route-map	1159
show ip bgp nexthop	1160
show ip bgp summary	1160
show ip community-list	1161
show ip extcommunity-list	1161
show ip prefix-list	1162
show ip prefix-list detail	1162
show ip prefix-list summary	1163
Policy-based Routing for BGP	1163
route-map	1165
call	1166
continue	1167
description	1167
match as-path	1168
match community	1168
match extcommunity	1169
match ip address	1170
match ip next-hop	1170
match ip route-source	1171
match metric	1171
match origin	1172
match peer	1172
on-match	1173
set aggregator as	1173
set as-path	1174
set atomic-aggregate	1175
set comm-list delete	1175
set community	1176
set extcommunity	1177
set ip next-hop	1178
set local-preference	1179
set metric	1180

set origin	1180
set originator-id	1181
set weight	1182
show route-map	1182
<b>39 PIM Commands</b>	<b>1185</b>
router pim	1186
ip pim	1186
ip pim hello-holdtime	1188
ip pim hello-interval	1188
ip pim join-prune-holdtime	1189
ip pim override-interval	1189
ip pim propagation-delay	1190
show ip pim interface	1191
show ip pim neighbor	1191
ip pim dr-priority	1192
ip pim join-prune-interval	1194
ip pim rp-address	1195
ip pim spt-threshold	1196
ip pim ssm range	1197
<b>40 Multicast Routing Commands</b>	<b>1199</b>
ip multicast-routing	1199
show ip mroute	1200

---

<b>Section III</b>	<b>Appendices</b>	<b>1203</b>
	<b>A Troubleshooting</b>	<b>1205</b>
	Problems Accessing the Management Interface	1205
	Using System Logs	1206
	<b>B License Information</b>	<b>1207</b>
	The GNU General Public License	1207
	<b>List of Commands</b>	<b>1211</b>

---

# Tables

Table 1: DHCP Options 60, 66 and 67 Statements	77
Table 2: DHCPv6 Options 59 and 60 Statements	77
Table 3: DHCP Options 55 and 124 Statements	77
Table 4: General Command Modes	89
Table 5: Configuration Command Modes	91
Table 6: Keystroke Commands	92
Table 7: Command Group Index	93
Table 8: General Commands	97
Table 9: System Management Commands	105
Table 10: Cloud Management Commands	106
Table 11: Cloud Management Agent Options	108
Table 12: Device Designation Commands	112
Table 13: Banner Commands	113
Table 14: System Status Commands	122
Table 15: show access-list tcam-utilization - display description	123
Table 16: show process cpu guard - display description	125
Table 17: show system – display description	129
Table 18: show version – display description	132
Table 19: Fan Control Commands	133
Table 20: Frame Size Commands	133
Table 21: Flash/File Commands	135
Table 22: File Directory Information	142
Table 23: Line Commands	148
Table 24: Event Logging Commands	159
Table 25: Logging Levels	161
Table 26: show logging flash/ram - display description	166
Table 27: show logging trap - display description	167
Table 28: Event Logging Commands	167
Table 29: Time Commands	171

Table 30: Predefined Summer-Time Parameters	182
Table 31: Time Range Commands	188
Table 32: Switch Cluster Commands	191
Table 33: Dying-Gasp Commands	197
Table 34: SNMP Commands	199
Table 35: show snmp engine-id - display description	214
Table 36: show snmp group - display description	215
Table 37: show snmp user - display description	216
Table 38: show snmp view - display description	217
Table 39: RMON Commands	225
Table 40: sFlow Commands	233
Table 41: Authentication Commands	239
Table 42: User Access Commands	240
Table 43: Default Login Settings	242
Table 44: Authentication Sequence Commands	244
Table 45: RADIUS Client Commands	246
Table 46: TACACS+ Client Commands	251
Table 47: AAA Commands	255
Table 48: Web Server Commands	267
Table 49: HTTPS System Support	270
Table 50: Telnet Server Commands	271
Table 51: Secure Shell Commands	274
Table 52: show ssh - display description	282
Table 53: 802.1X Port Authentication Commands	282
Table 54: Management IP Filter Commands	298
Table 55: PPPoE Intermediate Agent Commands	300
Table 56: show pppoe intermediate-agent statistics - display description	308
Table 57: General Security Commands	309
Table 58: Management IP Filter Commands	310
Table 59: show port security - display description	315
Table 60: Network Access Commands	316
Table 61: Dynamic QoS Profiles	320
Table 62: Web Authentication	331
Table 63: DHCP Snooping Commands	337
Table 64: Option 82 information	341

Table 65: Option 82 information	347
Table 66: DHCP Snooping Commands	351
Table 67: IPv4 Source Guard Commands	361
Table 68: IPv6 Source Guard Commands	369
Table 69: ARP Inspection Commands	375
Table 70: DoS Protection Commands	383
Table 71: Commands for Configuring Traffic Segmentation	389
Table 72: Traffic Segmentation Forwarding	390
Table 73: Access Control List Commands	395
Table 74: IPv4 ACL Commands	395
Table 75: IPv6 ACL Commands	402
Table 76: MAC ACL Commands	408
Table 77: ARP ACL Commands	414
Table 78: ACL Information Commands	417
Table 79: Interface Commands	421
Table 80: show interfaces counters - display description	434
Table 81: show interfaces switchport - display description	441
Table 82: Link Aggregation Commands	455
Table 83: show lacp counters - display description	466
Table 84: show lacp internal - display description	466
Table 85: show lacp neighbors - display description	467
Table 86: show lacp sysid - display description	468
Table 87: PoE Commands	475
Table 88: Maximum PoE Based on PD Classification	476
Table 89: show power inline status - display description	479
Table 90: show power mainpower - display description	480
Table 91: Port Mirroring Commands	481
Table 92: Mirror Port Commands	481
Table 93: RSPAN Commands	484
Table 94: Congestion Control Commands	491
Table 95: Rate Limit Commands	491
Table 96: Rate Limit Commands	493
Table 97: ATC Commands	494
Table 98: Loopback Detection Commands	509
Table 99: UniDirectional Link Detection Commands	515

Table 100: show udd - display description	520
Table 101: Address Table Commands	523
Table 102: Address Table Commands	529
Table 103: TWAMP Commands	535
Table 104: Spanning Tree Commands	537
Table 105: Recommended STA Path Cost Range	552
Table 106: Default STA Path Costs	552
Table 107: VLAN Commands	569
Table 108: GVRP and Bridge Extension Commands	570
Table 109: show bridge-ext - display description	574
Table 110: Commands for Editing VLAN Groups	576
Table 111: Commands for Configuring VLAN Interfaces	578
Table 112: Commands for Displaying VLAN Information	585
Table 113: 802.1Q Tunneling Commands	586
Table 114: L2 Protocol Tunnel Commands	594
Table 115: VLAN Translation Commands	598
Table 116: Protocol-based VLAN Commands	601
Table 117: IP Subnet VLAN Commands	605
Table 118: MAC Based VLAN Commands	607
Table 119: Voice VLAN Commands	609
Table 120: Excluded VLAN Commands	616
Table 121: ERPS Commands	619
Table 122: ERPS Request/State Priority	644
Table 123: show erps statistics - detailed display description	649
Table 124: show erps ring - summary display description	650
Table 125: Priority Commands	653
Table 126: Priority Commands (Layer 2)	653
Table 127: Priority Commands (Layer 3 and 4)	658
Table 128: Mapping Internal Per-hop Behavior to Hardware Queues	658
Table 129: Default Mapping of CoS/CFI to Internal PHB/Drop Precedence	659
Table 130: Default Mapping of DSCP Values to Internal PHB/Drop Values	661
Table 131: Default Mapping of IP Precedence to Internal PHB/Drop Values	662
Table 132: Quality of Service Commands	669
Table 133: Control Plane Commands	687
Table 134: Multicast Filtering Commands	691

Table 135: IGMP Snooping Commands	691
Table 136: show ip igmp snooping statistics input - display description	714
Table 137: show ip igmp snooping statistics output - display description	714
Table 138: show ip igmp snooping statistics vlan query - display description	715
Table 139: Static Multicast Interface Commands	716
Table 140: IGMP Filtering and Throttling Commands	717
Table 141: IGMP Authentication RADIUS Attribute Value Pairs	721
Table 142: MLD Snooping Commands	730
Table 143: show ipv6 MLD snooping statistics input - display description	743
Table 144: show ipv6 MLD snooping statistics output - display description	744
Table 145: show ipv6 MLD snooping statistics query - display description	745
Table 146: show ipv6 MLD snooping statistics summary - display description	746
Table 147: MLD Filtering and Throttling Commands	747
Table 148: IGMP Commands (Layer 3)	756
Table 149: show ip igmp groups - display description	762
Table 150: show ip igmp groups detail - display description	763
Table 151: Multicast VLAN Registration for IPv4 Commands	764
Table 152: show mvr - display description	777
Table 153: show mvr interface - display description	779
Table 154: show mvr members - display description	781
Table 155: show mvr statistics input - display description	783
Table 156: show mvr statistics output - display description	783
Table 157: show mvr statistics query - display description	784
Table 158: show mvr statistics summary interface - display description	785
Table 159: show mvr statistics summary interface mvr vlan - description	786
Table 160: Multicast VLAN Registration for IPv6 Commands	788
Table 161: show mvr6 - display description	800
Table 162: show mvr6 interface - display description	802
Table 163: show mvr6 members - display description	805
Table 164: show mvr6 statistics input - display description	807
Table 165: show mvr6 statistics output - display description	807
Table 166: show mvr6 statistics query - display description	808
Table 167: show mvr6 statistics summary interface - display description	808
Table 168: show mvr6 statistics summary interface mvr vlan - description	810
Table 169: LLDP Commands	811

Table 170: LLDP MED Location CA Types	826
Table 171: CFM Commands	837
Table 172: show ethernet cfm configuration traps - display description	851
Table 173: show ethernet cfm maintenance-points local detail mep - display	855
Table 174: show ethernet cfm maintenance-points remote detail - display	856
Table 175: show ethernet cfm errors - display description	862
Table 176: show ethernet cfm linktrace-cache - display description	870
Table 177: Remote MEP Priority Levels	874
Table 178: MEP Defect Descriptions	874
Table 179: show fault-notify-generator - display description	876
Table 180: OAM Commands	879
Table 181: Address Table Commands	891
Table 182: show dns cache - display description	898
Table 183: show hosts - display description	898
Table 184: DHCP Commands	901
Table 185: DHCP Client Commands	901
Table 186: Options 60, 66 and 67 Statements	904
Table 187: Options 55 and 124 Statements	904
Table 188: DHCP Relay Commands	911
Table 189: DHCP Server Commands	918
Table 190: IP Interface Commands	933
Table 191: IPv4 Interface Commands	933
Table 192: Basic IP Configuration Commands	934
Table 193: Address Resolution Protocol Commands	942
Table 194: UDP Helper Commands	946
Table 195: IPv6 Configuration Commands	949
Table 196: show ipv6 interface - display description	962
Table 197: show ipv6 mtu - display description	964
Table 198: show ipv6 traffic - display description	965
Table 199: show ipv6 neighbors - display description	984
Table 200: ND Snooping Commands	986
Table 201: VRRP Commands	995
Table 202: show vrrp - display description	1001
Table 203: show vrrp brief - display description	1001
Table 204: show vrrp interface counters - display description	1003

Table 188: IP Routing Commands	1005
Table 189: Global Routing Configuration Commands	1005
Table 190: show ip host-route - display description	1009
Table 191: Routing Information Protocol Commands	1015
Table 188: Open Shortest Path First Commands	1033
Table 189: OSPFv2 Commands	1033
Table 190: OSPFv3 Commands	1072
Table 191: BGP Routing Commands	1093
Table 192: Border Gateway Protocol Commands – Version 4	1093
Table 193: show ip bgp community-info - display description	1154
Table 194: show ip bgp paths - display description	1158
Table 195: Policy-based Routing Configuration Commands	1164
Table 196: PIM-SM and PIM-SSM Multicast Routing Commands	1185
Table 197: show ip pim neighbor - display description	1192
Table 198: General Multicast Routing Commands	1199
Table 199: show ip mroute - display description	1201
Table 200: Troubleshooting Chart	1205



# Section I

## Getting Started

This section describes how to configure the switch for management access through the web interface or SNMP.

This section includes these chapters:

- ◆ ["Initial Switch Configuration" on page 57](#)



# 1

## Initial Switch Configuration

This chapter includes information on connecting to the switch and basic configuration procedures.

---

### Connecting to the Switch

The switch includes a built-in network management agent. The agent offers a variety of management options, including SNMP, RMON and a web-based interface. A PC may also be connected directly to the switch for configuration and monitoring via a command line interface (CLI).



**Note:** An IPv4 address for the primary network interface (VLAN 1) is set to an initial 192.168.2.10 by default. To change this address, see [“Setting an IP Address” on page 61](#).

---

### Configuration Options

The switch’s HTTP web agent allows you to configure switch parameters, monitor port connections, and display statistics using a standard web browser such as Internet Explorer 9+, Mozilla Firefox 52+, Google Chrome 54+, or Opera 41+, or more recent versions. The switch’s web management interface can be accessed from any computer attached to the network.

The CLI program can be accessed by a direct connection to the RS-232 serial console port on the switch, or remotely by a Telnet connection over the network.

The switch’s management agent also supports SNMP (Simple Network Management Protocol). This SNMP agent permits the switch to be managed from any system in the network using network management software.

The switch’s web interface, console interface, and SNMP agent allow you to perform the following management functions:

- ◆ Set user names and passwords
- ◆ Set an IP interface for any VLAN
- ◆ Configure SNMP parameters
- ◆ Enable/disable any port
- ◆ Set the speed/duplex mode for any port
- ◆ Configure the bandwidth of any port by limiting input or output rates

- ◆ Control port access through IEEE 802.1X security or static address filtering
- ◆ Filter packets using Access Control Lists (ACLs)
- ◆ Configure up to 4094 IEEE 802.1Q VLANs
- ◆ Enable GVRP automatic VLAN registration
- ◆ Configure IP routing for unicast traffic
- ◆ Configure IGMP multicast filtering
- ◆ Upload and download system firmware or configuration files via HTTP (using the web interface) or FTP/SFTP/TFTP (using the command line or web interface)
- ◆ Configure Spanning Tree parameters
- ◆ Configure Class of Service (CoS) priority queuing
- ◆ Configure static or LACP trunks (up to 28)
- ◆ Enable port mirroring
- ◆ Set storm control on any port for excessive broadcast, multicast, or unknown unicast traffic
- ◆ Display system information and statistics

### **Connecting to the Console Port**

The switch provides an RS-232 serial port that enables a connection to a PC or terminal for monitoring and configuring the switch. A null-modem console cable is provided with the switch.

Attach a VT100-compatible terminal, or a PC running a terminal emulation program to the switch. You can use the console cable provided with this package, or use a null-modem cable that complies with the wiring assignments shown in the Installation Guide.

To connect a terminal to the console port, complete the following steps:

- 1.** Connect the console cable to the serial port on a terminal, or a PC running terminal emulation software, and tighten the captive retaining screws on the DB-9 connector.
- 2.** Connect the other end of the cable to the RJ-45 serial port on the switch.
- 3.** Make sure the terminal emulation software is set as follows:
  - Select the appropriate serial port (COM port 1 or COM port 2).
  - Set the baud rate to 115200 bps.
  - Set the data format to 8 data bits, 1 stop bit, and no parity.
  - Set flow control to none.
  - Set the emulation mode to VT100.
  - When using HyperTerminal, select Terminal keys, not Windows keys.

**4.** Power on the switch.

After the system completes the boot cycle, the logon screen appears.

**Logging Onto the  
Command Line  
Interface**

The CLI program provides two different command levels — normal access level (Normal Exec) and privileged access level (Privileged Exec). The commands available at the Normal Exec level are a limited subset of those available at the Privileged Exec level and allow you to only display information and use basic utilities. To fully configure the switch parameters, you must access the CLI at the Privileged Exec level.

Access to both CLI levels are controlled by user names and passwords. The switch has a default user name and password for each level. To log into the CLI at the Privileged Exec level using the default user name and password, perform these steps:

- 1.** To initiate your console connection, press <Enter>. The “User Access Verification” procedure starts.
- 2.** At the User Name prompt, enter “admin.”
- 3.** At the Password prompt, also enter “admin.” (The password characters are not displayed on the console screen.)
- 4.** The session is opened and the CLI displays the “Console#” prompt indicating you have access at the Privileged Exec level.

**Setting Passwords**

If this is your first time to log into the CLI program, you should define new passwords for both default user names using the “username” command, record them and put them in a safe place.

Passwords can consist of up to 32 alphanumeric characters and are case sensitive. To prevent unauthorized access to the switch, set the passwords as follows:

- 1.** Open the console interface with the default user name and password “admin” to access the Privileged Exec level.
- 2.** Type “configure” and press <Enter>.
- 3.** Type “username guest password 0 *password*,” for the Normal Exec level, where *password* is your new password. Press <Enter>.

4. Type “username admin password 0 *password*,” for the Privileged Exec level, where *password* is your new password. Press <Enter>.

```
Username: admin
Password:

      CLI session with the ECS4650-54P is opened.
      To end the CLI session, enter [Exit].

Console#configure
Console(config)#username guest password 0 [password]
Console(config)#username admin password 0 [password]
Console(config)#
```



**Note:** This manual covers the ECS4650-54T and ECS4650-54P Gigabit Ethernet switches. Other than the difference in the number of ports and the support for PoE on the ECS4650-54P, there are no significant differences.

## Remote Connections

Prior to accessing the switch’s onboard agent via a network connection, you must first configure the network interface with a valid IPv4 or IPv6 address. The default network interface is VLAN 1 which includes all switch ports.

When configuring the network interface, the IP address, subnet mask, and default gateway may all be set using a console connection, or DHCP protocol as described in the following sections.

An IPv4 address for the primary network interface is set to an initial 192.168.2.10 by default. To manually configure this address or enable dynamic address assignment via DHCP, see “[Setting an IP Address](#)” on page 61.

After configuring the switch’s IP parameters, you can access the onboard configuration program from anywhere within the attached network. The onboard configuration program can be accessed using Telnet or SSH from any computer attached to the network. The switch can also be managed by any computer using a web browser (Internet Explorer 9, Mozilla Firefox 52, Google Chrome 54, or Opera 41, or more recent versions), or from a network computer using SNMP network management software.



**Note:** This switch supports eight Telnet sessions or SSH sessions.

**Note:** Any VLAN group can be assigned an IP interface address ([page 61](#)) for managing the switch.

The onboard program only provides access to basic configuration functions. To access the full range of SNMP management functions, you must use SNMP-based network management software.

---

## Configuring the Switch for Remote Management

**Using the Network Interface** The switch can be managed through the operational network, known as in-band management. Because in-band management traffic is mixed in with operational network traffic, it is subject to all of the filtering rules usually applied to a standard network ports such as ACLs and VLAN tagging. In-band network management can be accessed through a connection to any network port.

**Setting an IP Address** You must establish IP address information for a switch to obtain management access through the network. This can be done in either of the following ways:

- ◆ **Manual** — You have to input the information, including IP address and subnet mask. If your management station is not in the same IP subnet as the switch, you will also need to specify the default gateway router. To configure this device as the default gateway, use the `ip default-gateway` command.
- ◆ **Dynamic** — The switch can send IPv4 configuration requests to BOOTP or DHCP address allocation servers on the network, or automatically generate a unique IPv6 host address based on the local subnet address prefix received in router advertisement messages. An IPv6 link local address for use in a local network can also be dynamically generated as described in [“Obtaining an IPv6 Address” on page 66](#).

### Manual Configuration

You can manually assign an IP address to the switch. You may also need to specify a default gateway that resides between this device and management stations that exist on another network segment. Valid IPv4 addresses consist of four decimal numbers, 0 to 255, separated by periods. Anything other than this format will not be accepted by the CLI program.



**Note:** The default IPv4 address and subnet mask for VLAN 1 is 192.168.2.10 255.255.255.0, with no defined default gateway.

---

### Assigning an IPv4 Address

Before you can assign an IP address to the switch, you must obtain the following information from your network administrator:

- ◆ IP address for the switch
- ◆ Network mask for this network
- ◆ Default gateway for the network

To assign an IPv4 address to the switch, complete the following steps

1. From the Global Configuration mode prompt, type “interface vlan 1” to access the interface-configuration mode. Press <Enter>.
2. Type “ip address *ip-address netmask*,” where “ip-address” is the switch IP address and “netmask” is the network mask for the network. Press <Enter>.
3. Type “exit” to return to the global configuration mode prompt. Press <Enter>.
4. To set the IP address of the default gateway for the network to which the switch belongs, type “ip default-gateway *gateway*,” where “gateway” is the IP address of the default gateway. Press <Enter>.

```
Console(config)#interface vlan 1
Console(config-if)#ip address 192.168.1.5 255.255.255.0
Console(config-if)#exit
Console(config)#ip default-gateway 192.168.1.254
```

### Assigning an IPv6 Address

This section describes how to configure a “link local” address for connectivity within the local subnet only, and also how to configure a “global unicast” address, including a network prefix for use on a multi-segment network and the host portion of the address.

An IPv6 prefix or address must be formatted according to RFC 2373 “IPv6 Addressing Architecture,” using 8 colon-separated 16-bit hexadecimal values. One double colon may be used to indicate the appropriate number of zeros required to fill the undefined fields. For detailed information on the other ways to assign IPv6 addresses, see [“IPv6 Interface” on page 949](#).

**Link Local Address** — All link-local addresses must be configured with a prefix in the range of FE80~FEBF. Remember that this address type makes the switch accessible over IPv6 for all devices attached to the same local subnet only. Also, if the switch detects that the address you configured conflicts with that in use by another device on the subnet, it will stop using the address in question, and automatically generate a link local address that does not conflict with any other devices on the local subnet.

To configure an IPv6 link local address for the switch, complete the following steps:

1. From the Global Configuration mode prompt, type “interface vlan 1” to access the interface-configuration mode. Press <Enter>.

2. Type “*ipv6 address*” followed by up to 8 colon-separated 16-bit hexadecimal values for the *ipv6-address* similar to that shown in the example, followed by the “*link-local*” command parameter. Then press <Enter>.

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 address FE80::260:3EFF:FE11:6700 link-local
Console(config-if)#ipv6 enable
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled.
Link-local address:
    fe80::260:3eff:fe11:6700%1/64
Global unicast address(es):
    (None)
Joined group address(es):
    ff02::1:ff11:6700
    ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#
```

Address for Multi-segment Network — Before you can assign an IPv6 address to the switch that will be used to connect to a multi-segment network, you must obtain the following information from your network administrator:

- ◆ Prefix for this network
- ◆ IP address for the switch
- ◆ Default gateway for the network

For networks that encompass several different subnets, you must define the full address, including a network prefix and the host address for the switch. You can specify either the full IPv6 address, or the IPv6 address and prefix length. The prefix length for an IPv6 network is the number of bits (from the left) of the prefix that form the network address, and is expressed as a decimal number. For example, all IPv6 addresses that start with the first byte of 73 (hexadecimal) could be expressed as 73:0:0:0:0:0:0:0/8 or 73::/8.

To generate an IPv6 global unicast address for the switch, complete the following steps:

1. From the global configuration mode prompt, type “*interface vlan 1*” to access the interface-configuration mode. Press <Enter>.
2. From the interface prompt, type “*ipv6 address ipv6-address*” or “*ipv6 address ipv6-address/prefix-length*,” where “*prefix-length*” indicates the address bits used to form the network portion of the address. (The network address starts

from the left of the prefix and should encompass some of the ipv6-address bits.) The remaining bits are assigned to the host interface. Press <Enter>.

3. Type "exit" to return to the global configuration mode prompt. Press <Enter>.
4. To set the IP address of the IPv6 default gateway for the network to which the switch belongs, type "ipv6 default-gateway *gateway*," where "gateway" is the IPv6 address of the default gateway. Press <Enter>.

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 address 2001:DB8:2222:7272::/64
Console(config-if)#exit
Console(config)#ipv6 default-gateway 2001:DB8:2222:7272::254
Console(config)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled.
Link-local address:
    fe80::260:3eff:fe11:6700%1/64
Global unicast address(es):
    2001:db8:2222:7272::/64, subnet is 2001:db8:2222:7272::/
    64[TEN] [INVALID] [INVAL
ID]
Joined group address(es):
ff02::1:ff00:0
ff02::1:ff11:6700
ff02::1:2
ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#show ipv6 default-gateway
IPv6 default gateway 2001:db8:2222:7272::254
Console#
```

## Dynamic Configuration

### *Obtaining an IPv4 Address*

If you select the "bootp" or "dhcp" option, the system will immediately start broadcasting service requests. IP will be enabled but will not function until a BOOTP or DHCP reply has been received. Requests are broadcast every few minutes using exponential backoff until IP configuration information is obtained from a BOOTP or DHCP server. BOOTP and DHCP values can include the IP address, subnet mask, and default gateway. If the DHCP/BOOTP server is slow to respond, you may need to use the "ip dhcp restart client" command to re-start broadcasting service requests.

Note that the "ip dhcp restart client" command can also be used to start broadcasting service requests for all VLANs configured to obtain address assignments through BOOTP or DHCP. It may be necessary to use this command

when DHCP is configured on a VLAN, and the member ports which were previously shut down are now enabled.

If the “bootp” or “dhcp” option is saved to the startup-config file (step 6), then the switch will start broadcasting service requests as soon as it is powered on.

To automatically configure the switch by communicating with BOOTP or DHCP address allocation servers on the network, complete the following steps:

1. From the Global Configuration mode prompt, type “interface vlan 1” to access the interface-configuration mode. Press <Enter>.
2. At the interface-configuration mode prompt, use one of the following commands:
  - To obtain IP settings via DHCP, type “ip address dhcp” and press <Enter>.
  - To obtain IP settings via BOOTP, type “ip address bootp” and press <Enter>.
3. Type “end” to return to the Privileged Exec mode. Press <Enter>.
4. Wait a few minutes, and then check the IP configuration settings by typing the “show ip interface” command. Press <Enter>.
5. Then save your configuration changes by typing “copy running-config startup-config.” Enter the startup file name and press <Enter>.

```
Console(config)#interface vlan 1
Console(config-if)#ip address dhcp
Console(config-if)#end
Console#show ip interface
VLAN 1 is Administrative Up - Link Up
  Address is 00-E0-0C-00-00-FD
  Index: 1001, MTU: 1500
  Address Mode is DHCP
  IP Address: 192.168.0.4 Mask: 255.255.255.0
  Proxy ARP is disabled
  DHCP Client Vendor Class ID (text): ECS4650-54P
  DHCP Relay Server:
Console#copy running-config startup-config
Startup configuration file name []: startup
\Write to FLASH Programming.

\Write to FLASH finish.
Success.
```

### Obtaining an IPv6 Address

**Link Local Address** — There are several ways to configure IPv6 addresses. The simplest method is to automatically generate a “link local” address (identified by an address prefix in the range of FE80~FEBF). This address type makes the switch accessible over IPv6 for all devices attached to the same local subnet.

To generate an IPv6 link local address for the switch, complete the following steps:

1. From the Global Configuration mode prompt, type “interface vlan 1” to access the interface-configuration mode. Press <Enter>.
2. Type “ipv6 enable” and press <Enter>.

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 enable
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled.
Link-local address:
 fe80::2e0:cff:fe00:fd%1/64
Global unicast address(es):
 2001:db8:2222:7272::/64, subnet is 2001:db8:2222:7272::/64
Joined group address(es):
 ff02::1:ff00:0
 ff02::1:ff11:6700
 ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#
```

## Configuring the Switch for Cloud Management

The Edgecore ecCLOUD Controller is a cloud-based network service available from anywhere through a web-browser interface. The switch can be managed by the ecCLOUD controller once you have set up an account and registered the device on the system.

By default, the cloud management agent is disabled on the switch. Setting the cloud management agent to enabled allows the switch to be managed through the ecCLOUD system after the next reboot.

To enable the cloud management agent, log into the CLI and use the **mgmt enable** command from the Global Config level. Then reboot the switch to initiate communications with the ecCLOUD controller.

```
Username: admin
Password:

CLI session with the ECS4650-54P is opened.
To end the CLI session, enter [Exit].

Console#configure
Console(config)#mgmt enable
Console(config)#exit
Console#reload
System will be restarted, continue <y/n>? y
```

For more information on cloud management configuration, see [“Cloud Management” on page 106](#).

---

## Enabling SNMP Management Access

The switch can be configured to accept management commands from Simple Network Management Protocol (SNMP) applications such as Edgework ECView Pro. You can configure the switch to respond to SNMP requests or generate SNMP traps.

When SNMP management stations send requests to the switch (either to return information or to set a parameter), the switch provides the requested data or sets the specified parameter. The switch can also be configured to send information to SNMP managers (without being requested by the managers) through trap messages, which inform the manager that certain events have occurred.

The switch includes an SNMP agent that supports SNMP version 1, 2c, and 3 clients. To provide management access for version 1 or 2c clients, you must specify a community string. The switch provides a default MIB View (i.e., an SNMPv3 construct) for the default “public” community string that provides read access to the entire MIB tree, and a default view for the “private” community string that provides read/write access to the entire MIB tree. However, you may assign new views to version 1 or 2c community strings that suit your specific security requirements (see [snmp-server view](#) command).

### Community Strings (for SNMP version 1 and 2c clients)

Community strings are used to control management access to SNMP version 1 and 2c stations, as well as to authorize SNMP stations to receive trap messages from the switch. You therefore need to assign community strings to specified users, and set the access level.

The default strings are:

- ◆ **public** - with read-only access. Authorized management stations are only able to retrieve MIB objects.

- ◆ **private** - with read/write access. Authorized management stations are able to both retrieve and modify MIB objects.

To prevent unauthorized access to the switch from SNMP version 1 or 2c clients, it is recommended that you change the default community strings.

To configure a community string, complete the following steps:

1. From the Privileged Exec level global configuration mode prompt, type “snmp-server community *string mode*,” where “string” is the community access string and “mode” is **rw** (read/write) or **ro** (read only). Press <Enter>. (Note that the default mode is read only.)
2. To remove an existing string, simply type “no snmp-server community *string*,” where “string” is the community access string to remove. Press <Enter>.

```
Console(config)#snmp-server community admin rw
Console(config)#snmp-server community private
Console(config)#
```



**Note:** If you do not intend to support access to SNMP version 1 and 2c clients, we recommend that you delete both of the default community strings. If there are no community strings, then SNMP management access from SNMP v1 and v2c clients is disabled.

## Trap Receivers

You can also specify SNMP stations that are to receive traps from the switch. To configure a trap receiver, use the “snmp-server host” command. From the Privileged Exec level global configuration mode prompt, type:

```
“snmp-server host host-address community-string [version {1 | 2c | 3 {auth | noauth | priv}}]”
```

where “host-address” is the IP address for the trap receiver, “community-string” specifies access rights for a version 1/2c host, or is the user name of a version 3 host, “version” indicates the SNMP client version, and “auth | noauth | priv” means that authentication, no authentication, or authentication and privacy is used for v3 clients. Then press <Enter>. For a more detailed description of these parameters, see the [snmp-server host](#) command. The following example creates a trap host for each type of SNMP client.

```
Console(config)#snmp-server host 10.1.19.23 batman
Console(config)#snmp-server host 10.1.19.98 robin version 2c
Console(config)#snmp-server host 10.1.19.34 barbie version 3 auth
Console(config)#
```

## Configuring Access for SNMP Version 3 Clients

To configure management access for SNMPv3 clients, you need to first create a view that defines the portions of MIB that the client can read or write, assign the view to a group, and then assign the user to a group. The following example creates one view called “mib-2” that includes the entire MIB-2 tree branch, and then another view that includes the IEEE 802.1d bridge MIB. It assigns these respective read and read/write views to a group call “r&d” and specifies group authentication via MD5 or SHA. In the last step, it assigns a v3 user to this group, indicating that MD5 will be used for authentication, provides the password “greenpeace” for authentication, and the password “einstien” for encryption.

```
Console(config)#snmp-server view mib-2 1.3.6.1.2.1 included
Console(config)#snmp-server view 802.1d 1.3.6.1.2.1.17 included
Console(config)#snmp-server group r&d v3 auth read mib-2 write 802.1d
Console(config)#snmp-server user steve r&d v3 auth md5 greenpeace priv des56
einstien
Console(config)#
```

For a more detailed explanation on how to configure the switch for access from SNMP v3 clients, refer to [“SNMP Commands” on page 199](#) or to the *Web Management Guide*.

---

## Managing System Files

The switch’s flash memory supports three types of system files that can be managed by the CLI program, the web interface, or SNMP. The switch’s file system allows files to be uploaded and downloaded, copied, deleted, and set as a start-up file.

The types of files are:

- ◆ **Configuration** — This file type stores system configuration information and is created when configuration settings are saved. Saved configuration files can be selected as a system start-up file or can be uploaded via FTP/SFTP/SCP/TFTP to a server for backup. The file named “Factory\_Default\_Config.cfg” contains all the system default settings and cannot be deleted from the system. If the system is booted with the factory default settings, the switch will also create a file named “startup1.cfg” that contains system settings for switch initialization, including information about the unit identifier, and MAC address for the switch. The configuration settings from the factory defaults configuration file are copied to this file, which is then used to boot the switch. See [“Saving or Restoring Configuration Settings” on page 71](#) for more information.
- ◆ **Operation Code** — System software that is executed after boot-up, also known as run-time code. This code runs the switch operations and provides the CLI and web management interfaces.

- ◆ **Diagnostic Code** — Software that is run during system boot-up, also known as POST (Power On Self-Test).



**Note:** The Boot ROM and Loader cannot be uploaded or downloaded from the FTP/SFTP/SCP/TFTP server. You must follow the instructions in the release notes for new firmware, or contact your distributor for help.

Due to the size limit of the flash memory, the switch supports only two operation code files. However, you can have as many diagnostic code files and configuration files as available flash memory space allows. The available flash memory can be checked by using the **dir** command.

In the system flash memory, one file of each type must be set as the start-up file. During a system boot, the diagnostic and operation code files set as the start-up file are run, and then the start-up configuration file is loaded.

Note that configuration files should be downloaded using a file name that reflects the contents or usage of the file settings. If you download directly to the running-config, the system will reboot, and the settings will have to be copied from the running-config to a permanent file.

### Upgrading the Operation Code

The following example shows how to download new firmware to the switch and activate it. The TFTP server could be any standards-compliant server running on Windows or Linux. When downloading from an FTP server, the logon interface will prompt for a user name and password configured on the remote server. Note that “anonymous” is set as the default user name.

File names on the switch are case-sensitive. The destination file name should not contain slashes (\ or /), and the maximum length for file names is 32 characters for files on the switch or 128 characters for files on the server. (Valid characters: A-Z, a-z, 0-9, “,”,“-”)

```
Console#copy tftp file
TFTP server IP address: 192.168.2.243
Choose file type:
  1. config; 2. opcode: 2
Source file name: runtime.bix
Destination file name: runtime.bix
Flash programming started.
Flash programming completed.
Success.
Console#config
Console(config)#boot system opcode:runtime.bix
Success.
Console(config)#exit
Console#dir
File Name                               Type   Startup Modified Time          Size (bytes)
-----
Unit 1:
runtime_v1.1.0.8.bix                    OpCode N      2023-01-17 01:19:41     51,894,508
runtime.bix                              OpCode Y      2023-02-07 14:40:05     51,893,948
Factory_Default_Config.cfg              Config N      2023-01-17 01:09:16         455
```

```
startup1.cfg                Config Y          2023-02-17 07:39:01      1,673
-----
Free space for compressed user config files:  58,925,056
Total space:                                165,584,896

Console#
```

### Saving or Restoring Configuration Settings

Configuration commands only modify the running configuration file and are not saved when the switch is rebooted. To save all your configuration changes in nonvolatile storage, you must copy the running configuration file to the start-up configuration file using the “copy” command.

New startup configuration files must have a name specified. File names on the switch are case-sensitive, can be from 1 to 31 characters, must not contain slashes (\ or /), and the leading letter of the file name must not be a period (.). (Valid characters: A-Z, a-z, 0-9, “,”, “-”, “\_”)

There can be more than one user-defined configuration file saved in the switch’s flash memory, but only one is designated as the “startup” file that is loaded when the switch boots. The **copy running-config startup-config** command always sets the new file as the startup file. To select a previously saved configuration file, use the **boot system config:<filename>** command.

The maximum number of saved configuration files depends on available flash memory. The amount of available flash memory can be checked by using the **dir** command.

To save the current configuration settings, enter the following command:

1. From the Privileged Exec mode prompt, type “copy running-config startup-config” and press <Enter>.
2. Enter the name of the start-up file. Press <Enter>.

```
Console#copy running-config startup-config
Startup configuration file name []: startup
\Write to FLASH Programming.

\Write to FLASH finish.
Success.

Console#
```

To restore configuration settings from a backup server, enter the following command:

1. From the Privileged Exec mode prompt, type “copy tftp startup-config” and press <Enter>.
2. Enter the address of the TFTP server. Press <Enter>.

3. Enter the name of the startup file stored on the server. Press <Enter>.
4. Enter the name for the startup file on the switch. Press <Enter>.

```
Console#copy tftp startup-config
TFTP server IP address: 192.168.0.4
Source configuration file name: startup-rd.cfg
Startup configuration file name [startup1.cfg]:

Success.
Console#
```

---

## Automatic Installation of Operation Code and Configuration Settings

### Downloading Operation Code from a File Server

Automatic Operation Code Upgrade can automatically download an operation code file when a file newer than the currently installed one is discovered on the file server. After the file is transferred from the server and successfully written to the file system, it is automatically set as the startup file, and the switch is rebooted.

#### Usage Guidelines

- ◆ If this feature is enabled, the switch searches the defined URL once during the bootup sequence.
- ◆ FTP (port 21) and TFTP (port 69) are both supported. Note that the TCP/UDP port bindings cannot be modified to support servers listening on non-standard ports.
- ◆ The host portion of the upgrade file location URL must be a valid IPv4 IP address. DNS host names are not recognized. Valid IP addresses consist of four numbers, 0 to 255, separated by periods.
- ◆ The path to the directory must also be defined. If the file is stored in the root directory for the FTP/TFTP service, then use the "/" to indicate this (e.g., ftp://192.168.0.1/).
- ◆ The file name must not be included in the upgrade file location URL. The file name of the code stored on the remote server must be ECS4650.bix (using lower case letters as indicated).
- ◆ The FTP connection is made with PASV mode enabled. PASV mode is needed to traverse some fire walls, even if FTP traffic is not blocked. PASV mode cannot be disabled.
- ◆ The switch-based search function is case-insensitive in that it will accept a file name in upper or lower case (i.e., the switch will accept *ECS4650.BIX* from the server even though *ECS4650.bix* was requested). However, keep in mind that

the file systems of many operating systems such as Unix and most Unix-like systems (FreeBSD, NetBSD, OpenBSD, and most Linux distributions, etc.) are case-sensitive, meaning that two files in the same directory, *ecs4650.bix* and *ECS4650.BIX* are considered to be unique files. Thus, if the upgrade file is stored as *ECS4650.BIX* (or even *Ecs4650.bix*) on a case-sensitive server, then the switch (requesting *ECS4650.BIX*) will not be upgraded because the server does not recognize the requested file name and the stored file name as being equal. A notable exception in the list of case-sensitive Unix-like operating systems is Mac OS X, which by default is case-insensitive. Please check the documentation for your server's operating system if you are unsure of its file system's behavior.

- ◆ Note that the switch itself does not distinguish between upper and lower-case file names, and only checks to see if the file stored on the server is more recent than the current runtime image.
- ◆ If two operation code image files are already stored on the switch's file system, then the non-startup image is deleted before the upgrade image is transferred.
- ◆ The automatic upgrade process will take place in the background without impeding normal operations (data switching, etc.) of the switch.
- ◆ During the automatic search and transfer process, the administrator cannot transfer or update another operation code image, configuration file, public key, or HTTPS certificate (i.e., no other concurrent file management operations are possible).
- ◆ The upgrade operation code image is set as the startup image after it has been successfully written to the file system.
- ◆ The switch will send an SNMP trap and make a log entry upon all upgrade successes and failures.
- ◆ The switch will immediately restart after the upgrade file is successfully written to the file system and set as the startup image.

To enable automatic upgrade, enter the following commands:

1. Specify the TFTP or FTP server to check for new operation code.

- When specifying a TFTP server, the following syntax must be used, where *filedir* indicates the path to the directory containing the new image:

```
tftp://192.168.0.1[/filedir]/
```

- When specifying an FTP server, the following syntax must be used, where *filedir* indicates the path to the directory containing the new image:

```
ftp://[username[:password@]]192.168.0.1[/filedir]/
```

If the user name is omitted, "anonymous" will be used for the connection. If the password is omitted a null string ("") will be used for the connection.

If no user name nor password is required for the connection, then the "@" character cannot be used in the path name.

This shows how to specify a TFTP server where new code is stored.

```
Console(config)#upgrade opcode path tftp://192.168.0.1/sm24/  
Console(config)#
```

This shows how to specify an FTP server where new code is stored.

```
Console(config)#upgrade opcode path ftp://site9:billy@192.168.0.1/sm24/  
Console(config)#
```

2. Set the switch to automatically reboot and load the new code after the opcode upgrade is completed.

```
Console(config)#upgrade opcode reload  
Console(config)#
```

3. Set the switch to automatically upgrade the current operational code when a new version is detected on the server. When the switch starts up and automatic image upgrade is enabled by this command, the switch will follow these steps when it boots up:
  - a. It will search for a new version of the image at the location specified by **upgrade opcode path** command. The name for the new image stored on the FTP/SFTP/SCP/TFTP server must be ECS4650.bix. If the switch detects a code version newer than the one currently in use, it will download the new image. If two code images are already stored in the switch, the image not set to start up the system will be overwritten by the new version.
  - b. After the image has been downloaded, the switch will send a trap message to log whether or not the upgrade operation was successful.
  - c. It sets the new version as the startup image.
  - d. It then restarts the system to start using the new image.

```
Console(config)#upgrade opcode auto  
Console(config)#
```

4. Display the automatic upgrade settings.

```

Console#show upgrade
Auto Image Upgrade Global Settings:
  Status      : Enabled
  Reload Status : Enabled
  Path        :
  File Name   : ECS4650.bix
Console#

```

The following shows an example of the upgrade process.

```

...
Automatic Upgrade is looking for a new image
New image detected: current version V1.1.0.8; new version V1.1.0.9
Image upgrade in progress
Downloading new image
Flash programming started
Flash programming completed
Success
The switch will now restart
...

```

### Specifying a DHCP Client Identifier

DHCP servers index their database of address bindings using the client's Media Access Control (MAC) Address or a unique client identifier. The client identifier is used to identify the vendor class and configuration of the switch to the DHCP server, which then uses this information to decide on how to service the client or the type of information to return.

DHCP client Identifier (Option 60) is used by DHCP clients to specify their unique identifier. The client identifier is optional and can be specified while configuring DHCP on the primary network interface. DHCP Option 60 is disabled by default.

The general framework for this DHCP option is set out in RFC 2132 (Option 60). This information is used to convey configuration settings or other identification information about a client, but the specific string to use should be supplied by your service provider or network administrator. Options 60 (vendor-class-identifier), 66 (tftp-server-name) and 67 (bootfile-name) statements can be added to the server daemon's configuration file as described in the following section.

If the DHCP server has an index entry for a switch requesting service, it should reply with the TFTP server name and boot file name. Note that the vendor class identifier can be formatted in either text or hexadecimal, but the format used by both the client and server must be the same.

```

Console#config
Console(config)#vlan database
Console(config-vlan)#vlan 2
Console(config-vlan)#exit
Console(config)#interface vlan 2

```

```
Console(config-if)#ip dhcp client class-id hex 0000e8666572
Console(config-if)#
```

---

---

## Downloading a Configuration File and Other Parameters from a DHCP Server

Information passed on to the switch from a DHCP server may also include a configuration file to be downloaded and the TFTP servers where that file can be accessed, as well as other parameters. If the Factory Default Configuration file is used to provision the switch at startup, in addition to requesting IP configuration settings from the DHCP server, it will also ask for the name of a bootup configuration file and TFTP servers where that file is stored.

If the switch receives information that allows it to download the remote bootup file, it will save this file to a local buffer, and then restart the provision process.

Note the following DHCP client behavior:

- ◆ To enable dynamic provisioning via a DHCP server, this feature must be enabled using the `ip dhcp dynamic-provision` or `ipv6 dhcp dynamic-provision` command.
- ◆ The bootup configuration file received from a (TFTP or HTTP) server is stored on the switch with the original file name. If this file name already exists in the switch, the file is overwritten.
- ◆ If the name of the bootup configuration file is the same as the Factory Default Configuration file, the download procedure will be terminated, and the switch will not send any further DHCP client requests.
- ◆ If the switch fails to download the bootup configuration file based on information passed by the DHCP server, it will not send any further DHCP client requests.
- ◆ If the switch does not receive a DHCP response prior to completing the bootup process, it will continue to send a DHCP client request once a minute. These requests will only be terminated if the switch's address is manually configured, but will resume if the address mode is set back to DHCP.

To successfully transmit a bootup configuration file to the switch, the DHCP daemon (using a Linux based system for this example) must be configured with the following information:

- ◆ For IPv4 DHCP, options 60, 66 and 67 statements can be added to the daemon's configuration file.

**Table 1: DHCP Options 60, 66 and 67 Statements**

Option	Statement	
	Keyword	Parameter
60	vendor-class-identifier	a string indicating the vendor class identifier
66	tftp-server-name	a string indicating the tftp server name
67	bootfile-name	a string indicating the bootfile name

- ◆ For DHCPv6, options 59 and 60 statements can be added to the daemon's configuration file.

**Table 2: DHCPv6 Options 59 and 60 Statements**

Option	Statement	
	Keyword	Parameter
59	OPT_BOOTFILE_URL	a string indicating the bootfile location (must conform to RFC3986)
60	OPT_BOOTFILE_PARAM	multiple UTF-8 ([RFC3629]) strings that specify parameters for the boot file

- ◆ By default, IPv4 DHCP option 66/67 parameters are not carried in a DHCP server reply. To ask for a DHCP reply with option 66/67 information, the DHCP client request sent by this switch includes a "parameter request list" asking for this information. Besides these items, the client request also includes a "vendor class identifier" that allows the DHCP server to identify the device, and select the appropriate configuration file for download. This information is included in Options 55 and 124.

**Table 3: DHCP Options 55 and 124 Statements**

Option	Statement	
	Keyword	Parameter
55	dhcp-parameter-request-list	a list of parameters, separated by a comma ','
124	vendor-class-identifier	a string indicating the vendor class identifier

The following configuration example is provided for a Linux-based IPv4 DHCP daemon (dhcpd.conf file). In the "Vendor class" section, the server will always send Option 66 and 67 to tell the switch to download the "test" configuration file from server 192.168.255.101.

```
ddns-update-style ad-hoc;

default-lease-time 600;
max-lease-time 7200;

log-facility local7;

server-name "Server1";
Server-identifier 192.168.255.250;
#option 66, 67
option space dynamicProvision code width 1 length 1 hash size 2;
option dynamicProvision.tftp-server-name code 66 = text;
option dynamicProvision.bootfile-name code 67 = text;

subnet 192.168.255.0 netmask 255.255.255.0 {
    range 192.168.255.160 192.168.255.200;
    option routers 192.168.255.101;
    option tftp-server-name "192.168.255.100"; #Default Option 66
    option bootfile-name "bootfile";          #Default Option 67
}

class "Option66,67_1" {                #DHCP Option 60 Vendor class
two
    match if option vendor-class-identifier = "ECS4650-54P";
    option tftp-server-name "192.168.255.101";
    option bootfile-name "test";
}
```



---

**Note:** Use “ECS4650-54T,” or “ECS4650-54P” for the vendor-class-identifier in the dhcpd.conf file.

---

## Setting the System Clock

Simple Network Time Protocol (SNTP) or Network Time Protocol (NTP) can be used to set the switch’s internal clock based on periodic updates from a time server. Maintaining an accurate time on the switch enables the system log to record meaningful dates and times for event entries. You can also manually set the clock. If the clock is not set manually or via SNTP or NTP, the switch will only record the time from the factory default set at the last bootup.

When the SNTP client is enabled, the switch periodically sends a request for a time update to a configured time server. You can configure up to three time server IP addresses. The switch will attempt to poll each server in the configured sequence.

The switch also supports the following time settings:

- ◆ **Time Zone** – You can specify the offset from Coordinated Universal Time (UTC), also known as Greenwich Mean Time (GMT).

- ◆ Summer Time/Daylight Saving Time (DST) – In some regions, the time shifts by one hour in the fall and spring. The switch supports manual entry for one-time or recurring clock shifts.

## Setting the Time Manually

To manually set the clock to 14:11:36, April 1st, 2013, enter this command.

```
Console#calendar set 14 11 36 1 April 2013
Console#
```

To set the time zone, enter a command similar to the following.

```
Console(config)#clock timezone Japan hours 8 after-UTC
Console(config)#
```

To set the time shift for summer time, enter a command similar to the following.

```
Console(config)#clock summer-time SUMMER date 2 april 2013 0 0 30 june 2013 0
0
Console(config)#
```

To display the clock configuration settings, enter the following command.

```
Console#show calendar
Current Time       : Jul 28 00:54:20 2015
Time Zone         : Japan, 08:00
Summer Time       : SUMMER, offset 60 minutes
                   Apr 2 2013 00:00 to Jun 30 2015 00:00
Summer Time in Effect : Yes
Console#
```

## Configuring SNTP

Setting the clock based on an SNTP server can provide more accurate clock synchronization across network switches than manually-configured time. To configure SNTP, set the switch as an SNTP client, and then set the polling interval, and specify a time server as shown in the following example.

```
Console(config)#sntp client
Console(config)#sntp poll 60
Console(config)#sntp server 10.1.0.19
Console(config)#exit
Console#show sntp
Current Time      : Apr  2 16:06:07 2013
Poll Interval    : 60 seconds
Current Mode     : Unicast
SNTP Status      : Enabled
SNTP Server      : 10.1.0.19
Current Server   : 10.1.0.19
Console#
```

**Configuring NTP** Requesting the time from a an NTP server is the most secure method. You can enable NTP authentication to ensure that reliable updates are received from only authorized NTP servers. The authentication keys and their associated key number must be centrally managed and manually distributed to NTP servers and clients. The key numbers and key values must match on both the server and client.

When more than one time server is configured, the client will poll all of the time servers, and compare the responses to determine the most reliable and accurate time update for the switch.

To configure NTP time synchronization, enter commands similar to the following.

```
Console(config)#ntp client
Console(config)#ntp authentication-key 45 md5 thisiskey45
Console(config)#ntp authenticate
Console(config)#ntp server 192.168.3.20
Console(config)#ntp server 192.168.3.21
Console(config)#ntp server 192.168.5.23 key 19
Console(config)#exit
Console#show ntp
Current Time           : Apr 29 13:57:32 2011
Polling                : 1024 seconds
Current Mode           : unicast
NTP Status             : Enabled
NTP Authenticate Status : Enabled
Last Update NTP Server : 192.168.0.88      Port: 123
Last Update Time      : Mar 12 02:41:01 2013 UTC
NTP Server 192.168.0.88 version 3
NTP Server 192.168.3.21 version 3
NTP Server 192.168.4.22 version 3 key 19
NTP Authentication Key 19 md5 42V68751663T6K11P2J307210R885

Current Time           : Apr  2 16:28:34 2013
Polling                : 1024 seconds
Current Mode           : unicast
NTP Status             : Enabled
NTP Authenticate Status : Enabled
Last Update NTP Server : 192.168.5.23      Port: 0
Last Update Time      : Apr  2 16:00:00 2013 UTC
NTP Server 192.168.3.20 version 3
NTP Server 192.168.3.21 version 3
NTP Server 192.168.5.23 version 3 key 19
NTP Authentication Key 45 md5 2662T75S5658RU5424180034777
Console#
```

# Section II

## Command Line Interface

This section provides a detailed description of the Command Line Interface, along with examples for all of the commands.

This section includes these chapters:

- ◆ [“Using the Command Line Interface” on page 83](#)
- ◆ [“General Commands” on page 97](#)
- ◆ [“System Management Commands” on page 105](#)
- ◆ [“SNMP Commands” on page 199](#)
- ◆ [“Remote Monitoring Commands” on page 225](#)
- ◆ [“Flow Sampling Commands” on page 233](#)
- ◆ [“Authentication Commands” on page 239](#)
- ◆ [“General Security Measures” on page 309](#)
- ◆ [“Access Control Lists” on page 395](#)
- ◆ [“Interface Commands” on page 421](#)
- ◆ [“Link Aggregation Commands” on page 455](#)
- ◆ [“Power over Ethernet Commands” on page 475](#)
- ◆ [“Port Mirroring Commands” on page 481](#)
- ◆ [“Congestion Control Commands” on page 491](#)
- ◆ [“Loopback Detection Commands” on page 509](#)
- ◆ [“UniDirectional Link Detection Commands” on page 515](#)

- ◆ "Address Table Commands" on page 523
- ◆ "TWAMP Commands" on page 535
- ◆ "Spanning Tree Commands" on page 537
- ◆ "VLAN Commands" on page 569
- ◆ "ERPS Commands" on page 619
- ◆ "Class of Service Commands" on page 653
- ◆ "Quality of Service Commands" on page 669
- ◆ "Control Plane Commands" on page 687
- ◆ "Multicast Filtering Commands" on page 691
- ◆ "LLDP Commands" on page 811
- ◆ "CFM Commands" on page 837
- ◆ "OAM Commands" on page 879
- ◆ "Domain Name Service Commands" on page 891
- ◆ "DHCP Commands" on page 901
- ◆ "IP Interface Commands" on page 933
- ◆ "VRRP Commands" on page 995
- ◆ "IP Routing Commands" on page 1005
- ◆ "RIP Commands" on page 1015
- ◆ "OSPF Commands" on page 1033
- ◆ "BGPv4 Commands" on page 1093
- ◆ "PIM Commands" on page 1185
- ◆ "Multicast Routing Commands" on page 1199

# 2

## Using the Command Line Interface

This chapter describes how to use the Command Line Interface (CLI).

### Accessing the CLI

When accessing the management interface for the switch over a direct connection to the server's console port, or via a Telnet or Secure Shell connection (SSH), the switch can be managed by entering command keywords and parameters at the prompt. Using the switch's command-line interface (CLI) is very similar to entering commands on a UNIX system.

**Console Connection** To access the switch through the console port, perform these steps:

1. At the console prompt, enter the user name and password. (The default user names are "admin" and "guest" with corresponding passwords of "admin" and "guest.") When the administrator user name and password is entered, the CLI displays the "Console#" prompt and enters privileged access mode (i.e., Privileged Exec). But when the guest user name and password is entered, the CLI displays the "Console>" prompt and enters normal access mode (i.e., Normal Exec).
2. Enter the necessary commands to complete your desired tasks.
3. When finished, exit the session with the "quit" or "exit" command.

After connecting to the system through the console port, the login screen displays:

```
User Access Verification

Username: admin
Password:

      CLI session with the ECS4650-54P is opened.
      To end the CLI session, enter [Exit].

Console#
```

**Telnet Connection** Telnet operates over the IP transport protocol. In this environment, your management station and any network device you want to manage over the network must have a valid IP address. Valid IP addresses consist of four numbers, 0 to 255, separated by periods. Each address consists of a network portion and host portion. For example, the IP address assigned to this switch, 10.1.0.1, consists of a network portion (10.1.0) and a host portion (1).



**Note:** An IPv4 address for the primary network interface (VLAN 1) is set to an initial 192.168.2.10 by default.

To access the switch through a Telnet session, you must first set the IP address for the Master unit, and set the default gateway if you are managing the switch from a different IP subnet. For example,

```
Console(config)#interface vlan 1
Console(config-if)#ip address 10.1.0.254 255.255.255.0
Console(config-if)#exit
Console(config)#ip default-gateway 10.1.0.254
Console(config)#
```

If your corporate network is connected to another network outside your office or to the Internet, you need to apply for a registered IP address. However, if you are attached to an isolated network, then you can use any IP address that matches the network segment to which you are attached.

After you configure the switch with an IP address, you can open a Telnet session by performing these steps:

1. From the remote host, enter the Telnet command and the IP address or host name of the device you want to access.
2. At the prompt, enter the user name and system password. The CLI will display the "Vty-*n*#" prompt for the administrator to show that you are using privileged access mode (i.e., Privileged Exec), or "Vty-*n*>" for the guest to show that you are using normal access mode (i.e., Normal Exec), where *n* indicates the number of the current Telnet session.
3. Enter the necessary commands to complete your desired tasks.
4. When finished, exit the session with the "quit" or "exit" command.

After entering the Telnet command, the login screen displays:

```
Username: admin
Password:

CLI session with the ECS4650-54P is opened.
To end the CLI session, enter [Exit].
```

```
Vty-1#
```



**Note:** You can open up to eight sessions to the device via Telnet or SSH.

## Entering Commands

This section describes how to enter CLI commands.

### Keywords and Arguments

A CLI command is a series of keywords and arguments. Keywords identify a command, and arguments specify configuration parameters. For example, in the command “show interfaces status ethernet 1/5,” **show interfaces** and **status** are keywords, **ethernet** is an argument that specifies the interface type, and **1/5** specifies the unit/port.

You can enter commands as follows:

- ◆ To enter a simple command, enter the command keyword.
- ◆ To enter multiple commands, enter each command in the required order. For example, to enable Privileged Exec command mode, and display the startup configuration, enter the following commands. The default password “super” is used to change from Normal Exec to Privileged Exec mode:

```
Console>enable  
Password:  
Console#show startup-config
```

- ◆ To enter commands that require parameters, enter the required parameters after the command keyword. For example, to set a password for the administrator, enter:

```
Console(config)#username admin password 0 smith
```

### Minimum Abbreviation

The CLI will accept a minimum number of characters that uniquely identify a command. For example, the command “configure” can be entered as **con**. If an entry is ambiguous, the system will prompt for further input.

### Command Completion

If you terminate input with a Tab key, the CLI will print the remaining characters of a partial keyword up to the point of ambiguity. In the “logging history” example, typing **log** followed by a tab will result in printing the command up to “**logging**.”

**Getting Help on Commands** You can display a brief description of the help system by entering the **help** command. You can also display command syntax by using the “?” character to list keywords or parameters.

### Showing Commands

If you enter a “?” at the command prompt, the system will display the first level of keywords or command groups. You can also display a list of valid keywords for a specific command. For example, the command “**show system ?**” displays a list of possible show commands:

```
Console#show ?
  access-group      Access groups
  access-list       Access lists
  accounting         Uses the specified accounting list
  arp               Information of ARP cache
  authorization     Information of authorization
  auto-traffic-control Auto traffic control information
  banner            Banner info
  bridge-ext        Bridge extension information
  cable-diagnostics Shows the information of cable diagnostics
  calendar          Date and time information
  class-map         Displays class maps
  cluster           Display cluster
  debug             State of each debugging option
  discard           Discard packet
  dns               DNS information
  dos-protection    Shows the system dos-protection summary information
  dot1q-tunnel      dot1q-tunnel
  dot1x             802.1X content
  dying-gasp        Dying gasp information
  efm               Ethernet First Mile feature
  erps              Displays ERPS configuration
  ethernet          Shows Metro Ethernet information
  excluded-vlan     Excluded vlan information
  garp              GARP properties
  gvrp              GVRP interface information
  history           Shows history information
  hosts             Host information
  interfaces        Shows interface information
  ip                IP information
  ipv6              IPv6 information
  l2protocol-tunnel Layer 2 protocol tunneling configuration
  lacp              LACP statistics
  line              TTY line information
  lldp              LLDP
  log               Log records
  logging           Logging setting
  loop              Shows the information of loopback
  loopback-detection Shows loopback detection information
  mac               MAC access list
  mac-address-table Configuration of the address table
  mac-vlan          MAC-based VLAN information
  management        Shows management information
  memory            Memory utilization
  mlag              Displays MLAG information
  mvr               multicast vlan registration
  mvr6              IPv6 Multicast VLAN registration
  network-access    Shows the entries of the secure port.
  nlm               Show notification log
  ntp               Network Time Protocol configuration
```

policy-map	Displays policy maps
port	Port characteristics
port-channel	Port channel information
power	Shows power
power-save	Shows the power saving information
pppoe	Displays PPPoE configuration
privilege	Shows current privilege level
process	Device process
protocol-vlan	Protocol-VLAN information
public-key	Public key information
qos	Quality of Service
queue	Priority queue information
radius-server	RADIUS server information
reload	Shows the reload settings
rmon	Remote monitoring information
route-map	Shows route-map
rspan	Display status of the current RSPAN configuration
running-config	Information on the running configuration
sflow	Shows the sflow information
smart-pair	Displays backup port information
snmp	Simple Network Management Protocol configuration and statistics
snmp-server	Displays SNMP server configuration
sntp	Simple Network Time Protocol configuration
spanning-tree	Spanning-tree configuration
ssh	Secure shell server connections
startup-config	Startup system configuration
subnet-vlan	IP subnet-based VLAN information
system	System information
tacacs-server	TACACS server information
tech-support	Technical information
time-range	Time range
traffic-segmentation	Traffic segmentation information
twamp	TWAMP configuration, statistics and session information
udld	Displays UDLD information
upgrade	Shows upgrade information
users	Information about users logged in
version	System hardware and software versions
vlan	Shows virtual LAN settings
vlan-translation	VLAN translation information
voice	Shows the voice VLAN information
vrrp	Shows VRRP
watchdog	Displays watchdog status
web-auth	Shows web authentication configuration

```
Console#show
```

The command “**show interfaces ?**” will display the following information:

```
Console#show interfaces ?
  brief          Shows brief interface description
  counters       Interface counters information
  history        Historical sample of interface counters information
  protocol-vlan  Protocol-VLAN information
  status        Shows interface status
  switchport    Shows interface switchport information
  transceiver    Interface of transceiver information
  transceiver-threshold  Interface of transceiver-threshold information
Console#
```

Show commands which display more than one page of information (e.g., **show running-config**) pause and require you to press the [Space] bar to continue displaying one more page, the [Enter] key to display one more line, or the [a] key to display the rest of the information without stopping. You can press any other key to terminate the display.

### Partial Keyword Lookup

If you terminate a partial keyword with a question mark, alternatives that match the initial letters are provided. (Remember not to leave a space between the command and question mark.) For example “**s?**” shows all the keywords starting with “s.”

```
Console#show s?  
sflow          smart-pair      snmp            snmp-server     sntp  
  
spanning-tree  ssh            startup-config  subnet-vlan     system  
Console#show s
```

### Negating the Effect of Commands

For many configuration commands you can enter the prefix keyword “**no**” to cancel the effect of a command or reset the configuration to the default value. For example, the **logging** command will log system messages to a host server. To disable logging, specify the **no logging** command. This guide describes the negation effect for all applicable commands.

### Using Command History

The CLI maintains a history of commands that have been entered. You can scroll back through the history of commands by pressing the up arrow key. Any command displayed in the history list can be executed again, or first modified and then executed.

Using the **show history** command displays a longer list of recently executed commands.

### Understanding Command Modes

The command set is divided into Exec and Configuration classes. Exec commands generally display information on system status or clear statistical counters. Configuration commands, on the other hand, modify interface parameters or enable certain switching functions. These classes are further divided into different modes. Available commands depend on the selected mode. You can always enter a question mark “**?**” at the prompt to display a list of the commands available for the current mode. The command classes and associated modes are displayed in the following table:

**Table 4: General Command Modes**

Class	Mode	
Exec	Normal Privileged	
Configuration	Global*	Access Control List Class Map DHCP IGMP Profile Interface Line Multiple Spanning Tree Policy Map Route Map Router Time Range VLAN Database

\* You must be in Privileged Exec mode to access the Global configuration mode.  
You must be in Global Configuration mode to access any of the other configuration modes.

**Exec Commands** When you open a new console session on the switch with the user name and password “guest,” the system enters the Normal Exec command mode (or guest mode), displaying the “Console>” command prompt. Only a limited number of the commands are available in this mode. You can access all commands only from the Privileged Exec command mode (or administrator mode). To access Privilege Exec mode, open a new console session with the user name and password “admin.” The system will now display the “Console#” command prompt. You can also enter Privileged Exec mode from within Normal Exec mode, by entering the [enable](#) command, followed by the privileged level password “super.”

To enter Privileged Exec mode, enter the following user names and passwords:

```

Username: admin
Password: [admin login password]

      CLI session with the ECS4650-54P is opened.
      To end the CLI session, enter [Exit].

Console#

```

```

Username: guest
Password: [guest login password]

      CLI session with the ECS4650-54P is opened.
      To end the CLI session, enter [Exit].

Console>enable
Password: [privileged level password]
Console#

```

**Configuration Commands** Configuration commands are privileged level commands used to modify switch settings. These commands modify the running configuration only and are not saved when the switch is rebooted. To store the running configuration in non-volatile storage, use the **copy running-config startup-config** command.

The configuration commands are organized into different modes:

- ◆ Global Configuration - These commands modify the system level configuration, and include commands such as **hostname** and **snmp-server community**.
- ◆ Access Control List Configuration - These commands are used for packet filtering.
- ◆ Class Map Configuration - Creates a DiffServ class map for a specified traffic type.
- ◆ DHCP Configuration - These commands are used to configure the DHCP server.
- ◆ IGMP Profile - Sets a profile group and enters IGMP filter profile configuration mode.
- ◆ Interface Configuration - These commands modify the port configuration such as **speed-duplex** and **negotiation**.
- ◆ Line Configuration - These commands modify the console port and Telnet configuration, and include command such as **parity** and **databits**.
- ◆ Multiple Spanning Tree Configuration - These commands configure settings for the selected multiple spanning tree instance.
- ◆ Policy Map Configuration - Creates a DiffServ policy map for multiple interfaces.
- ◆ Time Range - Sets a time range for use by other functions, such as Access Control Lists.
- ◆ VLAN Configuration - Includes the command to create VLAN groups.

To enter the Global Configuration mode, enter the command **configure** in Privileged Exec mode. The system prompt will change to "Console(config)#" which gives you access privilege to all Global Configuration commands.

```
Console#configure  
Console(config)#
```

To enter the other modes, at the configuration prompt type one of the following commands. Use the **exit** or **end** command to return to the Privileged Exec mode.

**Table 5: Configuration Command Modes**

Mode	Command	Prompt	Page
Access Control List	access-list arp	Console(config-arp-acl)	<a href="#">414</a>
	access-list ip standard	Console(config-std-acl)	<a href="#">396</a>
	access-list ip extended	Console(config-ext-acl)	<a href="#">396</a>
	access-list ipv6 standard	Console(config-std-ipv6-acl)	<a href="#">402</a>
	access-list ipv6 extended	Console(config-ext-ipv6-acl)	<a href="#">402</a>
	access-list mac	Console(config-mac-acl)	<a href="#">408</a>
CFM	ethernet cfm domain	Console(config-ether-cfm)	<a href="#">843</a>
Class Map	class-map	Console(config-cmap)	<a href="#">670</a>
Interface	interface {ethernet <i>port</i>   port-channel <i>id</i>   vlan <i>id</i> }	Console(config-if)	<a href="#">423</a>
Line	line {console   vty}	Console(config-line)	<a href="#">149</a>
MSTP	spanning-tree mst-configuration	Console(config-mstp)	<a href="#">543</a>
Policy Map	policy-map	Console(config-pmap)	<a href="#">674</a>
Router	router {bgp   ipv6 ospf   ospf   pim   rip}	Console(config-router)	<a href="#">1097</a>
			<a href="#">1073</a>
			<a href="#">1035</a>
			<a href="#">1186</a>
			<a href="#">1016</a>
Control Plane	control-plane	Console(config-cp)	<a href="#">687</a>
Time Range	time-range	Console(config-time-range)	<a href="#">188</a>
VLAN	vlan database	Console(config-vlan)	<a href="#">576</a>

For example, you can use the following commands to enter interface configuration mode, and then return to Privileged Exec mode

```

Console(config)#interface ethernet 1/5
:
:
Console(config-if)#exit
Console(config)#

```

**Command Line Processing** Commands are not case sensitive. You can abbreviate commands and parameters as long as they contain enough letters to differentiate them from any other currently available commands or parameters. You can use the Tab key to complete partial commands, or enter a partial command followed by the “?” character to display a list of possible matches. You can also use the following editing keystrokes for command-line processing:

**Table 6: Keystroke Commands**

Keystroke	Function
Ctrl-A	Shifts cursor to start of command line.
Ctrl-B	Shifts cursor to the left one character.
Ctrl-C	Terminates the current task and displays the command prompt.
Ctrl-E	Shifts cursor to end of command line.
Ctrl-F	Shifts cursor to the right one character.
Ctrl-K	Deletes all characters from the cursor to the end of the line.
Ctrl-L	Repeats current command line on a new line.
Ctrl-N	Enters the next command line in the history buffer.
Ctrl-P	Enters the last command.
Ctrl-R	Repeats current command line on a new line.
Ctrl-U	Deletes from the cursor to the beginning of the line.
Ctrl-W	Deletes the last word typed.
Esc-B	Moves the cursor back one word.
Esc-D	Deletes from the cursor to the end of the word.
Esc-F	Moves the cursor forward one word.
Delete key or backspace key	Erases a mistake when entering a command.

**Showing Status Information** There are various “show” commands which display configuration settings or the status of specified processes. Many of these commands will not display any information unless the switch is properly configured, and in some cases the interface to which a command applies is up.

For example, if a static router port is configured, the corresponding show command will not display any information unless IGMP snooping is enabled, and the link for the static router port is up.

```
Console#configure
Console(config)#ip igmp snooping vlan 1 mrouter ethernet 1/11
Console(config)#end
Console#show ip igmp snooping mrouter
  VLAN M'cast Router Ports Type
  ---- -
Console#configure
```

```

Console(config)#ip igmp snooping
Console(config)#end
Console#show ip igmp snooping mrouter
VLAN M'cast Router Ports Type
-----
1     Eth 1/11           Static
Console#

```

## CLI Command Groups

The system commands can be broken down into the functional groups shown below.

**Table 7: Command Group Index**

Command Group	Description	Page
General	Basic commands for entering privileged access mode, restarting the system, or quitting the CLI	<a href="#">97</a>
System Management	Display and setting of system information, basic modes of operation, maximum frame size, file management, console port and telnet settings, system logs, SMTP alerts, the system clock, and switch clustering	<a href="#">105</a>
Simple Network Management Protocol	Activates authentication failure traps; configures community access strings, and trap receivers	<a href="#">199</a>
Remote Monitoring	Supports statistics, history, alarm and event groups	<a href="#">225</a>
Flow Sampling	Used with a remote sFlow Collector to provide an accurate, detailed and real-time overview of the types and levels of traffic present on the network	<a href="#">233</a>
User Authentication	Configures user names and passwords, command privilege levels, logon access using local or remote authentication, management access through the web server, Telnet server and Secure Shell; as well as port security, IEEE 802.1X port access control, and restricted access based on specified IP addresses	<a href="#">239</a>
General Security Measures	Segregates traffic for clients attached to common data ports; and prevents unauthorized access by configuring valid static or dynamic addresses, MAC address authentication, filtering DHCP requests and replies, and discarding invalid ARP responses	<a href="#">309</a>
Access Control List	Provides filtering for IPv4 frames (based on address, protocol, TCP/UDP port number or TCP control code), IPv6 frames (based on address, DSCP traffic class, or next header), or non-IP frames (based on MAC address or Ethernet type)	<a href="#">395</a>
Interface	Configures the connection parameters for all Ethernet ports, aggregated links, and VLANs	<a href="#">421</a>
Link Aggregation	Statically groups multiple ports into a single logical trunk; configures Link Aggregation Control Protocol for port trunks	<a href="#">455</a>
Power over Ethernet*	Configures power output for connected devices	<a href="#">475</a>
Mirror Port	Mirrors data to another port for analysis without affecting the data passing through or the performance of the monitored port	<a href="#">481</a>

**Table 7: Command Group Index (Continued)**

<b>Command Group</b>	<b>Description</b>	<b>Page</b>
Congestion Control	Sets the input/output rate limits, traffic storm thresholds, and thresholds for broadcast and multicast storms which can be used to trigger configured rate limits or to shut down a port.	491
Loopback Detection	Detects general loopback conditions caused by hardware problems or faulty protocol settings	509
Address Table	Configures the address table for filtering specified addresses, displays current entries, clears the table, or sets the aging time	523
Spanning Tree	Configures Spanning Tree settings for the switch	537
ERPS	Configures Ethernet Ring Protection Switching for increased availability of Ethernet rings commonly used in service provider networks	619
VLANs	Configures VLAN settings, and defines port membership for VLAN groups; also enables or configures private VLANs, protocol VLANs, voice VLANs, and QinQ tunneling	569
Class of Service	Sets port priority for untagged frames, selects strict priority or weighted round robin, relative weight for each priority queue, also sets priority for DSCP	653
Quality of Service	Configures Differentiated Services	669
Control Plane	Configures a QoS policy for the control-plane interface	687
Multicast Filtering	Configures IGMP multicast filtering, query, profile, and proxy parameters; specifies ports attached to a multicast router; also configures multicast VLAN registration, and IPv6 MLD snooping	691
Link Layer Discovery Protocol	Configures LLDP settings to enable information discovery about neighbor devices	811
Connectivity Fault Management	Configures connectivity monitoring using continuity check messages, fault verification through loopback messages, and fault isolation by examining end-to-end connections between Provider or Customer Edge devices	837
OAM	Configures Operations, Administration and Maintenance remote management tools required to monitor and maintain the links to subscriber CPEs	879
Domain Name Service	Configures DNS services.	891
Dynamic Host Configuration Protocol	Configures DHCP client, relay and server functions	901
IP Interface	Configures IP address for the switch interfaces; also configures ARP parameters	933
IP Routing	Configures static unicast routing	1005
RIP Routing	Configures RIPv1/v2 dynamic routing	1015
OSPF Routing	Configures OSPFv2 and OSPFv3 dynamic routing	1033
BGP Routing	Configures BGPv4 dynamic routing	1093
PIM Multicast Routing	Configures multicast routing protocols PIM-SM and PIM-SSM	1185
Multicast Routing	Enables IPv4 multicast routing	1199

\* ECS4650-54P

The access mode shown in the following tables is indicated by these abbreviations:

**ACL** (Access Control List Configuration)

**CFM** (Connectivity Fault Management Configuration)

**CM** (Class Map Configuration)

**CP** (Control Plane Interface Configuration)

**ERPS** (Ethernet Ring Protection Switching Configuration)

**GC** (Global Configuration)

**IC** (Interface Configuration)

**IPC** (IGMP Profile Configuration)

**LC** (Line Configuration)

**MST** (Multiple Spanning Tree)

**NE** (Normal Exec)

**PE** (Privileged Exec)

**PM** (Policy Map Configuration)

**RC** (Router Configuration)

**RM** (Route Map Configuration)

**VC** (VLAN Database Configuration)



# 3

## General Commands

The general commands are used to control the command access mode, configuration mode, and other basic functions.

**Table 8: General Commands**

Command	Function	Mode
<code>prompt</code>	Customizes the CLI prompt	GC
<code>reload</code>	Restarts the system at a specified time, after a specified delay, or at a periodic interval	GC
<code>enable</code>	Activates privileged mode	NE
<code>quit</code>	Exits a CLI session	NE, PE
<code>show history</code>	Shows the command history buffer	NE, PE
<code>configure</code>	Activates global configuration mode	PE
<code>disable</code>	Returns to normal mode from privileged mode	PE
<code>reload</code>	Restarts the system immediately	PE
<code>show reload</code>	Displays the current reload settings, and the time at which next scheduled reload will take place	PE
<code>end</code>	Returns to Privileged Exec mode	any config. mode
<code>exit</code>	Returns to the previous configuration mode, or exits the CLI	any mode

**prompt** This command customizes the CLI prompt. Use the **no** form to restore the default prompt.

### Syntax

**prompt** *string*

**no prompt**

*string* - Any alphanumeric string to use for the CLI prompt.  
(Maximum length: 32 characters)

### Default Setting

Console

### Command Mode

Global Configuration

### Command Usage

This command can be used to set the command line prompt as shown in the example below. Using the **no** form of either command will restore the default command line prompt.

### Example

```
Console(config)#prompt RD2
RD2(config)#
```

**reload** (Global Configuration) This command restarts the system at a specified time, after a specified delay, or at a periodic interval. You can reboot the system immediately, or you can configure the switch to reset after a specified amount of time. Use the **cancel** option to remove a configured setting.

### Syntax

```
reload {at hour minute [{month day | day month} [year]] |
in {hour hours | minute minutes | hour hours minute minutes} |
regularly hour minute [period {daily | weekly day-of-week |
monthly day-of-month}] | cancel [at | in | regularly]
```

**reload at** - A specified time at which to reload the switch.

*hour* - The hour at which to reload. (Range: 0-23)

*minute* - The minute at which to reload. (Range: 0-59)

*month* - The month at which to reload. (january ... december)

*day* - The day of the month at which to reload. (Range: 1-31)

*year* - The year at which to reload. (Range: 1970-2037)

**reload in** - An interval after which to reload the switch.

*hours* - The number of hours, combined with the minutes, before the switch resets. (Range: 0-576)

*minutes* - The number of minutes, combined with the hours, before the switch resets. (Range: 0-34560)

**reload regularly** - A periodic interval at which to reload the switch.

*hour* - The hour at which to reload. (Range: 0-23)

*minute* - The minute at which to reload. (Range: 0-59)

*day-of-week* - Day of the week at which to reload.  
(Range: monday ... saturday)

*day-of-month* - Day of the month at which to reload. (Range: 1-31)

**reload cancel** - Cancels the specified reload option.

### Default Setting

None

**Command Mode**

Privileged Exec, Global Configuration

**Command Usage**

- ◆ This command resets the entire system.
- ◆ Any combination of reload options may be specified. If the same option is re-specified, the previous setting will be overwritten.
- ◆ When the system is restarted, it will always run the Power-On Self-Test. It will also retain all configuration information stored in non-volatile memory by the [copy running-config startup-config](#) command (See [“copy” on page 137](#)).

**Example**

This example shows how to reset the switch after 30 minutes:

```

Console(config)#reload in minute 30
***
*** --- Rebooting at January  1 02:10:43 2016 ---
***

Are you sure to reboot the system at the specified time? <y/n>

```

**enable** This command activates Privileged Exec mode. In privileged mode, additional commands are available, and certain commands display additional information. See [“Understanding Command Modes” on page 88](#).

**Syntax****enable** [*level*]*level* - Privilege level to log into the device.

The device has two predefined privilege levels: 0: Normal Exec, 15: Privileged Exec. Enter level 15 to access Privileged Exec mode.

**Default Setting**

Level 15

**Command Mode**

Normal Exec

**Command Usage**

- ◆ “super” is the default password required to change the command mode from Normal Exec to Privileged Exec. (To set this password, see the [enable password](#) command.)
- ◆ The “#” character is appended to the end of the prompt to indicate that the system is in privileged access mode.

### Example

```
Console>enable
Password: [privileged level password]
Console#
```

### Related Commands

[disable \(102\)](#)

[enable password \(240\)](#)

**quit** This command exits the configuration program.

### Default Setting

None

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

The **quit** and **exit** commands can both exit the configuration program.

### Example

This example shows how to quit a CLI session:

```
Console#quit

Press ENTER to start session

User Access Verification

Username:
```

**show history** This command shows the contents of the command history buffer.

### Default Setting

None

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

The history buffer size is fixed at 10 Execution commands and 10 Configuration commands.

**Example**

In this example, the show history command lists the contents of the command history buffer:

```

Console#show history
Execution command history:
 2 config
 1 show history

Configuration command history:
 4 interface vlan 1
 3 exit
 2 interface vlan 1
 1 end

Console#

```

The **!** command repeats commands from the Execution command history buffer when you are in Normal Exec or Privileged Exec Mode, and commands from the Configuration command history buffer when you are in any of the configuration modes. In this example, the **!2** command repeats the second command in the Execution history buffer (**config**).

```

Console#!2
Console#config
Console(config)#

```

**configure** This command activates Global Configuration mode. You must enter this mode to modify any settings on the switch. You must also enter Global Configuration mode prior to enabling some of the other configuration modes, such as Interface Configuration, Line Configuration, and VLAN Database Configuration. See [“Understanding Command Modes” on page 88](#).

**Default Setting**

None

**Command Mode**

Privileged Exec

**Example**

```

Console#configure
Console(config)#

```

**Related Commands**

[end \(103\)](#)

**disable** This command returns to Normal Exec mode from privileged mode. In normal access mode, you can only display basic information on the switch's configuration or Ethernet statistics. To gain access to all commands, you must use the privileged mode. See [“Understanding Command Modes” on page 88](#).

**Default Setting**

None

**Command Mode**

Privileged Exec

**Command Usage**

The “>” character is appended to the end of the prompt to indicate that the system is in normal access mode.

**Example**

```
Console#disable  
Console>
```

**Related Commands**

[enable \(99\)](#)

**reload (Privileged Exec)** This command restarts the system.



**Note:** When the system is restarted, it will always run the Power-On Self-Test. It will also retain all configuration information stored in non-volatile memory by the copy running-config startup-config command.

**Default Setting**

None

**Command Mode**

Privileged Exec

**Command Usage**

This command resets the entire system.

**Example**

This example shows how to reset the switch:

```
Console#reload  
System will be restarted, continue <y/n>? y
```

**show reload** This command displays the current reload settings, and the time at which next scheduled reload will take place.

#### Command Mode

Privileged Exec

#### Example

```
Console#show reload
Reloading switch in time:                0 hours 29 minutes.

The switch will be rebooted at January  1 02:11:50 2015.
Remaining Time: 0 days, 0 hours, 29 minutes, 52 seconds.
Console#
```

**end** This command returns to Privileged Exec mode.

#### Default Setting

None

#### Command Mode

Global Configuration, Interface Configuration, Line Configuration, VLAN Database Configuration, and Multiple Spanning Tree Configuration.

#### Example

This example shows how to return to the Privileged Exec mode from the Interface Configuration mode:

```
Console(config-if)#end
Console#
```

**exit** This command returns to the previous configuration mode or exits the configuration program.

#### Default Setting

None

#### Command Mode

Any

### Example

This example shows how to return to the Privileged Exec mode from the Global Configuration mode, and then quit the CLI session:

```
Console(config)#exit
Console#exit

Press ENTER to start session

User Access Verification

Username:
```

# 4

## System Management Commands

The system management commands are used to control system logs, passwords, user names, management options, and display or configure a variety of other system information.

**Table 9: System Management Commands**

Command Group	Function
Cloud Management	Configures the switch for management from the ecCLOUD system
Device Designation	Configures information that uniquely identifies this switch
Banner Information	Configures administrative contact, device identification and location
System Status	Displays system configuration, active managers, and version information
Fan Control	Forces fans to full speed
Frame Size	Enables support for jumbo frames
File Management	Manages code image or switch configuration files
Line	Sets communication parameters for the serial port, including baud rate and console time-out
Event Logging	Controls logging of error messages
SMTP Alerts	Configures SMTP email alerts
Time (System Clock)	Sets the system clock automatically via NTP/SNTP server or manually
Time Range	Sets a time range for use by other functions, such as Access Control Lists
Switch Clustering	Configures management of multiple devices via a single IP address
Dying Gasp	Configures dying gasp messages when the device loses power

## Cloud Management

This section describes commands used to configure the cloud management agent on the switch for management through ecCLOUD.

**Table 10: Cloud Management Commands**

Command	Function	Mode
<code>mgmt</code>	Enables or disables cloud management for the switch	GC
<code>mgmt loglevel</code>	Sets the minimum level for logging messages	GC
<code>mgmt setoption</code>	Sets various options for the cloud management agent	GC
<code>mgmt property</code>	Sets cloud management settings to default values	GC
<code>mgmt upgrade</code>	Upgrades the cloud management agent code on the switch	PE
<code>show mgmt status</code>	Displays the cloud management agent status	PE
<code>show mgmt version</code>	Displays the cloud management agent code version	PE
<code>show mgmt log</code>	Displays log messages from the cloud management agent	PE
<code>show mgmt option</code>	Displays the cloud management agent configuration options	PE

**mgmt** This command enables or disables the cloud management agent for the switch.

### Syntax

**mgmt {enable | disable}**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Setting the cloud management agent to enabled allows the switch to be managed through the ecCLOUD system after the next reboot. By default, the cloud management agent is disabled.
- ◆ After setting the cloud management agent to enabled or disabled, it requires a reboot of the switch to take effect.

### Example

```
Console(config)#mgmt enable
Console(config)#
```

**mgmt loglevel** This command sets the minimum level for cloud management agent logging messages. Use the **no** form to reset to the default level.

#### Syntax

**mgmt loglevel** *level*

**no mgmt loglevel**

*level* - The minimum logging level. (Options: trace, debug, info, warn, error)

#### Default Setting

Info

#### Command Mode

Global Configuration

#### Command Usage

- ◆ The logging levels from minimum severity to maximum severity are: Trace, Debug, Info, Warn, Error.
- ◆ This command configures messages logged by the cloud management agent based on severity. Messages from the configured level up to the maximum level are logged. Therefore, if Info is the configured level, all messages for Info, Warn, and Error are logged.

#### Example

```
Console(config)#mgmt loglevel info
Console(config)#
```

**mgmt setoption** This command sets options for the cloud management agent. Use the **no** form to delete the specified option.

#### Syntax

**mgmt setoption** *option*

**no mgmt setoption** *option*

*option* - The option to set in the format "option name=value".

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

- ◆ This command configures cloud management agent settings that are used in communications between the switch and the ecCLOUD controller.

◆ The following table lists all the cloud management agent options.

**Table 11: Cloud Management Agent Options**

Name	Type	Required	Default	Notes
acn.settings.latitude	decimal	no	0	Latitude of device.
acn.settings.longitude	decimal	no	0	Longitude of device.
acn.settings.name	string	yes	"IgniteNet" (depends on brand)	Device's name used with the controller.
acn.mgmt.enabled	boolean	no	0	Whether or not to enable mgmtd agent. Used by external process which runs the actual mgmtd.
acn.mgmt.loglevel	string	no	"info"	Various logging levels for mgmtd. Possible values in lowering order: error, warn, info, debug, trace.
acn.mgmt.hb_interval	int	no	60	Heartbeat message sending interval.
acn.mgmt.hb_ack_timeout	int	no	57	Heartbeat acknowledgement timeout (to consider connection problem is present)
acn.mgmt.hb_retry_count	int	no	3	How many times to try and send a heartbeat without a received acknowledgment.
acn.mgmt.status_interval	int	no	300	How often to send events/client data/etc.
acn.mgmt.status_min_offset	int	no	0	Minimum time delay value for randomized offset for sending first status message.
acn.mgmt.status_max_offset	int	no	60	Maximum time delay value for randomized offset for sending first status message.
acn.mgmt.response_repetitions	int	no	120	How many response repetitions to send to the Controller (for live data, like graphs).
acn.mgmt.response_interval	int	no	3	Interval between subsequent repetitions.
acn.mgmt.fw_update_interval	int	no	5	Firmware update delay after receiving appropriate task.
acn.mgmt.fw_download_retries	int	no	10	Count of firmware download retries.
acn.mgmt.mac_tbl_interval	int	no	300	How often to send the MAC address table.
acn.mgmt.registration_inverval	int	no	60	Interval between registration attempts (if fails).
acn.mgmt.restart_interval	int	no	86400	(Temporary) interval between mgmtd restarts to free leaked memory.
acn.mgmt.task_expiry_interval	int	no	3600	Interval to check for expired tasks.
acn.mgmt.task_expiry_time	int	no	86400	Time after which task is considered to be expired.
acn.mgmt.acn.register.port	CS list	no	5222,443	Can contain multiple port values: 5222,443 for example. When more ports are present, mgmtd on first connection failure retries with the next port in the list.
acn.mgmt.os_time_tolerance	int	no	240	Maximum time difference between device OS time and cloud time to tolerate. If difference is bigger, mgmtd sets OS time to the controller's value.
acn.mgmt.dev_ca_off	int	no	0	Set this value to 1 to bypass SSL certificates check against registration service and XMPP server. Not to be used outside development scope.
acn.register.state	boolean	yes	0	Registration state: 0 = unreg, 1 = registered

**Table 11: Cloud Management Agent Options (Continued)**

Name	Type	Required	Default	Notes
acn.register.url	string	yes	https://regsvc.ignitenet.com/register	Registration URL.
acn.register.login	string	depends	(empty)	This is the xmpp username - it will ONLY be set after a successful registration.
acn.register.pass	string	depends	(empty)	This is the xmpp password - it will ONLY be set after a successful registration.
acn.register.host	string	depends	(empty)	This is the xmpp server - it will ONLY be set after a successful registration.

### Example

```
Console(config)#mgmt setoption acn.mgmt.status_interval=600
Console(config)#
```

**mgmt property** This command sets the cloud management agent properties to their default values.

### Syntax

**mgmt property default**

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#mgmt property default
Console(config)#
```

**mgmt upgrade** This command upgrades the cloud management agent software from a file on a TFTP server.

### Syntax

**mgmt upgrade {file-url}**

*file-url* - The path to a tar.gz archive file on a TFTP server in the format:  
tftp://<ip>/<folder>/<file>

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

The upgrade software file must be contained in a tar.gz archive file and include an MD5 checksum.

### Example

```
Console#mgmt upgrade tftp://192.168.1.9/download/mgmt.tar.gz  
Console#
```

**show mgmt status** This command displays the status of the cloud management agent.

### Syntax

**show mgmt status**

### Command Mode

Privileged Exec

### Example

```
Console#show mgmt status  
Console#
```

**show mgmt version** This command displays the version of the cloud management agent.

### Syntax

**show mgmt version**

### Command Mode

Privileged Exec

### Example

```
Console#show mgmt version  
Mgmt version: 1.4.3-16868  
Console#
```

**show mgmt log** This command displays the cloud management agent log messages.

### Syntax

**show mgmt log**

### Command Mode

Privileged Exec

## Example

```
Console#show mgmt log
Mgmted log:
2020-10-26 10:19:38 [info]: calling arg: result: true; nil
2020-10-26 10:19:38 [info]: Starting mgmted
2020-10-26 10:19:38 [info]: No default route, but uptime: 3907
2020-10-26 10:19:39 [info]: flash read
2020-10-26 10:19:39 [info]: Starting registration process
2020-10-26 10:19:39 [info]: mgmted status set to UNREGISTERED
2020-10-26 10:19:39 [info]: Sending registration request
2020-10-26 10:19:39 [info]: HTTPS: nil, host or service not provided, or not
known, nil, nil
2020-10-26 10:19:39 [info]: mgmted status set to REG_FAILED
2020-10-26 10:19:39 [error]: Error: Unable to contact registration service!
(Empty response)
Console#
```

**show mgmt option** This command displays the cloud management agent options.

## Syntax

**show mgmt option**

## Command Mode

Privileged Exec

## Example

```
Console#show mgmt option
Mgmted Option:
acn.mgmt=acn
acn.mgmt.loglevel=info
acn.mgmt.enabled=0
acn.register=register
acn.register.state=0
acn.register.url=https://regsvc.ignite.net.com/register
acn.settings.longitude=0
acn.settings.latitude=0
acn.settings.name=IgniteNet-Switch
Console#
```

## Device Designation

This section describes commands used to configure information that uniquely identifies the switch.

**Table 12: Device Designation Commands**

Command	Function	Mode
<a href="#">hostname</a>	Specifies the host name for the switch	GC
<a href="#">snmp-server contact</a>	Sets the system contact string	GC
<a href="#">snmp-server location</a>	Sets the system location string	GC

**hostname** This command specifies or modifies the host name for this device. Use the **no** form to restore the default host name.

### Syntax

**hostname** *name*

no hostname

*name* - The name of this host. (Maximum length: 255 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ The host name specified by this command is displayed by the [show system](#) command and on the Show > System web page.

### Example

```
Console(config)#hostname RD#1
Console(config)#
```

## Banner Information

These commands are used to configure and manage administrative information about the switch, its exact data center location, details of the electrical and network circuits that supply the switch, as well as contact information for the network administrator and system manager. This information is only available via the CLI and is automatically displayed before login as soon as a console or telnet connection has been established.

**Table 13: Banner Commands**

Command	Function	Mode
<code>banner configure</code>	Configures the banner information that is displayed before login	GC
<code>banner configure company</code>	Configures the Company information that is displayed by banner	GC
<code>banner configure dc-power-info</code>	Configures the DC Power information that is displayed by banner	GC
<code>banner configure department</code>	Configures the Department information that is displayed by banner	GC
<code>banner configure equipment-info</code>	Configures the Equipment information that is displayed by banner	GC
<code>banner configure equipment-location</code>	Configures the Equipment Location information that is displayed by banner	GC
<code>banner configure ip-lan</code>	Configures the IP and LAN information that is displayed by banner	GC
<code>banner configure lp-number</code>	Configures the LP Number information that is displayed by banner	GC
<code>banner configure manager-info</code>	Configures the Manager contact information that is displayed by banner	GC
<code>banner configure mux</code>	Configures the MUX information that is displayed by banner	GC
<code>banner configure note</code>	Configures miscellaneous information that is displayed by banner under the Notes heading	GC
<code>show banner</code>	Displays all banner information	PE

**banner configure** This command is used to interactively specify administrative information for this device.

### Syntax

`banner configure`

### Default Setting

None

## Command Mode

### Global Configuration

### Command Usage

The administrator can batch-input all details for the switch with one command. When the administrator finishes typing the company name and presses the enter key, the script prompts for the next piece of information, and so on, until all information has been entered. Pressing enter without inputting information at any prompt during the script's operation will leave the field empty. Spaces can be used during script mode because pressing the enter key signifies the end of data input. The delete and left-arrow keys terminate the script. The use of the backspace key during script mode is not supported. If, for example, a mistake is made in the company name, it can be corrected with the **banner configure company** command.

### Example

```
Console(config)#banner configure

Company: Edgecore Networks
Responsible department: R&D Dept
Name and telephone to Contact the management people
Manager1 name: Sr. Network Admin
  phone number: 123-555-1212
Manager2 name: Jr. Network Admin
  phone number: 123-555-1213
Manager3 name: Night-shift Net Admin / Janitor
  phone number: 123-555-1214
The physical location of the equipment.
City and street address: 12 Straight St. Motown, Zimbabwe
Information about this equipment:
Manufacturer: Edgecore Networks
ID: 123_unique_id_number
Floor: 2
Row: 7
Rack: 29
Shelf in this rack: 8
Information about DC power supply.
Floor: 2
Row: 7
Rack: 25
Electrical circuit: : ec-177743209-xb
Number of LP:12
Position of the equipment in the MUX:1/23
IP LAN:192.168.1.1
Note: This is a random note about this managed switch and can contain
  miscellaneous information.
Console(config)#
```

**banner configure company** This command is used to configure company information displayed in the banner. Use the **no** form to remove the company name from the banner display.

#### Syntax

**banner configure company** *name*

**no banner configure company**

*name* - The name of the company. (Maximum length: 32 characters)

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

Input strings cannot contain spaces. The **banner configure company** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

#### Example

```
Console(config)#banner configure company Big-Ben
Console(config)#
```

**banner configure dc-power-info** This command is use to configure DC power information displayed in the banner. Use the **no** form to restore the default setting.

#### Syntax

**banner configure dc-power-info floor** *floor-id* **row** *row-id* **rack** *rack-id*  
**electrical-circuit** *ec-id*

**no banner configure dc-power-info** [**floor** | **row** | **rack** | **electrical-circuit**]

*floor-id* - The floor number.

*row-id* - The row number.

*rack-id* - The rack number.

*ec-id* - The electrical circuit ID.

Maximum length of each parameter: 32 characters

#### Default Setting

None

#### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure dc-power-info** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure dc-power-info floor 3 row 15 rack 24
electrical-circuit 48v-id_3.15.24.2
Console(config)#
```

**banner configure department** This command is used to configure the department information displayed in the banner. Use the **no** form to restore the default setting.

### Syntax

**banner configure department** *dept-name*

**no banner configure department**

*dept-name* - The name of the department.  
(Maximum length: 32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure department** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure department R&D
Console(config)#
```

**banner configure equipment-info** This command is used to configure the equipment information displayed in the banner. Use the **no** form to restore the default setting.

### Syntax

**banner configure equipment-info manufacturer-id** *mfr-id* **floor** *floor-id*  
**row** *row-id* **rack** *rack-id* **shelf-rack** *sr-id* **manufacturer** *mfr-name*

**no banner configure equipment-info** [**floor** | **manufacturer** | **manufacturer-id** | **rack** | **row** | **shelf-rack**]

*mfr-id* - The name of the device model number.

*floor-id* - The floor number.

*row-id* - The row number.

*rack-id* - The rack number.

*sr-id* - The shelf number in the rack.

*mfr-name* - The name of the device manufacturer.

Maximum length of each parameter: 32 characters

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure equipment-info** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure equipment-info manufacturer-id ECS4650-54P
  floor 3 row 10 rack 15 shelf-rack 12 manufacturer Edgecore
Console(config)#
```

**banner configure equipment-location** This command is used to configure the equipment location information displayed in the banner. Use the **no** form to restore the default setting.

### Syntax

**banner configure equipment-location** *location*

**no banner configure equipment-location**

*location* - The address location of the device.  
(Maximum length: 32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure equipment-location** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure equipment-location  
710_Network_Path,_Indianapolis  
Console(config)#
```

**banner configure ip-lan** This command is used to configure the device IP address and subnet mask information displayed in the banner. Use the **no** form to restore the default setting.

### Syntax

**banner configure ip-lan** *ip-mask*

**no banner configure ip-lan**

*ip-mask* - The IP address and subnet mask of the device.  
(Maximum length: 32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure ip-lan** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure ip-lan 192.168.1.1/255.255.255.0  
Console(config)#
```

**banner configure lp-number** This command is used to configure the LP number information displayed in the banner. Use the **no** form to restore the default setting.

#### Syntax

**banner configure lp-number** *lp-num*

**no banner configure lp-number**

*lp-num* - The LP number. (Maximum length: 32 characters)

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

Input strings cannot contain spaces. The **banner configure lp-number** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

#### Example

```
Console(config)#banner configure lp-number 12
Console(config)#
```

**banner configure manager-info** This command is used to configure the manager contact information displayed in the banner. Use the **no** form to restore the default setting.

#### Syntax

**banner configure manager-info**

**name** *mgr1-name* **phone-number** *mgr1-number*  
[**name2** *mgr2-name* **phone-number** *mgr2-number* |  
**name3** *mgr3-name* **phone-number** *mgr3-number*]

**no banner configure manager-info** [**name1** | **name2** | **name3**]

*mgr1-name* - The name of the first manager.

*mgr1-number* - The phone number of the first manager.

*mgr2-name* - The name of the second manager.

*mgr2-number* - The phone number of the second manager.

*mgr3-name* - The name of the third manager.

*mgr3-number* - The phone number of the third manager.

Maximum length of each parameter: 32 characters

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure manager-info** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure manager-info name Albert_Einstein phone-  
number 123-555-1212 name2 Lamar phone-number 123-555-1219  
Console(config)#
```

**banner configure mux** This command is used to configure the mux information displayed in the banner. Use the **no** form to restore the default setting.

### Syntax

**banner configure mux** *muxinfo*

**no banner configure mux**

*muxinfo* - The circuit and PVC to which the switch is connected. (Maximum length: 32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure mux** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure mux telco-8734212kx_PVC-1/23  
Console(config)#
```

**banner configure note** This command is used to configure the note displayed in the banner. Use the **no** form to restore the default setting.

### Syntax

**banner configure note** *note-info*

**no banner configure note**

*note-info* - Miscellaneous information that does not fit the other banner categories, or any other information of importance to users of the switch CLI. (Maximum length: 150 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Input strings cannot contain spaces. The **banner configure note** command interprets spaces as data input boundaries. The use of underscores ( `_` ) or other unobtrusive non-letter characters is suggested for situations where white space is necessary for clarity.

### Example

```
Console(config)#banner configure note !!!!!ROUTINE_MAINTENANCE_firmware-
upgrade_0100-0500_GMT-0500_20071022!!!!!!_20min_network_impact_expected
Console(config)#
```

**show banner** This command displays all banner information.

### Command Mode

Privileged Exec

### Example

```
Console#show banner
Edgecore
WARNING - MONITORED ACTIONS AND ACCESSES
R&D

Albert_Einstein - 123-555-1212
Lamar - 123-555-1219

Station's information:
710_Network_Path,_Indianapolis

ECS4650-54P
Floor / Row / Rack / Sub-Rack
3/ 10 / 15 / 12
```

```
DC power supply:
Power Source A: Floor / Row / Rack / Electrical circuit
 3/ 15 / 24 / 48v-id_3.15.24.2
Number of LP: 12
Position MUX: telco-8734212kx_PVC-1/23
IP LAN: 192.168.1.1/255.255.255.0
Note: !!!!!ROUTINE_MAINTENANCE_firmware-upgrade_0100-0500_GMT-
      0500_20071022!!!!!!_20min_network_
Console#
```

## System Status

This section describes commands used to display system information.

**Table 14: System Status Commands**

Command	Function	Mode
<a href="#">show access-list</a> <a href="#">tcam-utilization</a>	Shows utilization parameters for TCAM	PE
<a href="#">show memory</a>	Shows memory utilization parameters	PE
<a href="#">show process cpu</a>	Shows CPU utilization parameters	PE
<a href="#">show process cpu guard</a>	Shows the CPU utilization watermark and threshold	NE
<a href="#">show process cpu task</a>	Shows CPU utilization per process	PE
<a href="#">show running-config</a>	Displays the configuration data currently in use	PE
<a href="#">show startup-config</a>	Displays the contents of the configuration file (stored in flash memory) that is used to start up the system	PE
<a href="#">show system</a>	Displays system information	NE, PE
<a href="#">show tech-support</a>	Displays a detailed list of system settings designed to help technical support resolve configuration or functional problems	PE
<a href="#">show users</a>	Shows all active console and Telnet sessions, including user name, idle time, and IP address of Telnet clients	NE, PE
<a href="#">show version</a>	Displays version information for the system	NE, PE
<a href="#">show watchdog</a>	Shows if watchdog debugging is enabled	PE
<a href="#">watchdog software</a>	Monitors key processes, and automatically reboots the system if any of these processes are not responding correctly	PE

**show access-list tcam-utilization** This command shows utilization parameters for TCAM (Ternary Content Addressable Memory), including the number policy control entries in use, and the number of free entries.

**Command Mode**

Privileged Exec

**Command Usage**

Policy control entries (PCEs) are used by various system functions which rely on rule-based searches, including Access Control Lists (ACLs), IP Source Guard filter rules, Quality of Service (QoS) processes, or traps.

For example, when binding an ACL to a port, each rule in an ACL will use two PCEs; and when setting an IP Source Guard filter rule for a port, the system will also use two PCEs.

**Example**

```

Console#show access-list tcam-utilization
Pool capability code:
  AM - MAC ACL, A4 - IPv4 ACL, A6S - IPv6 Standard ACL,
  A6E - IPv6 extended ACL, DM - MAC diffServ, D4 - IPv4 diffServ,
  D6S - IPv6 standard diffServ, D6E - IPv6 extended diffServ,
  AEM - Egress MAC ACL, AE4 - Egress IPv4 ACL,
  AE6S - Egress IPv6 standard ACL, AE6E - Egress IPv6 extended ACL,
  DEM - Egress MAC diffServ, DE4 - Egress IPv4 diffServ,
  DE6S - Egress IPv6 standard diffServ,
  DE6E - Egress IPv6 extended diffServ, W - Web authentication,
  I - IP source guard, I6 - IPv6 source guard, C - CPU interface,
  L - Link local, Reserved - Reserved, ALL - All supported function,

Unit Device Pool Total Used Free Capability
-----
  1      0    0  3072   33  3039 ALL
  1      0    0  3072    0  3039 EXCLUDED_VLAN

Console#

```

**Table 15: show access-list tcam-utilization - display description**

Field	Description
Pool Capability Code	Abbreviation for processes shown in the TCAM List.
Unit	Stack unit identifier.
Device	Memory chip used for indicated pools.
Pool	Rule slice (or call group). Each slice has a fixed number of rules that are used for the specified features.
Total	The maximum number of policy control entries allocated to the each pool.
Used	The number of policy control entries used by the operating system.
Free	The number of policy control entries available for use.
Capability	The processes assigned to each pool.

**show memory** This command shows memory utilization parameters, and alarm thresholds.

#### Command Mode

Normal Exec, Privileged Exec

#### Command Usage

This command shows the amount of memory currently free for use, the amount of memory allocated to active processes, the total amount of system memory, and the alarm thresholds.

#### Example

```
Console#show memory
  Status Bytes      %
-----
Free      541569024  50
Used      532172800  50
Total    1073741824

Alarm Configuration
Rising Threshold      : 90%
Falling Threshold     : 70%

Console#
```

#### Related Commands

[memory \(220\)](#)

**show process cpu** This command shows the CPU utilization parameters, alarm status, and alarm thresholds.

#### Command Mode

Normal Exec, Privileged Exec

#### Example

```
Console#show process cpu
CPU Utilization in the past 5 seconds : 24%

CPU Utilization in the past 60 seconds
Average Utilization      : 24%
Maximum Utilization     : 25%

Alarm Status
Current Alarm Status     : Off
Last Alarm Start Time   : Dec 31 00:00:19 2000
Last Alarm Duration Time : 15 seconds

Alarm Configuration
Rising Threshold        : 90%
Falling Threshold       : 70%

Console#
```

**Related Commands**  
[process cpu \(221\)](#)

**show process cpu guard** This command shows the CPU utilization watermark and threshold settings.

**Command Mode**  
Normal Exec, Privileged Exec

**Example**

```

Console#show process cpu guard
CPU Guard Configuration
  Status           : Disabled
  High Watermark   : 90%
  Low Watermark    : 70%
  Maximum Threshold : 500 packets per second
  Minimum Threshold : 50 packets per second
  Trap Status      : Disabled
CPU Guard Operation
  Current Threshold : 500 packets per second

Console#
    
```

**Table 16: show process cpu guard - display description**

Field	Description
<i>CPU Guard Configuration</i>	
Status	Shows if CPU Guard has been enabled.
High Watermark	If the percentage of CPU usage time is higher than the high-watermark, the switch stops packet flow to the CPU (allowing it to catch up with packets already in the buffer) until usage time falls below the low watermark.
Low Watermark	If packet flow has been stopped after exceeding the high watermark, normal flow will be restored after usage falls beneath the low watermark.
Maximum Threshold	If the number of packets being processed by the CPU is higher than the maximum threshold, the switch stops packet flow to the CPU (allowing it to catch up with packets already in the buffer) until the number of packets being processed falls below the minimum threshold.
Minimum Threshold	If packet flow has been stopped after exceeding the maximum threshold, normal flow will be restored after usage falls beneath the minimum threshold.
Trap Status	Shows if an alarm message will be generated when utilization exceeds the high watermark or exceeds the maximum threshold.
<i>CPU Guard Operation</i>	
Current Threshold	Shows the configured threshold in packets per second.

**Related Commands**  
[process cpu guard \(222\)](#)

**show process cpu task** This command shows the CPU utilization per process.

### Command Mode

Privileged Exec

### Example

```
Console#show process cpu task
Task          Util (%) Avg (%) Max (%)
-----
AMTRL3        0.00    0.00    0.00
AMTRL3_GROUP  0.00    0.00    0.00
AMTR_ASIC_COM 0.00    0.00    0.00
APP_PROTOCOL_GR 0.00    0.00    0.00
APP_PROTOCOL_PR 0.00    0.00    0.09
AUTH_GROUP    0.00    0.00    0.00
AUTH_PROC     0.00    0.00    0.00
CFGDB_TD      0.09    0.04    0.19
CLITASK0      0.09    0.04    0.10
.
.
.

Console#
```

**show running-config** This command displays the configuration information currently in use.

### Syntax

**show running-config** [**interface** *interface* | *key-words*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* (Range: 1-4094)

*key-words* - One of the following key words that identify a feature:

**acl, aclaccessgroup, autotrafficcontr, cfm, controlplane, createtrunk, dai, dhcpsnooping, dns, dot1x, dyinggasp, erps, ethernet, excludedvlan, heartbeat, heartbeat, http, igmpfilter, igmpsooping, ipaddress, ipv4dhcpdynamic, ipv6, ipv6dhcp, ipv6dhcpdynamic, ipv6dhcpsnooping, ipv6ndsnooping, l3global, lbd, line, lldp, loopback, macaddressstable, macvlan, managementip, mdns, mlag, mldsnooping, mvr, mvr6, netaccess, ntp, pppoeia, privilegelevel, protocolvlan, qos, qosclassmap,**

**qosglobalmap, qospolycymap, reload, remoteauthaaa, rmon, rspan, smartpair, smtp, snmp, sourceguard, spanningtreemstp, spanningtreestp, spanningtreexstp, ssh, subnetvlan, syslog, system, tftp, timerange, trafficseg, trunk, twampglobal, udd, userauth, vdsiglobal, vlan, vlandatabase, voicevlan, webauth**

## Command Mode

Privileged Exec

## Command Usage

- ◆ Use the **interface** keyword to display configuration data for the specified interface.
- ◆ Use this command in conjunction with the **show startup-config** command to compare the information in running memory to the information stored in non-volatile memory.
- ◆ This command displays settings for key command modes. Each mode group is separated by “!” symbols, and includes the configuration mode command, and corresponding commands. This command displays the following information:
  - MAC address for
  - SNMP community strings
  - Users (names, access levels, and encrypted passwords)
  - VLAN database (VLAN ID, name and state)
  - VLAN configuration settings for each interface
  - Multiple spanning tree instances (name and interfaces)
  - IP address configured for VLANs
  - Spanning tree settings
  - Interface settings
  - Any configured settings for the console port and Telnet
- ◆ For security reasons, user passwords are only displayed in encrypted format.

## Example

```

Console#show running-config
!<stackingDB>00</stackingDB>
!<stackingMac>01_00-e0-0c-00-00-fd_03</stackingMac>
!
snmp-server community public ro
snmp-server community private rw
!
enable password 7 1b3231655cebb7a1f783eddf27d254ca
!
vlan database
VLAN 1 name DefaultVlan media ethernet
!
spanning-tree mst configuration
!
interface ethernet 1/1
no negotiation
...
interface ethernet 1/18
no negotiation
    
```

```
!  
interface vlan 1  
  ip address dhcp  
!  
interface vlan 1  
!  
line console  
!  
line vty  
!  
end  
!  
Console#
```

### Related Commands

[show startup-config \(128\)](#)

**show startup-config** This command displays the configuration file stored in non-volatile memory that is used to start up the system.

### Command Mode

Privileged Exec

### Command Usage

- ◆ Use this command in conjunction with the **show running-config** command to compare the information in running memory to the information stored in non-volatile memory.
  
- ◆ This command displays settings for key command modes. Each mode group is separated by “!” symbols, and includes the configuration mode command, and corresponding commands. This command displays the following information:
  - MAC address for
  - SNMP community strings
  - SNMP trap authentication
  - Users (names and access levels)
  - VLAN database (VLAN ID, name and state)
  - Multiple spanning tree instances (name and interfaces)
  - Interface settings and VLAN configuration settings for each interface
  - IP address for VLANs
  - Any configured settings for the console port and Telnet

### Example

Refer to the example for the running configuration file.

### Related Commands

[show running-config \(126\)](#)

**show system** This command displays system information.

### Default Setting

None

### Command Mode

Normal Exec, Privileged Exec

### Example

```

Console#show system
System Description : ECS4650-54P
System OID String : 1.3.6.1.4.1.259.10.1.58.102
System Information
  System Up Time      : 0 days, 0 hours, 5 minutes, and 16.53 seconds
  System Name         :
  System Location     :
  System Contact      :
  MAC Address (Unit 1) : D0-77-CE-F8-D3-29
  Web Server          : Enabled
  Web Server Port     : 80
  Web Secure Server   : Enabled
  Web Secure Server Port : 443
  Telnet Server       : Enabled
  Telnet Server Port  : 23
  Jumbo Frame         : Disabled

System Fan:
  Force Fan Speed Full : Disabled
Unit 1
  Fan 1: Ok           Fan 2: Ok           Fan 3: Ok
  Fan 1 speed: 7957 rpm  Fan 2 speed: 8047 rpm  Fan 3 speed: 8047 rpm

System Temperature:
Unit 1
  Temperature 1: 23 degrees

Console#

```

**Table 17: show system – display description**

Parameter	Description
System Description	Brief description of device type.
System OID String	MIB II object ID for switch's network management subsystem.
System Up Time	Length of time the management agent has been up.
System Name	Name assigned to the switch system.
System Location	Specifies the system location.
System Contact	Administrator responsible for the system.
MAC Address	MAC address assigned to this switch.
Web Server/Port	Shows administrative status of web server and UDP port number.
Web Secure Server/Port	Shows administrative status of secure web server and UDP port number.

**Table 17: show system – display description (Continued)**

Parameter	Description
Telnet Server/Port	Shows administrative status of Telnet server and TCP port number.
Jumbo Frame	Shows if jumbo frames are enabled or disabled.

**show tech-support** This command displays a detailed list of system settings designed to help technical support resolve configuration or functional problems.

### Command Mode

Privileged Exec

### Command Usage

This command generates a long list of information including detailed system and interface settings. It is therefore advisable to direct the output to a file using any suitable output capture function provided with your terminal emulation program.

### Example

```

User Access Verification

Username: admin
Password:

      CLI session with the ECS4650-54P is opened.
      To end the CLI session, enter [Exit].

Vty-2#show tech-support

dir:
File Name                               Type   Startup Modified Time          Size (bytes)
-----
Unit 1:
runtime.bix                             OpCode Y      2023-02-07 14:40:05    51,893,948
Factory_Default_Config.cfg              Config N      2023-01-17 01:09:16      455
startupl.cfg                             Config Y      2023-02-17 07:39:01      1,673
-----
Free space for compressed user config files: 109,490,176
Total space: 165,584,896

show arp:
ARP Cache Timeout: 1200 (seconds)

IP Address      MAC Address      Type      Interface
-----
192.168.2.99    F0-79-59-8F-2B-FE dynamic      VLAN 1

Total entry : 1

show interfaces brief:
Interface Name      Status      PVID Pri Speed/Duplex  Type      Trunk
-----
Eth 1/ 1            Up          1  0 Auto-1000full 1000BASE-T None
Eth 1/ 2            Up          1  0 Auto          1000BASE-T None
Eth 1/ 3            Up          1  0 Auto          1000BASE-T None
Eth 1/ 4            Up          1  0 Auto          1000BASE-T None
Eth 1/ 5            Up          1  0 Auto          1000BASE-T None
  
```

...

**show users** Shows all active console and Telnet sessions, including user name, idle time, and IP address of Telnet client.

### Default Setting

None

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

The session used to execute this command is indicated by a "\*" symbol next to the Line (i.e., session) index number.

### Example

```

Console#show users
User Name Accounts:
User Name          Privilege  Public-Key
-----
admin              15 None
guest              0 None

Online Users:
Line      Session ID User Name          Idle Time (h:m:s) Remote IP Addr
-----
*Console      0 admin              0:00:01

Web Online Users:
Line      User Name          Idle Time (h:m:s) Remote IP Addr
-----
Console#

```

**show version** This command displays hardware and software version information for the system.

### Command Mode

Normal Exec, Privileged Exec

### Example

```

Console#show version
Serial Number      : EC2253000014
Hardware Version   : R01
Number of Ports    : 28
Main Power Status  : Up
Role               : Master
Loader Version     : 0.0.0.8
Linux Kernel Version : 4.14.76-19.0.0
Operation Code Version : 1.1.0.8

```

```
Console#
```

**Table 18: show version – display description**

Parameter	Description
Serial Number	The serial number of the switch.
Hardware Version	Hardware version of the main board.
Number of Ports	Number of built-in ports.
Main Power Status	Displays the status of the main power supply.
Role	Shows that this switch is operating as Master or Slave.
Loader Version	Version number of loader code.
Linux Kernel Version	Version number of Linux kernel.
Operation Code Version	Version number of runtime code.

**show watchdog** This command shows if watchdog debugging is enabled.

#### Command Mode

Privileged Exec

#### Example

```
Console#show watchdog
Software Watchdog Information
Status : Enabled
AutoReload : Enabled
Console#
```

**watchdog software** This command monitors key processes, and automatically reboots the system if any of these processes are not responding correctly.

#### Syntax

**watchdog software {disable | enable}**

#### Default Setting

Disabled

#### Command Mode

Privileged Exec

#### Example

```
Console#watchdog software disable
Console#
```

## Fan Control

This section describes the command used to force fan speed.

**Table 19: Fan Control Commands**

Command	Function	Mode
<code>fan-speed force-full</code>	Forces fans to full speed	GC
<code>show system</code>	Shows if full fan speed is enabled	NE, PE

**fan-speed force-full** This command sets all fans to full speed. Use the **no** form to reset the fans to normal operating speed.

### Syntax

**[no] fan-speed force-full**

### Default Setting

Normal speed

### Command Mode

Global Configuration

### Example

```
Console(config)#fan-speed force-full
Console(config)#
```

## Frame Size

This section describes commands used to configure the Ethernet frame size on the switch.

**Table 20: Frame Size Commands**

Command	Function	Mode
<code>jumbo frame</code>	Enables support for jumbo frames	GC

**jumbo frame** This command enables support for layer 2 jumbo frames for Gigabit and 10 Gigabit Ethernet ports. Use the **no** form to disable it.

### Syntax

**[no] jumbo frame**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ This switch provides more efficient throughput for large sequential data transfers by supporting layer 2 jumbo frames on Gigabit and 10 Gigabit Ethernet ports or trunks up to 10240 bytes. Compared to standard Ethernet frames that run only up to 1.5 KB, using jumbo frames significantly reduces the per-packet overhead required to process protocol encapsulation fields.
- ◆ To use jumbo frames, both the source and destination end nodes (such as a computer or server) must support this feature. Also, when the connection is operating at full duplex, all switches in the network between the two end nodes must be able to accept the extended frame size. And for half-duplex connections, all devices in the collision domain would need to support jumbo frames.
- ◆ The current setting for jumbo frames can be displayed with the [show system](#) command.

### Example

```
Console(config)#jumbo frame  
Console(config)#
```

### Related Commands

[show system \(129\)](#)

[show ipv6 mtu \(963\)](#)

---

## File Management

### Managing Firmware

Firmware can be uploaded and downloaded to or from an FTP/FTPS/SFTP/SCP/TFTP server. By saving runtime code to a file on an FTP/FTPS/SFTP/SCP/TFTP server, that file can later be downloaded to the switch to restore operation. The switch can also be set to use new firmware without overwriting the previous version.

When downloading runtime code, the destination file name can be specified to replace the current image, or the file can be first downloaded using a different name from the current runtime code file, and then the new file set as the startup file.

## Saving or Restoring Configuration Settings

Configuration settings can be uploaded and downloaded to and from an FTP/FTPS/SFTP/SCP/TFTP server. The configuration file can be later downloaded to restore switch settings.

The configuration file can be downloaded under a new file name and then set as the startup file, or the current startup configuration file can be specified as the destination file to directly replace it. Note that the file “Factory\_Default\_Config.cfg” can be copied to the FTP/FTPS/SFTP/SCP/TFTP server, but cannot be used as the destination on the switch.

**Table 21: Flash/File Commands**

Command	Function	Mode
<i>General Commands</i>		
<code>boot system</code>	Specifies the file or image used to start up the system	GC
<code>copy</code>	Copies a code image or a switch configuration to or from flash memory or an FTP/SFTP/SCP/TFTP server	PE
<code>delete</code>	Deletes a file or code image	PE
<code>dir</code>	Displays a list of files in flash memory	PE
<code>umount usbdisk</code>	Prepares the USB memory device to be safely removed	PE
<code>whichboot</code>	Displays the files booted	PE
<i>Automatic Code Upgrade Commands</i>		
<code>upgrade opcode auto</code>	Automatically upgrades the current image when a new version is detected on the indicated server	GC
<code>upgrade opcode path</code>	Specifies an FTP/SFTP/SCP/TFTP server and directory in which the new opcode is stored	GC
<code>upgrade opcode reload</code>	Reloads the switch automatically after the opcode upgrade is completed	GC
<code>show upgrade</code>	Shows the opcode upgrade configuration settings.	PE
<i>TFTP Configuration Commands</i>		
<code>ip tftp retry</code>	Specifies the number of times the switch can retry transmitting a request to a TFTP server	GC
<code>ip tftp timeout</code>	Specifies the time the switch can wait for a response from a TFTP server before retransmitting a request or timing out for the last retry	GC
<code>show ip tftp</code>	Displays information about TFTP settings	PE

## General Commands

**boot system** This command specifies the file or image used to start up the system.

### Syntax

**boot system** {**boot-rom** | **config** | **opcode**}: *filename*

**boot-rom**\* - Boot ROM.

**config**\* - Configuration file.

**opcode**\* - Run-time operation code.

*filename* - Name of configuration file or code image.

\* The colon (:) is required.

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ A colon (:) is required after the specified file type.
- ◆ If the file contains an error, it cannot be set as the default file.

### Example

```
Console(config)#boot system config: startup
Console(config)#
```

### Related Commands

[dir \(141\)](#)

[whichboot \(143\)](#)

**copy** This command moves (upload/download) a code image or configuration file between the switch's flash memory and an FTP/FTPS/SCP/SFTP/TFTP server. When you save the system code or configuration settings to a file on an FTP/FTPS/SCP/SFTP/TFTP server, that file can later be downloaded to the switch to restore system operation. The success of the file transfer depends on the accessibility of the FTP/FTPS/SCP/SFTP/TFTP server and the quality of the network connection.

### Syntax

**copy file {file | ftp | ftps | running-config | scp | sftp | startup-config | tftp | unit | usbdisk}**

**copy ftp {add-to-running-config | file | https-certificate | public-key | running-config | startup-config}**

**copy running-config {file | ftp | ftps | sftp | startup-config | tftp}**

**copy startup-config {file | ftp | ftps | running-config | sftp | tftp}**

**copy tftp {add-to-running-config | file | https-certificate | public-key | running-config | startup-config}**

**add-to-running-config** - Keyword that adds the settings listed in the specified file to the running configuration.

**file** - Keyword that allows you to copy to/from a file.

**ftp** - Keyword that allows you to copy to/from an FTP server.

**ftps** - Keyword that allows you to copy to/from an FTPS server.

**https-certificate** - Keyword that allows you to copy the HTTPS secure site certificate.

**public-key** - Keyword that allows you to copy a SSH key from a TFTP server. (See "Secure Shell" on page 274.)

**running-config** - Keyword that allows you to copy to/from the current running configuration.

**scp** - Keyword that copies a file to or from an SCP server.

**sftp** - Keyword that copies a file to or from an SFTP server.

**startup-config** - The configuration used for system initialization.

**tftp** - Keyword that allows you to copy to/from a TFTP server.

**unit** - Keyword that copies a file to/from a device unit.

**usbdisk** - Keyword that copies a file to/from a USB device.

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ The system prompts for data required to complete the copy command.
- ◆ The destination file name should not contain slashes (\ or /), and the maximum length for file names is 32 characters for files on the switch or 127 characters for files on the server. (Valid characters: A-Z, a-z, 0-9, "", "-")
- ◆ The switch supports only two operation code files, but the maximum number of user-defined configuration files is 16.
- ◆ You can use "Factory\_Default\_Config.cfg" as the source to copy from the factory default configuration file, but you cannot use it as the destination.
- ◆ To replace the startup configuration, you must use **startup-config** as the destination.
- ◆ The Boot ROM and Loader cannot be uploaded or downloaded from the FTP/FTPS/SCP/SFTP/TFTP server. You must follow the instructions in the release notes for new firmware, or contact your distributor for help.
- ◆ For information on specifying an https-certificate, see "Replacing the Default Secure-site Certificate" in the *Web Management Guide*. For information on configuring the switch to use HTTPS for a secure connection, see the [ip http secure-server](#) command.
- ◆ The reload command will not be accepted during copy operations to flash memory.
- ◆ When logging into an FTP server, the interface prompts for a user name and password configured on the remote server. Note that "anonymous" is set as the default user name.
- ◆ When logging into a remote SFTP/FTPS server, the interface prompts for a user name and password configured on the remote server. If this is a first time connection, the system checks to see if the public key offered by the server matches one stored locally. If not, the server's public key will be copied to the local system.
- ◆ Secure Shell FTP (SFTP) provides a method of transferring files between two network devices over an SSH2-secured connection. SFTP functions similar to Secure Copy (SCP), using SSH for user authentication and data encryption.  
  
Although the underlying premises of SFTP are similar to SCP, it requires some additional steps to verify the protocol versions and perform security checks. SFTP connection setup includes verification of the DSS signature, creation of session keys, creation of client-server and server-client ciphers, SSH key exchange, and user authentication. An SFTP channel is then opened, the SFTP protocol version compatibility verified, and SFTP finally initialized.
- ◆ The reload command will not be accepted during copy operations to flash memory.

### Example

The following example shows how to download new firmware from a TFTP server:

```
Console#copy tftp file
TFTP server ip address: 10.1.0.19
Choose file type:
  1. config:  2. opcode: 2
Source file name: m360.bix
Destination file name: m360.bix
\Write to FLASH Programming.
-Write to FLASH finish.
Success.
Console#
```

The following example shows how to upload the configuration settings to a file on the TFTP server:

```
Console#copy file tftp
Choose file type:
  1. config:  2. opcode: 1
Source file name: startup
TFTP server ip address: 10.1.0.99
Destination file name: startup.01
TFTP completed.
Success.

Console#
```

The following example shows how to copy the running configuration to a startup file.

```
Console#copy running-config file
destination file name: startup
Write to FLASH Programming.
\Write to FLASH finish.
Success.

Console#
```

The following example shows how to download a configuration file:

```
Console#copy tftp startup-config
TFTP server ip address: 10.1.0.99
Source configuration file name: startup.01
Startup configuration file name [startup]:
Write to FLASH Programming.

\Write to FLASH finish.
Success.

Console#
```

This example shows how to copy a secure-site certificate from an TFTP server. It then reboots the switch to activate the certificate:

```
Console#copy tftp https-certificate
TFTP server ip address: 10.1.0.19
Source certificate file name: SS-certificate
Source private file name: SS-private
Private password: *****

Success.
Console#reload
System will be restarted, continue <y/n>? y
```

This example shows how to copy a public-key used by SSH from an TFTP server. Note that public key authentication via SSH is only supported for users configured locally on the switch.

```
Console#copy tftp public-key
TFTP server IP address: 192.168.1.19
Source public-key file name: steve.pub
Username: steve
TFTP Download
Success.
Write to FLASH Programming.
Success.

Console#
```

This example shows how to copy a file to an FTP server.

```
Console#copy ftp file
FTP server IP address: 169.254.1.11
User[anonymous]: admin
Password[]: *****
Choose file type:
  1. config:  2. opcode: 2
Source file name: BLANC.BIX
Destination file name: BLANC.BIX
Console#
```

This example shows how to copy a file from an SFTP server. Note that the public key offered by the server is not found on the local system, but is saved locally after the user selects to continue the copy operation.

```
Console#copy sftp file
SFTP server IP address: 192.168.0.110
User [Anonymous]: admin
Password:
Choose file type:
  1. config; 2. opcode: 1
Source file name: startup2.cfg
Destination file name: startup2.cfg
```

```
Success.  
Console#
```

**delete** This command deletes a file or image.

### Syntax

**delete** {**file name** *filename* | **https-certificate** | **public-key** *username*}

**file** - Keyword that allows you to delete a file.

**name** - Keyword indicating a file.

*filename* - Name of configuration file or code image.

**https-certificate** - Keyword that allows you to delete the HTTPS secure site certificate. You must reboot the switch to load the default certificate.

**public-key** - Keyword that allows you to delete a SSH key on the switch. (See “Secure Shell” on page 274.)

*username* – Name of an SSH user. (Range: 1-8 characters)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ If the file type is used for system startup, then this file cannot be deleted.
- ◆ “Factory\_Default\_Config.cfg” cannot be deleted.

### Example

This example shows how to delete the test2.cfg configuration file from flash memory.

```
Console#delete file name test2.cfg  
Console#
```

### Related Commands

[dir \(141\)](#)

[delete public-key \(278\)](#)

**dir** This command displays a list of files in flash memory.

### Syntax

**dir** [*unit:*] {**boot-rom** | **config:** | **opcode:** | **usbdisk**} [*filename*]

*unit* - Unit identifier. (Range: 1)

**boot-rom** - Boot ROM (or diagnostic) image file.

**config** - Switch configuration file.

**opcode** - Run-time operation code image file.

**usbdisk** - Installed USB device file.

*filename* - Name of configuration file or code image. If this file exists but contains errors, information on this file cannot be shown.

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

If you enter the command **dir** without any parameters, the system displays all files.

File information is shown below:

**Table 22: File Directory Information**

Column Heading	Description
File Name	The name of the file.
Type	File types: Operation Code, and Config file.
Startup	Shows if this file is used when the system is started.
Modify Time	The date and time the file was last modified.
Size	The length of the file in bytes.

### Example

The following example shows how to display all file information:

```
Console#dir
File Name                               Type      Startup Modified Time          Size (bytes)
-----
Unit 1:
runtime.bix                             OpCode    Y      2023-02-07 14:40:05     51,893,948
Factory_Default_Config.cfg              Config    N      2023-01-17 01:09:16         455
startup1.cfg                             Config    Y      2023-02-17 07:39:01         1,673
-----
Free space for compressed user config files: 109,490,176
Total space:                               165,584,896
Console#
```

**umount usbdisk** This command prepares the USB memory device to be safely removed from the switch.

## Syntax

**umount usbdisk**

## Default Setting

None

## Command Mode

Privileged Exec

## Command Usage

Before disconnecting a USB memory device, you must unmount it first. This is similar to “Safely Remove Hardware” in Windows where the device will not unmount until all data transfers have been finished.

## Example

```
Console#umount usbdisk
You can safely remove your usbdisk.
Console#
```

**whichboot** This command displays which files were booted when the system powered up.

## Syntax

**whichboot**

## Default Setting

None

## Command Mode

Privileged Exec

## Example

This example shows the information displayed by the **whichboot** command. See the table under the **dir** command for a description of the file information displayed by this command.

```
Console#whichboot
File Name                               Type   Startup Modified Time      Size (bytes)
-----
Unit 1:
runtime.bix                             OpCode Y      2023-02-07 14:40:05  51,893,948
startup1.cfg                             Config Y      2023-02-17 07:39:01    1,673
Console#
```

## Automatic Code Upgrade Commands

**upgrade opcode auto** This command automatically upgrades the current operational code when a new version is detected on the server indicated by the [upgrade opcode path](#) command. Use the **no** form of this command to restore the default setting.

### Syntax

**[no] upgrade opcode auto**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ This command is used to enable or disable automatic upgrade of the operational code. When the switch starts up and automatic image upgrade is enabled by this command, the switch will follow these steps when it boots up:
  1. It will search for a new version of the image at the location specified by [upgrade opcode path](#) command. The name for the new image stored on the TFTP server must be ECS4650.bix. If the switch detects a code version newer than the one currently in use, it will download the new image. If two code images are already stored in the switch, the image not set to start up the system will be overwritten by the new version.
  2. After the image has been downloaded, the switch will send a trap message to log whether or not the upgrade operation was successful.
  3. It sets the new version as the startup image.
  4. It then restarts the system to start using the new image.
- ◆ Any changes made to the default setting can be displayed with the [show running-config](#) or [show startup-config](#) commands.

### Example

```
Console(config)#upgrade opcode auto
Console(config)#upgrade opcode path tftp://192.168.0.1/sm24/
Console(config)#
```

If a new image is found at the specified location, the following type of messages will be displayed during bootstrap.

```

:
Automatic Upgrade is looking for a new image
New image detected: current version 1.1.0.8; new version 1.1.0.9
Image upgrade in progress
The switch will restart after upgrade succeeds
Downloading new image
Flash programming started
Flash programming completed
The switch will now restart
:

```

**upgrade opcode path** This command specifies an TFTP server and directory in which the new opcode is stored. Use the **no** form of this command to clear the current setting.

### Syntax

**upgrade opcode path** *opcode-dir-url*

**no upgrade opcode path**

*opcode-dir-url* - The location of the new code.

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ This command is used in conjunction with the [upgrade opcode auto](#) command to facilitate automatic upgrade of new operational code stored at the location indicated by this command.
- ◆ The name for the new image stored on the TFTP server must be ECS4650.bix. However, note that file name is not to be included in this command.
- ◆ When specifying a TFTP server, the following syntax must be used, where *filedir* indicates the path to the directory containing the new image:

```
tftp://192.168.0.1[/filedir]/
```

- ◆ When specifying an FTP server, the following syntax must be used, where *filedir* indicates the path to the directory containing the new image:

```
ftp://[username[:password@]]192.168.0.1[/filedir]/
```

If the user name is omitted, "anonymous" will be used for the connection. If the password is omitted a null string ("") will be used for the connection.

### Example

This shows how to specify a TFTP server where new code is stored.

```
Console(config)#upgrade opcode path tftp://192.168.0.1/sm24/  
Console(config)#
```

This shows how to specify an FTP server where new code is stored.

```
Console(config)#upgrade opcode path ftp://admin:billy@192.168.0.1/sm24/  
Console(config)#
```

**upgrade opcode reload** This command reloads the switch automatically after the opcode upgrade is completed. Use the **no** form to disable this feature.

### Syntax

**[no] upgrade opcode reload**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Example

This shows how to specify a TFTP server where new code is stored.

```
Console(config)#upgrade opcode reload  
Console(config)#
```

**show upgrade** This command shows the opcode upgrade configuration settings.

### Command Mode

Privileged Exec

### Example

```
Console#show upgrade  
Auto Image Upgrade Global Settings:  
  Status      : Disabled  
  Reload Status : Disabled  
  Path        :  
  File Name   : ECS4650.bix  
Console#
```

## TFTP Configuration Commands

**ip tftp retry** This command specifies the number of times the switch can retry transmitting a request to a TFTP server after waiting for the configured timeout period and receiving no response. Use the **no** form to restore the default setting.

### Syntax

**ip tftp retry** *retries*

**no ip tftp retry**

*retries* - The number of times the switch can resend a request to a TFTP server before it aborts the connection. (Range: 1-16)

### Default Setting

15

### Command Mode

Global Configuration

### Example

```
Console(config)#ip tftp retry 10
Console(config)#
```

**ip tftp timeout** This command specifies the time the switch can wait for a response from a TFTP server before retransmitting a request or timing out for the last retry. Use the **no** form to restore the default setting.

### Syntax

**ip tftp timeout** *seconds*

**no ip tftp timeout**

*seconds* - The the time the switch can wait for a response from a TFTP server before retransmitting a request or timing out. (Range: 1-65535 seconds)

### Default Setting

5 seconds

### Command Mode

Global Configuration

### Example

```
Console(config)#ip tftp timeout 10
Console(config)#
```

**show ip tftp** This command displays information about the TFTP settings configured on this switch.

### Syntax

**show ip tftp**

### Command Mode

Privileged Exec

### Example

```
Console#show ip tftp
TFTP Settings:
  Retries : 15
  Timeout : 5 seconds
Console#
```

## Line

You can access the onboard configuration program by attaching a VT100 compatible device to the server's serial port. These commands are used to set communication parameters for the serial port or Telnet (i.e., a virtual terminal).

**Table 23: Line Commands**

Command	Function	Mode
<a href="#">line</a>	Identifies a specific line for configuration and starts the line configuration mode	GC
<a href="#">accounting commands</a>	Applies an accounting method to commands entered at specific CLI privilege levels	LC
<a href="#">accounting exec</a>	Applies an accounting method to local console, Telnet or SSH connections	LC
<a href="#">authorization commands</a>	Applies an authorization method to commands entered at specific CLI privilege levels	LC
<a href="#">authorization exec</a>	Applies an authorization method to local console, Telnet or SSH connections	LC
<a href="#">databits*</a>	Sets the number of data bits per character that are interpreted and generated by hardware	LC
<a href="#">exec-timeout</a>	Sets the interval that the command interpreter waits until user input is detected	LC
<a href="#">login</a>	Enables password checking at login	LC
<a href="#">parity*</a>	Defines the generation of a parity bit	LC
<a href="#">password</a>	Specifies a password on a line	LC
<a href="#">password-thresh</a>	Sets the password intrusion threshold, which limits the number of failed logon attempts	LC

**Table 23: Line Commands** (Continued)

Command	Function	Mode
<a href="#">silent-time*</a>	Sets the amount of time the management console is inaccessible after the number of unsuccessful logon attempts exceeds the threshold set by the <a href="#">password-thresh</a> command	LC
<a href="#">speed*</a>	Sets the terminal baud rate	LC
<a href="#">stopbits*</a>	Sets the number of the stop bits transmitted per byte	LC
<a href="#">timeout login response</a>	Sets the interval that the system waits for a login attempt	LC
<a href="#">disconnect</a>	Terminates a line connection	PE
<a href="#">terminal</a>	Configures terminal settings, including escape-character, line length, terminal type, and width	PE
<a href="#">show line</a>	Displays a terminal line's parameters	NE, PE

\* These commands only apply to the serial port.

**line** This command identifies a specific line for configuration, and to process subsequent line configuration commands.

### Syntax

**line** {**console** | **vty**}

**console** - Console terminal line.

**vty** - Virtual terminal for remote console access (i.e., Telnet).

### Default Setting

There is no default line.

### Command Mode

Global Configuration

### Command Usage

Telnet is considered a virtual terminal connection and will be shown as “VTY” in screen displays such as [show users](#). However, the serial communication parameters (e.g., databits) do not affect Telnet connections.

### Example

To enter console line mode, enter the following command:

```
Console(config)#line console
Console(config-line)#
```

### Related Commands

[show line \(158\)](#)

[show users \(131\)](#)

**databits** This command sets the number of data bits per character that are interpreted and generated by the console port. Use the **no** form to restore the default value.

#### Syntax

**databits** {**7** | **8**}

**no databits**

**7** - Seven data bits per character.

**8** - Eight data bits per character.

#### Default Setting

8 data bits per character

#### Command Mode

Line Configuration

#### Command Usage

The **databits** command can be used to mask the high bit on input from devices that generate 7 data bits with parity. If parity is being generated, specify 7 data bits per character. If no parity is required, specify 8 data bits per character.

#### Example

To specify 7 data bits, enter this command:

```
Console(config-line-console)#databits 7
Console(config-line-console)#
```

#### Related Commands

[parity \(152\)](#)

**exec-timeout** This command sets the interval that the system waits until user input is detected. Use the **no** form to restore the default.

#### Syntax

**exec-timeout** [*seconds*]

**no exec-timeout**

*seconds* - Integer that specifies the timeout interval.

(Range: 60 - 65535 seconds; 0: no timeout)

#### Default Setting

10 minutes

#### Command Mode

Line Configuration

### Command Usage

- ◆ If user input is detected within the timeout interval, the session is kept open; otherwise the session is terminated.
- ◆ This command applies to both the local console and Telnet connections.
- ◆ The timeout for Telnet cannot be disabled.
- ◆ Using the command without specifying a timeout restores the default setting.

### Example

To set the timeout to two minutes, enter this command:

```
Console(config-line-console)#exec-timeout 120
Console(config-line-console)#
```

**login** This command enables password checking at login. Use the **no** form to disable password checking and allow connections without a password.

### Syntax

**login [local]**

**no login**

**local** - Selects local password checking. Authentication is based on the user name specified with the [username](#) command.

### Default Setting

login local

### Command Mode

Line Configuration

### Command Usage

- ◆ There are three authentication modes provided by the switch itself at login:
  - **login** selects authentication by a single global password as specified by the [password](#) line configuration command. When using this method, the management interface starts in Normal Exec (NE) mode.
  - **login local** selects authentication via the user name and password specified by the [username](#) command (i.e., default setting). When using this method, the management interface starts in Normal Exec (NE) or Privileged Exec (PE) mode, depending on the user's privilege level (0 or 15 respectively).
  - **no login** selects no authentication. When using this method, the management interface starts in Normal Exec (NE) mode.

- ◆ This command controls login authentication via the switch itself. To configure user names and passwords for remote authentication servers, you must use the RADIUS or TACACS software installed on those servers.

#### Example

```
Console(config-line-console)#login local
Console(config-line-console)#
```

#### Related Commands

[username \(241\)](#)

[password \(153\)](#)

**parity** This command defines the generation of a parity bit. Use the **no** form to restore the default setting.

#### Syntax

**parity** {**none** | **even** | **odd**}

**no parity**

**none** - No parity

**even** - Even parity

**odd** - Odd parity

#### Default Setting

No parity

#### Command Mode

Line Configuration

#### Command Usage

Communication protocols provided by devices such as terminals and modems often require a specific parity bit setting.

#### Example

To specify no parity, enter this command:

```
Console(config-line-console)#parity none
Console(config-line-console)#
```

**password** This command specifies the password for a line. Use the **no** form to remove the password.

### Syntax

**password** {0 | 7} *password*

**no password**

{0 | 7} - 0 means plain password, 7 means encrypted password

*password* - Character string that specifies the line password.

(Maximum length: 32 characters plain text or encrypted, case sensitive)

### Default Setting

No password is specified.

### Command Mode

Line Configuration

### Command Usage

- ◆ When a connection is started on a line with password protection, the system prompts for the password. If you enter the correct password, the system shows a prompt. You can use the [password-thresh](#) command to set the number of times a user can enter an incorrect password before the system terminates the line connection and returns the terminal to the idle state.
- ◆ The encrypted password is required for compatibility with legacy password settings (i.e., plain text or encrypted) when reading the configuration file from an FTP/SFTP server during system bootup. There is no need for you to manually configure encrypted passwords.

### Example

```
Console(config-line-console)#password 0 secret
Console(config-line-console)#
```

### Related Commands

[login \(151\)](#)

[password-thresh \(153\)](#)

**password-thresh** This command sets the password intrusion threshold which limits the number of failed logon attempts. Use the **no** form to remove the threshold value.

### Syntax

**password-thresh** [*threshold*]

**no password-thresh**

*threshold* - The number of allowed password attempts. (Range: 1-120; 0: no threshold)

#### Default Setting

The default value is three attempts.

#### Command Mode

Line Configuration

#### Command Usage

When the logon attempt threshold is reached, the system interface becomes silent for a specified amount of time before allowing the next logon attempt. (Use the [silent-time](#) command to set this interval.) When this threshold is reached for Telnet, the Telnet logon interface shuts down.

#### Example

To set the password threshold to five attempts, enter this command:

```
Console(config-line-console)#password-thresh 5
Console(config-line-console)#
```

#### Related Commands

[silent-time \(154\)](#)

**silent-time** This command sets the amount of time the management console is inaccessible after the number of unsuccessful logon attempts exceeds the threshold set by the [password-thresh](#) command. Use the **no** form to remove the silent time value.

#### Syntax

**silent-time** [*seconds*]

**no silent-time**

*seconds* - The number of seconds to disable console response.  
(Range: 1-65535; 0 means disabled)

#### Default Setting

Disabled

#### Command Mode

Line Configuration

#### Example

To set the silent time to 60 seconds, enter this command:

```
Console(config-line-console)#silent-time 60
Console(config-line-console)#
```

## Related Commands

[password-thresh \(153\)](#)

**speed** This command sets the terminal line's baud rate. This command sets both the transmit (to terminal) and receive (from terminal) speeds. Use the **no** form to restore the default setting.

### Syntax

**speed** *bps*

**no speed**

*bps* - Baud rate in bits per second.

(Options: 9600, 19200, 38400, 57600, 115200 bps)

### Default Setting

115200 bps

### Command Mode

Line Configuration

### Command Usage

Set the speed to match the baud rate of the device connected to the serial port. Some baud rates available on devices connected to the port might not be supported. The system indicates if the speed you selected is not supported.

### Example

To specify 57600 bps, enter this command:

```
Console(config-line-console)#speed 57600
Console(config-line-console)#
```

**stopbits** This command sets the number of the stop bits transmitted per byte. Use the **no** form to restore the default setting.

### Syntax

**stopbits** {1 | 2}

**no stopbits**

1 - One stop bit

2 - Two stop bits

### Default Setting

1 stop bit

**Command Mode**  
Line Configuration

**Example**

To specify 2 stop bits, enter this command:

```
Console(config-line-console)#stopbits 2
Console(config-line-console)#
```

**timeout login response** This command sets the interval that the system waits for a user to log into the CLI. Use the **no** form to restore the default setting.

**Syntax**

**timeout login response** [*seconds*]

**no timeout login response**

*seconds* - Integer that specifies the timeout interval.  
(Range: 10 - 300 seconds)

**Default Setting**

300 seconds

**Command Mode**  
Line Configuration

**Command Usage**

- ◆ If a login attempt is not detected within the timeout interval, the connection is terminated for the session.
- ◆ This command applies to both the local console and Telnet connections.
- ◆ The timeout for Telnet cannot be disabled.
- ◆ Using the command without specifying a timeout restores the default setting.

**Example**

To set the timeout to two minutes, enter this command:

```
Console(config-line)#timeout login response 120
Console(config-line)#
```

**disconnect** This command terminates an SSH, Telnet, or console connection.

### Syntax

**disconnect** *session-id*

*session-id* – The session identifier for an SSH, Telnet or console connection.  
(Range: 0-8)

### Command Mode

Privileged Exec

### Command Usage

Specifying session identifier “0” will disconnect the console connection. Specifying any other identifiers for an active session will disconnect an SSH or Telnet connection.

### Example

```
Console#disconnect 1
Console#
```

### Related Commands

[show ssh \(281\)](#)

[show users \(131\)](#)

**terminal** This command configures terminal settings, including escape-character, lines displayed, terminal type, width, and command history. Use the **no** form with the appropriate keyword to restore the default setting.

### Syntax

**terminal** {**escape-character** {**ASCII-number** | *character*} | **history** [**size** *size*] | **length** *length* | **terminal-type** {**ansi-bbs** | **vt-100** | **vt-102**} | **width** *width*}

**escape-character** - The keyboard character used to escape from current line input.

**ASCII-number** - ASCII decimal equivalent. (Range: 0-255)

*character* - Any valid keyboard character.

**history** - The number of lines stored in the command buffer, and recalled using the arrow keys. (Range: 0-256)

**length** - The number of lines displayed on the screen. (Range: 24-200, where 0 means not to pause)

**terminal-type** - The type of terminal emulation used.

**ansi-bbs** - ANSI-BBS

**vt-100** - VT-100

**vt-102** - VT-102

**width** - The number of character columns displayed on the terminal.  
(Range: 80-300)

#### Default Setting

Escape Character: 27 (ASCII-number)

History: 10

Length: 24

Terminal Type: VT100

Width: 80

#### Command Mode

Privileged Exec

#### Example

This example sets the number of lines displayed by commands with lengthy output such as `show running-config` to 48 lines.

```
Console#terminal length 48
Console#
```

**show line** This command displays the terminal line's parameters.

#### Syntax

**show line** [**console** | **vty**]

**console** - Console terminal line.

**vty** - Virtual terminal for remote console access (i.e., Telnet).

#### Default Setting

Shows all lines

#### Command Mode

Normal Exec, Privileged Exec

#### Example

To show all lines, enter this command:

```
Console#show line
Terminal Configuration for this session:
Length                : 24
Width                 : 80
History Size          : 10
Escape Character(ASCII-number) : 27
Terminal Type         : VT100

Console Configuration:
Password Threshold   : 3 times
EXEC Timeout         : 600 seconds
Login Timeout        : 300 seconds
```

```
Silent Time       : Disabled
Baud Rate        : 115200
Data Bits       : 8
Parity          : None
Stop Bits       : 1

VTY Configuration:
Password Threshold : 3 times
EXEC Timeout      : 600 seconds
Login Timeout     : 300 sec.
Silent Time       : Disabled
Console#
```

## Event Logging

This section describes commands used to configure event logging on the switch.

**Table 24: Event Logging Commands**

Command	Function	Mode
<a href="#">logging command</a>	Stores CLI command execution records in syslog RAM and flash	GC
<a href="#">logging facility</a>	Sets the facility type for remote logging of syslog messages	GC
<a href="#">logging history</a>	Limits syslog messages saved to switch memory based on severity	GC
<a href="#">logging host</a>	Adds a syslog server host IP address that will receive logging messages	GC
<a href="#">logging level</a>	Sets the logging level for user login and log out	GC
<a href="#">logging on</a>	Controls logging of error messages	GC
<a href="#">logging trap</a>	Limits syslog messages saved to a remote server based on severity	GC
<a href="#">clear log</a>	Clears messages from the logging buffer	PE
<a href="#">show log</a>	Displays log messages	PE
<a href="#">show logging</a>	Displays the state of logging	PE

**logging command** This command stores CLI command execution records in syslog RAM and flash. Use the **no** form to disable this feature.

### Syntax

**[no] logging command**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

The records stored include the commands executed from the CLI, command execution time and information about the CLI user including user name, user interface (console, Telnet, SSH) and user IP address. The severity level for this record type is 6 (see the [logging facility](#) command).

### Example

```
Console(config)#logging facility 19  
Console(config)#
```

**logging facility** This command sets the facility type for remote logging of syslog messages. Use the **no** form to return the type to the default.

### Syntax

**logging facility** *type*

**no logging facility**

*type* - A number that indicates the facility used by the syslog server to dispatch log messages to an appropriate service. (Range: 16-23)

### Default Setting

23

### Command Mode

Global Configuration

### Command Usage

The command specifies the facility type tag sent in syslog messages. (See RFC 3164.) This type has no effect on the kind of messages reported by the switch. However, it may be used by the syslog server to sort messages or to store messages in the corresponding database.

### Example

```
Console(config)#logging facility 19  
Console(config)#
```

**logging history** This command limits syslog messages saved to switch memory based on severity. The **no** form returns the logging of syslog messages to the default level.

### Syntax

**logging history** {**flash** | **ram**} *level*

**no logging history** {**flash** | **ram**}

**flash** - Event history stored in flash memory (i.e., permanent memory).

**ram** - Event history stored in temporary RAM (i.e., memory flushed on power reset).

*level* - One of the levels listed below. Messages sent include the selected level down to level 0. (Range: 0-7)

**Table 25: Logging Levels**

Level	Severity Name	Description
7	debugging	Debugging messages
6	informational	Informational messages only
5	notifications	Normal but significant condition, such as cold start
4	warnings	Warning conditions (e.g., return false, unexpected return)
3	errors	Error conditions (e.g., invalid input, default used)
2	critical	Critical conditions (e.g., memory allocation, or free memory error - resource exhausted)
1	alerts	Immediate action needed
0	emergencies	System unusable

#### Default Setting

Flash: errors (level 3 - 0)

RAM: debugging (level 7 - 0)

#### Command Mode

Global Configuration

#### Command Usage

The message level specified for flash memory must be a higher priority (i.e., numerically lower) than that specified for RAM.

#### Example

```
Console(config)#logging history ram 0
Console(config)#
```

**logging host** This command adds a syslog server host IP address that will receive logging messages. Use the **no** form to remove a syslog server host.

#### Syntax

**logging host** *host-ip-address* [**port** *udp-port*]

**no logging host** *host-ip-address*

*host-ip-address* - The IPv4 or IPv6 address of a syslog server.

*udp-port* - UDP port number used by the remote server. (Range: 1-65535)

### Default Setting

UPD Port: 514

### Command Mode

Global Configuration

### Command Usage

- ◆ Use this command more than once to build up a list of host IP addresses.
- ◆ The maximum number of host IP addresses allowed is five.

### Example

```
Console(config)#logging host 10.1.0.3  
Console(config)#
```

**logging level** This command sets the syslog logging severity level for user login and log out. Use the **no** form to set the logging level to the default value.

### Syntax

**logging level** {**user-login** *level* | **user-logout** *level*}

**no logging level** {**user-login** | **user-logout**}

**user-login** - Specifies the level to log when a user logs in.

**user-logout** - Specifies the level to log when a user logs out.

*level* - The syslog severity level to log (Range: 1-7)

### Default Setting

6

### Command Mode

Global Configuration

### Command Usage

Logging severity levels are described in [Table 25](#).

### Example

```
Console(config)#logging level user-login 5  
Console(config)#
```

**logging on** This command controls logging of error messages, sending debug or error messages to a logging process. The **no** form disables the logging process.

#### Syntax

**[no] logging on**

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

The logging process controls error messages saved to switch memory or sent to remote syslog servers. You can use the [logging history](#) command to control the type of error messages that are stored in memory. You can use the [logging trap](#) command to control the type of error messages that are sent to specified syslog servers.

#### Example

```
Console(config)#logging on  
Console(config)#
```

#### Related Commands

[logging history \(160\)](#)

[logging trap \(163\)](#)

[clear log \(164\)](#)

**logging trap** This command enables the logging of system messages to a remote server, or limits the syslog messages saved to a remote server based on severity. Use this command without a specified level to enable remote logging. Use the **no** form to disable remote logging.

#### Syntax

**logging trap [level *level*]**

**no logging trap [level]**

*level* - One of the syslog severity levels listed in the table on [page 160](#). Messages sent include the selected level through level 0.

#### Default Setting

Disabled

Level 7

#### Command Mode

Global Configuration

### Command Usage

- ◆ Using this command with a specified level enables remote logging and sets the minimum severity level to be saved.
- ◆ Using this command without a specified level also enables remote logging, but restores the minimum severity level to the default.

### Example

```
Console(config)#logging trap level 4  
Console(config)#
```

**clear log** This command clears messages from the log buffer.

### Syntax

**clear log** [**flash** | **ram**]

**flash** - Event history stored in flash memory (i.e., permanent memory).

**ram** - Event history stored in temporary RAM (i.e., memory flushed on power reset).

### Default Setting

Flash and RAM

### Command Mode

Privileged Exec

### Example

```
Console#clear log  
Console#
```

### Related Commands

[show log \(164\)](#)

**show log** This command displays the log messages stored in local memory.

### Syntax

**show log** {**flash** | **ram**} [*word* | **login**]

**flash** - Event history stored in flash memory (i.e., permanent memory).

**ram** - Event history stored in temporary RAM (i.e., memory flushed on power reset).

*word* - Specifies query function information

**login** - Shows the contents of login buffers

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ All log messages are retained in RAM and Flash after a warm restart (i.e., power is reset through the command interface).
- ◆ All log messages are retained in Flash and purged from RAM after a cold restart (i.e., power is turned off and then on through the power source).

### Example

The following example shows the event message stored in RAM.

```
Console#show log ram
[1] 00:01:30 2001-01-01
    "VLAN 1 link-up notification."
    level: 6, module: 5, function: 1, and event no.: 1
[0] 00:01:30 2001-01-01
    "Unit 1, Port 1 link-up notification."
    level: 6, module: 5, function: 1, and event no.: 1
Console#
```

**show logging** This command displays the configuration settings for logging messages to local switch memory, to an SMTP event handler, or to a remote syslog server.

### Syntax

**show logging** {**level** | **flash** | **ram** | **sendmail** | **trap**}

**level** - Displays logging levels for user login and log out.

**flash** - Displays settings for storing event messages in flash memory (i.e., permanent memory).

**ram** - Displays settings for storing event messages in temporary RAM (i.e., memory flushed on power reset).

**sendmail** - Displays settings for the SMTP event handler ([page 170](#)).

**trap** - Displays settings for the trap function.

### Default Setting

None

### Command Mode

Privileged Exec

### Example

The following example shows that system logging is enabled, the message level for flash memory is “errors” (i.e., default level 3 - 0), and the message level for RAM is “debugging” (i.e., default level 7 - 0).

```
Console#show logging flash
Global Configuration:
  Syslog Logging      : Enabled
Flash Logging Configuration:
  History Logging in Flash : Level Errors (3)
Console#show logging ram
Global Configuration:
  Syslog Logging      : Enabled
Ram Logging Configuration:
  History Logging in RAM  : Level Debugging (7)
Console#
```

**Table 26: show logging flash/ram - display description**

Field	Description
Syslog Logging	Shows if system logging has been enabled via the <a href="#">logging on</a> command.
History Logging in Flash	The message level(s) reported based on the <a href="#">logging history</a> command.
History Logging in RAM	The message level(s) reported based on the <a href="#">logging history</a> command.

The following example displays settings for the trap function.

```
Console#show logging trap
Global Configuration:
  Syslog Logging      : Enabled
Remote Logging Configuration:
  Status              : Disabled
  Facility Type       : Local use 7 (23)
```

```
Level Type           : Debugging messages (7)
Console#
```

**Table 27: show logging trap - display description**

Field	Description
<i>Global Configuration</i>	
Syslog logging	Shows if system logging has been enabled via the <a href="#">logging on</a> command.
<i>Remote Logging Configuration</i>	
Status	Shows if remote logging has been enabled via the <a href="#">logging trap</a> command.
Facility Type	The facility type for remote logging of syslog messages as specified in the <a href="#">logging facility</a> command.
Level Type	The severity threshold for syslog messages sent to a remote server as specified in the <a href="#">logging trap</a> command.

### Related Commands

[show logging sendmail \(170\)](#)

## SMTP Alerts

These commands configure SMTP event handling, and forwarding of alert messages to the specified SMTP servers and email recipients.

**Table 28: Event Logging Commands**

Command	Function	Mode
<a href="#">logging sendmail</a>	Enables SMTP event handling	GC
<a href="#">logging sendmail destination-email</a>	Email recipients of alert messages	GC
<a href="#">logging sendmail host</a>	SMTP servers to receive alert messages	GC
<a href="#">logging sendmail level</a>	Severity threshold used to trigger alert messages	GC
<a href="#">logging sendmail source-email</a>	Email address used for "From" field of alert messages	GC
<a href="#">show logging sendmail</a>	Displays SMTP event handler settings	PE

**logging sendmail** This command enables SMTP event handling. Use the **no** form to disable this function.

### Syntax

**[no] logging sendmail**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Example

```
Console(config)#logging sendmail  
Console(config)#
```

**logging sendmail destination-email** This command specifies the email recipients of alert messages. Use the **no** form to remove a recipient.

### Syntax

**[no] logging sendmail destination-email** *email-address*

*email-address* - The source email address used in alert messages.  
(Range: 1-41 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

You can specify up to five recipients for alert messages. However, you must enter a separate command to specify each recipient.

### Example

```
Console(config)#logging sendmail destination-email ted@this-company.com  
Console(config)#
```

**logging sendmail host** This command specifies SMTP servers that will be sent alert messages. Use the **no** form to remove an SMTP server.

### Syntax

**[no] logging sendmail host** *ip-address*

*ip-address* - IPv4 address of an SMTP server that will be sent alert messages for event handling.

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ You can specify up to three SMTP servers for event handling. However, you must enter a separate command to specify each server.
- ◆ To send email alerts, the switch first opens a connection, sends all the email alerts waiting in the queue one by one, and finally closes the connection.
- ◆ To open a connection, the switch first selects the server that successfully sent mail during the last connection, or the first server configured by this command. If it fails to send mail, the switch selects the next server in the list and tries to send mail again. If it still fails, the system will repeat the process at a periodic interval. (A trap will be triggered if the switch cannot successfully open a connection.)

### Example

```
Console(config)#logging sendmail host 192.168.1.19  
Console(config)#
```

**logging sendmail level** This command sets the severity threshold used to trigger alert messages. Use the **no** form to restore the default setting.

### Syntax

**logging sendmail level** *level*

**no logging sendmail level**

*level* - One of the system message levels ([page 160](#)). Messages sent include the selected level down to level 0. (Range: 0-7; Default: 7)

### Default Setting

Level 7

### Command Mode

Global Configuration

### Command Usage

The specified level indicates an event threshold. All events at this level or higher will be sent to the configured email recipients. (For example, using Level 7 will report all events from level 7 to level 0.)

### Example

This example will send email alerts for system errors from level 3 through 0.

```
Console(config)#logging sendmail level 3  
Console(config)#
```

### logging sendmail source-email

This command sets the email address used for the “From” field in alert messages. Use the **no** form to restore the default value.

### Syntax

**logging sendmail source-email** *email-address*

**no logging sendmail source-email**

*email-address* - The source email address used in alert messages.  
(Range: 1-41 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

You may use an symbolic email address that identifies the switch, or the address of an administrator responsible for the switch.

### Example

```
Console(config)#logging sendmail source-email bill@this-company.com  
Console(config)#
```

### show logging sendmail

This command displays the settings for the SMTP event handler.

### Command Mode

Privileged Exec

### Example

```
Console#show logging sendmail  
SMTP Servers  
-----  
192.168.1.19  
  
SMTP Minimum Severity Level: 7  
  
SMTP Destination E-mail Addresses  
-----  
ted@this-company.com
```

```
SMTP Source E-mail Address: bill@this-company.com

SMTP Status: Enabled
Console#
```

## Time

The system clock can be dynamically set by polling a set of specified time servers (NTP or SNTP). Maintaining an accurate time on the switch enables the system log to record meaningful dates and times for event entries. If the clock is not set, the switch will only record the time from the factory default set at the last bootup.

**Table 29: Time Commands**

Command	Function	Mode
<i>SNTP Commands</i>		
<a href="#">sntp client</a>	Accepts time from specified time servers	GC
<a href="#">sntp poll</a>	Sets the interval at which the client polls for time	GC
<a href="#">sntp server</a>	Specifies one or more time servers	GC
<a href="#">show sntp</a>	Shows current SNTP configuration settings	PE
<i>NTP Commands</i>		
<a href="#">ntp authenticate</a>	Enables authentication for NTP traffic	GC
<a href="#">ntp authentication-key</a>	Configures authentication keys	GC
<a href="#">ntp client</a>	Enables the NTP client for time updates from specified servers	GC
<a href="#">ntp server</a>	Specifies NTP servers to poll for time updates	GC
<a href="#">show ntp</a>	Shows current NTP configuration settings	PE
<a href="#">show ntp status</a>	Shows the status of time updates	PE
<a href="#">show ntp statistics peer</a>	Shows statistics from an NTP peer	PE
<a href="#">show ntp peer-status</a>	Shows the status of connections to NTP peers	PE
<i>Manual Configuration Commands</i>		
<a href="#">clock summer-time (date)</a>	Configures summer time* for the switch's internal clock	GC
<a href="#">clock summer-time (predefined)</a>	Configures summer time* for the switch's internal clock	GC
<a href="#">clock summer-time (recurring)</a>	Configures summer time* for the switch's internal clock	GC
<a href="#">clock timezone</a>	Sets the time zone for the switch's internal clock	GC
<a href="#">clock timezone-predefined</a>	Sets the time zone for the switch's internal clock from a list of predefined time zones	GC
<a href="#">calendar set</a>	Sets the system date and time	PE
<a href="#">show calendar</a>	Displays the current date and time setting	NE, PE

\* Daylight savings time.

## SNTP Commands

**sntp client** This command enables SNTP client requests for time synchronization from NTP or SNTP time servers specified with the [sntp server](#) command. Use the **no** form to disable SNTP client requests.

### Syntax

**[no] sntp client**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ The time acquired from time servers is used to record accurate dates and times for log events. Without SNTP, the switch only records the time starting from the factory default set at the last bootup (e.g., Dec 31 07:32:04 2014).
- ◆ This command enables client time requests to time servers specified via the [sntp server](#) command. It issues time synchronization requests based on the interval set via the [sntp poll](#) command.

### Example

```
Console(config)#sntp server 10.1.0.19
Console(config)#sntp poll 60
Console(config)#sntp client
Console(config)#end
Console#show sntp
Current Time: Dec 23 02:52:44 2015
Poll Interval: 60
Current Mode: Unicast
SNTP Status : Enabled
SNTP Server 137.92.140.80
Current Server: 137.92.140.80
Console#
```

### Related Commands

[sntp server \(173\)](#)

[sntp poll \(173\)](#)

[show sntp \(174\)](#)

**sntp poll** This command sets the interval between sending time requests when the switch is set to SNTP client mode. Use the **no** form to restore to the default.

#### Syntax

**sntp poll** *seconds*

**no sntp poll**

*seconds* - Interval between time requests. (Range: 16-16384 seconds)

#### Default Setting

16 seconds

#### Command Mode

Global Configuration

#### Example

```
Console(config)#sntp poll 60
Console#
```

#### Related Commands

[sntp client \(172\)](#)

**sntp server** This command sets the IP address of the servers to which SNTP time requests are issued. Use the this command with no arguments to clear all time servers from the current list. Use the **no** form to clear all time servers from the current list, or to clear a specific server.

#### Syntax

**sntp server** [*ip1* [*ip2* [*ip3*]]]

**no sntp server** [*ip1* [*ip2* [*ip3*]]]

*ip* - IPv4 or IPv6 address of a time server (NTP or SNTP).  
(Range: 1 - 3 addresses)

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

This command specifies time servers from which the switch will poll for time updates when set to SNTP client mode. The client will poll the time servers in the order specified until a response is received. It issues time synchronization requests based on the interval set via the [sntp poll](#) command.

#### Example

```
Console(config)#ntp server 10.1.0.19
Console#
```

#### Related Commands

[ntp client \(172\)](#)

[ntp poll \(173\)](#)

[show ntp \(174\)](#)

**show ntp** This command displays the current time and configuration settings for the SNTP client, and indicates whether or not the local time has been properly updated.

#### Command Mode

Normal Exec, Privileged Exec

#### Command Usage

This command displays the current time, the poll interval used for sending time synchronization requests, and the current SNTP mode (i.e., unicast).

#### Example

```
Console#show ntp
Current Time   : Nov  5 18:51:22 2015
Poll Interval  : 16 seconds
Current Mode   : Unicast
SNTP Status    : Enabled
SNTP Server    : 137.92.140.80
                : 137.92.140.90
                : 137.92.140.99
Current Server : 137.92.140.80
Console#
```

## NTP Commands

**ntp authenticate** This command enables authentication for NTP client-server communications. Use the **no** form to disable authentication.

#### Syntax

```
[no] ntp authenticate
```

#### Default Setting

Disabled

#### Command Mode

Global Configuration

### Command Usage

You can enable NTP authentication to ensure that reliable updates are received from only authorized NTP servers. The authentication keys and their associated key number must be centrally managed and manually distributed to NTP servers and clients. The key numbers and key values must match on both the server and client.

### Example

```
Console(config)#ntp authenticate
Console(config)#
```

### Related Commands

[ntp authentication-key \(175\)](#)

**ntp authentication-key** This command configures authentication keys and key numbers to use when NTP authentication is enabled. Use the **no** form of the command to clear a specific authentication key or all keys from the current list.

### Syntax

**ntp authentication-key** *number* **md5** *key*

**no ntp authentication-key** [*number*]

*number* - The NTP authentication key ID number. (Range: 1-65533)

**md5** - Specifies that authentication is provided by using the message digest algorithm 5.

*key* - An MD5 authentication key string. The key string can be up to 32 case-sensitive printable ASCII characters (no spaces).

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ The key number specifies a key value in the NTP authentication key list. Up to 255 keys can be configured on the switch. Re-enter this command for each server you want to configure.
- ◆ Note that NTP authentication key numbers and values must match on both the server and client.
- ◆ NTP authentication is optional. When enabled with the **ntp authenticate** command, you must also configure at least one key number using this command.

- ◆ Use the **no** form of this command without an argument to clear all authentication keys in the list.

#### Example

```
Console(config)#ntp authentication-key 45 md5 thisiskey45
Console(config)#
```

#### Related Commands

[ntp authenticate \(174\)](#)

**ntp client** This command enables NTP client requests for time synchronization from NTP time servers specified with the **ntp servers** command. Use the **no** form to disable NTP client requests.

#### Syntax

**[no] ntp client**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ The SNTP and NTP clients cannot be enabled at the same time. First disable the SNTP client before using this command.
- ◆ The time acquired from time servers is used to record accurate dates and times for log events. Without NTP, the switch only records the time starting from the factory default set at the last bootup (e.g., Dec 10 16:04:43 2014).
- ◆ This command enables client time requests to time servers specified via the **ntp servers** command. Once enabled the switch will issue time synchronization requests periodically.

#### Example

```
Console(config)#ntp client
Console(config)#
```

#### Related Commands

[sntp client \(172\)](#)

[ntp server \(177\)](#)

**ntp server** This command sets the IP addresses of the servers to which NTP time requests are sent to. Use the **no** form of the command to clear a specific time server or all servers from the current list.

### Syntax

**ntp server** *ip-address* [**key** *key-number*]

**no ntp server** [*ip-address*]

*ip-address* - IP address of an NTP time server.

*key-number* - The number of an authentication key to use in communications with the server. (Range: 1-65535)

### Default Setting

Version number: 3

### Command Mode

Global Configuration

### Command Usage

- ◆ This command specifies time servers that the switch will poll for time updates when set to NTP client mode. The client will poll all the time servers configured, the responses received are filtered and compared to determine the most reliable and accurate time update for the switch.
- ◆ You can configure up to 3 NTP servers on the switch. Re-enter this command for each server you want to configure.
- ◆ NTP authentication is optional. If enabled with the **ntp authenticate** command, you must also configure at least one key number using the **ntp authentication-key** command.
- ◆ Use the **no** form of this command without an argument to clear all configured servers in the list.

### Example

```
Console(config)#ntp server 192.168.3.20
Console(config)#ntp server 192.168.3.21
Console(config)#ntp server 192.168.5.23 key 19
Console(config)#
```

### Related Commands

[ntp client \(176\)](#)

[show ntp peer-status \(179\)](#)

**show ntp** This command displays the current time and configuration settings for the NTP client, and indicates whether or not the local time has been properly updated from an NTP server.

#### Command Mode

Privileged Exec

#### Command Usage

This command displays the current time, the poll interval used for sending time synchronization requests, and the current NTP mode (i.e., unicast).

#### Example

```

Console#show ntp
Current Time           : Apr 29 13:57:32 2015
Polling Interval      : 1024 seconds
Current Mode          : unicast
NTP Status            : Disabled
NTP Authenticate Status : Enabled
Last Update NTP Server : 0.0.0.0          Port: 0
Last Update Time      : Jan  1 00:00:00 1970 UTC
NTP Server 192.168.3.20 version 3
NTP Server 192.168.3.21 version 3
NTP Server 192.168.4.22 version 3 key 19
NTP Authentication Key 19 md5 42V68751663T6K11P2J307210R885
Console#

```

**show ntp status** This command displays the current status of received time updates from an NTP peer.

#### Command Mode

Privileged Exec

#### Example

```

Console#show ntp status
System Peer           : 192.168.125.88
Leap Indicator        : 11
Stratum               : 14
Precision             : 0.000001907349 seconds
Root Distance         : 0.001160 seconds
Root Dispersion       : 0.948900 seconds
Reference ID          : 192.168.125.88
Reference Time        : e0c697a3.6b04c19f  Wed, Jul  3 2019  2:55:31.418
Console#

```

**show ntp statistics peer** This command displays the statistics from an NTP peer.

#### Syntax

**show ntp statistics peer** {*ip-address* | *ipv6-address* | *hostname*}

*ip-address* - IP address of an NTP peer.

*ipv6-address* - IPv6 address of an NTP peer.

*hostname* - Host name of an NTP peer.

## Command Mode

Privileged Exec

## Example

```

Console#show ntp statistics Peer 192.168.125.88
Remote Host      : 192.168.125.88
Local Interface  : 192.168.125.138
Time Last Received : 223 seconds
Time Until Next Send : 772 seconds
Reachability Change : 229 seconds
Packets Sent     : 8
Packets Received : 8
Bad Authentication : 0
Bogus Origin     : 0
Duplicate        : 0
Bad Dispersion   : 0
Bad Reference Time : 0
Candidate Order  : 6
Console#

```

**show ntp peer-status** This command displays the status of connections to NTP peers.

## Syntax

**show ntp peer-status** [*ip-address* | *ipv6-address* | *hostname*]

*ip-address* - IP address of an NTP time server.

*ipv6-address* - IPv6 address of an NTP time server.

*hostname* - Host name of an NTP time server.

## Command Mode

Privileged Exec

## Example

```

Console#show ntp peer-status
* : system peer
Remote Host      Local Interface St Poll  Reach Delay  Offset  Dispersion
-----
1.1.1.1          0.0.0.0      16  1024  0 0.000000  0.00000  3.99217010
192.168.1.10    0.0.0.0      16  1024  0 0.000000  0.00000  3.99217010
*192.168.125.88 192.168.125.138 13  1024  1 0.001160 -0.00011 0.96824998
Console#

```

## Manual Configuration Commands

**clock summer-time (date)** This command sets the start, end, and offset times of summer time (daylight savings time) for the switch on a one-time basis. Use the **no** form to disable summer time.

### Syntax

**clock summer-time** *name* **date** *b-date b-month b-year b-hour b-minute e-date e-month e-year e-hour e-minute [offset]*

### **no clock summer-time**

*name* - Name of the time zone while summer time is in effect, usually an acronym. (Range: 1-30 characters)

*b-date* - Day of the month when summer time will begin. (Range: 1-31)

*b-month* - The month when summer time will begin. (Options: **january** | **february** | **march** | **april** | **may** | **june** | **july** | **august** | **september** | **october** | **november** | **december**)

*b-year* - The year summer time will begin.

*b-hour* - The hour summer time will begin. (Range: 0-23 hours)

*b-minute* - The minute summer time will begin. (Range: 0-59 minutes)

*e-date* - Day of the month when summer time will end. (Range: 1-31)

*e-month* - The month when summer time will end. (Options: **january** | **february** | **march** | **april** | **may** | **june** | **july** | **august** | **september** | **october** | **november** | **december**)

*e-year* - The year summer time will end.

*e-hour* - The hour summer time will end. (Range: 0-23 hours)

*e-minute* - The minute summer time will end. (Range: 0-59 minutes)

*offset* - Summer time offset from the regular time zone, in minutes. (Range: 1-120 minutes)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ In some countries or regions, clocks are adjusted through the summer months so that afternoons have more daylight and mornings have less. This is known as Summer Time, or Daylight Savings Time (DST). Typically, clocks are adjusted forward one hour at the start of spring and then adjusted backward in autumn.
- ◆ This command sets the summer-time time zone relative to the currently configured time zone. To specify a time corresponding to your local time when

summer time is in effect, you must indicate the number of minutes your summer-time time zone deviates from your regular time zone (that is, the offset).

### Example

The following example sets the 2014 Summer Time ahead by 60 minutes on March 9th and returns to normal time on November 2nd.

```
Console(config)#clock summer-time DEST date march 9 2014 01 59 november 2
2014 01 59 60
Console(config)#
```

### Related Commands

[show sntp \(174\)](#)

**clock summer-time (predefined)** This command configures the summer time (daylight savings time) status and settings for the switch using predefined configurations for several major regions in the world. Use the **no** form to disable summer time.

### Syntax

**clock summer-time** *name* **predefined** [**australia** | **europe** | **new-zealand** | **usa**]

**no clock summer-time**

*name* - Name of the timezone while summer time is in effect, usually an acronym. (Range: 1-30 characters)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ In some countries or regions, clocks are adjusted through the summer months so that afternoons have more daylight and mornings have less. This is known as Summer Time, or Daylight Savings Time (DST). Typically, clocks are adjusted forward one hour at the start of spring and then adjusted backward in autumn.
- ◆ This command sets the summer-time time relative to the configured time zone. To specify the time corresponding to your local time when summer time is in effect, select the predefined summer-time time zone appropriate for your location, or manually configure summer time if these predefined configurations do not apply to your location (see [clock summer-time \(date\)](#) or [clock summer-time \(recurring\)](#)).

Table 30: Predefined Summer-Time Parameters

Region	Start Time, Day, Week, & Month	End Time, Day, Week, & Month	Rel. Offset
Australia	00:00:00, Sunday, Week 5 of October	23:59:59, Sunday, Week 5 of March	60 min
Europe	00:00:00, Sunday, Week 5 of March	23:59:59, Sunday, Week 5 of October	60 min
New Zealand	00:00:00, Sunday, Week 1 of October	23:59:59, Sunday, Week 3 of March	60 min
USA	00:00:00, Sunday, Week 2 of March	23:59:59, Sunday, Week 1 of November	60 min

**Example**

The following example sets the Summer Time setting to use the predefined settings for the European region.

```
Console(config)#clock summer-time MESZ predefined europe
Console(config)#
```

**Related Commands**

[show sntp \(174\)](#)

**clock summer-time (recurring)** This command allows the user to manually configure the start, end, and offset times of summer time (daylight savings time) for the switch on a recurring basis. Use the **no** form to disable summer-time.

**Syntax**

**clock summer-time** *name* **recurring** *b-week b-day b-month b-hour b-minute e-week e-day e-month e-hour e-minute [offset]*

**no clock summer-time**

*name* - Name of the timezone while summer time is in effect, usually an acronym. (Range: 1-30 characters)

*b-week* - The week of the month when summer time will begin. (Range: 1-5)

*b-day* - The day of the week when summer time will begin. (Options: **sunday** | **monday** | **tuesday** | **wednesday** | **thursday** | **friday** | **saturday**)

*b-month* - The month when summer time will begin. (Options: **january** | **february** | **march** | **april** | **may** | **june** | **july** | **august** | **september** | **october** | **november** | **december**)

*b-hour* - The hour when summer time will begin. (Range: 0-23 hours)

*b-minute* - The minute when summer time will begin. (Range: 0-59 minutes)

*e-week* - The week of the month when summer time will end. (Range: 1-5)

*e-day* - The day of the week summer time will end. (Options: **sunday** | **monday** | **tuesday** | **wednesday** | **thursday** | **friday** | **saturday**)

*e-month* - The month when summer time will end. (Options: **january** | **february** | **march** | **april** | **may** | **june** | **july** | **august** | **september** | **october** | **november** | **december**)

*e-hour* - The hour when summer time will end. (Range: 0-23 hours)

*e-minute* - The minute when summer time will end. (Range: 0-59 minutes)

*offset* - Summer-time offset from the regular time zone, in minutes. (Range: 1-120 minutes)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ In some countries or regions, clocks are adjusted through the summer months so that afternoons have more daylight and mornings have less. This is known as Summer Time, or Daylight Savings Time (DST). Typically, clocks are adjusted forward one hour at the start of spring and then adjusted backward in autumn.
- ◆ This command sets the summer-time time zone relative to the currently configured time zone. To display a time corresponding to your local time when summer time is in effect, you must indicate the number of minutes your summer-time time zone deviates from your regular time zone (that is, the offset).

### Example

The following example sets a recurring 60 minute offset summer-time to begin on the Friday of the 1st week of March at 01:59 hours and summer time to end on the Saturday of the 2nd week of November at 01:59 hours.

```
Console(config)#clock summer-time MESZ recurring 1 friday march 01 59 3
    saturday november 1 59 60
Console(config)#
```

### Related Commands

[show sntp \(174\)](#)

**clock timezone** This command sets the time zone for the switch's internal clock.

### Syntax

```
clock timezone name hour hours minute minutes
{before-utc | after-utc}
```

*name* - Name of timezone, usually an acronym. (Range: 1-30 characters)

*hours* - Number of hours before/after UTC. (Range: 0-12 hours before UTC, 0-13 hours after UTC)

*minutes* - Number of minutes before/after UTC. (Range: 0-59 minutes)

**before-utc** - Sets the local time zone before (east) of UTC.

**after-utc** - Sets the local time zone after (west) of UTC.

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

This command sets the local time zone relative to the Coordinated Universal Time (UTC, formerly Greenwich Mean Time or GMT), based on the earth's prime meridian, zero degrees longitude. To display a time corresponding to your local time, you must indicate the number of hours and minutes your time zone is east (before) or west (after) of UTC.

#### Example

```
Console(config)#clock timezone Japan hours 8 minute 0 after-UTC
Console(config)#
```

#### Related Commands

[show sntp \(174\)](#)

**clock timezone-predefined** This command sets the time zone for the switch's internal clock from a set of predefined time zones.

#### Syntax

**clock timezone-predefined** *timezone*

*timezone* - Name of timezone as listed in the list in the command usage section.

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

This command sets the local time zone by selecting a pre-defined GMT zone with a geographical description.

Select one time zone from the following list to use as the *timezone* parameter with the command:

GMT+0100-Amsterdam,Berlin,Bern,Rome,Stockholm,Vienna  
GMT+0100-Belgrade,Bratislava,Budapest,Ljubljana,Prague  
GMT+0100-Brussels,Copenhagen,Madrid,Paris  
GMT+0100-Sarajevo,Skopje,Warsaw,Zagreb  
GMT+0100-WestCentralAfrica  
GMT+0200-Athens,Beirut,Istanbul,Minsk  
GMT+0200-Bucharest  
GMT+0200-Cairo  
GMT+0200-Harare,Pretoria  
GMT+0200-Helsinki,Kyiv,Riga,Sofia,Tallinn,Vilnius  
GMT+0200-Jerusalem  
GMT+0300-Baghdad  
GMT+0300-Kuwait,Riyadh  
GMT+0300-Moscow,St.Petersburg,Volgograd  
GMT+0300-Nairobi  
GMT+0330-Tehran  
GMT+0400-Abu-Dhabi,Muscat  
GMT+0400-Baku,Tbilisi,Yerevan  
GMT+0430-Kabul  
GMT+0500-Ekaterinburg  
GMT+0500-Islamabad,Karachi,Tashkent  
GMT+0530-Chennai,Calcuta,Mumbai,New-Delhi  
GMT+0545-Kathmandu  
GMT+0600-Almaty,Novosibirsk  
GMT+0600-Astana,Dhaka  
GMT+0600-Sri-Jayawardenepura  
GMT+0630-Rangoon  
GMT+0700-Bangkok,Hanoi,Jakarta  
GMT+0700-Krasnoyarsk  
GMT+0800-Beijing,Chongqing,Hong-Kong,Urumqi  
GMT+0800-Irkutsk,Ulaan-Bataar  
GMT+0800-Kuala-Lumpur,Singapore  
GMT+0800-Perth  
GMT+0800-Taipei  
GMT+0900-Osaka,Sapporo,Tokyo  
GMT+0900-Seoul  
GMT+0900-Yakutsk  
GMT+0930-Adelaide  
GMT+0930-Darwin  
GMT+1000-Brisbane  
GMT+1000-Canberra,Melbourne,Sydney  
GMT+1000-Guam,PortMoresby  
GMT+1000-Hobart  
GMT+1000-Vladivostok  
GMT+1030-Lord-Howe-Island  
GMT+1100-Magadan,Solomon-Is.,New-Caledonia  
GMT+1130-Kingston  
GMT+1200-Auckland,Wellington  
GMT+1200-Fiji,Kamchatka,Marshall-Is  
GMT+1245-Chatham-Island  
GMT+1300-Nuku'alofa  
GMT+1400-Kiritimati  
GMT-0100-Azores  
GMT-0100-Cape-Verde-Is  
GMT-0200-Mid-Atlantic  
GMT-0300-Brasilia

GMT-0300-Buenos-Aires,Georgetown  
GMT-0300-Greenland  
GMT-0330-Newfoundland  
GMT-0400-Atlantic-Time(Canada)  
GMT-0400-Caracas,La-Paz  
GMT-0400-Santiago  
GMT-0500-Bogota,Lima,Quito  
GMT-0500-Eastern-Time(US&Canada)  
GMT-0500-Indiana(East)  
GMT-0600-Central-America  
GMT-0600-Central-Time(US&Canada)  
GMT-0600-Guadalajara,Mexico-City,Monterrey  
GMT-0600-Saskatchewan  
GMT-0700-Arizona  
GMT-0700-Chihuahua,La-Paz,Mazatlan  
GMT-0700-Mountain-Time(US&Canada)  
GMT-0800-Pacific-Time(US&Canada),Tijuana  
GMT-0900-Alaska  
GMT-0930-Taiohae  
GMT-1000-Hawaii  
GMT-1100-Midway-Island,Samoa  
GMT-1200-International-Date-Line-West  
GMT-Casablanca,Monrovia  
GMT-Greenwich-Mean-Time-Dublin,Edinburgh,Lisbon,London

### Example

This example sets the timezone to GMT+1030-Lord-Howe-Island and shows the result.

```
Console(config)#clock timezone-predefined GMT+1030-Lord-Howe-Island
Console(config)#end
Console#show calendar
Current Time       : May 31 18:22:21 2018
Time Zone         : GMT+1030-LordHoweIsland
Summer Time      : Not configured
Summer Time in Effect : No
Console#
```

**calendar set** This command sets the system clock. It may be used if there is no time server on your network, or if you have not configured the switch to receive signals from a time server.

### Syntax

**calendar set** *hour min sec* {*day month year* | *month day year*}

*hour* - Hour in 24-hour format. (Range: 0 - 23)

*min* - Minute. (Range: 0 - 59)

*sec* - Second. (Range: 0 - 59)

*day* - Day of month. (Range: 1 - 31)

*month* - **january** | **february** | **march** | **april** | **may** | **june** | **july** | **august** | **september** | **october** | **november** | **december**

*year* - Year (4-digit). (Range: 1970 - 2037)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Note that when SNTP is enabled, the system clock cannot be manually configured.

### Example

This example shows how to set the system clock to 15:12:34, February 1st, 2015.

```
Console#calendar set 15 12 34 1 February 2015
Console#
```

**show calendar** This command displays the system clock.

### Default Setting

None

### Command Mode

Normal Exec, Privileged Exec

### Example

```
Console#show calendar
Current Time      : May 13 14:08:18 2014
Time Zone        : UTC, 08:00
Summer Time      : Not configured
```

```
Summer Time in Effect : No
Console#
```

## Time Range

This section describes the commands used to sets a time range for use by other functions, such as Access Control Lists.

**Table 31: Time Range Commands**

Command	Function	Mode
<code>time-range</code>	Specifies the name of a time range, and enters time range configuration mode	GC
<code>absolute</code>	Sets the absolute time range for the execution of a command	TR
<code>periodic</code>	Sets the time range for the periodic execution of a command	TR
<code>show time-range</code>	Shows configured time ranges.	PE

**time-range** This command specifies the name of a time range, and enters time range configuration mode. Use the **no** form to remove a previously specified time range.

### Syntax

**[no] time-range** *name*

*name* - Name of the time range. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ This command sets a time range for use by other functions, such as Access Control Lists.
- ◆ A maximum of eight rules can be configured for a time range.

### Example

```
Console(config)#time-range r&d
Console(config-time-range)#
```

### Related Commands

[Access Control Lists \(395\)](#)

**absolute** This command sets the absolute time range for the execution of a command. Use the **no** form to remove a previously specified time.

### Syntax

**absolute start** *hour minute day month year*  
[**end** *hour minutes day month year*]

**absolute end** *hour minutes day month year*

**no absolute**

*hour* - Hour in 24-hour format. (Range: 0-23)

*minute* - Minute. (Range: 0-59)

*day* - Day of month. (Range: 1-31)

*month* - **january** | **february** | **march** | **april** | **may** | **june** | **july** | **august** |  
**september** | **october** | **november** | **december**

*year* - Year (4-digit). (Range: 2013-2037)

### Default Setting

None

### Command Mode

Time Range Configuration

### Command Usage

- ◆ If a time range is already configured, you must use the **no** form of this command to remove the current entry prior to configuring a new time range.
- ◆ If both an absolute rule and one or more periodic rules are configured for the same time range (i.e., named entry), that entry will only take effect if the current time is within the absolute time range and one of the periodic time ranges.

### Example

This example configures the time for the single occurrence of an event.

```
Console(config)#time-range r&d
Console(config-time-range)#absolute start 1 1 1 april 2009 end 2 1 1 april
2009
Console(config-time-range)#
```

**periodic** This command sets the time range for the periodic execution of a command. Use the **no** form to remove a previously specified time range.

### Syntax

```
[no] periodic {daily | friday | monday | saturday | sunday | thursday |  
tuesday | wednesday | weekdays | weekend} hour minute to {daily | friday |  
monday | saturday | sunday | thursday | tuesday | wednesday | weekdays  
| weekend} hour minute}
```

**daily** - Daily

**friday** - Friday

**monday** - Monday

**saturday** - Saturday

**sunday** - Sunday

**thursday** - Thursday

**tuesday** - Tuesday

**wednesday** - Wednesday

**weekdays** - Weekdays

**weekend** - Weekends

*hour* - Hour in 24-hour format. (Range: 0-23)

*minute* - Minute. (Range: 0-59)

### Default Setting

None

### Command Mode

Time Range Configuration

### Command Usage

- ◆ If a time range is already configured, you must use the **no** form of this command to remove the current entry prior to configuring a new time range.
- ◆ If both an absolute rule and one or more periodic rules are configured for the same time range (i.e., named entry), that entry will only take effect if the current time is within the absolute time range and one of the periodic time ranges.

### Example

This example configures a time range for the periodic occurrence of an event.

```
Console(config)#time-range sales  
Console(config-time-range)#periodic daily 1 1 to 2 1  
Console(config-time-range)#
```

**show time-range** This command shows configured time ranges.

### Syntax

**show time-range** *[name]*

*name* - Name of the time range. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show time-range r&d
Time-range r&d:
  status: inactive
  absolute start 01:01 01 April 2015
  periodic   Daily 01:01 to   Daily 02:01
  periodic   Daily 02:01 to   Daily 03:01
Console#
```

## Switch Clustering

Switch Clustering is a method of grouping switches together to enable centralized management through a single unit. Switches that support clustering can be grouped together regardless of physical location or switch type, as long as they are connected to the same local network.

**Table 32: Switch Cluster Commands**

Command	Function	Mode
<a href="#">cluster</a>	Configures clustering on the switch	GC
<a href="#">cluster commander</a>	Configures the switch as a cluster Commander	GC
<a href="#">cluster ip-pool</a>	Sets the cluster IP address pool for Members	GC
<a href="#">cluster member</a>	Sets Candidate switches as cluster members	GC
<a href="#">rcommand</a>	Provides configuration access to Member switches	PE
<a href="#">show cluster</a>	Displays the switch clustering status	PE
<a href="#">show cluster members</a>	Displays current cluster Members	PE
<a href="#">show cluster candidates</a>	Displays current cluster Candidates in the network	PE

### Using Switch Clustering

- ◆ A switch cluster has a primary unit called the “Commander” which is used to manage all other “Member” switches in the cluster. The management station

can use either Telnet or the web interface to communicate directly with the Commander through its IP address, and then use the Commander to manage the Member switches through the cluster's "internal" IP addresses.

- ◆ Clustered switches must be in the same Ethernet broadcast domain. In other words, clustering only functions for switches which can pass information between the Commander and potential Candidates or active Members through VLAN 4093.
- ◆ Once a switch has been configured to be a cluster Commander, it automatically discovers other cluster-enabled switches in the network. These "Candidate" switches only become cluster Members when manually selected by the administrator through the management station.
- ◆ The cluster VLAN 4093 is not configured by default. Before using clustering, take the following actions to set up this VLAN:
  1. Create VLAN 4093 (see ["Editing VLAN Groups" on page 576](#)).
  2. Add the participating ports to this VLAN (see ["Configuring VLAN Interfaces" on page 578](#)), and set them to hybrid mode, tagged members, PVID = 1, and acceptable frame type = all.



**Note:** Cluster Member switches can be managed either through a Telnet connection to the Commander, or through a web management connection to the Commander. When using a console connection, from the Commander CLI prompt, use the [rcommand](#) to connect to the Member switch.

---

**cluster** This command enables clustering on the switch. Use the **no** form to disable clustering.

#### Syntax

**[no] cluster**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ To create a switch cluster, first be sure that clustering is enabled on the switch (the default is disabled), then set the switch as a Cluster Commander. Set a Cluster IP Pool that does not conflict with any other IP subnets in the network. Cluster IP addresses are assigned to switches when they become Members and are used for communication between Member switches and the Commander.

- ◆ Switch clusters are limited to the same Ethernet broadcast domain.
- ◆ There can be up to 100 candidates and 36 member switches in one cluster.
- ◆ A switch can only be a Member of one cluster.
- ◆ Configured switch clusters are maintained across power resets and network changes.

### Example

```
Console(config)#cluster  
Console(config)#
```

**cluster commander** This command enables the switch as a cluster Commander. Use the **no** form to disable the switch as cluster Commander.

### Syntax

**[no] cluster commander**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Once a switch has been configured to be a cluster Commander, it automatically discovers other cluster-enabled switches in the network. These “Candidate” switches only become cluster Members when manually selected by the administrator through the management station.
- ◆ Cluster Member switches can be managed through a Telnet connection to the Commander. From the Commander CLI prompt, use the [rcommand id](#) command to connect to the Member switch.

### Example

```
Console(config)#cluster commander  
Console(config)#
```

**cluster ip-pool** This command sets the cluster IP address pool. Use the **no** form to reset to the default address.

#### Syntax

**cluster ip-pool** *ip-address*

**no cluster ip-pool**

*ip-address* - The base IP address for IP addresses assigned to cluster Members. The IP address must start 10.x.x.x.

#### Default Setting

10.254.254.1

#### Command Mode

Global Configuration

#### Command Usage

- ◆ An “internal” IP address pool is used to assign IP addresses to Member switches in the cluster. Internal cluster IP addresses are in the form 10.x.x.*member-ID*. Only the base IP address of the pool needs to be set since Member IDs can only be between 1 and 36.
- ◆ Set a Cluster IP Pool that does not conflict with addresses in the network IP subnet. Cluster IP addresses are assigned to switches when they become Members and are used for communication between Member switches and the Commander.
- ◆ You cannot change the cluster IP pool when the switch is currently in Commander mode. Commander mode must first be disabled.

#### Example

```
Console(config)#cluster ip-pool 10.2.3.4  
Console(config)#
```

**cluster member** This command configures a Candidate switch as a cluster Member. Use the **no** form to remove a Member switch from the cluster.

#### Syntax

**cluster member mac-address** *mac-address* **id** *member-id*

**no cluster member id** *member-id*

*mac-address* - The MAC address of the Candidate switch.

*member-id* - The ID number to assign to the Member switch. (Range: 1-36)

#### Default Setting

No Members

### Command Mode

Global Configuration

### Command Usage

- ◆ The maximum number of cluster Members is 36.
- ◆ The maximum number of cluster Candidates is 100.

### Example

```
Console(config)#cluster member mac-address 00-12-34-56-78-9a id 5  
Console(config)#
```

**rcommand** This command provides access to a cluster Member CLI for configuration.

### Syntax

**rcommand id** *member-id*

*member-id* - The ID number of the Member switch. (Range: 1-36)

### Command Mode

Privileged Exec

### Command Usage

- ◆ This command only operates through a Telnet connection to the Member switch. Managing cluster Members using the local console CLI on the Commander is not supported.
- ◆ There is no need to enter the username and password for access to the Member switch CLI.

### Example

```
Console#rcommand id 1  
  
CLI session with the ECS4650-54P is opened.  
To end the CLI session, enter [Exit].  
  
Vty-0#
```

**show cluster** This command shows the switch clustering configuration.

**Command Mode**  
Privileged Exec

**Example**

```
Console#show cluster
Role           : commander
Interval Heartbeat : 30
Heartbeat Loss Count : 3 seconds
Number of Members : 1
Number of Candidates : 2
Console#
```

**show cluster members** This command shows the current switch cluster members.

**Command Mode**  
Privileged Exec

**Example**

```
Console#show cluster members
Cluster Members:
ID       : 1
Role     : Active member
IP Address : 10.254.254.2
MAC Address : 00-E0-0C-00-00-FE
Description : ECS4650-54T
Console#
```

**show cluster candidates** This command shows the discovered Candidate switches in the network.

**Command Mode**  
Privileged Exec

**Example**

```
Console#show cluster candidates
Cluster Candidates:
Role           MAC Address           Description
-----
Candidate join 00-E0-0C-00-00-FE      ECS4650-54T
Candidate      00-12-CF-0B-47-A0      ECS4650-54T
Console#
```

## Dying Gasp

When the switch enters an unrecoverable condition, such as a power failure, it can be configured to send “dying-gasp” notification messages to other devices.

**Table 33: Dying-Gasp Commands**

Command	Function	Mode
<code>dying-gasp</code>	Configures the type of dying-gasp message to send	GC
<code>show dying-gasp status</code>	Shows the dying-gasp configuration and status	PE
<code>show dying-gasp packets</code>	Shows the contents of the stored dying-gasp packet	PE

**dying-gasp** This command specifies the type of dying-gasp message to send when the switch encounters an abrupt loss of power. Use the **no** form to restore the default setting.

### Syntax

**dying-gasp** {**efm-oam** | **snmp-trap** *ip-address* | **syslog** *ip-address* | **none**}

**no dying-gasp**

**efm-oam** - Send an EFM-OAM dying-gasp packet.

**snmp-trap** - Send an SNMP trap packet to a specified receiver.

**syslog** - Send a Syslog dying-gasp packet to a specified server.

*ip-address* - The IPv4 or IPv6 host address.

**none** - Disables sending a dying-gasp message.

### Default Setting

EFM-OAM

### Command Mode

Global Configuration

### Command Usage

When the notification type is EFM OAM, the switch uses the **efm oam critical-link-event dying-gasp** command to enable the sending of an EFM OAM dying gasp message on OAM-enabled ports.

### Example

```
Console(config)#dying-gasp snmp-trap 10.2.3.4
Console(config)#
```

**show dying-gasp status** This command shows the dying-gasp configuration and status.

**Command Mode**

Privileged Exec

**Example**

```
Console#show dying-gasp status
Dying Gasp Configuration:
  Notification Type : Syslog
  Server IP Address : 192.168.1.1
Status:
  Update Timer   : 30 seconds
  Packet         : Ready
Console#
```

**show dying-gasp packets** This command shows the contents of the stored dying-gasp packet.

**Command Mode**

Privileged Exec

**Example**

```
Console#show dying-gasp packets
Interface           : Eth 1/1
Source MAC Address  : 00-10-80-CC-22-01
Source IP Address   : 192.168.1.1
Source Port Number  : 1042
Destination MAC Address : 00-10-80-CC-22-02
Destination IP Address : 192.168.1.10
Destination Port Number : 162
Console#
```

# SNMP Commands

SNMP commands control access to this switch from management stations using the Simple Network Management Protocol (SNMP), as well as the error types sent to trap managers.

SNMP Version 3 also provides security features that cover message integrity, authentication, and encryption; as well as controlling user access to specific areas of the MIB tree. To use SNMPv3, first set an SNMP engine ID (or accept the default), specify read and write access views for the MIB tree, configure SNMP user groups with the required security model (i.e., SNMP v1, v2c or v3) and security level (i.e., authentication and privacy), and then assign SNMP users to these groups, along with their specific authentication and privacy passwords.

**Table 34: SNMP Commands**

Command	Function	Mode
<i>General SNMP Commands</i>		
<code>snmp-server</code>	Enables the SNMP agent	GC
<code>snmp-server community</code>	Sets up the community access string to permit access to SNMP commands	GC
<code>snmp-server contact</code>	Sets the system contact string	GC
<code>snmp-server location</code>	Sets the system location string	GC
<code>show snmp</code>	Displays the status of SNMP communications	NE, PE
<i>SNMP Target Host Commands</i>		
<code>snmp-server enable traps</code>	Enables the device to send SNMP traps (i.e., SNMP notifications)	GC
<code>snmp-server host</code>	Specifies the recipient of an SNMP notification operation	GC
<code>snmp-server enable port-traps link-up-down</code>	Enables the device to send SNMP traps (i.e., SNMP notifications) when a link-up or link-down state change occurs	IC
<code>snmp-server enable port-traps mac-notification</code>	Enables the device to send SNMP traps (i.e., SNMP notifications) when a dynamic MAC address is added or removed	IC
<code>show snmp-server enable port-traps</code>	Shows if SNMP traps are enabled or disabled for the specified interfaces	PE
<i>SNMPv3 Engine Commands</i>		
<code>snmp-server engine-id</code>	Sets the SNMP engine ID	GC
<code>snmp-server group</code>	Adds an SNMP group, mapping users to views	GC
<code>snmp-server user</code>	Adds a user to an SNMP group	GC
<code>snmp-server view</code>	Adds an SNMP view	GC

**Table 34: SNMP Commands** (Continued)

Command	Function	Mode
<code>show snmp engine-id</code>	Shows the SNMP engine ID	PE
<code>show snmp group</code>	Shows the SNMP groups	PE
<code>show snmp user</code>	Shows the SNMP users	PE
<code>show snmp view</code>	Shows the SNMP views	PE
<i>Notification Log Commands</i>		
<code>nlm</code>	Enables the specified notification log	GC
<code>snmp-server notify-filter</code>	Creates a notification log and specifies the target host	GC
<code>show nlm oper-status</code>	Shows operation status of configured notification logs	PE
<code>show snmp notify-filter</code>	Displays the configured notification logs	PE
<i>ATC Trap Commands</i>		
<code>snmp-server enable port-traps atc broadcast-alarm-clear</code>	Sends a trap when broadcast traffic falls beneath the lower threshold after a storm control response has been triggered	IC (Port)
<code>snmp-server enable port-traps atc broadcast-alarm-fire</code>	Sends a trap when broadcast traffic exceeds the upper threshold for automatic storm control	IC (Port)
<code>snmp-server enable port-traps atc broadcast-control-apply</code>	Sends a trap when broadcast traffic exceeds the upper threshold for automatic storm control and the apply timer expires	IC (Port)
<code>snmp-server enable port-traps atc broadcast-control-release</code>	Sends a trap when broadcast traffic falls beneath the lower threshold after a storm control response has been triggered and the release timer expires	IC (Port)
<code>snmp-server enable port-traps atc multicast-alarm-clear</code>	Sends a trap when multicast traffic falls beneath the lower threshold after a storm control response has been triggered	IC (Port)
<code>snmp-server enable port-traps atc multicast-alarm-fire</code>	Sends a trap when multicast traffic exceeds the upper threshold for automatic storm control	IC (Port)
<code>snmp-server enable port-traps atc multicast-control-apply</code>	Sends a trap when multicast traffic exceeds the upper threshold for automatic storm control and the apply timer expires	IC (Port)
<code>snmp-server enable port-traps atc multicast-control-release</code>	Sends a trap when multicast traffic falls beneath the lower threshold after a storm control response has been triggered and the release timer expires	IC (Port)
<i>Transceiver Power Threshold Trap Commands</i>		
<code>transceiver-threshold current</code>	Sends a trap when the transceiver current falls outside the specified thresholds	IC (Port)
<code>transceiver-threshold rx-power</code>	Sends a trap when the power level of the received signal falls outside the specified thresholds	IC (Port)
<code>transceiver-threshold temperature</code>	Sends a trap when the transceiver temperature falls outside the specified thresholds	IC (Port)
<code>transceiver-threshold tx-power</code>	Sends a trap when the power level of the transmitted signal power outside the specified thresholds	IC (Port)
<code>transceiver-threshold voltage</code>	Sends a trap when the transceiver voltage falls outside the specified thresholds	IC (Port)

Table 34: SNMP Commands (Continued)

Command	Function	Mode
<i>Additional Trap Commands</i>		
<code>memory</code>	Sets the rising and falling threshold for the memory utilization alarm	GC
<code>process cpu</code>	Sets the rising and falling threshold for the CPU utilization alarm	GC
<code>process cpu guard</code>	Sets the CPU utilization watermark and threshold	GC
<code>show memory</code>	Shows memory utilization parameters	PE
<code>show process cpu</code>	Shows CPU utilization parameters	NE, PE
<code>show process cpu guard</code>	Shows the CPU utilization watermark and threshold	PE
<code>show process cpu task</code>	Shows CPU utilization per process	NE, PE

## General SNMP Commands

**snmp-server** This command enables the SNMPv3 engine and services for all management clients (i.e., versions 1, 2c, 3). Use the **no** form to disable the server.

### Syntax

**[no] snmp-server**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Example

```
Console(config)#snmp-server
Console(config)#
```

**snmp-server community** This command defines community access strings used to authorize management access by clients using SNMP v1 or v2c. Use the **no** form to remove the specified community string.

### Syntax

**snmp-server community** *string* [**ro** | **rw**]

**no snmp-server community** *string*

*string* - Community string that acts like a password and permits access to the SNMP protocol. (Maximum length: 32 characters, case sensitive; Maximum number of strings: 5)

**ro** - Specifies read-only access. Authorized management stations are only able to retrieve MIB objects.

**rw** - Specifies read/write access. Authorized management stations are able to both retrieve and modify MIB objects.

#### Default Setting

- ◆ **public** - Read-only access. Authorized management stations are only able to retrieve MIB objects.
- ◆ **private** - Read/write access. Authorized management stations are able to both retrieve and modify MIB objects.

#### Command Mode

Global Configuration

#### Example

```
Console(config)#snmp-server community alpha rw
Console(config)#
```

**snmp-server contact** This command sets the system contact string. Use the **no** form to remove the system contact information.

#### Syntax

**snmp-server contact** *string*

no snmp-server contact

*string* - String that describes the system contact information.  
(Maximum length: 255 characters)

#### Default Setting

None

#### Command Mode

Global Configuration

#### Example

```
Console(config)#snmp-server contact Paul
Console(config)#
```

#### Related Commands

[snmp-server location \(203\)](#)

**snmp-server location** This command sets the system location string. Use the **no** form to remove the location string.

### Syntax

**snmp-server location** *text*

**no snmp-server location**

*text* - String that describes the system location.  
(Maximum length: 255 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#snmp-server location WC-19
Console(config)#
```

### Related Commands

[snmp-server contact \(202\)](#)

**show snmp** This command can be used to check the status of SNMP communications.

### Default Setting

None

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

This command provides information on the community access strings, counters for SNMP input and output protocol data units, and whether or not SNMP logging has been enabled with the **snmp-server enable traps** command.

### Example

```
Console#show snmp

SNMP Agent : Enabled

SNMP Traps :
  Authentication : Enabled
  MAC-notification : Disabled
  MAC-notification interval : 1 second(s)

SNMP Communities :
  1. public, and the access level is read-only
```

```

2. private, and the access level is read/write

0 SNMP packets input
  0 Bad SNMP version errors
  0 Unknown community name
  0 Illegal operation for community name supplied
  0 Encoding errors
  0 Number of requested variables
  0 Number of altered variables
  0 Get-request PDUs
  0 Get-next PDUs
  0 Set-request PDUs
0 SNMP packets output
  0 Too big errors
  0 No such name errors
  0 Bad values errors
  0 General errors
  0 Response PDUs
  0 Trap PDUs

SNMP Logging: Disabled
Console#

```

## SNMP Target Host Commands

**snmp-server enable traps** This command enables this device to send Simple Network Management Protocol traps or informs (i.e., SNMP notifications). Use the **no** form to disable SNMP notifications.

### Syntax

**[no] snmp-server enable traps [authentication | mac-notification [interval seconds]]**

**authentication** - Keyword to issue authentication failure notifications.

**mac-notification** - Keyword to issue trap when a dynamic MAC address is added or removed.

**interval** - Specifies the interval between issuing two consecutive traps. (Range: 1-3600 seconds; Default: 1 second)

### Default Setting

Issue authentication traps  
Other traps are disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ If you do not enter an **snmp-server enable traps** command, no notifications controlled by this command are sent. In order to configure this device to send SNMP notifications, you must enter at least one **snmp-server enable traps** command. If you enter the command with no keywords, both authentication

notifications are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled.

- ◆ The **snmp-server enable traps** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. In order to send notifications, you must configure at least one **snmp-server host** command.
- ◆ The authentication traps are legacy notifications, and therefore when used for SNMP Version 3 hosts, they must be enabled in conjunction with the corresponding entries in the Notify View assigned by the **snmp-server group** command.
- ◆ Interface link-up and link-down traps can be configured using the **snmp-server enable port-traps link-up-down** command.

### Example

```
Console(config)#snmp-server enable traps authentication
Console(config)#
```

### Related Commands

[snmp-server host \(205\)](#)

**snmp-server host** This command specifies the recipient of a Simple Network Management Protocol notification operation. Use the **no** form to remove the specified host.

### Syntax

```
snmp-server host host-addr [inform [retry retries | timeout seconds]]
community-string [version {1 | 2c | 3 {auth | noauth | priv} [udp-port port]}]
```

```
no snmp-server host host-addr
```

*host-addr* - IPv4 or IPv6 address of the host (the targeted recipient).  
(Maximum host addresses: 5 trap destination IP address entries)

**inform** - Notifications are sent as inform messages. Note that this option is only available for version 2c and 3 hosts. (Default: traps are used)

*retries* - The maximum number of times to resend an inform message if the recipient does not acknowledge receipt. (Range: 0-255; Default: 3)

*seconds* - The number of seconds to wait for an acknowledgment before resending an inform message. (Range: 0-2147483647 centiseconds; Default: 1500 centiseconds)

*community-string* - Password-like community string sent with the notification operation to SNMP V1 and V2c hosts. Although you can set this string using the **snmp-server host** command by itself, we recommend defining it with the **snmp-server community** command prior to using the **snmp-server host** command. (Maximum length: 32 characters)

**version** - Specifies whether to send notifications as SNMP Version 1, 2c or 3 traps. (Range: 1, 2c, 3; Default: 1)

**auth | noauth | priv** - This group uses SNMPv3 with authentication, no authentication, or with authentication and privacy. See “Simple Network Management Protocol” in the *Web Management Guide* for further information about these authentication and encryption options.

**port** - Host UDP port to use. (Range: 1-65535; Default: 162)

### Default Setting

Host Address: None

Notification Type: Traps

SNMP Version: 1

UDP Port: 162

### Command Mode

Global Configuration

### Command Usage

- ◆ If you do not enter an **snmp-server host** command, no notifications are sent. In order to configure the switch to send SNMP notifications, you must enter at least one **snmp-server host** command. In order to enable multiple hosts, you must issue a separate **snmp-server host** command for each host.
- ◆ The **snmp-server host** command is used in conjunction with the [snmp-server enable traps](#) command. Use the [snmp-server enable traps](#) command to enable the sending of traps or informs and to specify which SNMP notifications are sent globally. For a host to receive notifications, at least one [snmp-server enable traps](#) command and the **snmp-server host** command for that host must be enabled.
- ◆ Some notification types cannot be controlled with the [snmp-server enable traps](#) command. For example, some notification types are always enabled.
- ◆ Notifications are issued by the switch as trap messages by default. The recipient of a trap message does not send a response to the switch. Traps are therefore not as reliable as inform messages, which include a request for acknowledgement of receipt. Informs can be used to ensure that critical information is received by the host. However, note that informs consume more system resources because they must be kept in memory until a response is received. Informs also add to network traffic. You should consider these effects when deciding whether to issue notifications as traps or informs.

To send an inform to a SNMPv2c host, complete these steps:

1. Enable the SNMP agent ([page 201](#)).
2. Create a view with the required notification messages ([page 213](#)).
3. Create a group that includes the required notify view ([page 210](#)).

4. Allow the switch to send SNMP traps; i.e., notifications ([page 204](#)).
5. Specify the target host that will receive inform messages with the **snmp-server host** command as described in this section.

To send an inform to a SNMPv3 host, complete these steps:

1. Enable the SNMP agent ([page 201](#)).
  2. Create a remote SNMPv3 user to use in the message exchange process ([page 211](#)).
  3. Create a view with the required notification messages ([page 213](#)).
  4. Create a group that includes the required notify view ([page 210](#)).
  5. Allow the switch to send SNMP traps; i.e., notifications ([page 204](#)).
  6. Specify the target host that will receive inform messages with the **snmp-server host** command as described in this section.
- ◆ The switch can send SNMP Version 1, 2c or 3 notifications to a host IP address, depending on the SNMP version that the management station supports. If the **snmp-server host** command does not specify the SNMP version, the default is to send SNMP version 1 notifications.
  - ◆ If you specify an SNMP Version 3 host, then the community string is interpreted as an SNMP user name. The user name must first be defined with the [snmp-server user](#) command. Otherwise, an SNMPv3 group will be automatically created by the **snmp-server host** command using the name of the specified community string, and default settings for the read, write, and notify view.

### Example

```
Console(config)#snmp-server host 10.1.19.23 batman
Console(config)#
```

### Related Commands

[snmp-server enable traps \(204\)](#)

**snmp-server enable port-traps link-up-down** This command enables the device to send SNMP traps (i.e., SNMP notifications) when a link-up or link-down state change occurs. Use the **no** form to restore the default setting.

### Syntax

**[no] snmp-server enable port-traps link-up-down**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps link-up-down
Console(config)#
```

**snmp-server enable port-traps mac-notification** This command enables the device to send SNMP traps (i.e., SNMP notifications) when a dynamic MAC address is added or removed. Use the no form to restore the default setting.

### Syntax

**[no] snmp-server enable port-traps mac-notification**

**mac-notification** - Keyword to issue trap when a dynamic MAC address is added or removed.

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

This command can enable MAC authentication traps on the current interface only if they are also enabled at the global level with the [snmp-server enable traps mac-authentication](#) command.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps mac-notification
Console(config)#
```

**show snmp-server enable port-traps** This command shows if SNMP traps are enabled or disabled for the specified interfaces.

### Syntax

**show snmp-server enable port-traps interface [interface]**

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**Command Mode**

Privileged Exec

**Example**

```

Console#show snmp-server enable port-traps interface
Interface MAC Notification Trap
-----
Eth 1/1                               No
Eth 1/2                               No
Eth 1/3                               No
:
```

**SNMPv3 Commands**

**snmp-server engine-id** This command configures an identification string for the SNMPv3 engine. Use the **no** form to restore the default.

**Syntax**

**snmp-server engine-id** {**local** | **remote** {*ip-address*}} *engineid-string*

**no snmp-server engine-id** {**local** | **remote** {*ip-address*}}

**local** - Specifies the SNMP engine on this switch.

**remote** - Specifies an SNMP engine on a remote device.

*ip-address* - IPv4 or IPv6 address of the remote device.

*engineid-string* - String identifying the engine ID. (Range: 9-64 hexadecimal characters)

**Default Setting**

A unique engine ID is automatically generated by the switch based on its MAC address.

**Command Mode**

Global Configuration

**Command Usage**

- ◆ An SNMP engine is an independent SNMP agent that resides either on this switch or on a remote device. This engine protects against message replay, delay, and redirection. The engine ID is also used in combination with user passwords to generate the security keys for authenticating and encrypting SNMPv3 packets.
- ◆ A remote engine ID is required when using SNMPv3 informs. (See the [snmp-server host](#) command.) The remote engine ID is used to compute the security digest for authentication and encryption of packets passed between the switch and a user on the remote host. SNMP passwords are localized using the engine ID of the authoritative agent. For informs, the authoritative SNMP agent is the

remote agent. You therefore need to configure the remote agent's SNMP engine ID before you can send proxy requests or informs to it.

- ◆ Trailing zeroes need not be entered to uniquely specify a engine ID. In other words, the value "0123456789" is equivalent to "0123456789" followed by 16 zeroes for a local engine ID.
- ◆ A local engine ID is automatically generated that is unique to the switch. This is referred to as the default engine ID. If the local engine ID is deleted or changed, all SNMP users will be cleared. You will need to reconfigure all existing users (page 211).

### Example

```
Console(config)#snmp-server engine-id local 1234567890
Console(config)#snmp-server engine-id remote 192.168.1.19 9876543210
Console(config)#
```

### Related Commands

[snmp-server host \(205\)](#)

**snmp-server group** This command adds an SNMP group, mapping SNMP users to SNMP views. Use the **no** form to remove an SNMP group.

### Syntax

```
snmp-server group groupname
{v1 | v2c | v3 {auth | noauth | priv}}
[read readview] [write writeview] [notify notifyview]
```

```
no snmp-server group groupname
```

*groupname* - Name of an SNMP group. A maximum of 22 groups can be configured. (Range: 1-32 characters)

**v1** | **v2c** | **v3** - Use SNMP version 1, 2c or 3.

**auth** | **noauth** | **priv** - This group uses SNMPv3 with authentication, no authentication, or with authentication and privacy. See "Simple Network Management Protocol" in the *Web Management Guide* for further information about these authentication and encryption options.

*readview* - Defines the view for read access. (1-32 characters)

*writeview* - Defines the view for write access. (1-32 characters)

*notifyview* - Defines the view for notifications. (1-32 characters)

### Default Setting

Default groups: public<sup>1</sup> (read only), private<sup>2</sup> (read/write)

*readview* - Every object belonging to the Internet OID space (1).

*writeview* - Nothing is defined.

*notifyview* - Nothing is defined.

## Command Mode

Global Configuration

## Command Usage

- ◆ A group sets the access policy for the assigned users.
- ◆ When authentication is selected, the MD5 or SHA algorithm is used as specified in the `snmp-server user` command.
- ◆ When privacy is selected, the DES 56-bit algorithm is used for data encryption.
- ◆ For additional information on the notification messages supported by this switch, see the table for “Supported Notification Messages” in the *Web Management Guide*. Also, note that the authentication, link-up and link-down messages are legacy traps and must therefore be enabled in conjunction with the `snmp-server enable traps` command.

## Example

```
Console(config)#snmp-server group r&d v3 auth write daily
Console(config)#
```

**snmp-server user** This command adds a user to an SNMP group, restricting the user to a specific SNMP Read, Write, or Notify View. Use the **no** form to remove a user from an SNMP group.

## Syntax

```
snmp-server user username groupname
{v1 | v2c | v3 [encrypted] [auth {md5 | sha} auth-password [priv {3des |
aes128 | aes192 | aes256 | des56} priv-password]]
```

```
snmp-server user username groupname remote ip-address
{v3 [encrypted] [auth {md5 | sha} auth-password [priv {3des | aes128 |
aes192 | aes256 | des56} priv-password]]
```

```
no snmp-server user username {v1 | v2c | v3 | remote ip-address v3}
```

*username* - Name of user connecting to the SNMP agent. A maximum of 22 groups can be configured. (Range: 1-32 characters)

*groupname* - Name of an SNMP group to which the user is assigned. (Range: 1-32 characters)

**remote** - Specifies an SNMP engine on a remote device.

*ip-address* - IPv4 address of the remote device.

**v1** | **v2c** | **v3** - Use SNMP version 1, 2c or 3.

**encrypted** - Accepts the password as encrypted input.

1. No view is defined.
2. Maps to the defaultview.

**auth** - Uses SNMPv3 with authentication.

**md5** | **sha** - Uses MD5 or SHA authentication.

*auth-password* - Authentication password. Enter as plain text if the **encrypted** option is not used. Otherwise, enter an encrypted password. (Range: 8-32 characters for unencrypted password.)

If the **encrypted** option is selected, enter an encrypted password. (Range: 32 characters for MD5 encrypted password, 40 characters for SHA encrypted password)

**priv** - Uses SNMPv3 with privacy.

**3des** - Uses SNMPv3 with privacy with 3DES (168-bit) encryption.

**aes128** - Uses SNMPv3 with privacy with AES128 encryption.

**aes192** - Uses SNMPv3 with privacy with AES192 encryption.

**aes256** - Uses SNMPv3 with privacy with AES256 encryption.

**des56** - Uses SNMPv3 with privacy with DES56 encryption.

*priv-password* - Privacy password. Enter as plain text if the **encrypted** option is not used. Otherwise, enter an encrypted password. (Range: 8-32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Local users (i.e., the command does not specify a remote engine identifier) must be configured to authorize management access for SNMPv3 clients, or to identify the source of SNMPv3 trap messages sent from the local switch.
- ◆ Remote users (i.e., the command specifies a remote engine identifier) must be configured to identify the source of SNMPv3 inform messages sent from the local switch.
- ◆ The SNMP engine ID is used to compute the authentication/privacy digests from the password. You should therefore configure the engine ID with the [snmp-server engine-id](#) command before using this configuration command.
- ◆ Before you configure a remote user, use the [snmp-server engine-id](#) command to specify the engine ID for the remote device where the user resides. Then use the **snmp-server user** command to specify the user and the IP address for the remote device where the user resides. The remote agent's SNMP engine ID is used to compute authentication/privacy digests from the user's password. If the remote engine ID is not first configured, the **snmp-server user** command specifying a remote user will fail.

- ◆ SNMP passwords are localized using the engine ID of the authoritative agent. For informs, the authoritative SNMP agent is the remote agent. You therefore need to configure the remote agent's SNMP engine ID before you can send proxy requests or informs to it.

### Example

```
Console(config)#snmp-server user steve r&d v3 auth md5 greenpeace priv des56
  einstien
Console(config)#snmp-server engine-id remote 192.168.1.19 9876543210
Console(config)#snmp-server user mark r&d remote 192.168.1.19 v3 auth md5
  greenpeace priv des56 einstien
Console(config)#
```

**snmp-server view** This command adds an SNMP view which controls user access to the MIB. Use the **no** form to remove an SNMP view.

### Syntax

**snmp-server view** *view-name oid-tree* {**included** | **excluded**}

**no snmp-server view** *view-name*

*view-name* - Name of an SNMP view. A maximum of 32 views can be configured. (Range: 1-32 characters)

*oid-tree* - Object identifier of a branch within the MIB tree. Wild cards can be used to mask a specific portion of the OID string. (Refer to the examples.)

**included** - Defines an included view.

**excluded** - Defines an excluded view.

### Default Setting

defaultview (includes access to the entire MIB tree)

### Command Mode

Global Configuration

### Command Usage

- ◆ Views are used in the [snmp-server group](#) command to restrict user access to specified portions of the MIB tree.
- ◆ The predefined view "defaultview" includes access to the entire MIB tree.

### Examples

This view includes MIB-2.

```
Console(config)#snmp-server view mib-2 1.3.6.1.2.1 included
Console(config)#
```

This view includes the MIB-2 interfaces table, ifDescr. The wild card is used to select all the index values in the following table.

```
Console(config)#snmp-server view ifEntry.2 1.3.6.1.2.1.2.2.1.*.2 included
Console(config)#
```

This view includes the MIB-2 interfaces table, and the mask selects all index entries.

```
Console(config)#snmp-server view ifEntry.a 1.3.6.1.2.1.2.2.1.1.* included
Console(config)#
```

**show snmp engine-id** This command shows the SNMP engine ID.

### Command Mode

Privileged Exec

### Example

This example shows the default engine ID.

```
Console#show snmp engine-id
Local SNMP EngineID: 8000002a80000000000e8666672
Local SNMP EngineBoots: 1

Remote SNMP Engine ID                               IP address
80000000030004e2b316c54321                          192.168.1.19
Console#
```

**Table 35: show snmp engine-id - display description**

Field	Description
Local SNMP engineID	String identifying the engine ID.
Local SNMP engineBoots	The number of times that the engine has (re-)initialized since the snmp EngineID was last configured.
Remote SNMP engineID	String identifying an engine ID on a remote device.
IP address	IP address of the device containing the corresponding remote SNMP engine.

**show snmp group** This command shows information on SNMP groups. Four default groups are provided – SNMPv1 read-only access and read/write access, and SNMPv2c read-only access and read/write access.

### Command Mode

Privileged Exec

### Example

```

Console#show snmp group
Group Name       : r&d
Security Model   : v3
Security Level   : Authentication and privacy
Read View        : No readview specified
Write View       : No writeview specified
Notify View      : No notifyview specified
Storage Type     : Nonvolatile
Row Status       : Active

Group Name       : public
Security Model   : v1
Read View        : defaultview
Write View       : No writeview specified
Notify View      : No notifyview specified
Storage Type     : Volatile
Row Status       : Active

Group Name       : public
Security Model   : v2c
Read View        : defaultview
Write View       : No writeview specified
Notify View      : No notifyview specified
Storage Type     : Volatile
Row Status       : Active

Group Name       : private
Security Model   : v1
Read View        : defaultview
Write View       : defaultview
Notify View      : No notifyview specified
Storage Type     : Volatile
Row Status       : Active

Group Name       : private
Security Model   : v2c
Read View        : defaultview
Write View       : defaultview
Notify View      : No notifyview specified
Storage Type     : Volatile
Row Status       : Active
Console#

```

**Table 36: show snmp group - display description**

Field	Description
Group Name	Name of an SNMP group.
Security Model	The SNMP version.

**Table 36: show snmp group - display description** (Continued)

Field	Description
Security Level	This associated security level can use SNMPv3 with authentication, no authentication, or with authentication and privacy.
Read View	The associated read view.
Write View	The associated write view.
Notify View	The associated notify view.
Storage Type	The storage type for this entry.
Row Status	The row status of this entry.

**show snmp user** This command shows information on SNMP users.

### Command Mode

Privileged Exec

### Example

```

Console#show snmp user
Engine ID           : 800001030300e00c0000fd0000
User Name           : steve
Group Name          : rd
Security Model      : v1
Security Level      : None
Authentication Protocol : None
Privacy Protocol    : None
Storage Type        : Nonvolatile
Row Status          : Active

SNMP remote user
Engine ID           : 0000937564846450000
User Name           : mark
Group Name          : public
Security Model      : v3
Security Level      : Authentication and privacy
Authentication Protocol : MD5
Privacy Protocol    : DES56
Storage Type        : Nonvolatile
Row Status          : Active
Console#

```

**Table 37: show snmp user - display description**

Field	Description
Engine ID	String identifying the engine ID.
User Name	Name of user connecting to the SNMP agent.
Group Name	Name of an SNMP group.
Security Model	The user security model: SNMP v1, v2c or v3.
Security Level	Indicates if authentication or encryption are used.

**Table 37: show snmp user - display description** (Continued)

Field	Description
Authentication Protocol	The authentication protocol used with SNMPv3.
Privacy Protocol	The privacy protocol used with SNMPv3.
Storage Type	The storage type for this entry.
Row Status	The row status of this entry.
SNMP remote user	A user associated with an SNMP engine on a remote device.

**show snmp view** This command shows information on the SNMP views.

### Command Mode

Privileged Exec

### Example

```

Console#show snmp view
View Name: mib-2
Subtree OID: 1.2.2.3.6.2.1
View Type: included
Storage Type: permanent
Row Status: active

View Name      : defaultview
Subtree OID    : 1
View Type      : included
Storage Type   : volatile
Row Status     : active
Console#

```

**Table 38: show snmp view - display description**

Field	Description
View Name	Name of an SNMP view.
Subtree OID	A branch in the MIB tree.
View Type	Indicates if the view is included or excluded.
Storage Type	The storage type for this entry.
Row Status	The row status of this entry.

## Notification Log Commands

**nlm** This command enables or disables the specified notification log.

### Syntax

**[no] nlm** *filter-name*

*filter-name* - Notification log name. (Range: 1-32 characters)

**Default Setting**

None

**Command Mode**

Global Configuration

**Command Usage**

- ◆ Notification logging is enabled by default, but will not start recording information until a logging profile specified by the `snmp-server notify-filter` command is enabled by the `nlm` command.
- ◆ Disabling logging with this command does not delete the entries stored in the notification log.

**Example**

This example enables the notification log A1.

```
Console(config)#nlm A1
Console(config)#
```

**snmp-server notify-filter** This command creates an SNMP notification log. Use the **no** form to remove this log.

**Syntax**

**[no] snmp-server notify-filter** *profile-name* **remote** *ip-address*

*profile-name* - Notification log profile name. (Range: 1-32 characters)

*ip-address* - IPv4 or IPv6 address of a remote device. The specified target host must already have been configured using the `snmp-server host` command.



**Note:** The notification log is stored locally. It is not sent to a remote device. This remote host parameter is only required to complete mandatory fields in the SNMP Notification MIB.

**Default Setting**

None

**Command Mode**

Global Configuration

**Command Usage**

- ◆ Systems that support SNMP often need a mechanism for recording Notification information as a hedge against lost notifications, whether there are Traps or Informs that may exceed retransmission limits. The Notification Log MIB (NLM,

RFC 3014) provides an infrastructure in which information from other MIBs may be logged.

- ◆ Given the service provided by the NLM, individual MIBs can now bear less responsibility to record transient information associated with an event against the possibility that the Notification message is lost, and applications can poll the log to verify that they have not missed any important Notifications.
- ◆ If notification logging is not configured and enabled, when the switch reboots, some SNMP traps (such as warm start) cannot be logged.
- ◆ To avoid this problem, notification logging should be configured and enabled using the **snmp-server notify-filter** command and **nlm** command, and these commands stored in the startup configuration file. Then when the switch reboots, SNMP traps (such as warm start) can now be logged.
- ◆ When this command is executed, a notification log is created (with the default parameters defined in RFC 3014). Notification logging is enabled by default (see the **nlm** command), but will not start recording information until a logging profile specified with this command is enabled with the **nlm** command.
- ◆ Based on the default settings used in RFC 3014, a notification log can contain up to 256 entries, and the entry aging time is 1440 minutes. Information recorded in a notification log, and the entry aging time can only be configured using SNMP from a network management station.
- ◆ When a trap host is created with the **snmp-server host** command, a default notify filter will be created as shown in the example under the **show snmp notify-filter** command.

### Example

This example first creates an entry for a remote host, and then instructs the switch to record this device as the remote host for the specified notification log.

```
Console(config)#snmp-server host 10.1.19.23 batman
Console(config)#snmp-server notify-filter A1 remote 10.1.19.23
Console#
```

**show nlm oper-status** This command shows the operational status of configured notification logs.

#### Command Mode

Privileged Exec

#### Example

```
Console#show nlm oper-status
Filter Name: A1
Oper-Status: Operational
Console#
```

**show snmp notify-filter** This command displays the configured notification logs.

#### Command Mode

Privileged Exec

#### Example

This example displays the configured notification logs and associated target hosts.

```
Console#show snmp notify-filter
Filter profile name      IP address
-----
A1                       10.1.19.23
Console#
```

## Additional Trap Commands

**memory** This command sets an SNMP trap based on configured thresholds for memory utilization. Use the **no** form to restore the default setting.

#### Syntax

**memory** {**rising** *rising-threshold* | **falling** *falling-threshold*}

**no memory** {**rising** | **falling**}

*rising-threshold* - Rising threshold for memory utilization alarm expressed in percentage. (Range: 1-100)

*falling-threshold* - Falling threshold for memory utilization alarm expressed in percentage. (Range: 1-100)

#### Default Setting

Rising Threshold: 90%

Falling Threshold: 70%

#### Command Mode

Global Configuration

### Command Usage

Once the rising alarm threshold is exceeded, utilization must drop beneath the falling threshold before the alarm is terminated, and then exceed the rising threshold again before another alarm is triggered.

### Example

```
Console(config)#memory rising 80
Console(config)#memory falling 60
Console#
```

### Related Commands

[show memory \(124\)](#)

**process cpu** This command sets an SNMP trap based on configured thresholds for CPU utilization. Use the no form to restore the default setting.

### Syntax

**process cpu** {**rising** *rising-threshold* | **falling** *falling-threshold*}

**no process cpu** {**rising** | **falling**}

*rising-threshold* - Rising threshold for CPU utilization alarm expressed in percentage. (Range: 1-100)

*falling-threshold* - Falling threshold for CPU utilization alarm expressed in percentage. (Range: 1-100)

### Default Setting

Rising Threshold: 90%

Falling Threshold: 70%

### Command Mode

Global Configuration

### Command Usage

Once the rising alarm threshold is exceeded, utilization must drop beneath the falling threshold before the alarm is terminated, and then exceed the rising threshold again before another alarm is triggered.

### Example

```
Console(config)#process cpu rising 80
Console(config)#process cpu falling 60
Console#
```

### Related Commands

[show process cpu \(124\)](#)

**process cpu guard** This command sets the CPU utilization high and low watermarks in percentage of CPU time utilized and the CPU high and low thresholds in the number of packets being processed per second. Use the **no** form of this command without any parameters to restore all of the default settings, or with a specific parameter to restore the default setting for that item.

### Syntax

```
process cpu guard [high-watermark high-watermark |
low-watermark low-watermark | max-threshold max-threshold |
min-threshold min-threshold | trap]
```

*high-watermark* - If the percentage of CPU usage time is higher than the high-watermark, the switch stops packet flow to the CPU (allowing it to catch up with packets already in the buffer) until usage time falls below the low watermark. (Range: 40-100%)

*low-watermark* - If packet flow has been stopped after exceeding the high watermark, normal flow will be restored after usage falls beneath the low watermark. (Range: 40-100%)

*max-threshold* - If the number of packets being processed per second by the CPU is higher than the maximum threshold, the switch stops packet flow to the CPU (allowing it to catch up with packets already in the buffer) until the number of packets being processed falls below the minimum threshold. (Range: 50-500 pps)

*min-threshold* - If packet flow has been stopped after exceeding the maximum threshold, normal flow will be restored after usage falls beneath the minimum threshold. (Range: 50-500 pps)

**trap** - If traps are enabled, the switch will send an alarm message if CPU utilization exceeds the high watermark in percentage of CPU usage time or exceeds the maximum threshold in the number of packets being processed by the CPU.

### Default Setting

Guard Status: Disabled

High Watermark: 90%

Low Watermark: 70%

Maximum Threshold: 500 packets per second

Minimum Threshold: 50 packets per second

Trap Status: Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Once the high watermark is exceeded, utilization must drop beneath the low watermark before the alarm is terminated, and then exceed the high watermark again before another alarm is triggered.

- ◆ Once the maximum threshold is exceeded, utilization must drop beneath the minimum threshold before the alarm is terminated, and then exceed the maximum threshold again before another alarm is triggered.

### Example

```
Console(config)#process cpu guard high-watermark 80
Console(config)#process cpu guard low-watermark 60
Console(config)#
```

### Related Commands

[show process cpu guard \(125\)](#)



## 6

# Remote Monitoring Commands

Remote Monitoring allows a remote device to collect information or respond to specified events on an independent basis. This switch is an RMON-capable device which can independently perform a wide range of tasks, significantly reducing network management traffic. It can continuously run diagnostics and log information on network performance. If an event is triggered, it can automatically notify the network administrator of a failure and provide historical information about the event. If it cannot connect to the management agent, it will continue to perform any specified tasks and pass data back to the management station the next time it is contacted.

This switch supports mini-RMON, which consists of the Statistics, History, Event and Alarm groups. When RMON is enabled, the system gradually builds up information about its physical interfaces, storing this information in the relevant RMON database group. A management agent then periodically communicates with the switch using the SNMP protocol. However, if the switch encounters a critical event, it can automatically send a trap message to the management agent which can then respond to the event if so configured.

**Table 39: RMON Commands**

Command	Function	Mode
<code>rmon alarm</code>	Sets threshold bounds for a monitored variable	GC
<code>rmon event</code>	Creates a response event for an alarm	GC
<code>rmon collection history</code>	Periodically samples statistics	IC
<code>rmon collection rmon1</code>	Enables statistics collection	IC
<code>show rmon alarms</code>	Shows the settings for all configured alarms	PE
<code>show rmon events</code>	Shows the settings for all configured events	PE
<code>show rmon history</code>	Shows the sampling parameters for each entry	PE
<code>show rmon statistics</code>	Shows the collected statistics	PE

**rmon alarm** This command sets threshold bounds for a monitored variable. Use the **no** form to remove an alarm.

### Syntax

```
rmon alarm index variable interval {absolute | delta}
rising-threshold threshold [event-index] falling-threshold threshold
[event-index] [owner name]
```

```
no rmon alarm index
```

*index* – Index to this entry. (Range: 1-65535)

*variable* – The object identifier of the MIB variable to be sampled. Only variables of the type etherStatsEntry.n.n may be sampled. Note that etherStatsEntry.n uniquely defines the MIB variable, and etherStatsEntry.n.n defines the MIB variable, plus the etherStatsIndex. For example, 1.3.6.1.2.1.16.1.1.1.6.1 denotes etherStatsBroadcastPkts, plus the etherStatsIndex of 1.

*interval* – The polling interval. (Range: 1-31622400 seconds)

**absolute** – The variable is compared directly to the thresholds at the end of the sampling period.

**delta** – The last sample is subtracted from the current value and the difference is then compared to the thresholds.

*threshold* – An alarm threshold for the sampled variable.  
(Range: 0-2147483647)

*event-index* – The index of the event to use if an alarm is triggered. If there is no corresponding entry in the event control table, then no event will be generated. (Range: 0-65535)

*name* – Name of the person who created this entry. (Range: 1-127 characters)

### Default Setting

1.3.6.1.2.1.16.1.1.1.6.1 - 1.3.6.1.2.1.16.1.1.1.6.18/

Taking delta samples every 30 seconds, last value was 0

Rising threshold is 892800, assigned to event 0

Falling threshold is 446400, assigned to event 0

### Command Mode

Global Configuration

### Command Usage

- ◆ If an event is already defined for an index, the entry must be deleted before any changes can be made with this command.
- ◆ If the current value is greater than or equal to the rising threshold, and the last sample value was less than this threshold, then an alarm will be generated. After a rising event has been generated, another such event will not be

generated until the sampled value has fallen below the rising threshold, reaches the falling threshold, and again moves back up to the rising threshold.

- ◆ If the current value is less than or equal to the falling threshold, and the last sample value was greater than this threshold, then an alarm will be generated. After a falling event has been generated, another such event will not be generated until the sampled value has risen above the falling threshold, reaches the rising threshold, and again moves back down to the failing threshold.

### Example

```
Console(config)#rmon alarm 1 1.3.6.1.2.1.16.1.1.1.6.1 15 delta
  rising-threshold 100 1 falling-threshold 30 1 owner mike
Console(config)#
```

**rmon event** This command creates a response event for an alarm. Use the **no** form to remove an event.

### Syntax

**rmon event** *index* [**log**] | [**trap** *community*] | [**description** *string*] | [**owner** *name*]

**no rmon event** *index*

*index* – Index to this entry. (Range: 1-65535)

**log** – Generates an RMON log entry when the event is triggered. Log messages are processed based on the current configuration settings for event logging (see [“Event Logging” on page 159](#)).

**trap** – Sends a trap message to all configured trap managers (see the [snmp-server host](#) command).

*community* – A password-like community string sent with the trap operation to SNMP v1 and v2c hosts. Although this string can be set using the **rmon event** command by itself, it is recommended that the string be defined using the [snmp-server community](#) command prior to using the rmon event command. (Range: 1-32 characters)

*string* – A comment that describes this event. (Range: 1-127 characters)

*name* – Name of the person who created this entry. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

Global Configuration

**Command Usage**

- ◆ If an event is already defined for an index, the entry must be deleted before any changes can be made with this command.
- ◆ The specified events determine the action to take when an alarm triggers this event. The response to an alarm can include logging the alarm or sending a message to a trap manager.

**Example**

```
Console(config)#rmon event 2 log description urgent owner mike
Console(config)#
```

**rmon collection history** This command periodically samples statistics on a physical interface. Use the `no` form to disable periodic sampling.

**Syntax**

**rmon collection history controlEntry** *index*

[**buckets** *number* [**interval** *seconds*]] |

[**interval** *seconds*] |

[**owner** *name* [**buckets** *number* [**interval** *seconds*]]]

**no rmon collection history controlEntry** *index*

*index* – Index to this entry. (Range: 1-65535)

*number* – The number of buckets requested for this entry. (Range: 1-65535)

*seconds* – The polling interval. (Range: 1-3600 seconds)

*name* – Name of the person who created this entry.  
(Range: 1-32 characters)

**Default Setting**

1.3.6.1.2.1.16.1.1.1.6.1 - 1.3.6.1.2.1.16.1.1.1.6.18

Buckets: 50

Interval: 30 seconds for even numbered entries,  
1800 seconds for odd numbered entries

**Command Mode**

Interface Configuration (Ethernet)

**Command Usage**

- ◆ By default, each index number equates to a port on the switch, but can be changed to any number not currently in use.
- ◆ If periodic sampling is already enabled on an interface, the entry must be deleted before any changes can be made with this command.

- ◆ The information collected for each sample includes:  
input octets, packets, broadcast packets, multicast packets, undersize packets, oversize packets, fragments, jabbers, CRC alignment errors, collisions, drop events, and network utilization.
- ◆ The switch reserves two controlEntry index entries for each port. If a default index entry is re-assigned to another port by this command, the **show running-config** command will display a message indicating that this index is not available for the port to which is normally assigned.

For example, if control entry 15 is assigned to port 5 as shown below, the **show running-config** command will indicate that this entry is not available for port 8.

```
Console(config)#interface ethernet 1/5
Console(config-if)#rmon collection history controlEntry 15
Console(config-if)#end
Console#show running-config
!
interface ethernet 1/5
  rmon collection history controlEntry 15 buckets 50 interval 1800
...
interface ethernet 1/8
  no rmon collection history controlEntry 15
```

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#rmon collection history controlentry 21 owner mike buckets
24 interval 60
Console(config-if)#
```

**rmon collection rmon1** This command enables the collection of statistics on a physical interface. Use the **no** form to disable statistics collection.

### Syntax

**rmon collection rmon1 controlEntry** *index* [**owner name**]

**no rmon collection rmon1 controlEntry** *index*

*index* – Index to this entry. (Range: 1-65535)

*name* – Name of the person who created this entry.  
(Range: 1-32 characters)

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet)

**Command Usage**

- ◆ By default, each index number equates to a port on the switch, but can be changed to any number not currently in use.
- ◆ If statistics collection is already enabled on an interface, the entry must be deleted before any changes can be made with this command.
- ◆ The information collected for each entry includes:  
input octets, packets, broadcast packets, multicast packets, undersize packets, oversize packets, fragments, jabbers, CRC alignment errors, collisions, drop events, and packets of specified lengths

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#rmon collection rmon1 controrentry 1 owner mike
Console(config-if)#
```

**show rmon alarms** This command shows the settings for all configured alarms.

**Command Mode**

Privileged Exec

**Example**

```
Console#show rmon alarms
Alarm 1 is valid, owned by
Monitors 1.3.6.1.2.1.16.1.1.1.6.1 every 30 seconds
Taking delta samples, last value was 0
Rising threshold is 892800, assigned to event 0
Falling threshold is 446400, assigned to event 0
:
```

**show rmon events** This command shows the settings for all configured events.

**Command Mode**

Privileged Exec

**Example**

```
Console#show rmon events
Event 2 is valid, owned by mike
Description is urgent
Event firing causes log and trap to community , last fired 00:00:00
Console#
```

**show rmon history** This command shows the sampling parameters configured for each entry in the history group.

**Command Mode**  
Privileged Exec

### Example

```

Console#show rmon history
Entry 1 is valid, and owned by
Monitors 1.3.6.1.2.1.2.2.1.1.1 every 1800 seconds
Requested # of time intervals, ie buckets, is 8
Granted # of time intervals, ie buckets, is 8
Sample # 1 began measuring at 00:00:01
Received 77671 octets, 1077 packets,
61 broadcast and 978 multicast packets,
0 undersized and 0 oversized packets,
0 fragments and 0 jabbers packets,
0 CRC alignment errors and 0 collisions.
# of dropped packet events is 0
Network utilization is estimated at 0
:

```

**show rmon statistics** This command shows the information collected for all configured entries in the statistics group.

**Command Mode**  
Privileged Exec

### Example

```

Console#show rmon statistics
Interface 1 is valid, and owned by
Monitors 1.3.6.1.2.1.2.2.1.1.1 which has
Received 164289 octets, 2372 packets,
120 broadcast and 2211 multicast packets,
0 undersized and 0 oversized packets,
0 fragments and 0 jabbers,
0 CRC alignment errors and 0 collisions.
# of dropped packet events (due to lack of resources): 0
# of packets received of length (in octets):
64: 2245, 65-127: 87, 128-255: 31,
256-511: 5, 512-1023: 2, 1024-1518: 2
:

```



# 7

## Flow Sampling Commands

Flow sampling (sFlow) can be used with a remote sFlow Collector to provide an accurate, detailed and real-time overview of the types and levels of traffic present on the network. The sFlow Agent samples 1 out of  $n$  packets from all data traversing the switch, re-encapsulates the samples as sFlow datagrams and transmits them to the sFlow Collector. This sampling occurs at the internal hardware level where all traffic is seen, whereas traditional probes only have a partial view of traffic as it is sampled at the monitored interface. Moreover, the processor and memory load imposed by the sFlow agent is minimal since local analysis does not take place.



**Note:** The terms “collector”, “receiver” and “owner”, in the context of this chapter, all refer to a remote server capable of receiving the sFlow datagrams generated by the sFlow agent of the switch.

**Table 40: sFlow Commands**

Command	Function	Mode
<code>sflow owner</code>	Creates an sFlow collector which the switch uses to send samples to.	PE
<code>sflow polling instance</code>	Configures an sFlow polling data source that takes samples periodically based on time.	PE
<code>sflow sampling instance</code>	Configures an sFlow sampling data source that samples periodically based on a packet count.	PE
<code>show sflow</code>	Shows the global and interface settings for the sFlow process	PE

**sflow owner** This command creates an sFlow collector on the switch. Use the **no** form to remove the sFlow receiver.

### Syntax

```
sflow owner owner-name timeout timeout-value
[destination {ipv4-address | ipv6-address}
[max-datagram-size max-datagram-size] [version {v4 | v5}]
[port destination-udp-port] [max-datagram-size max-datagram-size]
[version {v4 | v5}]]
[port destination-udp-port]
```

**no sflow owner** *owner-name*

*owner-name* - Name of the collector. (Range: 1-30 alphanumeric characters)

*timeout-value* - The length of time the sFlow interface is available to send samples to a receiver, after which the owner and associated polling and sampling data source instances are removed from the configuration. (Range: 30-10000000 seconds)

*ipv4-address* - IPv4 address of the sFlow collector. Valid IPv4 addresses consist of four decimal numbers, 0 to 255, separated by periods.

*ipv6-address* - IPv6 address of the sFlow collector. An IPv6 address consists of 8 colon-separated 16-bit hexadecimal values. One double colon may be used to indicate the appropriate number of zeros required to fill the undefined fields.

*destination-udp-port* - The UDP port on which the collector is listening for sFlow streams. (Range: 1-65535)

*max-datagram-size* - The maximum size of the sFlow datagram payload. (Range: 200-1500 bytes)

**version {v4 | v5}** - Sends either v4 or v5 sFlow datagrams to the receiver.

### Default Setting

No owner is configured

UDP Port: 6343

Version: v5

Maximum Datagram Size: 1400 bytes

### Command Mode

Privileged Exec

### Command Usage

- ◆ Use the **sflow owner** command to create an owner instance of an sFlow collector. If the socket port, maximum datagram size, and datagram version are not specified, then the default values are used.
- ◆ Once an owner is created, the **sflow owner** command can again be used to modify the owner's port number. All other parameter values for the owner will be retained if the port is modified.

- ◆ Use the **no sflow owner** command to remove the collector.
- ◆ When the **sflow owner** command is issued, its associated timeout value will immediately begin to count down. Once the timeout value has reached zero seconds, the sFlow owner and its associated sampling sources will be deleted from the configuration.

### Example

This example shows an sflow collector being created on the switch.

```
Console#sflow owner stat_server1 timeout 100 destination 192.168.220.225 port
22500 max-datagram-size 512 version v5
Console#
```

This example shows how to modify the sFlow port number for an already configured collector.

```
Console#sflow owner stat_server1 timeout 100 port 35100
Console#
```

**sflow polling instance** This command enables an sFlow polling data source, for a specified interface, that polls periodically based on a specified time interval. Use the **no** form to remove the polling data source instance from the switch's sFlow configuration.

### Syntax

**sflow polling** {**interface** *interface*} **instance** *instance-id* **receiver** *owner-name*  
**polling-interval** *seconds*

**no sflow polling** {**interface** *interface*} **instance** *instance-id*

*interface* - The source from which the samples will be taken at specified intervals and sent to a collector.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

*instance-id* - An instance ID used to identify the sampling source. (Range: 1)

*owner-name* - The associated receiver, to which the samples will be sent. (Range: 1-30 alphanumeric characters)

**polling-interval** - The time interval at which the sFlow process adds counter values to the sample datagram. (Range: 1-10000000 seconds)

### Default Setting

No sFlow polling instance is configured.

**Command Mode**

Privileged Exec

**Command Usage**

This command enables a polling data source and configures the interval at which counter values are added to the sample datagram.

**Example**

This example sets the polling interval to 10 seconds.

```
Console#sflow polling interface ethernet 1/9 instance 1 receiver owner1
polling-interval 10
Console#
```

**sflow sampling instance**

This command enables an sFlow data source instance for a specific interface that takes samples periodically based on the number of packets processed. Use the **no** form to remove the sampling data source instance from the switch's sFlow configuration.

**Syntax**

**sflow sampling** {**interface** *interface*} **instance** *instance-id* **receiver** *owner-name*  
**sampling-rate** *sample-rate*  
[**max-header-size** *max-header-size*]

**no sflow sample** {**interface** *interface*} **instance** *instance-id*

*interface* - The source from which the samples will be taken and sent to a collector.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

*instance-id* - An instance ID used to identify the sampling source. (Range: 1)

*owner-name* - The associated receiver, to which the samples will be sent. (Range: 1-30 alphanumeric characters)

*sample-rate* - The packet sampling rate, or the number of packets out of which one sample will be taken. (Range: 256-16777215 packets)

*max-header-size* - The maximum size of the sFlow datagram header. (Range: 64-256 bytes)

**Default Setting**

No sFlow sampling instance id configured.

Maximum Header Size: 128 bytes

**Command Mode**

Privileged Exec

**Example**

This example enables a sampling data source on Ethernet interface 1/1, an associated receiver named "owner1", and a sampling rate of one out of 100. The maximum header size is also set to 200 bytes.

```
Console# sflow sampling interface ethernet 1/1 instance 1 receiver owner1
sampling-rate 100 max-header-size 200
Console#
```

The following command removes a sampling data source from Ethernet interface 1/1.

```
Console# no sflow sampling interface ethernet 1/1 instance 1
Console#
```

**show sflow** This command shows the global and interface settings for the sFlow process.

**Syntax**

**show sflow** [**owner** *owner-name* | **interface** *interface*]

*owner-name* - The associated receiver, to which the samples are sent.  
(Range: 1-30 alphanumeric characters)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**Command Mode**

Privileged Exec

**Example**

```
Console#show sflow interface ethernet 1/2

Receiver Owner Name   : stat1
Receiver Timeout      : 99633 sec
Receiver Destination  : 192.168.32.32
Receiver Socket Port  : 6343
Maximum Datagram Size : 1400 bytes
Datagram Version     : 4

Data Source           : Eth 1/2
Sampling Instance ID  : 1
Sampling Rate         : 512
Maximum Header Size   : 128 bytes

Console#
```



# Authentication Commands

You can configure this switch to authenticate users logging into the system for management access using local or remote authentication methods. Port-based authentication using IEEE 802.1X can also be configured to control either management access to the uplink ports or client access<sup>3</sup> to the data ports.

**Table 41: Authentication Commands**

Command Group	Function
<a href="#">User Accounts and Privilege Levels</a>	Configures the basic user names and passwords for management access, and assigns a privilege level to specified command groups or individual commands
<a href="#">Authentication Sequence</a>	Defines logon authentication method and precedence
<a href="#">RADIUS Client</a>	Configures settings for authentication via a RADIUS server
<a href="#">TACACS+ Client</a>	Configures settings for authentication via a TACACS+ server
<a href="#">AAA</a>	Configures authentication, authorization, and accounting for network access
<a href="#">Web Server</a>	Enables management access via a web browser
<a href="#">Telnet Server</a>	Enables management access via Telnet
<a href="#">Secure Shell</a>	Provides secure replacement for Telnet
<a href="#">802.1X Port Authentication</a>	Configures host authentication on specific ports using 802.1X
<a href="#">Management IP Filter</a>	Configures IP addresses that are allowed management access
<a href="#">PPPoE Intermediate Agent</a>	Configures relay parameters required for sending authentication messages between a client and broadband remote access servers

3. For other methods of controlling client access, see [“General Security Measures” on page 309](#).

## User Accounts and Privilege Levels

The basic commands required for management access and assigning command privilege levels are listed in this section. This switch also includes other options for password checking via the console or a Telnet connection (page 148), user authentication via a remote authentication server (page 239), and host access authentication for specific ports (page 282).

Table 42: User Access Commands

Command	Function	Mode
<code>enable password</code>	Sets a password to control access to the Privileged Exec level	GC
<code>username</code>	Establishes a user name-based authentication system at login	GC
<code>privilege</code>	Assigns a privilege level to specified command groups or individual commands	GC
<code>show privilege</code>	Shows the privilege level for the current user, or the privilege level for commands modified by the privilege command	PE

**enable password** After initially logging onto the system, you should set the Privileged Exec password. Remember to record it in a safe place. This command controls access to the Privileged Exec level from the Normal Exec level. Use the **no** form to reset the default password.

### Syntax

**enable password** [*level level*] {**0** | **7**} *password*

**no enable password** [*level level*]

**level level** - Sets the command access privileges. Only Level 15 is available, which provides full access to all commands. (Range: 0-15)

{**0** | **7**} - 0 means plain password, 7 means encrypted password.

*password* - Password for this privilege level.

(Maximum length: 32 characters plain text or encrypted, case sensitive)

### Default Setting

The default is level 15.

The default password is "super"

### Command Mode

Global Configuration

### Command Usage

- ◆ You cannot set a null password. You will have to enter a password to change the command mode from Normal Exec to Privileged Exec with the [enable](#) command.
- ◆ The encrypted password is required for compatibility with legacy password settings (i.e., plain text or encrypted) when reading the configuration file during system bootup or when downloading the configuration file from an FTP server. There is no need for you to manually configure encrypted passwords.

### Example

```
Console(config)#enable password level 15 0 admin
Console(config)#
```

### Related Commands

[enable \(99\)](#)

[authentication enable \(244\)](#)

**username** This command adds named users, requires authentication at login, specifies or changes a user's password (or specify that no password is required), or specifies or changes a user's access level. Use the **no** form to remove a user name.

### Syntax

**username** *name* {**access-level** *level* | **nopassword** | **password** {**0** | **7**} *password*}

**no username** *name*

*name* - The name of the user. (Maximum length: 32 characters, case sensitive. Maximum users: 16)

The device has two predefined users, **guest** which is assigned privilege level **0** (Normal Exec) and has access to a limited number of commands, and **admin** which is assigned privilege level 15 and has full access to all commands.

**access-level** *level* - Specifies command access privileges. (Range: 0-15)

Level 0, 8 and 15 are designed for users (guest), managers (network maintenance), and administrators (top-level access). The other levels can be used to configured specialized access profiles.

Level 0-7 provide the same default access privileges, all within Normal Exec mode under the "Console>" command prompt.

Level 8-14 provide the same default access privileges, including additional commands in Normal Exec mode, and a subset of commands in Privileged Exec mode under the "Console#" command prompt.

Level 15 provides full access to all commands.

The privilege level associated with any command can be changed using the [privilege](#) command.

Any privilege level can access all of the commands assigned to lower privilege levels. For example, privilege level 8 can access all commands assigned to privilege levels 7-0 according to default settings, and to any other commands assigned to levels 7-0 using the [privilege](#) command.

**nopassword** - No password is required for this user to log in.

{0 | 7} - 0 means plain password, 7 means encrypted password.

**password** *password* - The authentication password for the user. (Maximum length: 32 characters plain text or encrypted, case sensitive)

### Default Setting

The default access level is 0 (Normal Exec).

The factory defaults for the user names and passwords are:

Table 43: Default Login Settings

username	access-level	password
guest	0	guest
admin	15	admin

### Command Mode

Global Configuration

### Command Usage

The encrypted password is required for compatibility with legacy password settings (i.e., plain text or encrypted) when reading the configuration file during system bootup or when downloading the configuration file from an FTP server. There is no need for you to manually configure encrypted passwords.

### Example

This example shows how to set the access level and password for a user.

```
Console(config)#username bob access-level 15
Console(config)#username bob password 0 smith
Console(config)#
```

**privilege** This command assigns a privilege level to specified command groups or individual commands. Use the **no** form to restore the default setting.

### Syntax

**privilege** *mode* [**all**] **level** *level command*

**no privilege** *mode* [**all**] *command*

*mode* - The configuration mode containing the specified *command*.  
(See “Understanding Command Modes” on page 88 and “Configuration Commands” on page 90.)

**all** - Modifies the privilege level for all subcommands under the specified *command*.

**level level** - Specifies the privilege level for the specified *command*. Refer to the default settings described for the access level parameter under the `username` command. (Range: 0-15)

*command* - Specifies any command contained within the specified *mode*.

### Default Setting

Privilege level 0 provides access to a limited number of the commands which display the current status of the switch, as well as several database clear and reset functions. Level 8 provides access to all display status and configuration commands, except for those controlling various authentication and security features. Level 15 provides full access to all commands.

### Command Mode

Global Configuration

### Example

This example sets the privilege level for the ping command to Privileged Exec.

```
Console(config)#privilege exec level 15 ping
Console(config)#
```

**show privilege** This command shows the privilege level for the current user, or the privilege level for commands modified by the `privilege` command.

### Syntax

**show privilege [command]**

**command** - Displays the privilege level for all commands modified by the `privilege` command.

### Command Mode

Privileged Exec

### Example

This example shows the privilege level for any command modified by the `privilege` command.

```
Console#show privilege command
privilege line all level 0 accounting
privilege exec level 15 ping
Console(config)#
```

## Authentication Sequence

Three authentication methods can be specified to authenticate users logging into the system for management access. The commands in this section can be used to define the authentication method and sequence.

**Table 44: Authentication Sequence Commands**

Command	Function	Mode
<code>authentication enable</code>	Defines the authentication method and precedence for command mode change	GC
<code>authentication login</code>	Defines logon authentication method and precedence	GC

**authentication enable** This command defines the authentication method and precedence to use when changing from Exec command mode to Privileged Exec command mode with the `enable` command. Use the **no** form to restore the default.

### Syntax

**authentication enable** {[local] [radius] [tacacs]}

**no authentication enable**

**local** - Use local password only.

**radius** - Use RADIUS server password only.

**tacacs** - Use TACACS server password.

### Default Setting

Local

### Command Mode

Global Configuration

### Command Usage

- ◆ RADIUS uses UDP while TACACS+ uses TCP. UDP only offers best effort delivery, while TCP offers a connection-oriented transport. Also, note that RADIUS encrypts only the password in the access-request packet from the client to the server, while TACACS+ encrypts the entire body of the packet.
- ◆ RADIUS and TACACS+ logon authentication assigns a specific privilege level for each user name and password pair. The user name, password, and privilege level must be configured on the authentication server.
- ◆ You can specify three authentication methods in a single command to indicate the authentication sequence. For example, if you enter "**authentication enable radius tacacs local**," the user name and password on the RADIUS server is verified first. If the RADIUS server is not available, then authentication

is attempted on the TACACS+ server. If the TACACS+ server is not available, the local user name and password is checked.

### Example

```
Console(config)#authentication enable radius  
Console(config)#
```

### Related Commands

[enable password](#) - sets the password for changing command modes (240)

**authentication login** This command defines the login authentication method and precedence. Use the **no** form to restore the default.

### Syntax

**authentication login** {[local] [radius] [tacacs]}

**no authentication login**

**local** - Use local password.

**radius** - Use RADIUS server password.

**tacacs** - Use TACACS server password.

### Default Setting

Local

### Command Mode

Global Configuration

### Command Usage

- ◆ RADIUS uses UDP while TACACS+ uses TCP. UDP only offers best effort delivery, while TCP offers a connection-oriented transport. Also, note that RADIUS encrypts only the password in the access-request packet from the client to the server, while TACACS+ encrypts the entire body of the packet.
- ◆ RADIUS and TACACS+ logon authentication assigns a specific privilege level for each user name and password pair. The user name, password, and privilege level must be configured on the authentication server.
- ◆ You can specify three authentication methods in a single command to indicate the authentication sequence. For example, if you enter "**authentication login radius tacacs local**," the user name and password on the RADIUS server is verified first. If the RADIUS server is not available, then authentication is attempted on the TACACS+ server. If the TACACS+ server is not available, the local user name and password is checked.

### Example

```
Console(config)#authentication login radius  
Console(config)#
```

### Related Commands

[username](#) - for setting the local user names and passwords (241)

## RADIUS Client

Remote Authentication Dial-in User Service (RADIUS) is a logon authentication protocol that uses software running on a central server to control access to RADIUS-aware devices on the network. An authentication server contains a database of multiple user name/password pairs with associated privilege levels for each user or group that require management access to a switch.

Table 45: RADIUS Client Commands

Command	Function	Mode
<a href="#">radius-server acct-port</a>	Sets the RADIUS server network port	GC
<a href="#">radius-server auth-port</a>	Sets the RADIUS server network port	GC
<a href="#">radius-server host</a>	Specifies the RADIUS server	GC
<a href="#">radius-server key</a>	Sets the RADIUS encryption key	GC
<a href="#">radius-server encrypted-key</a>	Sets the RADIUS encryption key sent in encrypted text	GC
<a href="#">radius-server retransmit</a>	Sets the number of retries	GC
<a href="#">radius-server timeout</a>	Sets the interval between sending authentication requests	GC
<a href="#">show radius-server</a>	Shows the current RADIUS settings	PE

**radius-server acct-port** This command sets the RADIUS server network port for accounting messages. Use the **no** form to restore the default.

### Syntax

**radius-server acct-port** *port-number*

**no radius-server acct-port**

*port-number* - RADIUS server UDP port used for accounting messages.  
(Range: 1-65535)

### Default Setting

1813

### Command Mode

Global Configuration

### Example

```
Console(config)#radius-server acct-port 181
Console(config)#
```

**radius-server acct-port** This command sets the RADIUS server network port. Use the **no** form to restore the default.

### Syntax

**radius-server acct-port** *port-number*

**no radius-server acct-port**

*port-number* - RADIUS server UDP port used for authentication messages.  
(Range: 1-65535)

### Default Setting

1812

### Command Mode

Global Configuration

### Example

```
Console(config)#radius-server acct-port 181
Console(config)#
```

**radius-server host** This command specifies primary and backup RADIUS servers, and authentication and accounting parameters that apply to each server. Use the **no** form to remove a specified server, or to restore the default values.

### Syntax

**[no] radius-server** *index* **host** *host-ip-address* [**acct-port** *acct-port*] [**auth-port** *auth-port*] [**key** *key*] [**retransmit** *retransmit*] [**timeout** *timeout*]

*index* - Allows you to specify up to five servers. These servers are queried in sequence until a server responds or the retransmit period expires.

*host-ip-address* - IP address of server.

*acct-port* - RADIUS server UDP port used for accounting messages.  
(Range: 1-65535)

*auth-port* - RADIUS server UDP port used for authentication messages.  
(Range: 1-65535)

*key* - Encryption key used to authenticate logon access for client. Enclose any string containing blank spaces in double quotes.  
(Maximum length: 48 characters)

*retransmit* - Number of times the switch will try to authenticate logon access via the RADIUS server. (Range: 1-5)

*timeout* - Number of seconds the switch waits for a reply before resending a request. (Range: 1-10)

### Default Setting

auth-port - 1812  
acct-port - 1813  
timeout - 5 seconds  
retransmit - 3

### Command Mode

Global Configuration

### Example

```
Console(config)#radius-server 1 host 192.168.1.20 auth-port 181 timeout 10  
retransmit 5 key green  
Console(config)#
```

**radius-server key** This command sets the RADIUS encryption key. Use the **no** form to restore the default.

### Syntax

**radius-server key** *key-string*

**no radius-server key**

*key-string* - Encryption key used to authenticate logon access for client. Enclose any string containing blank spaces in double quotes. (Maximum length: 48 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#radius-server key green  
Console(config)#
```

**radius-server encrypted-key** This command sets the RADIUS encryption key to be sent in encrypted text. Use the **no** form to restore the default.

#### Syntax

**radius-server encrypted-key** *key-string*

**no radius-server key**

*key-string* - Encryption key sent in encrypted text and used to authenticate logon access for client. Enclose any character string using ASCII characters. (Maximum length: 48 characters, Base64 coding format)

#### Default Setting

None

#### Command Mode

Global Configuration

#### Example

```
Console(config)#radius-server encrypted-key Z3JlZW4=  
Console(config)#
```

**radius-server retransmit** This command sets the number of retries. Use the **no** form to restore the default.

#### Syntax

**radius-server retransmit** *number-of-retries*

**no radius-server retransmit**

*number-of-retries* - Number of times the switch will try to authenticate logon access via the RADIUS server. (Range: 1 - 5)

#### Default Setting

3

#### Command Mode

Global Configuration

#### Example

```
Console(config)#radius-server retransmit 5  
Console(config)#
```

**radius-server timeout** This command sets the interval between transmitting authentication requests to the RADIUS server. Use the **no** form to restore the default.

### Syntax

**radius-server timeout** *number-of-seconds*

**no radius-server timeout**

*number-of-seconds* - Number of seconds the switch waits for a reply before resending a request. (Range: 1-10)

### Default Setting

5

### Command Mode

Global Configuration

### Example

```
Console(config)#radius-server timeout 10
Console(config)#
```

**show radius-server** This command displays the current settings for the RADIUS server.

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show radius-server

Remote RADIUS Server Configuration:

Global Settings:
  Authentication Port Number : 1812
  Accounting Port Number    : 1813
  Retransmit Times          : 3
  Request Timeout           : 5

Server 1:
  Server IP Address         : 192.168.1.1
  Authentication Port Number : 1812
  Accounting Port Number    : 1813
  Retransmit Times          : 2
  Request Timeout           : 5

RADIUS Server Group:
Group Name                Member Index
-----
```

```
radius 1
Console#
```

## TACACS+ Client

Terminal Access Controller Access Control System (TACACS+) is a logon authentication protocol that uses software running on a central server to control access to TACACS-aware devices on the network. An authentication server contains a database of multiple user name/password pairs with associated privilege levels for each user or group that require management access to a switch.

**Table 46: TACACS+ Client Commands**

Command	Function	Mode
<code>tacacs-server host</code>	Specifies the TACACS+ server and optional parameters	GC
<code>tacacs-server key</code>	Sets the TACACS+ encryption key	GC
<code>tacacs-server encrypted-key</code>	Sets the TACACS+ encryption key sent in encrypted text	GC
<code>tacacs-server port</code>	Specifies the TACACS+ server network port	GC
<code>tacacs-server retransmit</code>	Sets the number of retries	GC
<code>tacacs-server timeout</code>	Sets the interval between sending authentication requests	GC
<code>show tacacs-server</code>	Shows the current TACACS+ settings	GC

**tacacs-server host** This command specifies the TACACS+ server and other optional parameters. Use the **no** form to remove the server, or to restore the default values.

### Syntax

**tacacs-server** *index* **host** *host-ip-address* [**key** *key*] [**port** *port-number*] [**retransmit** *retransmit*] [**timeout** *timeout*]

**no tacacs-server** *index*

*index* - The index for this server. (Range: 1-5)

*host-ip-address* - IPv4 or IPv6 address of a TACACS+ server.

*key* - Encryption key used to authenticate logon access for the client. Enclose any string containing blank spaces in double quotes. (Maximum length: 48 characters)

*port-number* - TACACS+ server TCP port used for authentication messages. (Range: 1-65535)

*retransmit* - Number of times the switch will try to authenticate logon access via the TACACS+ server. (Range: 1-5)

*timeout* - Number of seconds the switch waits for a reply before resending a request. (Range: 1-10)

### Default Setting

authentication port - 49  
timeout - 5 seconds  
retransmit - 3

### Command Mode

Global Configuration

### Example

```
Console(config)#tacacs-server 1 host 192.168.1.25 port 181 timeout 10  
retransmit 5 key green  
Console(config)#
```

**tacacs-server key** This command sets the TACACS+ encryption key. Use the **no** form to restore the default.

### Syntax

**tacacs-server key** *key-string*

**no tacacs-server key**

*key-string* - Encryption key used to authenticate logon access for the client.  
Enclose any string containing blank spaces in double quotes.  
(Maximum length: 48 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#tacacs-server key green  
Console(config)#
```

**tacacs-server encrypted-key** This command sets the TACACS+ encryption key to be sent in encrypted text. Use the **no** form to restore the default.

### Syntax

**tacacs-server encrypted-key** *key-string*

**no tacacs-server key**

*key-string* - Encryption key sent in encrypted text and used to authenticate logon access for client. Enclose any character string using ASCII characters. (Maximum length: 48 characters, Base64 coding format)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#tacacs-server encrypted-key Z3JlZW4=  
Console(config)#
```

**tacacs-server port** This command specifies the TACACS+ server network port. Use the **no** form to restore the default.

### Syntax

**tacacs-server port** *port-number*

**no tacacs-server port**

*port-number* - TACACS+ server TCP port used for authentication messages. (Range: 1-65535)

### Default Setting

49

### Command Mode

Global Configuration

### Example

```
Console(config)#tacacs-server port 181  
Console(config)#
```

**tacacs-server retransmit** This command sets the number of retries. Use the **no** form to restore the default.

#### Syntax

**tacacs-server retransmit** *number-of-retries*

**no tacacs-server retransmit**

*number-of-retries* - Number of times the switch will try to authenticate logon access via the TACACS+ server. (Range: 1 - 5)

#### Default Setting

3

#### Command Mode

Global Configuration

#### Example

```
Console(config)#tacacs-server retransmit 5  
Console(config)#
```

**tacacs-server timeout** This command sets the interval between transmitting authentication requests to the TACACS+ server. Use the **no** form to restore the default.

#### Syntax

**tacacs-server timeout** *number-of-seconds*

**no tacacs-server timeout**

*number-of-seconds* - Number of seconds the switch waits for a reply before resending a request. (Range: 1-10)

#### Default Setting

5

#### Command Mode

Global Configuration

#### Example

```
Console(config)#tacacs-server timeout 10  
Console(config)#
```

**show tacacs-server** This command displays the current settings for the TACACS+ server.

**Default Setting**

None

**Command Mode**

Privileged Exec

**Example**

```

Console#show tacacs-server

Remote TACACS+ Server Configuration:

Global Settings:
  Server Port Number : 49
  Retransmit Times   : 3
  Timeout            : 5

Server 1:
  Server IP Address  : 10.11.12.13
  Server Port Number : 49
  Retransmit Times   : 2
  Timeout            : 4

TACACS+ Server Group:
Group Name          Member Index
-----
tacacs+             1
Console#
  
```

**AAA**

The Authentication, Authorization, and Accounting (AAA) feature provides the main framework for configuring access control on the switch. The AAA functions require the use of configured RADIUS or TACACS+ servers in the network.

**Table 47: AAA Commands**

Command	Function	Mode
<a href="#">aaa accounting commands</a>	Enables accounting of Exec mode commands	GC
<a href="#">aaa accounting dot1x</a>	Enables accounting of 802.1X services	GC
<a href="#">aaa accounting exec</a>	Enables accounting of Exec services	GC
<a href="#">aaa accounting update</a>	Enables periodoc updates to be sent to the accounting server	GC
<a href="#">aaa authorization commands</a>	Enables accounting of Exec mode commands	GC
<a href="#">aaa authorization exec</a>	Enables authorization of Exec sessions	GC
<a href="#">aaa group server</a>	Groups security servers in to defined lists	GC
<a href="#">server</a>	Configures the IP address of a server in a group list	SG

Table 47: AAA Commands (Continued)

Command	Function	Mode
<code>accounting dot1x</code>	Applies an accounting method to an interface for 802.1X service requests	IC
<code>accounting commands</code>	Applies an accounting method to CLI commands entered by a user	Line
<code>accounting exec</code>	Applies an accounting method to local console, Telnet or SSH connections	Line
<code>authorization commands</code>	Applies an authorization method to CLI commands entered by a user	Line
<code>authorization exec</code>	Applies an authorization method to local console, Telnet or SSH connections	Line
<code>show accounting</code>	Displays all accounting information	PE
<code>show authorization</code>	Displays all authorization information	PE

**aaa accounting commands** This command enables the accounting of Exec mode commands. Use the **no** form to disable the accounting service.

### Syntax

**aaa accounting commands** *level* {**default** | *method-name*} **start-stop group** {**tacacs+** | *server-group*}

**no aaa accounting commands** *level* {**default** | *method-name*}

*level* - The privilege level for executing commands. (Range: 0-15)

**default** - Specifies the default accounting method for service requests.

*method-name* - Specifies an accounting method for service requests. (Range: 1-64 characters)

**start-stop** - Records accounting from starting point and stopping point.

**group** - Specifies the server group to use.

**tacacs+** - Specifies all TACACS+ hosts configured with the `tacacs-server host` command.

*server-group* - Specifies the name of a server group configured with the `aaa group server` command. (Range: 1-64 characters)

### Default Setting

Accounting is not enabled  
No servers are specified

### Command Mode

Global Configuration

### Command Usage

- ◆ The accounting of Exec mode commands is only supported by TACACS+ servers.
- ◆ Note that the **default** and *method-name* fields are only used to describe the accounting method(s) configured on the specified TACACS+ server, and do not actually send any information to the server about the methods to use.

### Example

```
Console(config)#aaa accounting commands 15 default start-stop group tacacs+
Console(config)#
```

**aaa accounting dot1x** This command enables the accounting of requested 802.1X services for network access. Use the **no** form to disable the accounting service.

### Syntax

```
aaa accounting dot1x {default | method-name}
start-stop group {radius | tacacs+ | server-group}
no aaa accounting dot1x {default | method-name}
```

**default** - Specifies the default accounting method for service requests.

*method-name* - Specifies an accounting method for service requests.  
(Range: 1-64 characters)

**start-stop** - Records accounting from starting point and stopping point.

**group** - Specifies the server group to use.

**radius** - Specifies all RADIUS hosts configure with the [radius-server host](#) command.

**tacacs+** - Specifies all TACACS+ hosts configure with the [tacacs-server host](#) command.

*server-group* - Specifies the name of a server group configured with the [aaa group server](#) command. (Range: 1-64 characters)

### Default Setting

Accounting is not enabled  
No servers are specified

### Command Mode

Global Configuration

### Command Usage

Note that the **default** and *method-name* fields are only used to describe the accounting method(s) configured on the specified RADIUS or TACACS+ servers, and do not actually send any information to the servers about the methods to use.

### Example

```
Console(config)#aaa accounting dot1x default start-stop group radius
Console(config)#
```

**aaa accounting exec** This command enables the accounting of requested Exec services for network access. Use the **no** form to disable the accounting service.

### Syntax

```
aaa accounting exec {default | method-name}
start-stop group {radius | tacacs+ | server-group}
no aaa accounting exec {default | method-name}
```

**default** - Specifies the default accounting method for service requests.

*method-name* - Specifies an accounting method for service requests.  
(Range: 1-64 characters)

**start-stop** - Records accounting from starting point and stopping point.

**group** - Specifies the server group to use.

**radius** - Specifies all RADIUS hosts configure with the [radius-server host](#) command.

**tacacs+** - Specifies all TACACS+ hosts configure with the [tacacs-server host](#) command.

*server-group* - Specifies the name of a server group configured with the [aaa group server](#) command. (Range: 1-64 characters)

### Default Setting

Accounting is not enabled  
No servers are specified

### Command Mode

Global Configuration

### Command Usage

- ◆ This command runs accounting for Exec service requests for the local console and Telnet connections.
- ◆ Note that the **default** and *method-name* fields are only used to describe the accounting method(s) configured on the specified RADIUS or TACACS+ servers, and do not actually send any information to the servers about the methods to use.

### Example

```
Console(config)#aaa accounting exec default start-stop group tacacs+
Console(config)#
```

**aaa accounting update** This command enables the sending of periodic updates to the accounting server. Use the **no** form to disable accounting updates.

### Syntax

**aaa accounting update** [**periodic** *interval*]

**no aaa accounting update**

*interval* - Sends an interim accounting record to the server at this interval.  
(Range: 1-2147483647 minutes)

### Default Setting

1 minute

### Command Mode

Global Configuration

### Command Usage

- ◆ When accounting updates are enabled, the switch issues periodic interim accounting records for all users on the system.
- ◆ Using the command without specifying an interim interval enables updates, but does not change the current interval setting.

### Example

```
Console(config)#aaa accounting update periodic 30
Console(config)#
```

**aaa authorization commands** This command enables the authorization of Exec mode commands. Use the **no** form to disable the authorization service.

### Syntax

**aaa authorization commands** *level* {**default** | *method-name*} **group** {**tacacs+** | *server-group*}

**no aaa authorization commands** *level* {**default** | *method-name*}

*level* - The privilege level for executing commands. (Range: 0-15)

**default** - Specifies the default authorization method for service requests.

*method-name* - Specifies an authorization method for service requests.  
(Range: 1-64 characters)

**group** - Specifies the server group to use.

**tacacs+** - Specifies all TACACS+ hosts configured with the [tacacs-server host](#) command.

*server-group* - Specifies the name of a server group configured with the [aaa group server](#) command. (Range: 1-64 characters)

**Default Setting**

Authorization is not enabled  
No servers are specified

**Command Mode**

Global Configuration

**Command Usage**

- ◆ The authorization of Exec mode commands is only supported by TACACS+ servers.
- ◆ Note that the **default** and *method-name* fields are only used to describe the authorization method(s) configured on the specified TACACS+ server, and do not actually send any information to the server about the methods to use.

**Example**

```
Console(config)#aaa authorization commands 15 default group tacacs+
Console(config)#
```

**aaa authorization exec** This command enables the authorization for Exec access. Use the **no** form to disable the authorization service.

**Syntax**

```
aaa authorization exec {default | method-name}
group {tacacs+ | server-group}
```

```
no aaa authorization exec {default | method-name}
```

**default** - Specifies the default authorization method for Exec access.

*method-name* - Specifies an authorization method for Exec access.  
(Range: 1-64 characters)

**group** - Specifies the server group to use.

**tacacs+** - Specifies all TACACS+ hosts configured with the [tacacs-server host](#) command.

*server-group* - Specifies the name of a server group configured with the [aaa group server](#) command. (Range: 1-64 characters)

**Default Setting**

Authorization is not enabled  
No servers are specified

**Command Mode**

Global Configuration

### Command Usage

- ◆ This command performs authorization to determine if a user is allowed to run an Exec shell for local console, Telnet, or SSH connections.
- ◆ AAA authentication must be enabled before authorization is enabled.
- ◆ If this command is issued without a specified named method, the default method list is applied to all interfaces or lines (where this authorization type applies), except those that have a named method explicitly defined.

### Example

```
Console(config)#aaa authorization exec default group tacacs+
Console(config)#
```

**aaa group server** Use this command to name a group of security server hosts. To remove a server group from the configuration list, enter the **no** form of this command.

### Syntax

**[no] aaa group server {radius | tacacs+} group-name**

**radius** - Defines a RADIUS server group.

**tacacs+** - Defines a TACACS+ server group.

*group-name* - A text string that names a security server group.  
(Range: 1-64 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#aaa group server radius tps
Console(config-sg-radius)#
```

**server** This command adds a security server to an AAA server group. Use the **no** form to remove the associated server from the group.

### Syntax

**[no] server {index | ip-address}**

*index* - Specifies the server index. (Range: RADIUS 1-5, TACACS+ 1)

*ip-address* - Specifies the host IP address of a server.

### Default Setting

None

### Command Mode

Server Group Configuration

### Command Usage

- ◆ When specifying the index for a RADIUS server, that server index must already be defined by the [radius-server host](#) command.
- ◆ When specifying the index for a TACACS+ server, that server index must already be defined by the [tacacs-server host](#) command.

### Example

```
Console(config)#aaa group server radius tps
Console(config-sg-radius)#server 10.2.68.120
Console(config-sg-radius)#
```

**accounting dot1x** This command applies an accounting method for 802.1X service requests on an interface. Use the **no** form to disable accounting on the interface.

### Syntax

**accounting dot1x** {**default** | *list-name*}

**no accounting dot1x**

**default** - Specifies the default method list created with the [aaa accounting dot1x](#) command.

*list-name* - Specifies a method list created with the [aaa accounting dot1x](#) command.

### Default Setting

None

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface ethernet 1/2
Console(config-if)#accounting dot1x tps
Console(config-if)#
```

**accounting commands** This command applies an accounting method to entered CLI commands. Use the **no** form to disable accounting for entered CLI commands.

### Syntax

**accounting commands** *level* {**default** | *list-name*}

**no accounting commands** *level*

*level* - The privilege level for executing commands. (Range: 0-15)

**default** - Specifies the default method list created with the [aaa accounting commands](#) command.

*list-name* - Specifies a method list created with the [aaa accounting commands](#) command.

### Default Setting

None

### Command Mode

Line Configuration

### Example

```
Console(config)#line console
Console(config-line)#accounting commands 15 default
Console(config-line)#
```

**accounting exec** This command applies an accounting method to local console, Telnet or SSH connections. Use the **no** form to disable accounting on the line.

### Syntax

**accounting exec** {**default** | *list-name*}

**no accounting exec**

**default** - Specifies the default method list created with the [aaa accounting exec](#) command.

*list-name* - Specifies a method list created with the [aaa accounting exec](#) command.

### Default Setting

None

### Command Mode

Line Configuration

### Example

```
Console(config)#line console
Console(config-line)#accounting exec tps
```

```
Console(config-line)#exit
Console(config)#line vty
Console(config-line)#accounting exec default
Console(config-line)#
```

**authorization commands** This command applies an authorization method to entered CLI commands. Use the **no** form to disable authorization for entered CLI commands.

### Syntax

**authorization commands** *level* {**default** | *list-name*}

**no authorization commands** *level*

*level* - The privilege level for executing commands. (Range: 0-15)

**default** - Specifies the default method list created with the **aaa authorization commands** command.

*list-name* - Specifies a method list created with the **aaa authorization commands** command.

### Default Setting

None

### Command Mode

Line Configuration

### Example

```
Console(config)#line console
Console(config-line)#authorization commands 15 default
Console(config-line)#
```

**authorization exec** This command applies an authorization method to local console, Telnet or SSH connections. Use the **no** form to disable authorization on the line.

### Syntax

**authorization exec** {**default** | *list-name*}

**no authorization exec**

**default** - Specifies the default method list created with the **aaa authorization exec** command.

*list-name* - Specifies a method list created with the **aaa authorization exec** command.

### Default Setting

None

## Command Mode

### Line Configuration

#### Example

```
Console(config)#line console
Console(config-line)#authorization exec tps
Console(config-line)#exit
Console(config)#line vty
Console(config-line)#authorization exec default
Console(config-line)#
```

**show accounting** This command displays the current accounting settings per function and per port.

#### Syntax

```
show accounting [commands [level]] |
[[dot1x [statistics [username user-name | interface interface]] |
exec [statistics] | statistics]
```

**commands** - Displays command accounting information.

*level* - Displays command accounting information for a specifiable command level.

**dot1x** - Displays dot1x accounting information.

**exec** - Displays Exec accounting records.

**statistics** - Displays accounting records.

*user-name* - Displays accounting records for a specifiable username.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### Default Setting

None

## Command Mode

Privileged Exec

#### Example

```
Console#show accounting
Accounting Type : dot1x
Method List    : default
Group List     : radius
Interface      : Eth 1/1
```

```

Method List      : tps
Group List       : radius
Interface        : Eth 1/2

Accounting Type  : EXEC
Method List      : default
Group List       : tacacs+
Interface        : vty

Accounting Type  : Commands 0
Method List      : default
Group List       : tacacs+
Interface        :
:
Accounting Type  : Commands 15
Method List      : default
Group List       : tacacs+
Interface        :

Console#

```

**show authorization** This command displays the current authorization settings per function and per port.

### Syntax

**show authorization [commands [*level*] | exec]**

**commands** - Displays command authorization information.

*level* - Displays command authorization information for a specifiable command level.

**exec** - Displays Exec authorization records.

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```

Console#show authorization
Authorization Type : EXEC
Method List       : default
Group List        : tacacs+
Interface         : vty

Authorization Type : Commands 0
Method List       : default
Group List        : tacacs+
Interface         :
:
Authorization Type : Commands 15
Method List       : default
Group List        : tacacs+
Interface         :

```

Console#

## Web Server

This section describes commands used to configure web browser management access to the switch.

**Table 48: Web Server Commands**

Command	Function	Mode
<code>ip http authentication</code>	Sets the method list for EXEC authorization of an EXEC session	GC
<code>ip http port</code>	Specifies the port to be used by the web browser interface	GC
<code>ip http server</code>	Allows the switch to be monitored or configured from a browser	GC
<code>ip http secure-port</code>	Specifies the TCP port number for HTTPS	GC
<code>ip http secure-server</code>	Enables HTTPS (HTTP/SSL) for encrypted communications	GC
<code>show authorization</code>	Displays all authorization information	PE
<code>show system</code>	Displays system information	NE, PE



**Note:** Users are automatically logged off of the HTTP server or HTTPS server if no input is detected for 300 seconds.

**ip http authentication** This command specifies the method list for EXEC authorization for starting an EXEC session used by the web browser interface. Use the **no** form to use the default port.

### Syntax

**ip http authentication aaa exec-authorization {default | *list-name*}**

**no ip http authentication aaa exec-authorization**

**default** - Specifies the default method list used for authorization requests.

*list-name* - Specifies a method list created with the [aaa authorization commands](#) command.

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#ip http authentication aaa exec-authorization default  
Console(config)#
```

### Related Commands

[aaa authorization commands \(259\)](#)

[ip http server \(268\)](#)

[show system \(129\)](#)

**ip http port** This command specifies the TCP port number used by the web browser interface. Use the **no** form to use the default port.

### Syntax

**ip http port** *port-number*

**no ip http port**

*port-number* - The TCP port to be used by the browser interface.  
(Range: 1-65535)

### Default Setting

80

### Command Mode

Global Configuration

### Example

```
Console(config)#ip http port 769  
Console(config)#
```

### Related Commands

[ip http server \(268\)](#)

[show system \(129\)](#)

**ip http server** This command allows this device to be monitored or configured from a browser. Use the **no** form to disable this function.

### Syntax

**[no] ip http server**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Example

```
Console(config)#ip http server
Console(config)#
```

### Related Commands

[ip http authentication \(267\)](#)

[show system \(129\)](#)

**ip http secure-port** This command specifies the TCP port number used for HTTPS connection to the switch's web interface. Use the **no** form to restore the default port.

### Syntax

**ip http secure-port** *port\_number*

**no ip http secure-port**

*port\_number* – The TCP port used for HTTPS. (Range: 1-65535, except for the following reserved ports: 1 and 25 - Linux kernel, 23 - Telnet, 80 - HTTP)

### Default Setting

443

### Command Mode

Global Configuration

### Command Usage

- ◆ You cannot configure the HTTP and HTTPS servers to use the same port.
- ◆ If you change the HTTPS port number, clients attempting to connect to the HTTPS server must specify the port number in the URL, in this format: **https://device:port\_number**

### Example

```
Console(config)#ip http secure-port 1000
Console(config)#
```

### Related Commands

[ip http secure-server \(269\)](#)

[show system \(129\)](#)

**ip http secure-server** This command enables the secure hypertext transfer protocol (HTTPS) over the Secure Socket Layer (SSL), providing secure access (i.e., an encrypted connection) to the switch's web interface. Use the **no** form to disable this function.

### Syntax

**[no] ip http secure-server**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Both HTTP and HTTPS service can be enabled independently on the switch. However, you cannot configure the HTTP and HTTPS servers to use the same UDP port.
- ◆ If you enable HTTPS, you must indicate this in the URL that you specify in your browser: **https://device[:port\_number]**
- ◆ When you start HTTPS, the connection is established in this way:
  - The client authenticates the server using the server's digital certificate.
  - The client and server negotiate a set of security protocols to use for the connection.
  - The client and server generate session keys for encrypting and decrypting data.
- ◆ The client and server establish a secure encrypted connection.

A padlock icon should appear in the status bar for Internet Explorer 9, Mozilla Firefox 52, Google Chrome 54, or Opera 41, or more recent versions.

The following web browsers and operating systems currently support HTTPS:

**Table 49: HTTPS System Support**

Web Browser	Operating System
Internet Explorer 9 or later	Windows 7, 8, 10
Mozilla Firefox 52 or later	Windows 7, 8, 10, Linux
Google Chrome 54 or later	Windows 7, 8, 10
Opera 41 or later	Windows 7, 8, 10, Linux

- ◆ To specify a secure-site certificate, see "Replacing the Default Secure-site Certificate" in the *Web Management Guide*. Also refer to the [copy tftp https-certificate](#) command.
- ◆ Connection to the web interface is not supported for HTTPS using an IPv6 link local address.

### Example

```
Console(config)#ip http secure-server
Console(config)#
```

### Related Commands

[ip http secure-port \(269\)](#)  
[copy tftp https-certificate \(137\)](#)  
[show system \(129\)](#)

## Telnet Server

This section describes commands used to configure Telnet management access to the switch.

**Table 50: Telnet Server Commands**

Command	Function	Mode
<a href="#">ip telnet max-sessions</a>	Specifies the maximum number of Telnet sessions that can simultaneously connect to this system	GC
<a href="#">ip telnet port</a>	Specifies the port to be used by the Telnet interface	GC
<a href="#">ip telnet server</a>	Allows the switch to be monitored or configured from Telnet	GC
<a href="#">telnet (client)</a>	Accesses a remote device using a Telnet connection	PE
<a href="#">show ip telnet</a>	Displays configuration settings for the Telnet server	PE



**Note:** This switch also supports a Telnet client function. A Telnet connection can be made from this switch to another device by entering the **telnet** command at the Privileged Exec configuration level.

**ip telnet max-sessions** This command specifies the maximum number of Telnet sessions that can simultaneously connect to this system. Use the **no** form to restore the default setting.

### Syntax

**ip telnet max-sessions** *session-count*

**no ip telnet max-sessions**

*session-count* - The maximum number of allowed Telnet session.  
(Range: 0-8)

### Default Setting

8 sessions

### Command Mode

Global Configuration

### Command Usage

A maximum of eight sessions can be concurrently opened for Telnet and Secure Shell (i.e., both Telnet and SSH share a maximum number of eight sessions).

### Example

```
Console(config)#ip telnet max-sessions 1  
Console(config)#
```

**ip telnet port** This command specifies the TCP port number used by the Telnet interface. Use the **no** form to use the default port.

### Syntax

**ip telnet port** *port-number*

**no telnet port**

*port-number* - The TCP port number to be used by the browser interface.  
(Range: 1-65535)

### Default Setting

23

### Command Mode

Global Configuration

### Example

```
Console(config)#ip telnet port 123  
Console(config)#
```

**ip telnet server** This command allows this device to be monitored or configured from Telnet. Use the **no** form to disable this function.

### Syntax

**[no] ip telnet server**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Example

```
Console(config)#ip telnet server
Console(config)#
```

**telnet (client)** This command accesses a remote device using a Telnet connection.

### Syntax

**telnet** *host*

*host* - IP address or alias of a remote device.

### Command Mode

Privileged Exec

### Example

```
Console#telnet 192.168.2.254
Connect To 192.168.2.254...

*****

WARNING - MONITORED ACTIONS AND ACCESSES

User Access Verification

Username:

Console(config)#
```

**show ip telnet** This command displays the configuration settings for the Telnet server.

### Command Mode

Normal Exec, Privileged Exec

### Example

```
Console#show ip telnet
IP Telnet Configuration:

Telnet Status: Enabled
Telnet Service Port: 23
Telnet Max Session: 8
Console#
```

## Secure Shell

This section describes the commands used to configure the SSH server. Note that you also need to install a SSH client on the management station when using this protocol to configure the switch.



**Note:** The switch supports only SSH Version 2.0 clients.

**Table 51: Secure Shell Commands**

Command	Function	Mode
<code>ip ssh authentication-retries</code>	Specifies the number of retries allowed by a client	GC
<code>ip ssh server</code>	Enables the SSH server on the switch	GC
<code>ip ssh timeout</code>	Specifies the authentication timeout for the SSH server	GC
<code>copy tftp public-key</code>	Copies the user's public key from a TFTP server to the switch	PE
<code>delete public-key</code>	Deletes the public key for the specified user	PE
<code>disconnect</code>	Terminates a line connection	PE
<code>ip ssh crypto host-key generate</code>	Generates the host key	PE
<code>ip ssh crypto zeroize</code>	Clears the host key from RAM	PE
<code>ip ssh save host-key</code>	Saves the host key from RAM to flash memory	PE
<code>show ip ssh</code>	Displays the status of the SSH server and the configured values for authentication timeout and retries	PE
<code>show public-key</code>	Shows the public key for the specified user or for the host	PE
<code>show ssh</code>	Displays the status of current SSH sessions	PE
<code>show users</code>	Shows SSH users, including privilege level and public key type	PE

### *Configuration Guidelines*

The SSH server on this switch supports both password and public key authentication. If password authentication is specified by the SSH client, then the password can be authenticated either locally or via a RADIUS or TACACS+ remote authentication server, as specified by the `authentication login` command. If public key authentication is specified by the client, then you must configure authentication keys on both the client and the switch as described in the following section. Note that regardless of whether you use public key or password authentication, you still have to generate authentication keys on the switch and enable the SSH server.

To use the SSH server, complete these steps:

1. Generate a Host Key Pair – Use the `ip ssh crypto host-key generate` command to create a host public/private key pair.
2. Provide Host Public Key to Clients – Many SSH client programs automatically import the host public key during the initial connection setup with the switch. Otherwise, you need to manually create a known hosts file on the management station and place the host public key in it. An entry for a public key in the known hosts file would appear similar to the following example:

```
10.1.0.54 1024 35 15684995401867669259333946775054617325313674890836547254
15020245593199868544358361651999923329781766065830956
108259132128902337654680172627257141342876294130119619556678259566410486957427
888146206519417467729848654686157177393901647793559423035774130980227370877945
4524083971752646358058176716709574804776117
```

3. Import Client's Public Key to the Switch – Use the `copy tftp public-key` command to copy a file containing the public key for all the SSH client's granted management access to the switch. (Note that these clients must be configured locally on the switch with the `username` command.) The clients are subsequently authenticated using these keys. The current firmware only accepts public key files based on standard UNIX format as shown in the following example for an RSA key:

```
1024 35
134108168560989392104094492015542534763164192187295892114317388005553616163105
177594083868631109291232226828519254374603100937187721199696317813662774141689
851320491172048303392543241016379975923714490119380060902539484084827178194372
288402533115952134861022902978982721353267131629432532818915045306393916643
steve@192.168.1.19
```

4. Set the Optional Parameters – Set other optional parameters, including the authentication timeout and the number of retries.
5. Enable SSH Service – Use the `ip ssh server` command to enable the SSH server on the switch.
6. *Authentication* – One of the following authentication methods is employed:

*Password Authentication (for SSH V2 Clients)*

- a. The client sends its password to the server.
- b. The switch compares the client's password to those stored in memory.
- c. If a match is found, the connection is allowed.



**Note:** To use SSH with only password authentication, the host public key must still be given to the client, either during initial connection or manually entered into the known host file. However, you do not need to configure the client's keys.

*Public Key Authentication* – When an SSH client attempts to contact the switch, the SSH server uses the host key pair to negotiate a session key and encryption method. Only clients that have a private key corresponding to the public keys stored on the switch can access it. The following exchanges take place during this process:

#### *Authenticating SSH v2 Clients*

- a. The client first queries the switch to determine if public key authentication using a preferred algorithm is acceptable.
- b. If the specified algorithm is supported by the switch, it notifies the client to proceed with the authentication process. Otherwise, it rejects the request.
- c. The client sends a signature generated using the private key to the switch.
- d. When the server receives this message, it checks whether the supplied key is acceptable for authentication, and if so, it then checks whether the signature is correct. If both checks succeed, the client is authenticated.



**Note:** The SSH server supports up to eight client sessions. The maximum number of client sessions includes both current Telnet sessions and SSH sessions.

**Note:** The SSH server can be accessed using any configured IPv4 or IPv6 interface address on the switch.

**ip ssh authentication-retries** This command configures the number of times the SSH server attempts to reauthenticate a user. Use the **no** form to restore the default setting.

#### Syntax

**ip ssh authentication-retries** *count*

**no ip ssh authentication-retries**

*count* – The number of authentication attempts permitted after which the interface is reset. (Range: 1-5)

#### Default Setting

3

#### Command Mode

Global Configuration

#### Example

```
Console(config)#ip ssh authentication-retries 2
Console(config)#
```

### Related Commands

[show ip ssh \(280\)](#)

**ip ssh server** This command enables the Secure Shell (SSH) server on this switch. Use the **no** form to disable this service.

### Syntax

**[no] ip ssh server**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ The SSH server supports up to eight client sessions. The maximum number of client sessions includes both current Telnet sessions and SSH sessions.
- ◆ The SSH server uses RSA for key exchange when the client first establishes a connection with the switch, and then negotiates with the client to select either DES (56-bit) or 3DES (168-bit) for data encryption.
- ◆ You must generate RSA host keys before enabling the SSH server.

### Example

```
Console#ip ssh crypto host-key generate
Console#configure
Console(config)#ip ssh server
Console(config)#
```

### Related Commands

[ip ssh crypto host-key generate \(278\)](#)

[show ssh \(281\)](#)

**ip ssh timeout** This command configures the timeout for the SSH server. Use the **no** form to restore the default setting.

### Syntax

**ip ssh timeout** *seconds*

**no ip ssh timeout**

*seconds* – The timeout for client response during SSH negotiation.  
(Range: 1-120)

### Default Setting

120 seconds

### Command Mode

Global Configuration

### Command Usage

The **timeout** specifies the interval the switch will wait for a response from the client during the SSH negotiation phase. Once an SSH session has been established, the timeout for user input is controlled by the [exec-timeout](#) command for vty sessions.

### Example

```
Console(config)#ip ssh timeout 60
Console(config)#
```

### Related Commands

[exec-timeout \(150\)](#)

[show ip ssh \(280\)](#)

**delete public-key** This command deletes the specified user's public key.

### Syntax

**delete public-key** *username*

*username* – Name of an SSH user. (Range: 1-8 characters)

### Default Setting

Deletes the RSA key.

### Command Mode

Privileged Exec

### Example

```
Console#delete public-key admin
Console#
```

**ip ssh crypto host-key generate** This command generates the host key pair (i.e., public and private).

### Syntax

**ip ssh crypto host-key generate**

### Default Setting

Generates the RSA key pairs.

### Command Mode

Privileged Exec

### Command Usage

- ◆ The switch uses RSA for SSHv2 clients.
- ◆ This command stores the host key pair in memory (i.e., RAM). Use the [ip ssh save host-key](#) command to save the host key pair to flash memory.
- ◆ Some SSH client programs automatically add the public key to the known hosts file as part of the configuration process. Otherwise, you must manually create a known hosts file and place the host public key in it.
- ◆ The SSH server uses this host key to negotiate a session key and encryption method with the client trying to connect to it.

### Example

```
Console#ip ssh crypto host-key generate
Console#
```

### Related Commands

[ip ssh crypto zeroize \(279\)](#)

[ip ssh save host-key \(280\)](#)

**ip ssh crypto zeroize** This command clears the host key from memory (i.e. RAM).

### Syntax

**ip ssh crypto zeroize**

### Default Setting

Clears the RSA key.

### Command Mode

Privileged Exec

### Command Usage

- ◆ This command clears the host key from volatile memory (RAM). Use the [no ip ssh save host-key](#) command to clear the host key from flash memory.
- ◆ The SSH server must be disabled before you can execute this command.

### Example

```
Console#ip ssh crypto zeroize
Console#
```

### Related Commands

[ip ssh crypto host-key generate \(278\)](#)  
[ip ssh save host-key \(280\)](#)  
[no ip ssh server \(277\)](#)

**ip ssh save host-key** This command saves the host key from RAM to flash memory.

### Syntax

**ip ssh save host-key**

### Default Setting

Saves the RSA key.

### Command Mode

Privileged Exec

### Example

```
Console#ip ssh save host-key  
Console#
```

### Related Commands

[ip ssh crypto host-key generate \(278\)](#)

**show ip ssh** This command displays the connection settings used when authenticating client access to the SSH server.

### Command Mode

Privileged Exec

### Example

```
Console#show ip ssh  
SSH Enabled - Version 2.0  
Negotiation Timeout : 120 seconds; Authentication Retries : 3  
Console#
```

**show public-key** This command shows the public key for the specified user or for the host.

### Syntax

**show public-key** [**user** *username*]| **host**

*username* – Name of an SSH user. (Range: 1-32 characters)

### Default Setting

Shows all public keys.

### Command Mode

Privileged Exec

### Command Usage

If no parameters are entered, all keys are displayed. If the user keyword is entered, but no user name is specified, then the public keys for all users are displayed.

### Example

```

Console#show public-key host
Host:
RSA:
-----BEGIN RSA PUBLIC KEY-----
MIIBCgKCAQEAspl/UuyjRjzxtmsLQUc28rtCzK0zxV4SACwLE4jPdJacX7yIMgyD
P+6wcj6QhZ5LYTByYltgZ8OpvhgcTcLbOPp/LWEgII+ntzUiJGIggXgggZtWwsTp
XC9WXgHzknKAvfI0zk2Ec/x4ryvSlWazEb0ygnozDPc8ZRV2iST+nzAKSCb3Oii3
SmpGk/NOzFK4OK3ouX1692Pfb64QSDXyi1BcmR0nMU943xC/F8JpTLKxQLiZSnSa
Ef1dcbOIXHKd7dedw4MauUhzDznIawAEu6R4d2HSjxDm9pOIio8he860+S8gpBSN
9kSgNXU7o3BarVvYZo2hPaEOLAFBv+tklQIDAQAB
-----END RSA PUBLIC KEY-----

Console#

```

**show ssh** This command displays the current SSH server connections.

### Command Mode

Privileged Exec

### Example

```

Console#show ssh
Connection Version State Username Encryption
1 2.0 Session-Started admin ctos aes128-cbc-hmac-md5
stoc aes128-cbc-hmac-md5

Console#

```

**Table 52: show ssh - display description**

Field	Description
Connection	The session number. A total of eight SSH and Telnet sessions are allowed.
Version	The Secure Shell version number.
State	The authentication negotiation state. (Values: Negotiation-Started, Authentication-Started, Session-Started)
Username	The user name of the client.

## 802.1X Port Authentication

The switch supports IEEE 802.1X (dot1x) port-based access control that prevents unauthorized access to the network by requiring users to first submit credentials for authentication. Client authentication is controlled centrally by a RADIUS server using EAP (Extensible Authentication Protocol).

**Table 53: 802.1X Port Authentication Commands**

Command	Function	Mode
<i>General Commands</i>		
<code>dot1x default</code>	Resets all dot1x parameters to their default values	GC
<code>dot1x eapol-pass-through</code>	Passes EAPOL frames to all ports in STP forwarding state when dot1x is globally disabled	GC
<code>dot1x system-auth-control</code>	Enables dot1x globally on the switch.	GC
<i>Authenticator Commands</i>		
<code>dot1x intrusion-action</code>	Sets the port response to intrusion when authentication fails	IC
<code>dot1x max-reauth-req</code>	Sets the maximum number of times that the switch sends an EAP-request/identity frame to the client before restarting the authentication process	IC
<code>dot1x max-req</code>	Sets the maximum number of times that the switch retransmits an EAP request/identity packet to the client before it times out the authentication session	IC
<code>dot1x operation-mode</code>	Allows single or multiple hosts on an dot1x port	IC
<code>dot1x port-control</code>	Sets dot1x mode for a port interface	IC
<code>dot1x re-authentication</code>	Enables re-authentication for all ports	IC
<code>dot1x timeout quiet-period</code>	Sets the time that a switch port waits after the Max Request Count has been exceeded before attempting to acquire a new client	IC
<code>dot1x timeout re-authperiod</code>	Sets the time period after which a connected client must be re-authenticated	IC
<code>dot1x timeout supp-timeout</code>	Sets the interval for a supplicant to respond	IC
<code>dot1x timeout tx-period</code>	Sets the time period during an authentication session that the switch waits before re-transmitting an EAP packet	IC

**Table 53: 802.1X Port Authentication Commands (Continued)**

Command	Function	Mode
<code>dot1x re-authenticate</code>	Forces re-authentication on specific ports	PE
<i>Supplicant Commands</i>		
<code>dot1x identity profile</code>	Configures dot1x supplicant user name and password	GC
<code>dot1x max-start</code>	Sets the maximum number of times that a port supplicant will send an EAP start frame to the client	IC
<code>dot1x pae supplicant</code>	Enables dot1x supplicant mode on an interface	IC
<code>dot1x timeout auth-period</code>	Sets the time that a supplicant port waits for a response from the authenticator	IC
<code>dot1x timeout held-period</code>	Sets the time a port waits after the maximum start count has been exceeded before attempting to find another authenticator	IC
<code>dot1x timeout start-period</code>	Sets the time that a supplicant port waits before resending an EAPOL start frame to the authenticator	IC
<i>Information Display Commands</i>		
<code>show dot1x</code>	Shows all dot1x related information	PE

## General Commands

**dot1x default** This command sets all configurable dot1x authenticator global and port settings to their default values.

### Command Mode

Global Configuration

### Command Usage

This command resets the following commands to their default settings:

- ◆ `dot1x system-auth-control`
- ◆ `dot1x eapol-pass-through`
- ◆ `dot1x port-control`
- ◆ `dot1x port-control multi-host max-count`
- ◆ `dot1x operation-mode`
- ◆ `dot1x max-req`
- ◆ `dot1x timeout quiet-period`
- ◆ `dot1x timeout tx-period`
- ◆ `dot1x timeout re-authperiod`
- ◆ `dot1x timeout sup-timeout`
- ◆ `dot1x re-authentication`
- ◆ `dot1x intrusion-action`

### Example

```
Console(config)#dot1x default  
Console(config)#
```

**dot1x eapol-pass-through** This command passes EAPOL frames through to all ports in STP forwarding state when dot1x is globally disabled. Use the **no** form to restore the default.

### Syntax

**[no] dot1x eapol-pass-through**

### Default Setting

Discards all EAPOL frames when dot1x is globally disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ When this device is functioning as intermediate node in the network and does not need to perform dot1x authentication, the **dot1x eapol pass-through** command can be used to forward EAPOL frames from other switches on to the authentication servers, thereby allowing the authentication process to still be carried out by switches located on the edge of the network.
- ◆ When this device is functioning as an edge switch but does not require any attached clients to be authenticated, the **no dot1x eapol-pass-through** command can be used to discard unnecessary EAPOL traffic.

### Example

This example instructs the switch to pass all EAPOL frame through to any ports in STP forwarding state.

```
Console(config)#dot1x eapol-pass-through  
Console(config)#
```

**dot1x system-auth-control** This command enables IEEE 802.1X port authentication globally on the switch. Use the **no** form to restore the default.

### Syntax

**[no] dot1x system-auth-control**

### Default Setting

Disabled

## Command Mode

Global Configuration

### Example

```
Console(config)#dot1x system-auth-control
Console(config)#
```

## Authenticator Commands

**dot1x intrusion-action** This command sets the port's response to a failed authentication, either to block all traffic, or to assign all traffic for the port to a guest VLAN. Use the **no** form to reset the default.

### Syntax

**dot1x intrusion-action** {**block-traffic** | **guest-vlan**}

**no dot1x intrusion-action**

**block-traffic** - Blocks traffic on this port.

**guest-vlan** - Assigns the user to the Guest VLAN.

### Default

block-traffic

### Command Mode

Interface Configuration

### Command Usage

- ◆ For guest VLAN assignment to be successful, the VLAN must be configured and set as active (see the [vlan database](#) command) and assigned as the guest VLAN for the port (see the [network-access guest-vlan](#) command).
- ◆ A port can only be assigned to the guest VLAN in case of failed authentication, if [switchport mode](#) is set to Hybrid.

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x intrusion-action guest-vlan
Console(config-if)#
```

**dot1x max-reauth-req** This command sets the maximum number of times that the switch sends an EAP-request/identity frame to the client before restarting the authentication process. Use the **no** form to restore the default.

#### Syntax

**dot1x max-reauth-req** *count*

**no dot1x max-reauth-req**

*count* – The maximum number of requests (Range: 1-10)

#### Default

2

#### Command Mode

Interface Configuration

#### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x max-reauth-req 2
Console(config-if)#
```

**dot1x max-req** This command sets the maximum number of times the switch port will retransmit an EAP request/identity packet to the client before it times out the authentication session. Use the **no** form to restore the default.

#### Syntax

**dot1x max-req** *count*

**no dot1x max-req**

*count* – The maximum number of requests (Range: 1-10)

#### Default

2

#### Command Mode

Interface Configuration

#### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x max-req 2
Console(config-if)#
```

**dot1x operation-mode** This command allows hosts (clients) to connect to an 802.1X-authorized port. Use the **no** form with no keywords to restore the default to single host. Use the **no** form with the **multi-host max-count** keywords to restore the default maximum count.

### Syntax

**dot1x operation-mode** {**single-host** | **multi-host** [**max-count** *count*] | **mac-based-auth**}

**no dot1x operation-mode** [**multi-host max-count**]

**single-host** – Allows only a single host to connect to this port.

**multi-host** – Allows multiple host to connect to this port.

**max-count** – Keyword for the maximum number of hosts.

*count* – The maximum number of hosts that can connect to a port.  
(Range: 1-1024; Default: 5)

**mac-based** – Allows multiple hosts to connect to this port, with each host needing to be authenticated.

### Default

Single-host

### Command Mode

Interface Configuration

### Command Usage

- ◆ The “max-count” parameter specified by this command is only effective if the dot1x mode is set to “auto” by the [dot1x port-control](#) command.
- ◆ In “multi-host” mode, only one host connected to a port needs to pass authentication for all other hosts to be granted network access. Similarly, a port can become unauthorized for all hosts if one attached host fails re-authentication or sends an EAPOL logoff message.
- ◆ In “mac-based-auth” mode, each host connected to a port needs to pass authentication. The number of hosts allowed access to a port operating in this mode is limited only by the available space in the secure address table (i.e., up to 1024 addresses).

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x operation-mode multi-host max-count 10
Console(config-if)#
```

**dot1x port-control** This command sets the dot1x mode on a port interface. Use the **no** form to restore the default.

### Syntax

**dot1x port-control** {**auto** | **force-authorized** | **force-unauthorized**}

**no dot1x port-control**

**auto** – Requires a dot1x-aware connected client to be authorized by the RADIUS server. Clients that are not dot1x-aware will be denied access.

**force-authorized** – Configures the port to grant access to all clients, either dot1x-aware or otherwise.

**force-unauthorized** – Configures the port to deny access to all clients, either dot1x-aware or otherwise.

### Default

force-authorized

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x port-control auto
Console(config-if)#
```

**dot1x re-authentication** This command enables periodic re-authentication for a specified port. Use the **no** form to disable re-authentication.

### Syntax

**[no] dot1x re-authentication**

### Command Mode

Interface Configuration

### Command Usage

- ◆ The re-authentication process verifies the connected client's user ID and password on the RADIUS server. During re-authentication, the client remains connected the network and the process is handled transparently by the dot1x client software. Only if re-authentication fails is the port blocked.
- ◆ The connected client is re-authenticated after the interval specified by the **dot1x timeout re-authperiod** command. The default is 3600 seconds.

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x re-authentication
Console(config-if)#
```

### Related Commands

[dot1x timeout re-authperiod \(289\)](#)

**dot1x timeout quiet-period** This command sets the time that a switch port waits after the maximum request count (see [page 286](#)) has been exceeded before attempting to acquire a new client. Use the **no** form to reset the default.

### Syntax

**dot1x timeout quiet-period** *seconds*

**no dot1x timeout quiet-period**

*seconds* - The number of seconds. (Range: 1-65535)

### Default

60 seconds

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x timeout quiet-period 350
Console(config-if)#
```

**dot1x timeout re-authperiod** This command sets the time period after which a connected client must be re-authenticated. Use the **no** form of this command to reset the default.

### Syntax

**dot1x timeout re-authperiod** *seconds*

**no dot1x timeout re-authperiod**

*seconds* - The number of seconds. (Range: 1-65535)

### Default

3600 seconds

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x timeout re-authperiod 300
Console(config-if)#
```

**dot1x timeout supp-timeout** This command sets the time that an interface on the switch waits for a response to an EAP request from a client before re-transmitting an EAP packet. Use the **no** form to reset to the default value.

### Syntax

**dot1x timeout supp-timeout** *seconds*

**no dot1x timeout supp-timeout**

*seconds* - The number of seconds. (Range: 1-65535)

### Default

30 seconds

### Command Mode

Interface Configuration

### Command Usage

This command sets the timeout for EAP-request frames other than EAP-request/identity frames. If dot1x authentication is enabled on a port, the switch will initiate authentication when the port link state comes up. It will send an EAP-request/identity frame to the client to request its identity, followed by one or more requests for authentication information. It may also send other EAP-request frames to the client during an active connection as required for reauthentication.

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x timeout supp-timeout 300
Console(config-if)#
```

**dot1x timeout tx-period** This command sets the time that an interface on the switch waits during an authentication session before re-transmitting an EAP packet. Use the **no** form to reset to the default value.

### Syntax

**dot1x timeout tx-period** *seconds*

**no dot1x timeout tx-period**

*seconds* - The number of seconds. (Range: 1-65535)

### Default

30 seconds

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x timeout tx-period 300
Console(config-if)#
```

**dot1x re-authenticate** This command forces re-authentication on all ports or a specific interface.

### Syntax

**dot1x re-authenticate** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Command Usage

The re-authentication process verifies the connected client's user ID and password on the RADIUS server. During re-authentication, the client remains connected the network and the process is handled transparently by the dot1x client software. Only if re-authentication fails is the port blocked.

### Example

```
Console#dot1x re-authenticate
Console#
```

## Supplicant Commands

**dot1x identity profile** This command sets the dot1x supplicant user name and password. Use the **no** form to delete the identity settings.

### Syntax

**dot1x identity profile** {**username** *username* | **password** *password* | **encrypted-password** *encrypted-pw*}

**no dot1x identity profile** {**username** | **password**}

*username* - Specifies the supplicant user name. (Range: 1-8 characters)

*password* - Specifies the supplicant password. (Range: 1-8 characters)

*encrypted-pw* - Specifies the supplicant password in encrypted text. (Range: 1-8 characters)

### Default

No user name or password

### Command Mode

Global Configuration

### Command Usage

The global supplicant user name and password are used to identify this switch as a supplicant when responding to an MD5 challenge from the authenticator. These parameters must be set when this switch passes client authentication requests to another authenticator on the network (see the [dot1x pae supplicant](#) command).

### Example

```
Console(config)#dot1x identity profile username steve
Console(config)#dot1x identity profile password excess
Console(config)#
```

**dot1x max-start** This command sets the maximum number of times that a port supplicant will send an EAP start frame to the client before assuming that the client is 802.1X unaware. Use the **no** form to restore the default value.

### Syntax

**dot1x max-start** *count*

**no dot1x max-start**

*count* - Specifies the maximum number of EAP start frames. (Range: 1-65535)

### Default

3

## Command Mode

### Interface Configuration

### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x max-start 10
Console(config-if)#
```

**dot1x pae supplicant** This command enables dot1x supplicant mode on a port. Use the **no** form to disable dot1x supplicant mode on a port.

### Syntax

**[no] dot1x pae supplicant**

### Default

Disabled

## Command Mode

### Interface Configuration

### Command Usage

- ◆ When devices attached to a port must submit requests to another authenticator on the network, configure the identity profile parameters (see [dot1x identity profile](#) command) which identify this switch as a supplicant, and enable dot1x supplicant mode for those ports which must authenticate clients through a remote authenticator using this command. In this mode the port will not respond to dot1x messages meant for an authenticator.
- ◆ This switch can be configured to serve as the authenticator on selected ports by setting the control mode to “auto” (see the [dot1x port-control](#) command), and as a supplicant on other ports by the setting the control mode to “force-authorized” and enabling dot1x supplicant mode with this command.
- ◆ A port cannot be configured as a dot1x supplicant if it is a member of a trunk or LACP is enabled on the port.

### Example

```
Console(config)#interface ethernet 1/2
Console(config-if)#dot1x pae supplicant
Console(config-if)#
```

**dot1x timeout auth-period** This command sets the time that a supplicant port waits for a response from the authenticator. Use the **no** form to restore the default setting.

#### Syntax

**dot1x timeout auth-period** *seconds*

**no dot1x timeout auth-period**

*seconds* - The number of seconds. (Range: 1-65535)

#### Default

30 seconds

#### Command Mode

Interface Configuration

#### Command Usage

This command sets the time that the supplicant waits for a response from the authenticator for packets other than EAPOL-Start.

#### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x timeout auth-period 60
Console(config-if)#
```

**dot1x timeout held-period** This command sets the time that a supplicant port waits before resending its credentials to find a new authenticator. Use the **no** form to reset the default.

#### Syntax

**dot1x timeout held-period** *seconds*

**no dot1x timeout held-period**

*seconds* - The number of seconds. (Range: 1-65535)

#### Default

60 seconds

#### Command Mode

Interface Configuration

#### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x timeout held-period 120
Console(config-if)#
```

**dot1x timeout start-period** This command sets the time that a supplicant port waits before resending an EAPOL start frame to the authenticator. Use the **no** form to restore the default setting.

#### Syntax

**dot1x timeout start-period** *seconds*

**no dot1x timeout start-period**

*seconds* - The number of seconds. (Range: 1-65535)

#### Default

30 seconds

#### Command Mode

Interface Configuration

#### Example

```
Console(config)#interface eth 1/2
Console(config-if)#dot1x timeout start-period 60
Console(config-if)#
```

## Information Display Commands

**show dot1x** This command shows general port authentication related settings on the switch or a specific interface.

#### Syntax

**show dot1x** [**statistics**] [**interface** *interface*]

**statistics** - Displays dot1x status for each port.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Command Usage

This command displays the following information:

- ◆ *Global 802.1X Parameters* – Shows whether or not 802.1X port authentication is globally enabled on the switch ([page 284](#)).

- ◆ *Authenticator Parameters* – Shows whether or not EAPOL pass-through is enabled ([page 284](#)).
- ◆ *Supplicant Parameters* – Shows the supplicant user name used when the switch responds to an MD5 challenge from an authenticator ([page 292](#)).
- ◆ *802.1X Port Summary* – Displays the port access control parameters for each interface that has enabled 802.1X, including the following items:
  - Type – Administrative state for port access control (Enabled, Authenticator, or Supplicant).
  - Operation Mode – Allows single or multiple hosts ([page 287](#)).
  - Control Mode – Dot1x port control mode ([page 288](#)).
  - Authorized – Authorization status (yes or n/a - not authorized).
- ◆ *802.1X Port Details* – Displays the port access control parameters for each interface, including the following items:
  - Reauthentication – Periodic re-authentication ([page 288](#)).
  - Reauth Period – Time after which a connected client must be re-authenticated ([page 289](#)).
  - Quiet Period – Time a port waits after Max Request Count is exceeded before attempting to acquire a new client ([page 289](#)).
  - TX Period – Time a port waits during authentication session before re-transmitting EAP packet ([page 290](#)).
  - Supplicant Timeout – Supplicant timeout.
  - Server Timeout – Server timeout. A RADIUS server must be set before the correct operational value of 10 seconds will be displayed in this field.
  - Reauth Max Retries – Maximum number of reauthentication attempts.
  - Max Request – Maximum number of times a port will retransmit an EAP request/identity packet to the client before it times out the authentication session ([page 286](#)).
  - Operation Mode– Shows if single or multiple hosts (clients) can connect to an 802.1X-authorized port.
  - Port Control–Shows the dot1x mode on a port as auto, force-authorized, or force-unauthorized ([page 288](#)).
  - Intrusion Action– Shows the port response to intrusion when authentication fails ([page 285](#)).
  - Supplicant– MAC address of authorized client.
- ◆ *Authenticator PAE State Machine*
  - State – Current state (including initialize, disconnected, connecting, authenticating, authenticated, aborting, held, force\_authorized, force\_unauthorized).
  - Reauth Count– Number of times connecting state is re-entered.
  - Current Identifier– The integer (0-255) used by the Authenticator to identify the current authentication session.

◆ *Backend State Machine*

- State – Current state (including request, response, success, fail, timeout, idle, initialize).
- Request Count– Number of EAP Request packets sent to the Supplicant without receiving a response.
- Identifier (Server)– Identifier carried in the most recent EAP Success, Failure or Request packet received from the Authentication Server.

◆ *Reauthentication State Machine*

State – Current state (including initialize, reauthenticate).

**Example**

```

Console#show dot1x
Global 802.1X Parameters
  System Auth Control      : Enabled

Authenticator Parameters:
  EAPOL Pass Through      : Disabled

Supplicant Parameters:
  Identity Profile Username : steve

802.1X Port Summary

Port      Type      Operation Mode Control Mode    Authorized
-----
Eth 1/ 1 Disabled  Single-Host   Force-Authorized Yes
Eth 1/ 2 Disabled  Single-Host   Force-Authorized Yes
'''
Eth 1/17 Disabled  Single-Host   Force-Authorized Yes
Eth 1/18 Enabled   Single-Host   Auto          Yes

Console#show dot1x interface ethernet 1/5

802.1X Authenticator is enabled on port 1/5
Reauthentication      : Enabled
Reauth Period         : 3600 seconds
Quiet Period          : 60 seconds
TX Period              : 30 seconds
Supplicant Timeout    : 30 seconds
Server Timeout        : 0 seconds
Reauth Max Retries    : 2
Max Request           : 2
Operation Mode        : Multi-host
Port Control          : Auto
Intrusion Action      : Block traffic

Supplicant             : 00-e0-29-94-34-65

Authenticator PAE State Machine
  State                : Authenticated
  Reauth Count         : 0
  Current Identifier    : 3

Backend State Machine
  State                : Idle
  Request Count        : 0
  Identifier(Server)    : 2
  
```

```
Reauthentication State Machine  
State : Initialize  
Console#
```

## Management IP Filter

This section describes commands used to configure IP management access to the switch.

**Table 54: Management IP Filter Commands**

Command	Function	Mode
<code>management</code>	Configures IP addresses that are allowed management access	GC
<code>show management</code>	Displays the switch to be monitored or configured from a browser	PE

**management** This command specifies the client IP addresses that are allowed management access to the switch through various protocols. A list of up to 15 IP addresses or IP address groups can be specified. Use the **no** form to restore the default setting.

### Syntax

```
[no] management {all-client | http-client | snmp-client | telnet-client}  
start-address [end-address]
```

**all-client** - Adds IP address(es) to all groups.

**http-client** - Adds IP address(es) to the web group.

**snmp-client** - Adds IP address(es) to the SNMP group.

**telnet-client** - Adds IP address(es) to the Telnet group.

*start-address* - A single IP address, or the starting address of a range.

*end-address* - The end address of a range.

### Default Setting

All addresses

### Command Mode

Global Configuration

### Command Usage

- ◆ The management interfaces are open to all IP addresses by default. Once you add an entry to a filter list, access to that interface is restricted to the specified addresses.

- ◆ If anyone tries to access a management interface on the switch from an invalid address, the switch will reject the connection, enter an event message in the system log, and send a trap message to the trap manager.
- ◆ IP address can be configured for SNMP, web, and Telnet access respectively. Each of these groups can include up to five different sets of addresses, either individual addresses or address ranges.
- ◆ When entering addresses for the same group (i.e., SNMP, web, or Telnet), the switch will not accept overlapping address ranges. When entering addresses for different groups, the switch will accept overlapping address ranges.
- ◆ You cannot delete an individual address from a specified range. You must delete the entire range, and re-enter the addresses.
- ◆ You can delete an address range just by specifying the start address, or by specifying both the start address and end address.

### Example

This example restricts management access to the indicated addresses.

```
Console(config)#management all-client 192.168.1.19
Console(config)#management all-client 192.168.1.25 192.168.1.30
Console#
```

**show management** This command displays the client IP addresses that are allowed management access to the switch through various protocols.

### Syntax

**show management {all-client | http-client | snmp-client | telnet-client}**

**all-client** - Displays IP addresses for all groups.

**http-client** - Displays IP addresses for the web group.

**snmp-client** - Displays IP addresses for the SNMP group.

**telnet-client** - Displays IP addresses for the Telnet group.

### Command Mode

Privileged Exec

### Example

```
Console#show management all-client
Management Ip Filter
HTTP-Client:
  Start IP address      End IP address
-----
1. 192.168.1.19        192.168.1.19
2. 192.168.1.25        192.168.1.30
```

```

SNMP-Client:
  Start IP address      End IP address
-----
1. 192.168.1.19        192.168.1.19
2. 192.168.1.25        192.168.1.30

TELNET-Client:
  Start IP address      End IP address
-----
1. 192.168.1.19        192.168.1.19
2. 192.168.1.25        192.168.1.30

Console#
  
```

## PPPoE Intermediate Agent

This section describes commands used to configure the PPPoE Intermediate Agent (PPPoE IA) relay parameters required for passing authentication messages between a client and broadband remote access servers.

**Table 55: PPPoE Intermediate Agent Commands**

Command	Function	Mode
<code>pppoe intermediate-agent</code>	Enables the PPPoE IA globally on the switch	GC
<code>pppoe intermediate-agent format-type</code>	Sets the access node identifier, generic error message, or vendor identifier for the switch	GC
<code>pppoe intermediate-agent port-enable</code>	Enables the PPPoE IA on an interface	IC
<code>pppoe intermediate-agent port-format-type</code>	Sets the circuit-id, remote-id, or remote-id delimiter for an interface	IC
<code>pppoe intermediate-agent port-format-type remote-id-delimiter</code>	Sets the remote-id delimiter for an interface	IC
<code>pppoe intermediate-agent trust</code>	Sets the trust mode for an interface	IC
<code>pppoe intermediate-agent vendor-tag strip</code>	Enables the stripping of vendor tags from PPPoE Discovery packets sent from a PPPoE server	IC
<code>clear pppoe intermediate-agent statistics</code>	Clears PPPoE IA statistics	PE
<code>show pppoe intermediate-agent info</code>	Displays PPPoE IA configuration settings	PE
<code>show pppoe intermediate-agent statistics</code>	Displays PPPoE IA statistics	PE

**pppoe intermediate-agent** This command enables the PPPoE Intermediate Agent globally on the switch. Use the **no** form to disable this feature.

### Syntax

**[no] pppoe intermediate-agent**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ The switch inserts a tag identifying itself as a PPPoE Intermediate Agent residing between the attached client requesting network access and the ports connected to broadband remote access servers (BRAS). The switch extracts access-loop information from the client's PPPoE Active Discovery Request, and forwards this information to all trusted ports designated by the **pppoe intermediate-agent trust** command. The BRAS detects the presence of the subscriber's circuit-ID tag inserted by the switch during the PPPoE discovery phase, and sends this tag as a NAS-port-ID attribute in PPP authentication and AAA accounting requests to a RADIUS server.
- ◆ PPPoE IA must be enabled globally by this command before this feature can be enabled on an interface using the **pppoe intermediate-agent port-enable** command.

### Example

```
Console(config)#pppoe intermediate-agent
Console(config)#
```

**pppoe intermediate-agent format-type** This command sets the access node identifier, generic error message, or vendor identifier for the switch. Use the **no** form to restore the default settings.

### Syntax

**pppoe intermediate-agent format-type** {**access-node-identifier** *node-id-string* | **generic-error-message** *error-message* | **vendor-id** *vendor-id-string*}

**no pppoe intermediate-agent format-type** {**access-node-identifier** | **generic-error-message**}

*node-id-string* - String identifying this switch as an PPPoE IA to the PPPoE server. (Range: 1-48 ASCII characters)

*error-message* - An error message notifying the sender that the PPPoE Discovery packet was too large.

*vendor-id-string* - This tag is used to pass vendor proprietary information. The first four octets of the tag contain the vendor id and the remainder is unspecified. The high-order octet of the vendor id is 0 and the low-order 3 octets are the SMI Network Management Private Enterprise Code of the Vendor in network byte order, as defined in the Assigned Numbers RFC (RFC 1700). (Range: 0-4294967295)

#### Default Setting

- ◆ Access Node Identifier: IP address of the first IPv4 interface on the switch.
- ◆ Generic Error Message: PPPoE Discover packet too large to process. Try reducing the number of tags added.
- ◆ Vendor Identifier: 3561  
(This is the enterprise number assigned to the Broadband Forum.)

#### Command Mode

Global Configuration

#### Command Usage

- ◆ The switch uses the access-node-identifier to generate the circuit-id for PPPoE discovery stage packets sent to the BRAS, but does not modify the source or destination MAC address of these PPPoE discovery packets.
- ◆ The vendor-specific tag is used to pass vendor proprietary information. The first four octets of this tag value contain the vendor identifier and the remainder is unspecified. The high-order octet of the vendor ID is 0 and the low-order 3 octets are the SMI Network Management Private Enterprise Code of the Vendor in network byte order, as defined in Assigned Numbers RFC 1700.
- ◆ These messages are forwarded to all trusted ports designated by the `pppoe intermediate-agent trust` command.

#### Example

```
Console(config)#pppoe intermediate-agent format-type access-node-identifier  
billibong  
Console(config)#
```

#### `pppoe intermediate-agent port-enable`

This command enables the PPPoE IA on an interface. Use the **no** form to disable this feature.

#### Syntax

**[no] pppoe intermediate-agent port-enable**

#### Default Setting

Disabled

## Command Mode

Interface Configuration (Ethernet, Port Channel)

## Command Usage

PPPoE IA must also be enabled globally on the switch for this command to take effect.

## Example

```

Console(config)#interface ethernet 1/5
Console(config-if)#pppoe intermediate-agent port-enable
Console(config-if)#

```

## pppoe intermediate-agent port-format-type

This command sets the circuit-id, remote-id, or remote-id delimiter for an interface. Use the **no** form to restore the default settings.

### Syntax

#### pppoe intermediate-agent port-format-type

```

{carry-to-client |
circuit-id [string | hostname-port-vlan] circuit-id-string |
remote-id {mac-cpe | string remote-id-string} |
remote-id-delimiter {enable | ascii-code}}

```

```

no pppoe intermediate-agent port-format-type {carry-to-client | circuit-id
| remote-id | remote-id-delimiter enable}

```

**carry-to-client** - Carries circuit ID/remote ID to the client.

*circuit-id-string* - String identifying the circuit identifier (or interface) on this switch to which the user is connected. (Range: 1-10 ASCII characters)

*circuit-id hostname-port-vlan* - Specifies circuit ID format hostname/port/vlan

**mac-cpe** - The MAC address of the CPE attached to this interface is used as the remote ID.

*remote-id-string* - String identifying the remote identifier (or interface) on this switch to which the user is connected. (Range: 1-63 ASCII characters)

**remote-id-delimiter enable** - Enables a user-specified delimiter value for the remote ID.

*ascii-code* - A character used to separate components in the remote circuit ID value. (Range: 0-255)

## Default Setting

carry-to-client: No

circuit-id: unit/port:vlan-id or 0/trunk-id:vlan-id

remote-id: port MAC address

remote-id-delimiter: ASCII code 35, ASCII character "#"

## Command Mode

Interface Configuration (Ethernet, Port Channel)

## Command Usage

- ◆ The PPPoE server extracts the Line-ID tag from PPPoE discovery stage messages, and uses the Circuit-ID field of that tag as a NAS-Port-ID attribute in AAA access and accounting requests.
- ◆ The switch intercepts PPPoE discovery frames from the client and inserts a unique line identifier using the PPPoE Vendor-Specific tag (0x0105) to PPPoE Active Discovery Initiation (PADI) and Request (PADR) packets. The switch then forwards these packets to the PPPoE server. The tag contains the Line-ID of the customer line over which the discovery packet was received, entering the switch (or access node) where the intermediate agent resides.
- ◆ Outgoing PAD Offer (PADO) and Session-confirmation (PADS) packets sent from the PPPoE Server include the Circuit-Id tag inserted by the switch, and should be stripped out of PADO and PADS packets which are to be passed directly to end-node clients using the `pppoe intermediate-agent vendor-tag strip` command.
- ◆ If the remote-id is unspecified, the port name will be used for this parameter. If the port name is not configured, the remote-id is set to the port MAC (yy-yy-yy-yy-yy-yy#), where # is the default delimiter.

## Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#pppoe intermediate-agent port-format-type circuit-id
string ECS4650-54P
Console(config-if)#
```

### pppoe intermediate-agent port-format-type remote-id-delimiter

This command sets the remote-id delimiter for an interface. Use the **enable** keyword to enable the delimiter. Use the **no** form with the **enable** keyword to disable the delimiter. Use the **no** form without any keywords to restore the default settings.

## Syntax

```
pppoe intermediate-agent port-format-type remote-id-delimiter  
{enable | ascii-code}
```

*ascii-code* - ASCII character of delimiter. (Range: 0-255)

## Default Setting

Disabled

ASCII code: 35 ("#")

## Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

If the delimiter is enabled and it occurs in the remote ID string, the string will be truncated at that point.

### Example

This command enables the delimiter for port 5.

```

Console(config)#interface ethernet 1/5
Console(config-if)#pppoe intermediate-agent port-format-type remote-id-
delimiter enable
Console(config-if)#

```

### pppoe intermediate-agent trust

This command sets an interface to trusted mode to indicate that it is connected to a PPPoE server. Use the **no** form to set an interface to untrusted mode.

### Syntax

**[no] pppoe intermediate-agent trust**

### Default Setting

Untrusted

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Set any interfaces connecting the switch to a PPPoE Server as trusted. Interfaces that connect the switch to users (PPPoE clients) should be set as untrusted.
- ◆ At least one trusted interface must be configured on the switch for the PPPoE IA to function.

### Example

```

Console(config)#interface ethernet 1/5
Console(config-if)#pppoe intermediate-agent trust
Console(config-if)#

```

### pppoe intermediate-agent vendor-tag strip

This command enables the stripping of vendor tags from PPPoE Discovery packets sent from a PPPoE server. Use the **no** form to disable this feature.

### Syntax

**[no] pppoe intermediate-agent vendor-tag strip**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

This command only applies to trusted interfaces. It is used to strip off vendor-specific tags (which carry subscriber and line identification information) in PPPoE Discovery packets received from an upstream PPPoE server before forwarding them to a user.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#pppoe intermediate-agent vendor-tag strip
Console(config-if)#
```

**clear pppoe intermediate-agent statistics** This command clears statistical counters for the PPPoE Intermediate Agent.

### Syntax

**clear pppoe intermediate-agent statistics interface** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Stack unit (Range: 1)

*port* - Port number (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

```
Console#clear pppoe intermediate-agent statistics
Console#
```

**show pppoe intermediate-agent info** This command displays configuration settings for the PPPoE Intermediate Agent.

### Syntax

**show pppoe intermediate-agent info** [**interface** [*interface*]]

```
interface
  ethernet unit/port
    unit - Stack unit. (Range: 1)
    port - Port number (Range: 1-28/54)
  port-channel channel-id (Range: 1-28)
```

**Command Mode**  
 Privileged Exec

**Example**

```
Console#show pppoe intermediate-agent info
PPPoE Intermediate Agent Global Status           : Enabled
PPPoE Intermediate Agent Vendor ID              : 3561
PPPoE Intermediate Agent Admin Access Node Identifier : 192.168.0.2
PPPoE Intermediate Agent Oper Access Node Identifier : 192.168.0.2
PPPoE Intermediate Agent Admin Generic Error Message :
  PPPoE Discover packet too large to process. Try reducing the number of tags
  added.
PPPoE Intermediate Agent Oper Generic Error Message :
  PPPoE Discover packet too large to process. Try reducing the number of tags
  added.
Console#show pppoe intermediate-agent info interface ethernet 1/1
Interface PPPoE IA Trusted Vendor-Tag Strip Admin Circuit-ID Admin Remote-ID
-----
Eth 1/1   No      No      No
          R-ID Delimiter  Delimiter ASCII  Oper Circuit-ID  Oper Remote-ID
          -----
          No              35 1/1:vid        CC-37-AB-BC-4F-FB
Carry Circuit and Remote ID to client: FALSE
Console#
```

**show pppoe intermediate-agent statistics** This command displays statistics for the PPPoE Intermediate Agent.  
**Syntax**

**show pppoe intermediate-agent statistics interface [interface]**

```
interface
  ethernet unit/port
    unit - Unit identifier. (Range: 1)
    port - Port number. (Range: 1-28/54)
  port-channel channel-id (Range: 1-28)
```

**Command Mode**  
 Privileged Exec

**Example**

```
Console#show pppoe intermediate-agent statistics interface ethernet 1/1
Eth 1/1 statistics
```

```

-----
Received :      All      PADI      PADO      PADR      PADS      PADT
-----
              3         0         0         0         0         3

Dropped  : Response from untrusted  Request towards untrusted  Malformed
-----
                          0                          0              0

Console#
  
```

**Table 56: show pppoe intermediate-agent statistics - display description**

Field	Description
<i>Received</i>	
PADI	PPPoE Active Discovery Initiation
PADO	PPPoE Active Discovery Offer
PADR	PPPoE Active Discovery Request
PADS	PPPoE Active Discovery Session-Confirmation
PADT	PPPoE Active Discovery Terminate
<i>Dropped</i>	
Response from untrusted	Response from an interface which not been configured as trusted.
Request towards untrusted	Request sent to an interface which not been configured as trusted.
Malformed	Corrupted PPPoE message.

# General Security Measures

This switch supports many methods of segregating traffic for clients attached to each of the data ports, and for ensuring that only authorized clients gain access to the network. Port-based authentication using IEEE 802.1X is commonly used for these purposes. In addition to these methods, several other options of providing client security are described in this chapter. These include port-based authentication, which can be configured to allow network client access by specifying a fixed set of MAC addresses. The addresses assigned to DHCP clients can also be carefully controlled with IP Source Guard and DHCP Snooping commands.

**Table 57: General Security Commands**

Command Group	Function
Port Security*	Configures secure addresses for a port
Network Access*	Configures MAC authentication and dynamic VLAN assignment
Web Authentication*	Configures Web authentication
Access Control Lists*	Provides filtering for IP frames (based on address, protocol, TCP/UDP port number or TCP control code) or non-IP frames (based on MAC address or Ethernet type)
DHCPv4 Snooping*	Filters untrusted DHCPv4 messages on insecure ports by building and maintaining a DHCPv4 snooping binding table
DHCPv6 Snooping*	Filters untrusted DHCPv6 messages on insecure ports by building and maintaining a DHCPv6 snooping binding table
IPv4 Source Guard*	Filters IP traffic on insecure ports for which the source address cannot be identified via DHCP snooping nor static source bindings
IPv6 Source Guard*	Filters IPv6 traffic on insecure ports for which the source address cannot be identified via DHCPv6 snooping nor static source bindings
ND Snooping	Maintains IPv6 prefix table and user address binding table which can be used for stateless address auto-configuration or for address filtering by IPv6 Source Guard
ARP Inspection	Validates the MAC-to-IP address bindings in ARP packets
Denial of Service Protection	Protects against Denial-of-Service attacks
Port-based Traffic Segmentation	Configures traffic segmentation for different client sessions based on specified downlink and uplink ports

\* The priority of execution for these filtering commands is Port Security, Port Authentication, Network Access, Web Authentication, Access Control Lists, DHCP Snooping, and then IPv4 Source Guard.

## Port Security

These commands can be used to enable port security on a port.

When MAC address learning is disabled on an interface, only incoming traffic with source addresses already stored in the dynamic or static address table for this port will be authorized to access the network.

When using port security, the switch stops learning new MAC addresses on the specified port when it has reached a configured maximum number. Only incoming traffic with source addresses already stored in the dynamic or static address table for this port will be authorized to access the network. The port will drop any incoming frames with a source MAC address that is unknown or has been previously learned from another port. If a device with an unauthorized MAC address attempts to use the switch port, the intrusion will be detected and the switch can automatically take action by disabling the port and sending a trap message.

**Table 58: Management IP Filter Commands**

Command	Function	Mode
<code>mac-address-table static</code>	Maps a static address to a port in a VLAN	GC
<code>mac-learning</code>	Enables MAC address learning on the selected physical interface or VLAN	IC
<code>port security</code>	Configures a secure port	IC
<code>port security mac-address sticky</code>	Saves the MAC addresses learned by port security as "sticky" entries	IC
<code>port security mac-address-as-permanent</code>	Saves the MAC addresses learned by port security as static entries.	PE
<code>show mac-address-table</code>	Displays entries in the bridge-forwarding database	PE
<code>show port security</code>	Displays port security status and secure address count	PE

**mac-learning** This command enables MAC address learning on the selected interface. Use the **no** form to disable MAC address learning.

### Syntax

**[no] mac-learning**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet or Port Channel)

### Command Usage

- ◆ The **no mac-learning** command immediately stops the switch from learning new MAC addresses on the specified port or trunk. Incoming traffic with source addresses not stored in the static address table, will be flooded. However, if a security function such as 802.1X or DHCP snooping is enabled and mac-learning is disabled, then only incoming traffic with source addresses stored in the static address table will be accepted, all other packets are dropped. Note that the dynamic addresses stored in the address table when MAC address learning is disabled are flushed from the system, and no dynamic addresses are subsequently learned until MAC address learning has been re-enabled.
- ◆ The mac-learning commands cannot be used if 802.1X Port Authentication has been globally enabled on the switch with the **dot1x system-auth-control** command, or if MAC Address Security has been enabled by the **port security** command on the same interface.

### Example

The following example disables MAC address learning for port 2.

```
Console(config)#interface ethernet 1/2
Console(config-if)#no mac-learning
Console(config-if)#
```

### Related Commands

[show interfaces status \(439\)](#)

**port security** This command enables or configures port security. Use the **no** form without any keywords to disable port security. Use the **no** form with the appropriate keyword to restore the default settings for a response to security violation or for the maximum number of allowed addresses.

### Syntax

**port security** [**action** {**shutdown** | **trap** | **trap-and-shutdown**} | **max-mac-count** *address-count*]

**no port security** [**action** | **max-mac-count**]

**action** - Response to take when port security is violated.

**shutdown** - Disable port only.

**trap** - Issue SNMP trap message only.

**trap-and-shutdown** - Issue SNMP trap message and disable port.

**max-mac-count**

*address-count* - The maximum number of MAC addresses that can be learned on a port. (Range: 0 - 1024, where 0 means disabled)

### Default Setting

Status: Disabled

Action: None

Maximum Addresses: 0

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ The default maximum number of MAC addresses allowed on a secure port is zero (that is, port security is disabled). To use port security, you must configure the maximum number of addresses allowed on a port using the **port security max-mac-count** command.
- ◆ When port security is enabled using the **port security** command, or the maximum number or allowed addresses is set to a value lower than the current limit after port security has been enabled, the switch first clears all dynamically learned entries from the address table. It then starts learning new MAC addresses on the specified port, and stops learning addresses when it reaches a configured maximum number. Only incoming traffic with source addresses already stored in the dynamic or static address table will be accepted.
- ◆ To configure the maximum number of address entries which can be learned on a port, specify the maximum number of dynamic addresses allowed. The switch will learn up to the maximum number of allowed address pairs <source MAC address, VLAN> for frames received on the port. (The specified maximum address count is effective when port security is enabled or disabled.) Note that you can manually add additional secure addresses to a port using the **mac-address-table static** command. When the port has reached the maximum number of MAC addresses, the port will stop learning new addresses. The MAC addresses already in the address table will be retained and will not be aged out.
- ◆ MAC addresses that port security has learned, can be saved in the configuration file as static entries. See command **port security mac-address-as-permanent**.
- ◆ If port security is enabled, and the maximum number of allowed addresses are set to a non-zero value, any device not in the address table that attempts to use the port will be prevented from accessing the switch.
- ◆ If a port is disabled due to a security violation, it must be manually re-enabled using the **no shutdown** command.
- ◆ A secure port has the following restrictions:
  - Cannot be connected to a network interconnection device.
  - Cannot be a trunk port.
  - RSPAN and port security are mutually exclusive functions. If port security is enabled on a port, that port cannot be set as an RSPAN uplink port. Also, when a port is configured as an RSPAN uplink port, source port, or destination port, port security cannot be enabled on that port.

### Example

The following example enables port security for port 5, and sets the response to a security violation to issue a trap message:

```
Console(config)#interface ethernet 1/5
Console(config-if)#port security action trap
```

### Related Commands

[show interfaces status \(439\)](#)

[shutdown \(430\)](#)

[mac-address-table static \(524\)](#)

**port security mac-address sticky** Use this command to save the MAC addresses that port security has learned as “sticky” entries.

### Syntax

**port security mac-address sticky**

### Command Mode

Interface Configuration

### Command Usage

- ◆ Sticky MAC addresses that port security has learned are dynamic addresses that cannot be moved to another port.
- ◆ If sticky MAC addresses are received on another secure port, then the port intrusion action is taken.

### Example

```
Console(config-if)#port security mac-address sticky
Console#
```

**port security mac-address-as-permanent** Use this command to save the MAC addresses that port security has learned as static entries.

### Syntax

**port security mac-address-as-permanent** [**interface** *interface*]

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Example

This example shows the switch saving the MAC addresses learned by port security on ethernet port 1/3.

```
Console#port security mac-address-as-permanent interface ethernet 1/3
Console#
```

**show port security** This command displays port security status and the secure address count.

### Syntax

**show port security** [**interface** *interface*]

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Example

This example shows the port security settings and number of secure addresses for all ports.

```
Console#show port security
Global Port Security Parameters
Secure MAC Aging Mode : Disabled

Port Security Port Summary
Port      Port Security Port Status Intrusion Action  MaxMacCnt CurrMacCnt
-----
Eth 1/ 1 Enabled      Secure/Up      Shutdown          20         2
Eth 1/ 2 Disabled     Secure/Down    None              0          0
Eth 1/ 3 Disabled     Secure/Down    None              0          0
Eth 1/ 4 Disabled     Secure/Down    None              0          0
Eth 1/ 5 Disabled     Secure/Down    None              0          0
:
```

**Table 59: show port security - display description**

Field	Description
Port	The Ethernet interface port number.
Secure MAC Aging Mode	Secure MAC aging mode status (enabled or disabled).
Port Security	The configured status (enabled or disabled).
Port Status	The operational status: <ul style="list-style-type: none"> <li>◆ Secure/Down – Port security is disabled.</li> <li>◆ Secure/Up – Port security is enabled.</li> <li>◆ Shutdown – Port is shut down due to a response to a port security violation.</li> </ul>
Intrusion Action	The configured intrusion response.
MaxMacCnt	The maximum number of addresses which can be stored in the address table for this interface (either dynamic or static).
CurrMacCnt	The current number of secure entries in the address table.

The following example shows the port security settings and number of secure addresses for a specific port. The Last Intrusion MAC and Last Time Detected Intrusion MAC fields show information about the last detected intrusion MAC address. These fields are not applicable if no intrusion has been detected or port security is disabled. The MAC Filter ID field is configured by the [network-access mac-filter](#) command. If this field displays Disabled, then any unknown source MAC address can be learned as a secure MAC address. If it displays a filter identifier, then only source MAC address entries in MAC Filter table can be learned as secure MAC addresses.

```

Console#show port security interface ethernet 1/2
Global Port Security Parameters
  Secure MAC Aging Mode : Disabled

Port Security Details
Port : 1/2
Port Security : Enabled
Port Status : Secure/Up
Intrusion Action : None
Max MAC Count : 0
Current MAC Count : 0
MAC Filter : Disabled
Last Intrusion MAC : NA
Last Time Detected Intrusion MAC : NA
Console#

```

This example shows information about a detected intrusion.

```

Console#show port security interface ethernet 1/2
Global Port Security Parameters
  Secure MAC Aging Mode : Disabled

Port Security Details
Port : 1/2
Port Security : Enabled

```

```

Port Status                : Secure/Up
Intrusion Action          : None
Max MAC Count             : 0
Current MAC Count         : 0
MAC Filter                : Disabled
Last Intrusion MAC        : 00-10-22-00-00-01
Last Time Detected Intrusion MAC : 2017/7/29 15:13:03
Console#

```

## Network Access (MAC Address Authentication)

Network Access authentication controls access to the network by authenticating the MAC address of each host that attempts to connect to a switch port. Traffic received from a specific MAC address is forwarded by the switch only if the source MAC address is successfully authenticated by a central RADIUS server. While authentication for a MAC address is in progress, all traffic is blocked until authentication is completed. Once successfully authenticated, the RADIUS server may optionally assign VLAN and QoS settings for the switch port.

**Table 60: Network Access Commands**

Command	Function	Mode
<a href="#">network-access aging</a>	Enables MAC address aging	GC
<a href="#">network-access mac-filter</a>	Adds a MAC address to a filter table	GC
<a href="#">mac-authentication reauth-time</a>	Sets the time period after which a connected MAC address must be re-authenticated	GC
<a href="#">network-access dynamic-qos</a>	Enables the dynamic quality of service feature	IC
<a href="#">network-access dynamic-vlan</a>	Enables dynamic VLAN assignment from a RADIUS server	IC
<a href="#">network-access guest-vlan</a>	Specifies the guest VLAN	IC
<a href="#">network-access link-detection</a>	Enables the link detection feature	IC
<a href="#">network-access link-detection link-down</a>	Configures the link detection feature to detect and act upon link-down events	IC
<a href="#">network-access link-detection link-up</a>	Configures the link detection feature to detect and act upon link-up events	IC
<a href="#">network-access link-detection link-up-down</a>	Configures the link detection feature to detect and act upon both link-up and link-down events	IC
<a href="#">network-access max-mac-count</a>	Sets the maximum number of MAC addresses that can be authenticated on a port via all forms of authentication	IC
<a href="#">network-access mode mac-authentication</a>	Enables MAC authentication on an interface	IC
<a href="#">network-access port-mac-filter</a>	Enables the specified MAC address filter	IC
<a href="#">mac-authentication intrusion-action</a>	Determines the port response when a connected host fails MAC authentication.	IC
<a href="#">mac-authentication max-mac-count</a>	Sets the maximum number of MAC addresses that can be authenticated on a port via MAC authentication	IC

Table 60: Network Access Commands (Continued)

Command	Function	Mode
<code>clear network-access</code>	Clears authenticated MAC addresses from the address table	PE
<code>show network-access</code>	Displays the MAC authentication settings for port interfaces	PE
<code>show network-access mac-address-table</code>	Displays information for entries in the secure MAC address table	PE
<code>show network-access mac-filter</code>	Displays information for entries in the MAC filter tables	PE

**network-access aging** Use this command to enable aging for authenticated MAC addresses stored in the secure MAC address table. Use the **no** form of this command to disable address aging.

### Syntax

**[no] network-access aging**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Authenticated MAC addresses are stored as dynamic entries in the switch's secure MAC address table and are removed when the aging time expires. The address aging time is determined by the `mac-address-table aging-time` command.
- ◆ This parameter applies to authenticated MAC addresses configured by the MAC Address Authentication process described in this section, as well as to any secure MAC addresses authenticated by 802.1X, regardless of the 802.1X Operation Mode (Single-Host, Multi-Host, or MAC-Based authentication as described under the `dot1x operation-mode` command).
- ◆ The maximum number of secure MAC addresses supported for the switch system is 1024.

### Example

```
Console(config)#network-access aging
Console(config)#
```

**network-access mac-filter** Use this command to add a MAC address into a filter table. Use the **no** form of this command to remove the specified MAC address.

### Syntax

**network-access mac-filter** *filter-id*  
**mac-address** *mac-address* [**mask** *mask-address*]

**no network-access mac-filter** *filter-id*  
**mac-address** *mac-address* **mask** *mask-address*

*filter-id* - Specifies a MAC address filter table. (Range: 1-64)

*mac-address* - Specifies a MAC address entry. (Format: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx)

*mask* - Specifies a MAC address bit mask for a range of addresses.

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Specified addresses are exempt from network access authentication.
- ◆ This command is different from configuring static addresses with the [mac-address-table static](#) command in that it allows you configure a range of addresses when using a mask, and then to assign these addresses to one or more ports with the [network-access port-mac-filter](#) command.
- ◆ Up to 64 filter tables can be defined.
- ◆ There is no limitation on the number of entries that can entered in a filter table.

### Example

```
Console(config)#network-access mac-filter 1 mac-address 11-22-33-44-55-66  
Console(config)#
```

**mac-authentication reauth-time** Use this command to set the time period after which an authenticated MAC address is removed from the secure address table. Use the **no** form of this command to restore the default value.

#### Syntax

**mac-authentication reauth-time** *seconds*

**no mac-authentication reauth-time**

*seconds* - The reauthentication time period. (Range: 120-1000000 seconds)

#### Default Setting

1800

#### Command Mode

Global Configuration

#### Command Usage

- ◆ The reauthentication time is a global setting and applies to all ports.
- ◆ When the reauthentication time expires for a secure MAC address it is reauthenticated with the RADIUS server. During the reauthentication process traffic through the port remains unaffected.

#### Example

```
Console(config)#mac-authentication reauth-time 300  
Console(config)#
```

**network-access dynamic-qos** Use this command to enable the dynamic QoS feature for an authenticated port. Use the **no** form to restore the default.

#### Syntax

**[no] network-access dynamic-qos**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration

#### Command Usage

- ◆ The RADIUS server may optionally return dynamic QoS assignments to be applied to a switch port for an authenticated user. The "Filter-ID" attribute (attribute 11) can be configured on the RADIUS server to pass the following QoS information:

Table 61: Dynamic QoS Profiles

Profile	Attribute Syntax	Example
DiffServ	<b>service-policy-in</b> = <i>policy-map-name</i>	service-policy-in=p1
Rate Limit	<b>rate-limit-input</b> = <i>rate (kbps)</i>	rate-limit-input=100 (kbps)
	<b>rate-limit-output</b> = <i>rate (kbps)</i>	rate-limit-output=200 (kbps)
802.1p	<b>switchport-priority-default</b> = <i>value</i>	switchport-priority-default=2
IP ACL	<b>ip-access-group-in</b> = <i>ip-acl-name</i>	ip-access-group-in=ipv4acl
IPv6 ACL	<b>ipv6-access-group-in</b> = <i>ipv6-acl-name</i>	ipv6-access-group-in=ipv6acl
MAC ACL	<b>mac-access-group-in</b> = <i>mac-acl-name</i>	mac-access-group-in=macAcl

- ◆ When the last user logs off of a port with a dynamic QoS assignment, the switch restores the original QoS configuration for the port.
- ◆ When a user attempts to log into the network with a returned dynamic QoS profile that is different from users already logged on to the same port, the user is denied access.
- ◆ While a port has an assigned dynamic QoS profile, any manual QoS configuration changes only take effect after all users have logged off of the port.



**Note:** Any configuration changes for dynamic QoS are not saved to the switch configuration file.

### Example

The following example enables the dynamic QoS feature on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access dynamic-qos
Console(config-if)#
```

**network-access dynamic-vlan** Use this command to enable dynamic VLAN assignment for an authenticated port. Use the **no** form to disable dynamic VLAN assignment.

### Syntax

**[no] network-access dynamic-vlan**

### Default Setting

Enabled

## Command Mode

Interface Configuration

### Command Usage

- ◆ When enabled, the VLAN identifiers returned by the RADIUS server through the 802.1X authentication process will be applied to the port, providing the VLANs have already been created on the switch. GVRP is not used to create the VLANs.
- ◆ The VLAN settings specified by the first authenticated MAC address are implemented for a port. Other authenticated MAC addresses on the port must have same VLAN configuration, or they are treated as an authentication failure.
- ◆ If dynamic VLAN assignment is enabled on a port and the RADIUS server returns no VLAN configuration, the authentication is still treated as a success, and the host assigned to the default untagged VLAN.
- ◆ When the dynamic VLAN assignment status is changed on a port, all authenticated addresses are cleared from the secure MAC address table.

### Example

The following example enables dynamic VLAN assignment on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access dynamic-vlan
Console(config-if)#
```

**network-access guest-vlan** Use this command to assign all traffic on a port to a guest VLAN when 802.1x authentication or MAC authentication is rejected. Use the **no** form of this command to disable guest VLAN assignment.

### Syntax

**network-access guest-vlan** *vlan-id*

**no network-access guest-vlan**

*vlan-id* - VLAN ID (Range: 1-4094)

### Default Setting

Disabled

## Command Mode

Interface Configuration

### Command Usage

- ◆ The VLAN to be used as the guest VLAN must be defined and set as active (See the [vlan database](#) command).

- ◆ When used with 802.1X authentication, the intrusion-action must be set for “guest-vlan” to be effective (see the `dot1x intrusion-action` command).
- ◆ A port can only be assigned to the guest VLAN in case of failed authentication, if `switchport mode` is set to Hybrid.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access guest-vlan 25
Console(config-if)#
```

**network-access link-detection** Use this command to enable link detection for the selected port. Use the **no** form of this command to restore the default.

### Syntax

**[no] network-access link-detection**

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access link-detection
Console(config-if)#
```

**network-access link-detection link-down** Use this command to detect link-down events. When detected, the switch can shut down the port, send an SNMP trap, or both. Use the **no** form of this command to disable this feature.

### Syntax

**network-access link-detection link-down**  
**action [shutdown | trap | trap-and-shutdown]**

**no network-access link-detection**

**action** - Response to take when port security is violated.

**shutdown** - Disable port only.

**trap** - Issue SNMP trap message only.

**trap-and-shutdown** - Issue SNMP trap message and disable the port.

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access link-detection link-down action trap
Console(config-if)#
```

### network-access link-detection link-up

Use this command to detect link-up events. When detected, the switch can shut down the port, send an SNMP trap, or both. Use the **no** form of this command to disable this feature.

### Syntax

**network-access link-detection link-up**  
**action [shutdown | trap | trap-and-shutdown]**

**no network-access link-detection**

**action** - Response to take when port security is violated.

**shutdown** - Disable port only.

**trap** - Issue SNMP trap message only.

**trap-and-shutdown** - Issue SNMP trap message and disable the port.

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access link-detection link-up action trap
Console(config-if)#
```

**network-access link-detection link-up-down** Use this command to detect link-up and link-down events. When either event is detected, the switch can shut down the port, send an SNMP trap, or both. Use the **no** form of this command to disable this feature.

#### Syntax

**network-access link-detection link-up-down  
action [shutdown | trap | trap-and-shutdown]**

**no network-access link-detection**

**action** - Response to take when port security is violated.

**shutdown** - Disable port only.

**trap** - Issue SNMP trap message only.

**trap-and-shutdown** - Issue SNMP trap message and disable the port.

#### Default Setting

Disabled

#### Command Mode

Interface Configuration

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access link-detection link-up-down action trap
Console(config-if)#
```

**network-access max-mac-count** Use this command to set the maximum number of MAC addresses that can be authenticated on a port interface via all forms of authentication. Use the **no** form of this command to restore the default.

#### Syntax

**network-access max-mac-count** *count*

**no network-access max-mac-count**

*count* - The maximum number of authenticated IEEE 802.1X and MAC addresses allowed. (Range: 1-2048)

#### Default Setting

1024

#### Command Mode

Interface Configuration

### Command Usage

The maximum number of MAC addresses per port is 1024, and the maximum number of secure MAC addresses supported for the switch system is 1024. When the limit is reached, all new MAC addresses are treated as authentication failures.

### Example

```
Console(config-if)#network-access max-mac-count 5  
Console(config-if)#
```

**network-access mode mac-authentication** Use this command to enable network access authentication on a port. Use the **no** form of this command to disable network access authentication.

### Syntax

**[no] network-access mode mac-authentication**

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Command Usage

- ◆ When enabled on a port, the authentication process sends a Password Authentication Protocol (PAP) request to a configured RADIUS server. The user name and password are both equal to the MAC address being authenticated.
- ◆ On the RADIUS server, PAP user name and passwords must be configured in the MAC address format XX-XX-XX-XX-XX-XX (all in upper case).
- ◆ Authenticated MAC addresses are stored as dynamic entries in the switch secure MAC address table and are removed when the aging time expires. The maximum number of secure MAC addresses supported for the switch system is 1024.
- ◆ Configured static MAC addresses are added to the secure address table when seen on a switch port. Static addresses are treated as authenticated without sending a request to a RADIUS server.
- ◆ MAC authentication cannot be configured on trunks (i.e., static nor dynamic).
- ◆ When port status changes to down, all MAC addresses are cleared from the secure MAC address table. Static VLAN assignments are not restored.
- ◆ The RADIUS server may optionally return a VLAN identifier list. VLAN identifier list is carried in the "Tunnel-Private-Group-ID" attribute. The VLAN list can contain multiple VLAN identifiers in the format "1u 2t", where "u" indicates an untagged VLAN and "t" a tagged VLAN. The "Tunnel-Type" attribute should be

set to "VLAN", the "Tunnel-Medium-Type" attribute set to "802", and the "Radius:Avenda Avenda-Tag-Id" attribute should be set to 0.

### Example

```
Console(config-if)#network-access mode mac-authentication
Console(config-if)#
```

**network-access port-mac-filter** Use this command to enable the specified MAC address filter. Use the **no** form of this command to disable the specified MAC address filter.

### Syntax

**network-access port-mac-filter** *filter-id*

**no network-access port-mac-filter**

*filter-id* - Specifies a MAC address filter table. (Range: 1-64)

### Default Setting

None

### Command Mode

Interface Configuration

### Command Mode

- ◆ Entries in the MAC address filter table can be configured with the [network-access mac-filter](#) command.
- ◆ Only one filter table can be assigned to a port.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#network-access port-mac-filter 1
Console(config-if)#
```

**mac-authentication intrusion-action** Use this command to configure the port response to a host MAC authentication failure. Use the **no** form of this command to restore the default.

#### Syntax

**mac-authentication intrusion-action** {**block-traffic** | **pass-traffic**}

**no mac-authentication intrusion-action**

**block-traffic** - Blocks traffic when the authentication has failed.

**pass-traffic** - Allows network access when authentication has failed.

#### Default Setting

Block Traffic

#### Command Mode

Interface Configuration

#### Example

```
Console(config-if)#mac-authentication intrusion-action block-traffic
Console(config-if)#
```

**mac-authentication max-mac-count** Use this command to set the maximum number of MAC addresses that can be authenticated on a port via MAC authentication. Use the **no** form of this command to restore the default.

#### Syntax

**mac-authentication max-mac-count** *count*

**no mac-authentication max-mac-count**

*count* - The maximum number of MAC-authenticated MAC addresses allowed. (Range: 1-1024)

#### Default Setting

1024

#### Command Mode

Interface Configuration

#### Example

```
Console(config-if)#mac-authentication max-mac-count 32
Console(config-if)#
```

**clear network-access** Use this command to clear entries from the secure MAC addresses table.

### Syntax

**clear network-access mac-address-table** [**static** | **dynamic**]  
[**address** *mac-address*] [**interface** *interface*]

**static** - Specifies static address entries.

**dynamic** - Specifies dynamic address entries.

*mac-address* - Specifies a MAC address entry. (Format: xx-xx-xx-xx-xx-xx)

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#clear network-access mac-address-table interface ethernet 1/1
Console#
```

**show network-access** Use this command to display the MAC authentication settings for port interfaces.

### Syntax

**show network-access** [**interface** *interface*]

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Default Setting

Displays the settings for all interfaces.

### Command Mode

Privileged Exec

## Example

```
Console#show network-access interface ethernet 1/1
Global secure port information
Reauthentication Time           : 1800
MAC Address Aging              : Disabled

Port : 1/1
MAC Authentication              : Disabled
MAC Authentication Intrusion Action : Block traffic
MAC Authentication Maximum MAC Counts : 1024
Maximum MAC Counts             : 1024
Dynamic VLAN Assignment        : Enabled
Dynamic QoS Assignment         : Disabled
MAC Filter ID                  : Disabled
Guest VLAN                     : Disabled
Link Detection                  : Disabled
Detection Mode                  : Link-down
Detection Action                : Trap
Console#
```

**show network-access mac-address-table** Use this command to display secure MAC address table entries.

### Syntax

```
show network-access mac-address-table [static | dynamic]
[address mac-address [mask]] [interface interface] [sort {address |
interface}]
```

**static** - Specifies static address entries.

**dynamic** - Specifies dynamic address entries.

*mac-address* - Specifies a MAC address entry.  
(Format: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx)

*mask* - Specifies a MAC address bit mask for filtering displayed addresses.

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**sort** - Sorts displayed entries by either MAC address or interface.

### Default Setting

Displays all filters.

### Command Mode

Privileged Exec

### Command Usage

When using a bit mask to filter displayed MAC addresses, a 1 means “care” and a 0 means “don't care”. For example, a MAC of 00-00-01-02-03-04 and mask FF-FF-FF-

00-00-00 would result in all MACs in the range 00-00-01-00-00-00 to 00-00-01-FF-FF-FF to be displayed. All other MACs would be filtered out.

### Example

```
Console#show network-access mac-address-table
Interface MAC Address      RADIUS Server  Time           Attribute
-----
1/1        00-00-01-02-03-04  172.155.120.17 00d06h32m50s  Static
1/1        00-00-01-02-03-05  172.155.120.17 00d06h33m20s  Dynamic
1/1        00-00-01-02-03-06  172.155.120.17 00d06h35m10s  Static
1/3        00-00-01-02-03-07  172.155.120.17 00d06h34m20s  Dynamic

Console#
```

**show network-access mac-filter** Use this command to display information for entries in the MAC filter tables.

### Syntax

**show network-access mac-filter** [*filter-id*]

*filter-id* - Specifies a MAC address filter table. (Range: 1-64)

### Default Setting

Displays all filters.

### Command Mode

Privileged Exec

### Example

```
Console#show network-access mac-filter
Filter ID MAC Address      MAC Mask
-----
1 00-00-01-02-03-08  FF-FF-FF-FF-FF-FF

Console#
```

## Web Authentication

Web authentication allows stations to authenticate and access the network in situations where 802.1X or Network Access authentication are infeasible or impractical. The web authentication feature allows unauthenticated hosts to request and receive a DHCP assigned IP address and perform DNS queries. All other traffic, except for HTTP protocol traffic, is blocked. The switch intercepts HTTP protocol traffic and redirects it to a switch-generated web page that facilitates user name and password authentication via RADIUS. Once authentication is successful, the web browser is forwarded on to the originally requested web page. Successful authentication is valid for all hosts connected to the port.



**Note:** RADIUS authentication must be activated and configured for the web authentication feature to work properly (see [“Authentication Sequence” on page 244](#)).

**Note:** Web authentication cannot be configured on trunk ports.

**Table 62: Web Authentication**

Command	Function	Mode
<code>web-auth login-attempts</code>	Defines the limit for failed web authentication login attempts	GC
<code>web-auth quiet-period</code>	Defines the amount of time to wait after the limit for failed login attempts is exceeded.	GC
<code>web-auth session-timeout</code>	Defines the amount of time a session remains valid	GC
<code>web-auth system-auth-control</code>	Enables web authentication globally for the switch	GC
<code>web-auth</code>	Enables web authentication for an interface	IC
<code>web-auth re-authenticate (Port)</code>	Ends all web authentication sessions on the port and forces the users to re-authenticate	PE
<code>web-auth re-authenticate (IP)</code>	Ends the web authentication session associated with the designated IP address and forces the user to re-authenticate	PE
<code>show web-auth</code>	Displays global web authentication parameters	PE
<code>show web-auth interface</code>	Displays interface-specific web authentication parameters and statistics	PE
<code>show web-auth summary</code>	Displays a summary of web authentication port parameters and statistics	PE

**web-auth login-attempts** This command defines the limit for failed web authentication login attempts. After the limit is reached, the switch refuses further login attempts until the quiet time expires. Use the **no** form to restore the default.

#### Syntax

**web-auth login-attempts** *count*

**no web-auth login-attempts**

*count* - The limit of allowed failed login attempts. (Range: 1-3)

#### Default Setting

3 login attempts

#### Command Mode

Global Configuration

#### Example

```
Console(config)#web-auth login-attempts 2  
Console(config)#
```

**web-auth quiet-period** This command defines the amount of time a host must wait after exceeding the limit for failed login attempts, before it may attempt web authentication again. Use the **no** form to restore the default.

#### Syntax

**web-auth quiet-period** *time*

**no web-auth quiet period**

*time* - The amount of time the host must wait before attempting authentication again. (Range: 1-180 seconds)

#### Default Setting

60 seconds

#### Command Mode

Global Configuration

#### Example

```
Console(config)#web-auth quiet-period 120  
Console(config)#
```

**web-auth session-timeout** This command defines the amount of time a web-authentication session remains valid. When the session timeout has been reached, the host is logged off and must re-authenticate itself the next time data transmission takes place. Use the **no** form to restore the default.

### Syntax

**web-auth session-timeout** *timeout*

**no web-auth session timeout**

*timeout* - The amount of time that an authenticated session remains valid.  
(Range: 300-3600 seconds)

### Default Setting

3600 seconds

### Command Mode

Global Configuration

### Example

```
Console(config)#web-auth session-timeout 1800
Console(config)#
```

**web-auth system-auth-control** This command globally enables web authentication for the switch. Use the **no** form to restore the default.

### Syntax

**[no] web-auth system-auth-control**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

Both **web-auth system-auth-control** for the switch and **web-auth** for an interface must be enabled for the web authentication feature to be active.

### Example

```
Console(config)#web-auth system-auth-control
Console(config)#
```

**web-auth** This command enables web authentication for an interface. Use the no form to restore the default.

#### Syntax

**[no] web-auth**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration

#### Command Usage

Both **web-auth system-auth-control** for the switch and **web-auth** for a port must be enabled for the web authentication feature to be active.

#### Example

```
Console(config-if)#web-auth
Console(config-if)#
```

**web-auth re-authenticate (Port)** This command ends all web authentication sessions connected to the port and forces the users to re-authenticate.

#### Syntax

**web-auth re-authenticate interface** *interface*

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### Default Setting

None

#### Command Mode

Privileged Exec

#### Example

```
Console#web-auth re-authenticate interface ethernet 1/2
Console#
```

**web-auth re-authenticate (IP)** This command ends the web authentication session associated with the designated IP address and forces the user to re-authenticate.

### Syntax

**web-auth re-authenticate interface** *interface ip*

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

*ip* - IPv4 formatted IP address

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#web-auth re-authenticate interface ethernet 1/2 192.168.1.5
Console#
```

**show web-auth** This command displays global web authentication parameters.

### Command Mode

Privileged Exec

### Example

```
Console#show web-auth
Global Web-Auth Parameters
  System Auth Control      : Enabled
  Session Timeout          : 3600
  Quiet Period             : 60
  Max Login Attempts       : 3
Console#
```

**show web-auth interface** This command displays interface-specific web authentication parameters and statistics.

### Syntax

**show web-auth interface** *interface*

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Example

```
Console#show web-auth interface ethernet 1/2
Web Auth Status      : Enabled

Host Summary

IP address           Web-Auth-State Remaining-Session-Time
-----
1.1.1.1              Authenticated   295
1.1.1.2              Authenticated   111
Console#
```

**show web-auth summary** This command displays a summary of web authentication port parameters and statistics.

### Command Mode

Privileged Exec

### Example

```
Console#show web-auth summary
Global Web-Auth Parameters
  System Auth Control      : Enabled
Port      Status           Authenticated Host Count
----      -
1/ 1     Disabled           0
1/ 2     Enabled             8
1/ 3     Disabled           0
1/ 4     Disabled           0
1/ 5     Disabled           0
:
```

## DHCPv4 Snooping

DHCPv4 snooping allows a switch to protect a network from rogue DHCPv4 servers or other devices which send port-related information to a DHCPv4 server. This information can be useful in tracking an IP address back to a physical port. This section describes commands used to configure DHCPv4 snooping.

**Table 63: DHCP Snooping Commands**

Command	Function	Mode
<code>ip dhcp snooping</code>	Enables DHCP snooping globally	GC
<code>ip dhcp snooping information option</code>	Enables or disables the use of DHCP Option 82 information, and specifies frame format for the remote-id	GC
<code>ip dhcp snooping information option encode no-subtype</code>	Disables use of sub-type and sub-length for the CID/RID in Option 82 information	GC
<code>ip dhcp snooping information option remote-id</code>	Sets the remote ID to the switch's IP address, MAC address, arbitrary string, TR-101 compliant node identifier, or removes VLAN ID from the end of the TR101 field	GC
<code>ip dhcp snooping information option tr101 board-id</code>	Sets the board identifier used in Option 82 information based on TR-101 syntax	GC
<code>ip dhcp snooping information policy</code>	Sets the information option policy for DHCP client packets that include Option 82 information	GC
<code>ip dhcp snooping verify mac-address</code>	Verifies the client's hardware address stored in the DHCP packet against the source MAC address in the Ethernet header	GC
<code>ip dhcp snooping vlan</code>	Enables DHCP snooping on the specified VLAN	GC
<code>ip dhcp snooping information option circuit-id</code>	Enables or disables the use of DHCP Option 82 information circuit-id suboption	IC
<code>ip dhcp snooping max-number</code>	configures the maximum number of DHCP clients which can be supported per interface	IC
<code>ip dhcp snooping trust</code>	Configures the specified interface as trusted	IC
<code>clear ip dhcp snooping binding</code>	Clears DHCP snooping binding table entries from RAM	PE
<code>clear ip dhcp snooping database flash</code>	Removes all dynamically learned snooping entries from flash memory.	PE
<code>ip dhcp snooping database flash</code>	Writes all dynamically learned snooping entries to flash memory	PE
<code>show ip dhcp snooping</code>	Shows the DHCP snooping configuration settings	PE
<code>show ip dhcp snooping binding</code>	Shows the DHCP snooping binding table entries	PE

**ip dhcp snooping** This command enables DHCP snooping globally. Use the **no** form to restore the default setting.

### Syntax

**[no] ip dhcp snooping**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Network traffic may be disrupted when malicious DHCP messages are received from an outside source. DHCP snooping is used to filter DHCP messages received on an unsecure interface from outside the network or fire wall. When DHCP snooping is enabled globally by this command, and enabled on a VLAN interface by the **ip dhcp snooping vlan** command, DHCP messages received on an untrusted interface (as specified by the **no ip dhcp snooping trust** command) from a device not listed in the DHCP snooping table will be dropped.
- ◆ When enabled, DHCP messages entering an untrusted interface are filtered based upon dynamic entries learned via DHCP snooping.
- ◆ Table entries are only learned for trusted interfaces. Each entry includes a MAC address, IP address, lease time, VLAN identifier, and port identifier.
- ◆ When DHCP snooping is enabled, the rate limit for the number of DHCP messages that can be processed by the switch is 100 packets per second. Any DHCP packets in excess of this limit are dropped.
- ◆ Filtering rules are implemented as follows:
  - If global DHCP snooping is disabled, all DHCP packets are forwarded.
  - If DHCP snooping is enabled globally, and also enabled on the VLAN where the DHCP packet is received, all DHCP packets are forwarded for a *trusted* port. If the received packet is a DHCP ACK message, a dynamic DHCP snooping entry is also added to the binding table.
  - If DHCP snooping is enabled globally, and also enabled on the VLAN where the DHCP packet is received, but the port is *not trusted*, it is processed as follows:
    - If the DHCP packet is a reply packet from a DHCP server (including OFFER, ACK or NAK messages), the packet is dropped.

- If the DHCP packet is from a client, such as a DECLINE or RELEASE message, the switch forwards the packet only if the corresponding entry is found in the binding table.
- If the DHCP packet is from client, such as a DISCOVER, REQUEST, INFORM, DECLINE or RELEASE message, the packet is forwarded if MAC address verification is disabled (as specified by the `ip dhcp snooping verify mac-address` command). However, if MAC address verification is enabled, then the packet will only be forwarded if the client's hardware address stored in the DHCP packet is the same as the source MAC address in the Ethernet header.
- If the DHCP packet is not a recognizable type, it is dropped.
- If a DHCP packet from a client passes the filtering criteria above, it will only be forwarded to trusted ports in the same VLAN.
- If a DHCP packet is from server is received on a trusted port, it will be forwarded to both trusted and untrusted ports in the same VLAN.
- ◆ If DHCP snooping is globally disabled, all dynamic bindings are removed from the binding table.
- ◆ *Additional considerations when the switch itself is a DHCP client* – The port(s) through which the switch submits a client request to the DHCP server must be configured as trusted (using the `ip dhcp snooping trust` command). Note that the switch will not add a dynamic entry for itself to the binding table when it receives an ACK message from a DHCP server. Also, when the switch sends out DHCP client packets for itself, no filtering takes place. However, when the switch receives any messages from a DHCP server, any packets received from untrusted ports are dropped.

### Example

This example enables DHCP snooping globally for the switch.

```
Console(config)#ip dhcp snooping
Console(config)#
```

### Related Commands

[ip dhcp snooping vlan \(345\)](#)

[ip dhcp snooping trust \(348\)](#)

**ip dhcp snooping information option** This command enables the use of DHCP Option 82 information for the switch, and specifies the frame format to use for the remote-id when Option 82 information is generated by the switch. Use the **no** form without any keywords to disable this function.

#### Syntax

**ip dhcp snooping information option**  
**no ip dhcp snooping information option**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ DHCP provides a relay mechanism for sending information about the switch and its DHCP clients to the DHCP server. Known as DHCP Option 82, it allows compatible DHCP servers to use the information when assigning IP addresses, or to set other services or policies for clients.
- ◆ When the DHCP Snooping Information Option 82 is enabled, the requesting client (or an intermediate relay agent that has used the information fields to describe itself) can be identified in the DHCP request packets forwarded by the switch and in reply packets sent back from the DHCP server.
- ◆ When the DHCP Snooping Information Option is enabled, clients can be identified by the switch port to which they are connected rather than just their MAC address. DHCP client-server exchange messages are then forwarded directly between the server and client without having to flood them to the entire VLAN.
- ◆ DHCP snooping must be enabled for the DHCP Option 82 information to be inserted into packets. When enabled, the switch will only add/remove option 82 information in incoming DHCP packets but not relay them. Packets are processed as follows:
  - If an incoming packet is a DHCP request packet with option 82 information, it will modify the option 82 information according to settings specified with **ip dhcp snooping information policy** command.
  - If an incoming packet is a DHCP request packet without option 82 information, enabling the DHCP snooping information option will add option 82 information to the packet.
  - If an incoming packet is a DHCP reply packet with option 82 information, enabling the DHCP snooping information option will remove option 82 information from the packetExample

This example enables the DHCP Snooping Information Option.

```
Console(config)#ip dhcp snooping information option
Console(config)#
```

### ip dhcp snooping information option encode no-subtype

This command disables the use of sub-type and sub-length fields for the circuit-ID (CID) and remote-ID (RID) in Option 82 information generated by the switch. Use the **no** form to enable the use of these fields.

#### Syntax

**[no] ip dhcp snooping information option encode no-subtype**

#### Default Setting

CID/RID sub-type: Enabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ Option 82 information generated by the switch is based on TR-101 syntax as shown below:

**Table 64: Option 82 information**

82	3-69	1	1-67	x1	x2	x3	x4	x5	x63
opt82	opt-len	sub-opt1	string-len						R-124 string

The circuit identifier used by this switch starts at sub-option1 and goes to the end of the R-124 string. The R-124 string includes the following information:

- sub-type - Distinguishes different types of circuit IDs.
- sub-length - Length of the circuit ID type
- access node identifier - ASCII string. Default is the MAC address of the switch's CPU. This field is set by the [ip dhcp snooping information option](#) command,
- eth - The second field is the fixed string "eth"
- slot - The slot represents the stack unit for this system.
- port - The port which received the DHCP request. If the packet arrives over a trunk, the value is the ifIndex of the trunk.
- vlan - Tag of the VLAN which received the DHCP request.

Note that the sub-type and sub-length fields can be enabled or disabled using the [ip dhcp snooping information option](#) command.

- The **ip dhcp snooping information option circuit-id** command can be used to modify the default settings described above.
- ◆ The format for TR101 option 82 is: "<IP> eth <SID>/<PORT>[:<VLAN>]". Note that the SID (Switch ID) is always 0. By default the PVID is added to the end of the TR101 field for untagged packets. For tagged packets, the VLAN ID is always added.

### Example

This example enables the use of sub-type and sub-length fields for the circuit-ID (CID) and remote-ID (RID).

```
Console(config)#no ip dhcp snooping information option encode no-subtype
Console(config)#
```

### ip dhcp snooping information option remote-id

This command sets the remote ID to the switch's IP address, MAC address, arbitrary string, TR-101 compliant node identifier, or removes VLAN ID from the end of the TR101 field. Use the **no** form to restore the default setting.

### Syntax

#### **ip dhcp snooping information option remote-id**

```
{ip-address [encode {ascii | hex}] |
mac-address [encode {ascii | hex}] |
string string [sub-option port-description [delimiter delimiter]] |
tr101 {node-identifier {ip | sysname} | no-vlan-field}}
```

#### **no ip dhcp snooping information option remote-id**

```
[ip-address encode] | [mac-address encode] | [string sub-option port-
description delimiter] | [tr101 no-vlan-field]
```

**mac-address** - Inserts a MAC address in the remote ID sub-option for the DHCP snooping agent (that is, the MAC address of the switch's CPU).

**ip-address** - Inserts an IP address in the remote ID sub-option for the DHCP snooping agent (that is, the IP address of the management interface).

**encode** - Indicates encoding in ASCII or hexadecimal.

*string* - An arbitrary string inserted into the remote identifier field.  
(Range: 1-32 characters)

**sub-option port-description** - Include the port description string.

**delimiter *delimiter*** - Include the delimiter (Range 0-255)

**tr101 node-identifier** - The remote ID generated by the switch is based on TR-101 syntax (R-124, Access\_Node\_ID).

**ip** - Specifies the switch's IP address as the node identifier.

**sysname** - Specifies the system name as the node identifier.

**tr101 no-vlan-field** - Do not add ":VLAN" in TR101 field for untagged packets.

**Default Setting**

MAC address: hexadecimal  
tr101 no-vlan-field: disabled

**Command Mode**

Global Configuration

**Command Usage**

The format for TR101 option 82 is: “<IP> eth <SID>/<PORT>[:<VLAN>]”. Note that the SID (Switch ID) is always 0. By default the PVID is added to the end of the TR101 field for untagged packets. For tagged packets, the VLAN ID is always added. Use the **ip dhcp snooping information option remote-id tr101 no-vlan-field** command to remove the VLAN ID from the end of the TR101 field for untagged packets. Use the **no** form of this command to add the PVID for untagged packets at the end of the TR101 field.

**Example**

This example sets the remote ID to the switch’s IP address.

```
Console(config)#ip dhcp snooping information option remote-id tr101
node-identifier ip
Console(config)#
```

**ip dhcp snooping  
information option  
tr101 board-id**

This command sets the board identifier used in Option 82 information based on TR-101 syntax. Use the **no** form to remove the board identifier.

**Syntax**

**ip dhcp snooping information option tr101 board-id** *board-id*

**no ip dhcp snooping information option tr101 board-id**

*board-id* – TR101 Board ID. (Range: 0-9)

**Default Setting**

not defined

**Command Mode**

Global Configuration

**Example**

This example sets the board ID to 0.

```
Console(config)#ip dhcp snooping information option tr101 board-id 0
Console(config)#
```

**ip dhcp snooping information policy** This command sets the DHCP snooping information option policy for DHCP client packets that include Option 82 information. Use the **no** form to restore the default setting.

#### Syntax

**ip dhcp snooping information policy {drop | keep | replace}**

**no ip dhcp snooping information policy**

**drop** - Drops the client's request packet instead of relaying it.

**keep** - Retains the Option 82 information in the client request, and forwards the packets to trusted ports.

**replace** - Replaces the Option 82 information circuit-id and remote-id fields in the client's request with information about the relay agent itself, inserts the relay agent's address (when DHCP snooping is enabled), and forwards the packets to trusted ports.

#### Default Setting

replace

#### Command Mode

Global Configuration

#### Command Usage

When the switch receives DHCP packets from clients that already include DHCP Option 82 information, the switch can be configured to set the action policy for these packets. The switch can either drop the DHCP packets, keep the existing information, or replace it with the switch's relay information.

#### Example

```
Console(config)#ip dhcp snooping information policy drop
Console(config)#
```

**ip dhcp snooping verify mac-address** This command verifies the client's hardware address stored in the DHCP packet against the source MAC address in the Ethernet header. Use the **no** form to disable this function.

#### Syntax

**[no] ip dhcp snooping verify mac-address**

#### Default Setting

Enabled

#### Command Mode

Global Configuration

### Command Usage

If MAC address verification is enabled, and the source MAC address in the Ethernet header of the packet is not same as the client's hardware address in the DHCP packet, the packet is dropped.

### Example

This example enables MAC address verification.

```
Console(config)#ip dhcp snooping verify mac-address
Console(config)#
```

### Related Commands

[ip dhcp snooping \(338\)](#)

[ip dhcp snooping vlan \(345\)](#)

[ip dhcp snooping trust \(348\)](#)

**ip dhcp snooping vlan** This command enables DHCP snooping on the specified VLAN. Use the **no** form to restore the default setting.

### Syntax

**[no] ip dhcp snooping vlan** *vlan-id*

*vlan-id* - ID of a configured VLAN (Range: 1-4094)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ When DHCP snooping is enabled globally using the [ip dhcp snooping](#) command, and enabled on a VLAN with this command, DHCP packet filtering will be performed on any untrusted ports within the VLAN as specified by the [ip dhcp snooping trust](#) command.
- ◆ When the DHCP snooping is globally disabled, DHCP snooping can still be configured for specific VLANs, but the changes will not take effect until DHCP snooping is globally re-enabled.
- ◆ When DHCP snooping is globally enabled, and then disabled on a VLAN, all dynamic bindings learned for this VLAN are removed from the binding table.

### Example

This example enables DHCP snooping for VLAN 1.

```
Console(config)#ip dhcp snooping vlan 1
Console(config)#
```

### Related Commands

[ip dhcp snooping \(338\)](#)

[ip dhcp snooping trust \(348\)](#)

### ip dhcp snooping information option circuit-id

This command specifies DHCP Option 82 circuit-id suboption information. Use the **no** form to use the default settings.

#### Syntax

**ip dhcp snooping information option circuit-id string** *string* |  
{**tr101** {**node-identifier** {**ip** | **sysname**} | **no-vlan-field**}

**no dhcp snooping information option circuit-id** [**tr101 no-vlan-field**]

*string* - An arbitrary string inserted into the circuit identifier field.  
(Range: 1-32 characters)

**tr101 node-identifier** - The remote ID generated by the switch is based on TR-101 syntax (R-124, Access\_Node\_ID).

**ip** - Specifies the switch's IP address as the node identifier.

**sysname** - Specifies the system name as the node identifier.

**tr101 no-vlan-field** - Do not add ":VLAN" in TR101 field for untagged packets.

#### Default Setting

VLAN-Unit-Port

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

- ◆ DHCP provides a relay mechanism for sending information about the switch and its DHCP clients to the DHCP server. DHCP Option 82 allows compatible DHCP servers to use the information when assigning IP addresses, to set other services or policies for clients. For more information of this process, refer to the Command Usage section under the [ip dhcp snooping information option](#) command.
- ◆ Option 82 information generated by the switch is based on TR-101 syntax as shown below:

**Table 65: Option 82 information**

82	3-69	1	1-67	x1	x2	x3	x4	x5	x63
opt82	opt-len	sub-opt1	string-len	R-124 string					

The circuit identifier used by this switch starts at sub-option1 and goes to the end of the R-124 string. The R-124 string includes the following information:

- sub-type - Distinguishes different types of circuit IDs.
- sub-length - Length of the circuit ID type
- access node identifier - ASCII string. Default is the MAC address of the switch’s CPU. This field is set by the `ip dhcp snooping information option` command,
- eth - The second field is the fixed string “eth”
- slot - The slot represents the stack unit for this system.
- port - The port which received the DHCP request. If the packet arrives over a trunk, the value is the ifIndex of the trunk.
- vlan - Tag of the VLAN which received the DHCP request.

Note that the sub-type and sub-length fields can be enabled or disabled using the `ip dhcp snooping information option` command.

- The `ip dhcp snooping information option circuit-id` command can be used to modify the default settings described above.
- ◆ The format for TR101 option 82 is: “<IP> eth <SID>/<PORT>[:<VLAN>]”. Note that the SID (Switch ID) is always 0. By default the PVID is added to the end of the TR101 field for untagged packets. For tagged packets, the VLAN ID is always added. Use the `ip dhcp snooping information option remote-id tr101 no-vlan-field` command to remove the VLAN ID from the end of the TR101 field for untagged packets. Use the `no` form of this command to add the PVID for untagged packets at the end of the TR101 field.

### Example

This example sets the DHCP Snooping Information circuit-id suboption string.

```

Console(config)#interface ethernet 1/1
Console(config-if)#ip dhcp snooping information option circuit-id string 4500
Console(config-if)#

```

**ip dhcp snooping max-number** This command configures the maximum number of DHCP clients which can be supported per interface. Use the **no** form to restore the default setting.

#### Syntax

**ip dhcp snooping max-number** *max-number*

**no dhcp snooping max-number**

*max-number* - Maximum number of DHCP clients. (Range: 1-16)

#### Default Setting

16

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Example

This example sets the maximum number of DHCP clients supported on port 1 to 2.

```
Console(config)#interface ethernet 1/1
Console(config-if)#ip dhcp snooping max-number 2
Console(config-if)#
```

**ip dhcp snooping trust** This command configures the specified interface as trusted. Use the **no** form to restore the default setting.

#### Syntax

**[no] ip dhcp snooping trust**

#### Default Setting

All interfaces are untrusted

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

- ◆ A trusted interface is an interface that is configured to receive only messages from within the network. An untrusted interface is an interface that is configured to receive messages from outside the network or fire wall.
- ◆ Set all ports connected to DHCP servers within the local network or fire wall to trusted, and all other ports outside the local network or fire wall to untrusted.
- ◆ When DHCP snooping is enabled globally using the **ip dhcp snooping** command, and enabled on a VLAN with **ip dhcp snooping vlan** command, DHCP packet filtering will be performed on any untrusted ports within the

VLAN according to the default status, or as specifically configured for an interface with the **no ip dhcp snooping trust** command.

- ◆ When an untrusted port is changed to a trusted port, all the dynamic DHCP snooping bindings associated with this port are removed.
- ◆ *Additional considerations when the switch itself is a DHCP client* – The port(s) through which it submits a client request to the DHCP server must be configured as trusted.

### Example

This example sets port 5 to untrusted.

```
Console(config)#interface ethernet 1/5
Console(config-if)#no ip dhcp snooping trust
Console(config-if)#
```

### Related Commands

[ip dhcp snooping \(338\)](#)

[ip dhcp snooping vlan \(345\)](#)

### clear ip dhcp snooping binding

This command clears DHCP snooping binding table entries from RAM. Use this command without any optional keywords to clear all entries from the binding table.

### Syntax

**clear ip dhcp snooping binding** [*mac-address* **vlan** *vlan-id*]

*mac-address* - Specifies a MAC address entry. (Format: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx)

*vlan-id* - ID of a configured VLAN (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#clear ip dhcp snooping binding 11-22-33-44-55-66 192.168.1.234
Console#
```

### clear ip dhcp snooping database flash

This command removes all dynamically learned snooping entries from flash memory.

### Command Mode

Privileged Exec

### Example

```
Console#clear ip dhcp snooping database flash
Console#
```

**ip dhcp snooping database flash** This command writes all dynamically learned snooping entries to flash memory.

### Command Mode

Privileged Exec

### Command Usage

This command can be used to store the currently learned dynamic DHCP snooping entries to flash memory. These entries will be restored to the snooping table when the switch is reset. However, note that the lease time shown for a dynamic entry that has been restored from flash memory will no longer be valid.

### Example

```
Console#ip dhcp snooping database flash
Console#
```

**show ip dhcp snooping** This command shows the DHCP snooping configuration settings.

### Command Mode

Privileged Exec

### Example

```
Console#show ip dhcp snooping
Global DHCP Snooping Status: disabled
DHCP Snooping Information Option Status: disabled
DHCP Snooping Information Option Sub-option Format: extra subtype included
DHCP Snooping Information Option Remote ID: MAC Address (hex encoded)
DHCP Snooping Information Option Remote ID TR101 VLAN Field: enabled
DHCP Snooping Information Option TR101 Board ID: none
DHCP Snooping Information Policy: replace
DHCP Snooping is configured on the following VLANs:
```

```
Verify Source MAC-Address: enabled
```

Interface	Trusted	Max-Num	Circuit-ID mode	Circuit-ID Value	Circuit-ID TR101 VLAN	Carry To Client
Eth 1/1	No	16	VLAN-Unit-Port	---	enabled	disabled
Eth 1/2	No	16	VLAN-Unit-Port	---	enabled	disabled
Eth 1/3	No	16	VLAN-Unit-Port	---	enabled	disabled
Eth 1/4	No	16	VLAN-Unit-Port	---	enabled	disabled
Eth 1/5	No	16	VLAN-Unit-Port	---	enabled	disabled
:						
:						
:						

## show ip dhcp snooping binding

This command shows the DHCP snooping binding table entries.

**Command Mode**  
Privileged Exec

### Example

```

Console#show ip dhcp snooping binding
MAC Address          IP Address      Lease(sec)  Type           VLAN  Interface
-----
11-22-33-44-55-66  192.168.0.99   0           Dynamic-DHCPSNP  1    Eth 1/5
Console#
    
```

## DHCPv6 Snooping

DHCPv6 snooping allows a switch to protect a network from rogue DHCPv6 servers or other devices which send port-related information to a DHCPv6 server. This information can be useful in tracking an IP address back to a physical port. This section describes commands used to configure DHCPv6 snooping.

**Table 66: DHCP Snooping Commands**

Command	Function	Mode
<code>ipv6 dhcp snooping</code>	Enables DHCPv6 snooping globally	GC
<code>ipv6 dhcp snooping option remote-id</code>	Enables insertion of DHCPv6 Option 37 relay agent remote-id	GC
<code>ipv6 dhcp snooping option remote-id policy</code>	Sets the information option policy for DHCPv6 client packets that include Option 37 information	GC
<code>ipv6 dhcp snooping vlan</code>	Enables DHCPv6 snooping on the specified VLAN	GC
<code>ipv6 dhcp snooping max-binding</code>	Sets the maximum number of entries which can be stored in the binding database for an interface	IC
<code>ipv6 dhcp snooping trust</code>	Configures the specified interface as trusted	IC
<code>clear ipv6 dhcp snooping binding</code>	Clears DHCPv6 snooping binding table entries from RAM	PE
<code>clear ipv6 dhcp snooping statistics</code>	Clears statistical counters for DHCPv6 snooping client, server and relay packets	PE
<code>show ipv6 dhcp snooping</code>	Shows the DHCPv6 snooping configuration settings	PE
<code>show ipv6 dhcp snooping binding</code>	Shows the DHCPv6 snooping binding table entries	PE
<code>show ipv6 dhcp snooping statistics</code>	Shows statistics for DHCPv6 snooping client, server and relay packets	PE

**ipv6 dhcp snooping** This command enables DHCPv6 snooping globally. Use the **no** form to restore the default setting.

### Syntax

**[no] ipv6 dhcp snooping**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Network traffic may be disrupted when malicious DHCPv6 messages are received from an outside source. DHCPv6 snooping is used to filter DHCPv6 messages received on an unsecure interface from outside the network or fire wall. When DHCPv6 snooping is enabled globally by this command, and enabled on a VLAN interface by the **ipv6 dhcp snooping vlan** command, DHCP messages received on an untrusted interface (as specified by the **no ipv6 dhcp snooping trust** command) from a device not listed in the DHCPv6 snooping table will be dropped.
- ◆ When enabled, DHCPv6 messages entering an untrusted interface are filtered based upon dynamic entries learned via DHCPv6 snooping.
- ◆ Table entries are only learned for trusted interfaces. Each entry includes a MAC address, IPv6 address, lease time, binding type, VLAN identifier, and port identifier.
- ◆ When DHCPv6 snooping is enabled, the rate limit for the number of DHCPv6 messages that can be processed by the switch is 100 packets per second. Any DHCPv6 packets in excess of this limit are dropped.
- ◆ Filtering rules are implemented as follows:
  - If global DHCPv6 snooping is disabled, all DHCPv6 packets are forwarded.
  - If DHCPv6 snooping is enabled globally, and also enabled on the VLAN where the DHCPv6 packet is received, DHCPv6 packets are forwarded for a *trusted* port as described below.
  - If DHCPv6 snooping is enabled globally, and also enabled on the VLAN where the DHCP packet is received, but the port is *not trusted*, DHCP packets are processed according to message type as follows:

#### *DHCP Client Packet*

- Request: Update entry in binding cache, recording client's DHCPv6 Unique Identifier (DUID), server's DUID, Identity Association (IA) type, IA

Identifier, and address (4 message exchanges to get IPv6 address), and forward to trusted port.

- Solicit: Add new entry in binding cache, recording client's DUID, IA type, IA ID (2 message exchanges to get IPv6 address with rapid commit option, otherwise 4 message exchanges), and forward to trusted port.
- Decline: If no matching entry is found in binding cache, drop this packet.
- Renew, Rebind, Release, Confirm: If no matching entry is found in binding cache, drop this packet.
- If the DHCPv6 packet is not a recognizable type, it is dropped.

If a DHCPv6 packet from a client passes the filtering criteria above, it will only be forwarded to trusted ports in the same VLAN.

#### *DHCP Server Packet*

- If a DHCP server packet is received on an *untrusted* port, drop this packet and add a log entry in the system.
- If a DHCPv6 Reply packet is received from a server on a *trusted* port, it will be processed in the following manner:
  - a. Check if IPv6 address in IA option is found in binding table:
    - If yes, continue to C.
    - If not, continue to B.
  - b. Check if IPv6 address in IA option is found in binding cache:
    - If yes, continue to C.
    - If not, check failed, and forward packet to trusted port.
  - c. Check status code in IA option:
    - If successful, and entry is in binding table, update lease time and forward to original destination.
    - If successful, and entry is in binding cache, move entry from binding cache to binding table, update lease time and forward to original destination.
    - Otherwise, remove binding entry. and check failed.
    - If a DHCPv6 Relay packet is received, check the relay message option in Relay-Forward or Relay-Reply packet, and process client and server packets as described above.

- ◆ If DHCPv6 snooping is globally disabled, all dynamic bindings are removed from the binding table.
- ◆ *Additional considerations when the switch itself is a DHCPv6 client* – The port(s) through which the switch submits a client request to the DHCPv6 server must be configured as trusted (using the `ipv6 dhcp snooping trust` command). Note that the switch will not add a dynamic entry for itself to the binding table when it receives an ACK message from a DHCPv6 server. Also, when the switch sends out DHCPv6 client packets for itself, no filtering takes place. However, when the switch receives any messages from a DHCPv6 server, any packets received from untrusted ports are dropped.

### Example

This example enables DHCPv6 snooping globally for the switch.

```
Console(config)#ipv6 dhcp snooping
Console(config)#
```

### Related Commands

[ipv6 dhcp snooping vlan \(356\)](#)  
[ipv6 dhcp snooping trust \(357\)](#)

### ipv6 dhcp snooping option remote-id

This command enables the insertion of remote-id option 37 information into DHCPv6 client messages. Remote-id option information such as the port attached to the client, DUID, and VLAN ID is used by the DHCPv6 server to assign preassigned configuration data specific to the DHCPv6 client. Use the **no** form of the command to disable this function.

### Syntax

**[no] ipv6 dhcp snooping option remote-id**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ DHCPv6 provides a relay mechanism for sending information about the switch and its DHCPv6 clients to the DHCPv6 server. Known as DHCPv6 Option 37, it allows compatible DHCPv6 servers to use the information when assigning IP addresses, or to set other services or policies for clients.
- ◆ When DHCPv6 Snooping Information Option 37 is enabled, the requesting client (or an intermediate relay agent that has used the information fields to describe itself) can be identified in the DHCPv6 request packets forwarded by the switch and in reply packets sent back from the DHCPv6 server.

- ◆ When the DHCPv6 Snooping Option 37 is enabled, clients can be identified by the switch port to which they are connected rather than just their MAC address. DHCPv6 client-server exchange messages are then forwarded directly between the server and client without having to flood them to the entire VLAN.
- ◆ DHCPv6 snooping must be enabled for the DHCPv6 Option 37 information to be inserted into packets. When enabled, the switch will either drop, keep or remove option 37 information in incoming DHCPv6 packets. Packets are processed as follows:
  - If an incoming packet is a DHCPv6 request packet with option 37 information, it will modify the option 37 information according to settings specified with `ipv6 dhcp snooping option remote-id policy` command.
  - If an incoming packet is a DHCPv6 request packet without option 37 information, enabling the DHCPv6 snooping information option will add option 37 information to the packet.
  - If an incoming packet is a DHCPv6 reply packet with option 37 information, enabling the DHCPv6 snooping information option will remove option 37 information from the packet.
- ◆ When this switch inserts Option 37 information in DHCPv6 client request packets, the switch's MAC address (hexadecimal) is used for the remote ID.

### Example

This example enables the DHCPv6 Snooping Remote-ID Option.

```
Console(config)#ipv6 dhcp snooping option remote-id
Console(config)#
```

### ipv6 dhcp snooping option remote-id policy

This command sets the remote-id option policy for DHCPv6 client packets that include Option 37 information. Use the **no** form to disable this function.

#### Syntax

**ipv6 dhcp snooping option remote-id policy {drop | keep | replace}**

**no ipv6 dhcp snooping option remote-id policy**

**drop** - Drops the client's request packet instead of relaying it.

**keep** - Retains the Option 37 information in the client request, and forwards the packets to trusted ports.

**replace** - Replaces the Option 37 remote-ID in the client's request with the relay agent's remote-ID (when DHCPv6 snooping is enabled), and forwards the packets to trusted ports.

#### Default Setting

drop

### Command Mode

Global Configuration

### Command Usage

When the switch receives DHCPv6 packets from clients that already include DHCP Option 37 information, the switch can be configured to set the action policy for these packets. The switch can either drop the DHCPv6 packets, keep the existing information, or replace it with the switch's relay agent information.

### Example

This example configures the switch to keep existing remote-id option 37 information within DHCPv6 client packets and forward it.

```
Console(config)#ipv6 dhcp snooping option remote-id policy keep  
Console(config)#
```

**ipv6 dhcp snooping vlan** This command enables DHCPv6 snooping on the specified VLAN. Use the **no** form to restore the default setting.

### Syntax

**[no] ipv6 dhcp snooping vlan** {*vlan-id* | *vlan-range*}

*vlan-id* - ID of a configured VLAN (Range: 1-4094)

*vlan-range* - A consecutive range of VLANs indicated by the use a hyphen, or a random group of VLANs with each entry separated by a comma.

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ When DHCPv6 snooping enabled globally using the [ipv6 dhcp snooping](#) command, and enabled on a VLAN with this command, DHCPv6 packet filtering will be performed on any untrusted ports within the VLAN as specified by the [ipv6 dhcp snooping trust](#) command.
- ◆ When the DHCPv6 snooping is globally disabled, DHCPv6 snooping can still be configured for specific VLANs, but the changes will not take effect until DHCPv6 snooping is globally re-enabled.
- ◆ When DHCPv6 snooping is enabled globally, and then disabled on a VLAN, all dynamic bindings learned for this VLAN are removed from the binding table.

### Example

This example enables DHCPv6 snooping for VLAN 1.

```
Console(config)#ipv6 dhcp snooping vlan 1
Console(config)#
```

### Related Commands

[ipv6 dhcp snooping \(352\)](#)

[ipv6 dhcp snooping trust \(357\)](#)

**ipv6 dhcp snooping max-binding** This command sets the maximum number of entries which can be stored in the binding database for an interface. Use the **no** form to restore the default setting.

### Syntax

**ipv6 dhcp snooping max-binding** *count*

**no ipv6 dhcp snooping max-binding**

*count* - Maximum number of entries. (Range: 1-5)

### Default Setting

5

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Example

This example sets the maximum number of binding entries to 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#ipv6 dhcp snooping max-binding 1
Console(config-if)#
```

**ipv6 dhcp snooping trust** This command configures the specified interface as trusted. Use the **no** form to restore the default setting.

### Syntax

**[no] ipv6 dhcp snooping trust**

### Default Setting

All interfaces are untrusted

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ A trusted interface is an interface that is configured to receive only messages from within the network. An untrusted interface is an interface that is configured to receive messages from outside the network or fire wall.
- ◆ Set all ports connected to DHCPv6 servers within the local network or fire wall to trusted, and all other ports outside the local network or fire wall to untrusted.
- ◆ When DHCPv6 snooping is enabled globally using the [ipv6 dhcp snooping](#) command, and enabled on a VLAN with [ipv6 dhcp snooping vlan](#) command, DHCPv6 packet filtering will be performed on any untrusted ports within the VLAN according to the default status, or as specifically configured for an interface with the **no ipv6 dhcp snooping trust** command.
- ◆ When an untrusted port is changed to a trusted port, all the dynamic DHCPv6 snooping bindings associated with this port are removed.
- ◆ *Additional considerations when the switch itself is a DHCPv6 client* – The port(s) through which it submits a client request to the DHCPv6 server must be configured as trusted.

### Example

This example sets port 5 to untrusted.

```
Console(config)#interface ethernet 1/5
Console(config-if)#no ipv6 dhcp snooping trust
Console(config-if)#
```

### Related Commands

[ipv6 dhcp snooping \(352\)](#)

[ipv6 dhcp snooping vlan \(356\)](#)

**clear ipv6 dhcp snooping binding** This command clears DHCPv6 snooping binding table entries from RAM. Use this command without any optional keywords to clear all entries from the binding table.

### Syntax

**clear ipv6 dhcp snooping binding** [*mac-address* *ipv6-address*]

*mac-address* - Specifies a MAC address entry. (Format: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx)

*ipv6-address* - Corresponding IPv6 address. This address must be entered according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

### Command Mode

Privileged Exec

### Example

```
Console(config)#clear ipv6 dhcp snooping binding 00-12-cf-01-02-03 2001::1
Console(config)#
```

**clear ipv6 dhcp snooping statistics** This command clears statistical counters for DHCPv6 snooping client, server and relay packets.

### Command Mode

Privileged Exec

### Example

```
Console(config)#clear ipv6 dhcp snooping statistics
Console(config)#
```

**show ipv6 dhcp snooping** This command shows the DHCPv6 snooping configuration settings.

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 dhcp snooping
Global DHCPv6 Snooping status: disabled
DHCPv6 Snooping remote-id option status: disabled
DHCPv6 Snooping remote-id policy: drop
DHCPv6 Snooping interface-id option status: enabled
DHCPv6 Snooping interface-id policy: replace
DHCPv6 Snooping is configured on the following VLANs:
```

Interface	Trusted	Max-binding	Current-binding
Eth 1/1	No	5	0
Eth 1/2	No	5	0
Eth 1/3	No	5	0
Eth 1/4	No	5	0
Eth 1/5	Yes	5	0
:			
:			

**show ipv6 dhcp snooping binding** This command shows the DHCPv6 snooping binding table entries.

**Command Mode**  
Privileged Exec

**Example**

```
Console#show ipv6 dhcp snooping binding
NA - Non-temporary address
TA - Temporary address
-----
Link-layer Address: 00-13-49-aa-39-26
IPv6 Address                               Lifetime  VLAN Port  Type
-----
2001:b021:1435:5612:ab3c:6792:a452:6712    2591998   1 Eth 1/5  NA
-----
Link-layer Address: 00-12-cf-01-02-03
IPv6 Address                               Lifetime  VLAN Port  Type
-----
                                           2001:b000::1  2591912   1 Eth 1/3  NA
Console#
```

**show ipv6 dhcp snooping statistics** This command shows statistics for DHCPv6 snooping client, server and relay packets.

**Command Mode**  
Privileged Exec

**Example**

```
Console#show ipv6 dhcp snooping statistics
DHCPv6 Snooping Statistics:
  Client Packet: Solicit, Request, Confirm, Renew, Rebind,
                 Decline, Release, Information-request
  Server Packet: Advertise, Reply, Reconfigure
  Relay Packet:  Relay-forward, Relay-reply
State   Client   Server   Relay    Total
-----
Received 10       9        0        19
Sent     9        9        0        18
Dropped  1        0        0        1
Console#
```

## IPv4 Source Guard

IPv4 Source Guard is a security feature that filters IPv4 traffic on network interfaces based on manually configured entries in the IPv4 Source Guard table, or dynamic entries in the DHCPv4 Snooping table when enabled (see “[DHCPv4 Snooping](#)” on [page 337](#)). IPv4 source guard can be used to prevent traffic attacks caused when a host tries to use the IPv4 address of a neighbor to access the network. This section describes commands used to configure IPv4 Source Guard.

**Table 67: IPv4 Source Guard Commands**

Command	Function	Mode
<code>ip source-guard binding</code>	Adds a static address to the source-guard binding table	GC
<code>ip source-guard</code>	Configures the switch to filter inbound traffic based on source IP address, or source IP address and corresponding MAC address	IC
<code>ip source-guard max-binding</code>	Sets the maximum number of entries that can be bound to an interface	IC
<code>ip source-guard mode</code>	Sets the source-guard learning mode to search for addresses in the ACL binding table or the MAC address binding table	IC
<code>clear ip source-guard binding blocked</code>	Remove all blocked records	PE
<code>show ip source-guard</code>	Shows whether source guard is enabled or disabled on each interface	PE
<code>show ip source-guard binding</code>	Shows the source guard binding table	PE

**ip source-guard binding** This command adds a static address to the source-guard ACL or MAC address binding table. Use the **no** form to remove a static entry.

### Syntax

```
ip source-guard binding [mode {acl | mac}] mac-address
vlan vlan-id ip-address interface ethernet unit/port-list
```

```
no ip source-guard binding [mode {acl | mac}] mac-address ip-address
```

**mode** - Specifies the binding mode.

**acl** - Adds binding to ACL table.

**mac** - Adds binding to MAC address table.

*mac-address* - A valid unicast MAC address.

*vlan-id* - ID of a configured VLAN for an ACL filtering table or a range of VLANs for a MAC address filtering table. To specify a list separate nonconsecutive VLAN identifiers with a comma and no spaces; use a hyphen to designate a range of IDs. (Range: 1-4094)

*ip-address* - A valid unicast IP address, including classful types A, B or C.

*unit* - Unit identifier. (Range: 1)

*port-list* - Physical port number or list of port numbers. Separate nonconsecutive port numbers with a comma and no spaces; or use a hyphen to designate a range of port numbers. (Range: 1-28/54)

### Default Setting

No configured entries

### Command Mode

Global Configuration

### Command Usage

- ◆ If the binding mode is not specified in this command, the entry is bound to the ACL table by default.
- ◆ Table entries include a MAC address, IP address, lease time, entry type (Static-IP-SG-Binding, Dynamic-DHCP-Binding), VLAN identifier, and port identifier.
- ◆ All static entries are configured with an infinite lease time, which is indicated with a value of zero by the `show ip source-guard` command.
- ◆ When source guard is enabled, traffic is filtered based upon dynamic entries learned via DHCP snooping, or static addresses configured in the source guard binding table with this command.
- ◆ An entry with same MAC address and a different VLAN ID cannot be added to the binding table.
- ◆ Static bindings are processed as follows:
  - A valid static IP source guard entry will be added to the binding table in ACL mode if one of the following conditions is true:
    - If there is no binding entry with the same VLAN ID and MAC address, a new entry will be added to the binding table using the type of static IP source guard binding.
    - If there is an entry with the same VLAN ID and MAC address, and the type of entry is static IP source guard binding, then the new entry will replace the old one.
    - If there is an entry with the same VLAN ID and MAC address, and the type of the entry is dynamic DHCP snooping binding, then the new entry will replace the old one and the entry type will be changed to static IP source guard binding.
    - Note that a static IP source guard entry cannot be added for a non-existent VLAN.
  - A valid static IP source guard entry will be added to the binding table in MAC mode if one of the following conditions are true:

- If there is no binding entry with the same IP address and MAC address, a new entry will be added to the binding table using the type of static IP source guard binding entry.
  - If there is a binding entry with same IP address and MAC address, then the new entry shall replace the old one.
- ◆ Only unicast addresses are accepted for static bindings.

### Example

This example configures a static source-guard binding on port 5. Since the binding mode is not specified, the entry is bound to the ACL table by default.

```
Console(config)#ip source-guard binding 00-E0-4C-68-14-79 vlan 1 192.168.0.99
interface ethernet 1/5
Console(config-if)#
```

### Related Commands

- [ip source-guard \(363\)](#)
- [ip dhcp snooping \(338\)](#)
- [ip dhcp snooping vlan \(345\)](#)

**ip source-guard** This command configures the switch to filter inbound traffic based on source IP address, or source IP address and corresponding MAC address. Use the **no** form to disable this function.

### Syntax

**ip source-guard {sip | sip-mac}**

**no ip source-guard**

**sip** - Filters traffic based on IP addresses stored in the binding table.

**sip-mac** - Filters traffic based on IP addresses and corresponding MAC addresses stored in the binding table.

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Source guard is used to filter traffic on an insecure port which receives messages from outside the network or fire wall, and therefore may be subject to traffic attacks caused by a host trying to use the IP address of a neighbor.
- ◆ Setting source guard mode to "sip" or "sip-mac" enables this function on the selected port. Use the "sip" option to check the VLAN ID, source IP address, and

port number against all entries in the binding table. Use the “sip-mac” option to check these same parameters, plus the source MAC address. Use the **no ip source guard** command to disable this function on the selected port.

- ◆ When enabled, traffic is filtered based upon dynamic entries learned via DHCP snooping, or static addresses configured in the source guard binding table.
- ◆ Table entries include a MAC address, IP address, lease time, entry type (Static-IP-SG-Binding, Dynamic-DHCP-Binding, VLAN identifier, and port identifier.
- ◆ Static addresses entered in the source guard binding table with the **ip source-guard binding** command are automatically configured with an infinite lease time. Dynamic entries learned via DHCP snooping are configured by the DHCP server itself.
- ◆ If the IP source guard is enabled, an inbound packet’s IP address (sip option) or both its IP address and corresponding MAC address (sip-mac option) will be checked against the binding table. If no matching entry is found, the packet will be dropped.
- ◆ Filtering rules are implemented as follows:
  - If DHCPv4 snooping is disabled (see [page 338](#)), IP source guard will check the VLAN ID, source IP address, port number, and source MAC address (for the sip-mac option). If a matching entry is found in the binding table and the entry type is static IP source guard binding, the packet will be forwarded.
  - If the DHCP snooping is enabled, IP source guard will check the VLAN ID, source IP address, port number, and source MAC address (for the sip-mac option). If a matching entry is found in the binding table and the entry type is static IP source guard binding, or dynamic DHCP snooping binding, the packet will be forwarded.
  - If IP source guard is enabled on an interface for which IP source bindings (dynamically learned via DHCP snooping or manually configured) are not yet configured, the switch will drop all IP traffic on that port, except for DHCP packets allowed by DHCP snooping.
  - Only unicast addresses are accepted for static bindings.

### Example

This example enables IP source guard on port 5.

```
Console(config)#interface ethernet 1/5
Console(config-if)#ip source-guard sip
Console(config-if)#
```

### Related Commands

[ip source-guard binding \(361\)](#)

[ip dhcp snooping \(338\)](#)

[ip dhcp snooping vlan \(345\)](#)

**ip source-guard max-binding** This command sets the maximum number of entries that can be bound to an interface. Use the **no** form to restore the default setting.

### Syntax

**ip source-guard [mode {acl | mac}] max-binding *number***

**no ip source-guard [mode {acl | mac}] max-binding**

**mode** - Specifies the learning mode.

**acl** - Searches for addresses in the ACL table.

**mac** - Searches for addresses in the MAC address table.

*number* - The maximum number of IP addresses that can be mapped to an interface in the binding table. (Range: 1-10)

### Default Setting

Mode: ACL, Maximum Binding: 5

Mode: MAC, Maximum Binding: 16

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ This command sets the maximum number of address entries that can be mapped to an interface in the binding table for the specified mode (ACL binding table or MAC address table) including dynamic entries discovered by DHCP snooping and static entries set by the [ip source-guard](#) command.
- ◆ The maximum binding for ACL mode restricts the number of “active” entries per port. If binding entries exceed the maximum number in IP source guard, only the maximum number of binding entries will be set. Dynamic binding entries exceeding the maximum number will be created but will not be active.
- ◆ The maximum binding for MAC mode restricts the number of MAC addresses learned per port. Authenticated IP traffic with different source MAC addresses cannot be learned if it would exceed this maximum number.

### Example

This example sets the maximum number of allowed entries for ACL mode in the binding table for port 5 to one entry. The mode is not specified, and therefore defaults to the ACL binding table.

```
Console(config)#interface ethernet 1/5
Console(config-if)#ip source-guard max-binding 1
Console(config-if)#
```

**ip source-guard mode** This command sets the source-guard learning mode to search for addresses in the ACL binding table or the MAC address binding table. Use the **no** form to restore the default setting.

### Syntax

**ip source-guard mode {acl | mac}**

**no ip source-guard mode**

**mode** - Specifies the learning mode.

**acl** - Searches for addresses in the ACL binding table.

**mac** - Searches for addresses in the MAC address binding table.

### Default Setting

ACL

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

There are two modes for the filtering table:

- ◆ ACL - IP traffic will be forwarded if it passes the checking process in the ACL mode binding table.
- ◆ MAC - A MAC entry will be added in MAC address table if IP traffic passes the checking process in MAC mode binding table.

### Example

This command sets the binding table mode for the specified interface to MAC mode:

```
Console(config)#interface ethernet 1/5
Console(config-if)#ip source-guard mode mac
Console(config-if)#
```

**clear ip source-guard binding blocked** This command clears source-guard binding table entries from RAM.

#### Syntax

**clear ip source-guard binding blocked**

#### Command Mode

Privileged Exec

#### Command Usage

When IP Source-Guard detects an invalid packet it creates a blocked record. These records can be viewed using the [show ip source-guard binding blocked](#) command. A maximum of 512 blocked records can be stored before the switch overwrites the oldest record with new blocked records. Use the **clear ip source-guard binding blocked** command to clear this table.

#### Example

This command clears the blocked record table.

```
Console(config)#clear ip source-guard binding blocked
Console(config)#
```

**show ip source-guard** This command shows whether source guard is enabled or disabled on each interface.

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip source-guard
```

Interface	Filter-type	Filter-table	ACL Table Max-binding	MAC Table Max-binding
Eth 1/1	DISABLED	ACL	5	1024
Eth 1/2	DISABLED	ACL	5	1024
Eth 1/3	DISABLED	ACL	5	1024
Eth 1/4	DISABLED	ACL	5	1024
Eth 1/5	DISABLED	ACL	5	1024
:				

**show ip source-guard binding** This command shows the source guard binding table.

#### Syntax

**show ip source-guard binding** [**dhcp-snooping** | **static** [**acl** | **mac**] | **blocked** [**vlan** *vlan-id* | **interface** *interface*]

**dhcp-snooping** - Shows dynamic entries configured with DHCP Snooping commands (see [page 337](#))

**static** - Shows static entries configured with the [ip source-guard binding](#) command.

**acl** - Shows static entries in the ACL binding table.

**mac** - Shows static entries in the MAC address binding table.

**blocked** - Shows MAC addresses which have been blocked by IP Source Guard.

*vlan-id* - ID of a configured VLAN (Range: 1-4094)

*interface* - Specifies a port interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip source-guard binding
MAC Address      IP Address      Type           VLAN      Interface
-----
00-10-b5-f4-d0-01 10.2.44.96     static-acl     1         Eth 1/1
Console#
```

## IPv6 Source Guard

IPv6 Source Guard is a security feature that filters IPv6 traffic on non-routed, Layer 2 network interfaces based on manually configured entries in the IPv6 Source Guard table, or dynamic entries in the Neighbor Discovery Snooping table or DHCPv6 Snooping table when either snooping protocol is enabled (see “[DHCPv6 Snooping](#)” on page 351). IPv6 source guard can be used to prevent traffic attacks caused when a host tries to use the IPv6 address of a neighbor to access the network. This section describes commands used to configure IPv6 Source Guard.

**Table 68: IPv6 Source Guard Commands**

Command	Function	Mode
<code>ipv6 source-guard binding</code>	Adds a static address to the source-guard binding table	GC
<code>ipv6 source-guard</code>	Configures the switch to filter inbound traffic based on source IP address	IC
<code>ipv6 source-guard max-binding</code>	Sets the maximum number of entries that can be bound to an interface	IC
<code>show ipv6 source-guard</code>	Shows whether source guard is enabled or disabled on each interface	PE
<code>show ipv6 source-guard binding</code>	Shows the source guard binding table	PE

**ipv6 source-guard binding** This command adds a static address to the source-guard binding table. Use the **no** form to remove a static entry.

### Syntax

**ipv6 source-guard binding** *mac-address* **vlan** *vlan-id* *ipv6-address*  
**interface** *interface*

**no ipv6 source-guard binding** *mac-address* *ipv6-address*

*mac-address* - A valid unicast MAC address.

*vlan-id* - ID of a configured VLAN (Range: 1-4094)

*ipv6-address* - Corresponding IPv6 address. This address must be entered according to RFC 2373 “IPv6 Addressing Architecture,” using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Default Setting

No configured entries

### Command Mode

Global Configuration

### Command Usage

- ◆ Table entries include an associated MAC address, IPv6 global unicast address, entry type (Static-IPv6-SG-Binding, Dynamic-ND-Snooping, Dynamic-DHCPv6-Snooping), VLAN identifier, and port identifier.
- ◆ Traffic filtering is based only on the source IPv6 address, VLAN ID, and port number.
- ◆ All static entries are configured with an infinite lease time, which is indicated with a value of zero by the `show ipv6 source-guard` command.
- ◆ When source guard is enabled, traffic is filtered based upon dynamic entries learned via ND snooping, DHCPv6 snooping, or static addresses configured in the source guard binding table with this command.
- ◆ An entry with same MAC address and a different VLAN ID cannot be added to the binding table.
- ◆ Static bindings are processed as follows:
  - If there is no entry with same and MAC address and IPv6 address, a new entry is added to binding table using static IPv6 source guard binding.
  - If there is an entry with same MAC address and IPv6 address, and the type of entry is static IPv6 source guard binding, then the new entry will replace the old one.
  - If there is an entry with same MAC address and IPv6 address, and the type of the entry is either a dynamic ND snooping binding or DHCPv6 snooping binding, then the new entry will replace the old one and the entry type will be changed to static IPv6 source guard binding.
  - Only unicast addresses are accepted for static bindings.

### Example

This example configures a static source-guard binding on port 5.

```
Console(config)#ipv6 source-guard binding 00-ab-11-cd-23-45 vlan 1 2001::1
interface ethernet 1/5
Console(config)#
```

### Related Commands

[ipv6 source-guard \(371\)](#)

[ipv6 dhcp snooping \(352\)](#)  
[ipv6 dhcp snooping vlan \(356\)](#)

**ipv6 source-guard** This command configures the switch to filter inbound traffic based on the source IP address stored in the binding table. Use the **no** form to disable this function.

### Syntax

**ipv6 source-guard sip**  
**no ipv6 source-guard**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Source guard is used to filter traffic on an insecure port which receives messages from outside the network or fire wall, and therefore may be subject to traffic attacks caused by a host trying to use the IP address of a neighbor.
- ◆ This command checks the VLAN ID, IPv6 global unicast source IP address, and port number against all entries in the binding table. Use the **no ipv6 source guard** command to disable this function on the selected port.
- ◆ After IPv6 source guard is enabled on an interface, the switch initially blocks all IPv6 traffic received on that interface, except for ND packets allowed by ND snooping and DHCPv6 packets allowed by DHCPv6 snooping. A port access control list (ACL) is applied to the interface. Traffic is then filtered based upon dynamic entries learned via ND snooping or DHCPv6 snooping, or static addresses configured in the source guard binding table. The port allows only IPv6 traffic with a matching entry in the binding table and denies all other IPv6 traffic.
- ◆ Table entries include a MAC address, IPv6 global unicast address, entry type (Static-IPv6-SG-Binding, Dynamic-ND-Snooping, Dynamic-DHCPv6-Snooping), VLAN identifier, and port identifier.
- ◆ Static addresses entered in the source guard binding table with the [ipv6 source-guard binding](#) command are automatically configured with an infinite lease time. Dynamic entries learned via DHCPv6 snooping are configured by the DHCPv6 server itself.
- ◆ If IPv6 source guard is enabled, an inbound packet's source IPv6 address will be checked against the binding table. If no matching entry is found, the packet will be dropped.

- ◆ Filtering rules are implemented as follows:
  - If ND snooping and DHCPv6 snooping are disabled, IPv6 source guard will check the VLAN ID, source IPv6 address, and port number. If a matching entry is found in the binding table and the entry type is static IPv6 source guard binding, the packet will be forwarded.
  - If ND snooping or DHCPv6 snooping is enabled, IPv6 source guard will check the VLAN ID, source IP address, and port number. If a matching entry is found in the binding table and the entry type is static IPv6 source guard binding, dynamic ND snooping binding, or dynamic DHCPv6 snooping binding, the packet will be forwarded.
  - If IPv6 source guard is enabled on an interface for which IPv6 source bindings (dynamically learned via ND snooping or DHCPv6 snooping, or manually configured) are not yet configured, the switch will drop all IPv6 traffic on that port, except for ND packets and DHCPv6 packets allowed by DHCPv6 snooping.
  - Only IPv6 global unicast addresses are accepted for static bindings.

### Example

This example enables IP source guard on port 5.

```
Console(config)#interface ethernet 1/5
Console(config-if)#ipv6 source-guard sip
Console(config-if)#
```

### Related Commands

[ipv6 source-guard binding \(369\)](#)

[ipv6 dhcp snooping \(352\)](#)

[ipv6 dhcp snooping vlan \(356\)](#)

**ipv6 source-guard max-binding** This command sets the maximum number of entries that can be bound to an interface. Use the **no** form to restore the default setting.

### Syntax

**ipv6 source-guard max-binding** *number*

**no ipv6 source-guard max-binding**

*number* - The maximum number of IPv6 addresses that can be mapped to an interface in the binding table. (Range: 1-5)

### Default Setting

5

## Command Mode

Interface Configuration (Ethernet)

## Command Usage

- ◆ This command sets the maximum number of address entries that can be mapped to an interface in the binding table, including both dynamic entries discovered by ND snooping, DHCPv6 snooping, and static entries set by the `ipv6 source-guard` command.
- ◆ IPv6 source guard maximum bindings must be set to a value higher than DHCPv6 snooping maximum bindings and ND snooping maximum bindings.
- ◆ If IPv6 source guard, ND snooping, and DHCPv6 snooping are enabled on a port, the dynamic bindings used by ND snooping, DHCPv6 snooping, and IPv6 source guard static bindings cannot exceed the maximum allowed bindings set by the **ipv6 source-guard max-binding** command. In other words, no new entries will be added to the IPv6 source guard binding table.
- ◆ If IPv6 source guard is enabled on a port, and the maximum number of allowed bindings is changed to a lower value, precedence is given to deleting entries learned through DHCPv6 snooping, ND snooping, and then manually configured IPv6 source guard static bindings, until the number of entries in the binding table reaches the newly configured maximum number of allowed bindings.

## Example

This example sets the maximum number of allowed entries in the binding table for port 5 to one entry.

```

Console(config)#interface ethernet 1/5
Console(config-if)#ipv6 source-guard max-binding 1
Console(config-if)#

```

**show ipv6 source-guard** This command shows whether IPv6 source guard is enabled or disabled on each interface, and the maximum allowed bindings.

## Command Mode

Privileged Exec

## Example

```

Console#show ipv6 source-guard
ipv6 permit link-local status: disable

Interface  Filter-type  Max-binding
-----  -
Eth 1/1    Disabled      5
Eth 1/2    Disabled      5
Eth 1/3    Disabled      5
Eth 1/4    Disabled      5

```

```
Eth 1/5      SIP          1
Eth 1/6      Disabled       5
:
```

**show ipv6 source-guard binding** This command shows the IPv6 source guard binding table.

#### Syntax

**show ipv6 source-guard binding [dynamic | static]**

**dynamic** - Shows dynamic entries configured with ND Snooping or DHCPv6 Snooping commands (see [page 351](#))

**static** - Shows static entries configured with the [ipv6 source-guard binding](#) command.

#### Command Mode

Privileged Exec

#### Example

```
Console#show ipv6 source-guard binding
DHCPV6SNP:
  DHCP - Stateful address
NDSNP:
  ND - Stateless address
STA - Static IPv6 source guard binding

MAC Address      IPv6 Address      VLAN Interface Type
-----
00AB-11CD-2345   2001::1          1 Eth 1/5 STA
Console#
```

## ARP Inspection

ARP Inspection validates the MAC-to-IP address bindings in Address Resolution Protocol (ARP) packets. It protects against ARP traffic with invalid address bindings, which forms the basis for certain “man-in-the-middle” attacks. This is accomplished by intercepting all ARP requests and responses and verifying each of these packets before the local ARP cache is updated or the packet is forwarded to the appropriate destination, dropping any invalid ARP packets.

ARP Inspection determines the validity of an ARP packet based on valid IP-to-MAC address bindings stored in a trusted database – the DHCP snooping binding database. ARP Inspection can also validate ARP packets against user-configured ARP access control lists (ACLs) for hosts with statically configured IP addresses.

This section describes commands used to configure ARP Inspection.

**Table 69: ARP Inspection Commands**

Command	Function	Mode
<code>ip arp inspection</code>	Enables ARP Inspection globally on the switch	GC
<code>ip arp inspection filter</code>	Specifies an ARP ACL to apply to one or more VLANs	GC
<code>ip arp inspection log-buffer logs</code>	Sets the maximum number of entries saved in a log message, and the rate at these messages are sent	GC
<code>ip arp inspection validate</code>	Specifies additional validation of address components in an ARP packet	GC
<code>ip arp inspection vlan</code>	Enables ARP Inspection for a specified VLAN or range of VLANs	GC
<code>ip arp inspection limit</code>	Sets a rate limit for the ARP packets received on a port	IC
<code>ip arp inspection trust</code>	Sets a port as trusted, and thus exempted from ARP Inspection	IC
<code>show ip arp inspection configuration</code>	Displays the global configuration settings for ARP Inspection	PE
<code>show ip arp inspection interface</code>	Shows the trust status and inspection rate limit for ports	PE
<code>show ip arp inspection log</code>	Shows information about entries stored in the log, including the associated VLAN, port, and address components	PE
<code>show ip arp inspection statistics</code>	Shows statistics about the number of ARP packets processed, or dropped for various reasons	PE
<code>show ip arp inspection vlan</code>	Shows configuration setting for VLANs, including ARP Inspection status, the ARP ACL name, and if the DHCP Snooping database is used after ACL validation is completed	PE

**ip arp inspection** This command enables ARP Inspection globally on the switch. Use the **no** form to disable this function.

#### Syntax

**[no] ip arp inspection**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ When ARP Inspection is enabled globally with this command, it becomes active only on those VLANs where it has been enabled with the `ip arp inspection vlan` command.

- ◆ When ARP Inspection is enabled globally and enabled on selected VLANs, all ARP request and reply packets on those VLANs are redirected to the CPU and their switching is handled by the ARP Inspection engine.
- ◆ When ARP Inspection is disabled globally, it becomes inactive for all VLANs, including those where ARP Inspection is enabled.
- ◆ When ARP Inspection is disabled, all ARP request and reply packets bypass the ARP Inspection engine and their manner of switching matches that of all other packets.
- ◆ Disabling and then re-enabling global ARP Inspection will not affect the ARP Inspection configuration for any VLANs.
- ◆ When ARP Inspection is disabled globally, it is still possible to configure ARP Inspection for individual VLANs. These configuration changes will only become active after ARP Inspection is globally enabled again.

### Example

```
Console(config)#ip arp inspection
Console(config)#
```

**ip arp inspection filter** This command specifies an ARP ACL to apply to one or more VLANs. Use the **no** form to remove an ACL binding. Use the **no** form to remove an ACL binding.

### Syntax

**ip arp inspection filter** *arp-acl-name* **vlan** {*vlan-id* | *vlan-range*} [**static**]

**no ip arp inspection filter** *arp-acl-name* **vlan** {*vlan-id* | *vlan-range*}

*arp-acl-name* - Name of an ARP ACL. (Maximum length: 16 characters)

*vlan-id* - VLAN ID. (Range: 1-4094)

*vlan-range* - A consecutive range of VLANs indicated by the use a hyphen, or a random group of VLANs with each entry separated by a comma.

**static** - ARP packets are only validated against the specified ACL, address bindings in the DHCP snooping database is not checked.

### Default Setting

ARP ACLs are not bound to any VLAN  
Static mode is not enabled

### Command Mode

Global Configuration

### Command Usage

- ◆ ARP ACLs are configured with the commands described under “ARP ACLs” on page 414.
- ◆ If static mode is enabled, the switch compares ARP packets to the specified ARP ACLs. Packets matching an IP-to-MAC address binding in a permit or deny rule are processed accordingly. Packets not matching any of the ACL rules are dropped. Address bindings in the DHCP snooping database are not checked.
- ◆ If static mode is not enabled, packets are first validated against the specified ARP ACL. Packets matching a deny rule are dropped. All remaining packets are validated against the address bindings in the DHCP snooping database.

### Example

```
Console(config)#ip arp inspection filter sales vlan 1
Console(config)#
```

### ip arp inspection log-buffer logs

This command sets the maximum number of entries saved in a log message, and the rate at which these messages are sent. Use the **no** form to restore the default settings.

### Syntax

**ip arp inspection log-buffer logs** *message-number* **interval** *seconds*

**no ip arp inspection log-buffer logs**

*message-number* - The maximum number of entries saved in a log message. (Range: 0-256, where 0 means no events are saved and no messages sent)

*seconds* - The interval at which log messages are sent. (Range: 0-86400)

### Default Setting

Message Number: 20

Interval: 10 seconds

### Command Mode

Global Configuration

### Command Usage

- ◆ ARP Inspection must be enabled with the `ip arp inspection` command before this command will be accepted by the switch.
- ◆ By default, logging is active for ARP Inspection, and cannot be disabled.
- ◆ When the switch drops a packet, it places an entry in the log buffer. Each entry contains flow information, such as the receiving VLAN, the port number, the source and destination IP addresses, and the source and destination MAC addresses.

- ◆ If multiple, identical invalid ARP packets are received consecutively on the same VLAN, then the logging facility will only generate one entry in the log buffer and one corresponding system message.
- ◆ The maximum number of entries that can be stored in the log buffer is determined by the *message-number* parameter. If the log buffer fills up before a message is sent, the oldest entry will be replaced with the newest one.
- ◆ The switch generates a system message on a rate-controlled basis determined by the *seconds* values. After the system message is generated, all entries are cleared from the log buffer.

### Example

```
Console(config)#ip arp inspection log-buffer logs 1 interval 10  
Console(config)#
```

**ip arp inspection validate** This command specifies additional validation of address components in an ARP packet. Use the **no** form to restore the default setting.

### Syntax

#### **ip arp inspection validate**

**{dst-mac [ip [allow-zeros] [src-mac]] | ip [allow-zeros] [src-mac] | src-mac}**

#### **no ip arp inspection validate**

**dst-mac** - Checks the destination MAC address in the Ethernet header against the target MAC address in the ARP body. This check is performed for ARP responses. When enabled, packets with different MAC addresses are classified as invalid and are dropped.

**ip** - Checks the ARP body for invalid and unexpected IP addresses. Addresses include 0.0.0.0, 255.255.255.255, and all IP multicast addresses. Sender IP addresses are checked in all ARP requests and responses, while target IP addresses are checked only in ARP responses.

**allow-zeros** - Allows sender IP address to be 0.0.0.0.

**src-mac** - Checks the source MAC address in the Ethernet header against the sender MAC address in the ARP body. This check is performed on both ARP requests and responses. When enabled, packets with different MAC addresses are classified as invalid and are dropped.

### Default Setting

No additional validation is performed

### Command Mode

Global Configuration

### Command Usage

By default, ARP Inspection only checks the IP-to-MAC address bindings specified in an ARP ACL or in the DHCP Snooping database.

### Example

```
Console(config)#ip arp inspection validate dst-mac  
Console(config)#
```

**ip arp inspection vlan** This command enables ARP Inspection for a specified VLAN or range of VLANs. Use the **no** form to disable this function.

### Syntax

**[no] ip arp inspection vlan** {*vlan-id* | *vlan-range*}

*vlan-id* - VLAN ID. (Range: 1-4094)

*vlan-range* - A consecutive range of VLANs indicated by the use a hyphen, or a random group of VLANs with each entry separated by a comma.

### Default Setting

Disabled on all VLANs

### Command Mode

Global Configuration

### Command Usage

- ◆ When ARP Inspection is enabled globally with the **ip arp inspection** command, it becomes active only on those VLANs where it has been enabled with this command.
- ◆ When ARP Inspection is enabled globally and enabled on selected VLANs, all ARP request and reply packets on those VLANs are redirected to the CPU and their switching is handled by the ARP Inspection engine.
- ◆ When ARP Inspection is disabled globally, it becomes inactive for all VLANs, including those where ARP Inspection is enabled.
- ◆ When ARP Inspection is disabled, all ARP request and reply packets bypass the ARP Inspection engine and their manner of switching matches that of all other packets.
- ◆ Disabling and then re-enabling global ARP Inspection will not affect the ARP Inspection configuration for any VLANs.
- ◆ When ARP Inspection is disabled globally, it is still possible to configure ARP Inspection for individual VLANs. These configuration changes will only become active after ARP Inspection is globally enabled again.

### Example

```
Console(config)#ip arp inspection vlan 1,2  
Console(config)#
```

**ip arp inspection limit** This command sets a rate limit for the ARP packets received on a port. Use the **no** form to restore the default setting.

### Syntax

**ip arp inspection limit** {rate *pps* | **none**}

**no ip arp inspection limit**

*pps* - The maximum number of ARP packets that can be processed by the CPU per second on trusted or untrusted ports. (Range: 0-750, where 0 means that no ARP packets can be forwarded)

**none** - There is no limit on the number of ARP packets that can be processed by the CPU.

### Default Setting

15

### Command Mode

Interface Configuration (Port, Static Aggregation)

### Command Usage

- ◆ This command applies to both trusted and untrusted ports.
- ◆ When the rate of incoming ARP packets exceeds the configured limit, the switch drops all ARP packets in excess of the limit.

### Example

```
Console(config)#interface ethernet 1/1  
Console(config-if)#ip arp inspection limit rate 150  
Console(config-if)#
```

**ip arp inspection trust** This command sets a port as trusted, and thus exempted from ARP Inspection. Use the **no** form to restore the default setting.

### Syntax

**[no] ip arp inspection trust**

### Default Setting

Untrusted

### Command Mode

Interface Configuration (Port, Static Aggregation)

### Command Usage

Packets arriving on untrusted ports are subject to any configured ARP Inspection and additional validation checks. Packets arriving on trusted ports bypass all of these checks, and are forwarded according to normal switching rules.

### Example

```

Console(config)#interface ethernet 1/1
Console(config-if)#ip arp inspection trust
Console(config-if)#

```

**show ip arp inspection configuration** This command displays the global configuration settings for ARP Inspection.

### Command Mode

Privileged Exec

### Example

```

Console#show ip arp inspection configuration

ARP Inspection Global Information:

Global IP ARP Inspection Status : disabled
Log Message Interval           : 1 s
Log Message Number             : 5
Need Additional Validation(s)  : Yes
Additional Validation Type      : Destination MAC address
Console#

```

**show ip arp inspection interface** This command shows the trust status and ARP Inspection rate limit for ports.

### Syntax

**show ip arp inspection interface** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

```
Console#show ip arp inspection interface ethernet 1/1

Port Number          Trust Status          Rate Limit (pps)
-----
Eth 1/1              Trusted               150
Console#
```

**show ip arp inspection log** This command shows information about entries stored in the log, including the associated VLAN, port, and address components.

**Command Mode**  
Privileged Exec

### Example

```
Console#show ip arp inspection log
Total log entries number is 1

Num VLAN Port Src IP Address Dst IP Address Src MAC Address Dst MAC Address
---
1 1 11 192.168.2.2 192.168.2.1 00-04-E2-A0-E2-7C FF-FF-FF-FF-FF-FF
Console#
```

**show ip arp inspection statistics** This command shows statistics about the number of ARP packets processed, or dropped for various reasons.

**Command Mode**  
Privileged Exec

### Example

```
Console#show ip arp inspection statistics

ARP packets received : 150
ARP packets dropped due to rate limit : 5
Total ARP packets processed by ARP Inspection : 150
ARP packets dropped by additional validation (source MAC address) : 0
ARP packets dropped by additional validation (destination MAC address): 0
ARP packets dropped by additional validation (IP address) : 0
ARP packets dropped by ARP ACLs : 0
ARP packets dropped by DHCP snooping : 0

Console#
```

**show ip arp inspection vlan** This command shows the configuration settings for VLANs, including ARP Inspection status, the ARP ACL name, and if the DHCP Snooping database is used after ARP ACL validation is completed.

### Syntax

**show ip arp inspection vlan** [*vlan-id* | *vlan-range*]

*vlan-id* - VLAN ID. (Range: 1-4094)

*vlan-range* - A consecutive range of VLANs indicated by the use a hyphen, or a random group of VLANs with each entry separated by a comma.

### Command Mode

Privileged Exec

### Command Usage

Enter this command to display the configuration settings for all VLANs, or display the settings for a specific VLAN by entering the VLAN identifier.

### Example

```
Console#show ip arp inspection vlan 1
```

VLAN ID	DAI Status	ACL Name	ACL Status
1	disabled	sales	static

```
Console#
```

## Denial of Service Protection

A denial-of-service attack (DoS attack) is an attempt to block the services provided by a computer or network resource. This kind of attack tries to prevent an Internet site or service from functioning efficiently or at all. In general, DoS attacks are implemented by either forcing the target to reset, to consume most of its resources so that it can no longer provide its intended service, or to obstruct the communication media between the intended users and the target so that they can no longer communicate adequately.

This section describes commands used to protect against DoS attacks.

**Table 70: DoS Protection Commands**

Command	Function	Mode
<code>dos-protection echo-charge</code>	Protects against DoS echo/charge attacks	GC
<code>dos-protection smurf</code>	Protects against DoS smurf attacks	GC
<code>dos-protection tcp-flooding</code>	Protects against DoS TCP-flooding attacks	GC
<code>dos-protection tcp-null-scan</code>	Protects against DoS TCP-null-scan attacks	GC
<code>dos-protection tcp-syn-fin-scan</code>	Protects against DoS TCP-SYN/FIN-scan attacks	GC

Table 70: DoS Protection Commands (Continued)

Command	Function	Mode
<code>dos-protection tcp-udp-port-zero</code>	Protects against attacks which set the Layer 4 source or destination port to zero	GC
<code>dos-protection tcp-xmas-scan</code>	Protects against DoS TCP-XMAS-scan attacks	GC
<code>dos-protection udp-flooding</code>	Protects against DoS UDP-flooding attacks	GC
<code>dos-protection win-nuke</code>	Protects against DoS WinNuke attacks	GC
<code>show dos-protection</code>	Shows the configuration settings for DoS protection	PE

**dos-protection echo-charge** This command protects against DoS echo/charge attacks in which the echo service repeats anything sent to it, and the charge (character generator) service generates a continuous stream of data. When used together, they create an infinite loop and result in a denial-of-service. Use the **no** form without the bit rate parameter to disable this feature, or with the bit rate parameter to restore the default rate limit..

#### Syntax

**dos-protection echo-charge [bit-rate-in-kilo rate]**

**no dos-protection echo-charge [bit-rate-in-kilo]**

*rate* – Maximum allowed rate. (Range: 64-2000 kbits/second)

#### Default Setting

Disabled, 1000 kbits/second

#### Command Mode

Global Configuration

#### Example

```
Console(config)#dos-protection echo-charge bit-rate-in-kilo 65  
Console(config)#
```

**dos-protection smurf** This command protects against DoS smurf attacks in which a perpetrator generates a large amount of spoofed ICMP Echo Request traffic to the broadcast destination IP address (255.255.255.255), all of which uses a spoofed source address of the intended victim. The victim should crash due to the many interrupts required to send ICMP Echo response packets. Use the **no** form to disable this feature.

#### Syntax

**[no] dos-protection smurf**

#### Default Setting

Disabled

### Command Mode

Global Configuration

### Example

```
Console(config)#dos-protection smurf  
Console(config)#
```

### dos-protection tcp-flooding

This command protects against DoS TCP-flooding attacks in which a perpetrator sends a succession of TCP SYN requests (with or without a spoofed-Source IP) to a target and never returns ACK packets. These half-open connections will bind resources on the target, and no new connections can be made, resulting in a denial of service. Use the **no** form without the bit rate parameter to disable this feature, or with the bit rate parameter to restore the default rate limit.

### Syntax

**dos-protection tcp-flooding [bit-rate-in-kilo *rate*]**

**no dos-protection tcp-flooding [bit-rate-in-kilo]**

*rate* – Maximum allowed rate. (Range: 64-2000 kbits/second)

### Default Setting

Disabled, 1000 kbits/second

### Command Mode

Global Configuration

### Example

```
Console(config)#dos-protection tcp-flooding bit-rate-in-kilo 65  
Console(config)#
```

### dos-protection tcp-null-scan

This command protects against DoS TCP-null-scan attacks in which a TCP NULL scan message is used to identify listening TCP ports. The scan uses a series of strangely configured TCP packets which contain a sequence number of 0 and no flags. If the target's TCP port is closed, the target replies with a TCP RST (reset) packet. If the target TCP port is open, it simply discards the TCP NULL scan. Use the **no** form to disable this feature.

### Syntax

**[no] dos-protection tcp-null-scan**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

In these packets, all TCP flags are 0.

### Example

```
Console(config)#dos-protection tcp-null-scan  
Console(config)#
```

### dos-protection tcp-syn-fin-scan

This command protects against DoS TCP-SYN/FIN-scan attacks in which a TCP SYN/FIN scan message is used to identify listening TCP ports. The scan uses a series of strangely configured TCP packets which contain SYN (synchronize) and FIN (finish) flags. If the target's TCP port is closed, the target replies with a TCP RST (reset) packet. If the target TCP port is open, it simply discards the TCP SYN FIN scan. Use the **no** form to disable this feature.

### Syntax

**[no] dos-protection tcp-syn-fin-scan**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Example

```
Console(config)#dos-protection tcp-syn-fin-scan  
Console(config)#
```

### dos-protection tcp-udp-port-zero

This command protects against DoS attacks in which the TCP or UDP source port or destination port is set to zero. This technique may be used as a form of DoS attack, or it may just indicate a problem with the source device. When this command is enabled, the switch will drop these packets. Use the **no** form to restore the default setting.

### Syntax

**[no] dos-protection tcp-udp-port-zero**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Example

```
Console(config)#dos-protection tcp-udp-port-zero
Console(config)#
```

**dos-protection tcp-xmas-scan** This command protects against DoS TCP-xmas-scan in which a so-called TCP XMAS scan message is used to identify listening TCP ports. This scan uses a series of strangely configured TCP packets which contain a sequence number of 0 and the URG, PSH and FIN flags. If the target's TCP port is closed, the target replies with a TCP RST packet. If the target TCP port is open, it simply discards the TCP XMAS scan. Use the **no** form to disable this feature.

### Syntax

**[no] dos-protection tcp-xmas-scan**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Example

```
Console(config)#dos-protection tcp-xmas-scan
Console(config)#
```

**dos-protection udp-flooding** This command protects against DoS UDP-flooding attacks in which a perpetrator sends a large number of UDP packets (with or without a spoofed-Source IP) to random ports on a remote host. The target will determine that application is listening at that port, and reply with an ICMP Destination Unreachable packet. It will be forced to send many ICMP packets, eventually leading it to be unreachable by other clients. Use the **no** form without the bit rate parameter to disable this feature, or with the bit rate parameter to restore the default rate limit.

### Syntax

**dos-protection udp-flooding [bit-rate-in-kilo *rate*]**

**no dos-protection udp-flooding [bit-rate-in-kilo]**

*rate* – Maximum allowed rate. (Range: 64-2000 kbits/second)

### Default Setting

Disabled, 1000 kbits/second

### Command Mode

Global Configuration

### Example

```
Console(config)#dos-protection udp-flooding bit-rate-in-kilo 65  
Console(config)#
```

### dos-protection win-nuke

This command protects against DoS WinNuke attacks in which affected the Microsoft Windows 3.1x/95/NT operating systems. In this type of attack, the perpetrator sends the string of OOB out-of-band (OOB) packets contained a TCP URG flag to the target computer on TCP port 139 (NetBIOS), casing it to lock up and display a “Blue Screen of Death.” This did not cause any damage to, or change data on, the computer’s hard disk, but any unsaved data would be lost. Microsoft made patches to prevent the WinNuke attack, but the OOB packets still put the service in a tight loop that consumed all available CPU time. Use the **no** form without the bit rate parameter to disable this feature, or with the bit rate parameter to restore the default rate limit.

### Syntax

**dos-protection win-nuke** [**bit-rate-in-kilo** *rate*]

**no dos-protection win-nuke** [**bit-rate-in-kilo**]

*rate* – Maximum allowed rate. (Range: 64-2000 kbits/second)

### Default Setting

Disabled, 1000 kbits/second

### Command Mode

Global Configuration

### Example

```
Console(config)#dos-protection win-nuke bit-rate-in-kilo 65  
Console(config)#
```

**show dos-protection** This command shows the configuration settings for the DoS protection commands.

### Command Mode

Privileged Exec

### Example

```
Console#show dos-protection  
Global DoS Protection:  
  
Echo/Chargen Attack           : Disabled, 1000 kilobits per second  
Smurf Attack                   : Enabled  
TCP Flooding Attack           : Disabled, 1000 kilobits per second  
TCP Null Scan                  : Enabled  
TCP SYN/FIN Scan              : Enabled  
TCP/UDP Packets with Port 0   : Enabled
```

```
TCP XMAS Scan           : Enabled
UDP Flooding Attack     : Disabled, 1000 kilobits per second
WinNuke Attack          : Disabled, 1000 kilobits per second
Console#
```

## Port-based Traffic Segmentation

If tighter security is required for passing traffic from different clients through downlink ports on the local network and over uplink ports to the service provider, port-based traffic segmentation can be used to isolate traffic for individual clients.

Traffic belonging to each client is isolated to the allocated downlink ports. But the switch can be configured to either isolate traffic passing across a client's allocated uplink ports from the uplink ports assigned to other clients, or to forward traffic through the uplink ports used by other clients, allowing different clients to share access to their uplink ports where security is less likely to be compromised.

**Table 71: Commands for Configuring Traffic Segmentation**

Command	Function	Mode
<code>traffic-segmentation</code>	Enables traffic segmentation	GC
<code>traffic-segmentation session</code>	Creates a client session	GC
<code>traffic-segmentation uplink/ downlink</code>	Configures uplink/downlink ports for client sessions	GC
<code>traffic-segmentation uplink-to-uplink</code>	Specifies whether or not traffic can be forwarded between uplink ports assigned to different client sessions	GC
<code>show traffic-segmentation</code>	Displays the configured traffic segments	PE

**traffic-segmentation** This command enables traffic segmentation. Use the **no** form to disable traffic segmentation.

### Syntax

**[no] traffic-segmentation**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Traffic segmentation provides port-based security and isolation between ports within the VLAN. Data traffic on the downlink ports can only be forwarded to, and from, the designated uplink port(s). Data cannot pass between downlink

ports in the same segmented group, nor to ports which do not belong to the same group.

- ◆ Traffic segmentation and normal VLANs can exist simultaneously within the same switch. Traffic may pass freely between uplink ports in segmented groups and ports in normal VLANs.
- ◆ When traffic segmentation is enabled, the forwarding state for the uplink and downlink ports assigned to different client sessions is shown below.

**Table 72: Traffic Segmentation Forwarding**

Destination Source	Session #1 Downlinks	Session #1 Uplinks	Session #2 Downlinks	Session #2 Uplinks	Normal Ports
<b>Session #1 Downlink Ports</b>	Blocking	Forwarding	Blocking	Blocking	Blocking
<b>Session #1 Uplink Ports</b>	Forwarding	Forwarding	Blocking	Blocking/ Forwarding*	Forwarding
<b>Session #2 Downlink Ports</b>	Blocking	Blocking	Blocking	Forwarding	Blocking
<b>Session #2 Uplink Ports</b>	Blocking	Blocking/ Forwarding*	Forwarding	Forwarding	Forwarding
<b>Normal Ports</b>	Forwarding	Forwarding	Forwarding	Forwarding	Forwarding

\* The forwarding state for uplink-to-uplink ports is configured by the [traffic-segmentation uplink-to-uplink](#) command.

- ◆ When traffic segmentation is disabled, all ports operate in normal forwarding mode based on the settings specified by other functions such as VLANs and spanning tree protocol.
- ◆ Enter the **traffic-segmentation** command without any parameters to enable traffic segmentation. Then set the interface members for segmented groups using the [traffic-segmentation uplink/downlink](#) command.
- ◆ Enter **no traffic-segmentation** to disable traffic segmentation and clear the configuration settings for segmented groups.

### Example

This example enables traffic segmentation globally on the switch.

```
Console(config)#traffic-segmentation
Console(config)#
```

**traffic-segmentation session** This command creates a traffic-segmentation client session. Use the **no** form to remove a client session.

### Syntax

**[no] traffic-segmentation session** *session-id*

*session-id* – Traffic segmentation session. (Range: 1-4)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Use this command to create a new traffic-segmentation client session.
- ◆ Using the **no** form of this command will remove any assigned uplink or downlink ports, restoring these interfaces to normal operating mode.

### Example

```
Console(config)#traffic-segmentation session 1  
Console(config)#
```

**traffic-segmentation uplink/downlink** This command configures the uplink and down-link ports for a segmented group of ports. Use the **no** form to remove a port from the segmented group.

### Syntax

**[no] traffic-segmentation [session** *session-id* **{uplink** *interface-list* **[downlink** *interface-list* **] downlink** *interface-list*

*session-id* – Traffic segmentation session. (Range: 1-4)

**uplink** – Specifies an uplink interface.

**downlink** – Specifies a downlink interface.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

Session 1 if not defined

No segmented port groups are defined.

### Command Mode

Global Configuration

### Command Usage

- ◆ A port cannot be configured in both an uplink and downlink list.
- ◆ A port can only be assigned to one traffic-segmentation session.
- ◆ When specifying an uplink or downlink, a list of ports may be entered by using a hyphen or comma in the *port* field. Note that lists are not supported for the *channel-id* field.
- ◆ A downlink port can only communicate with an uplink port in the same session. Therefore, if an uplink port is not configured for a session, the assigned downlink ports will not be able to communicate with any other ports.
- ◆ If a downlink port is not configured for the session, the assigned uplink ports will operate as normal ports.

### Example

This example enables traffic segmentation, and then sets port 10 as the uplink and ports 5-8 as downlinks.

```
Console(config)#traffic-segmentation
Console(config)#traffic-segmentation uplink ethernet 1/10
                downlink ethernet 1/5-8
Console(config)#
```

**traffic-segmentation uplink-to-uplink** This command specifies whether or not traffic can be forwarded between uplink ports assigned to different client sessions. Use the **no** form to restore the default.

### Syntax

**traffic-segmentation uplink-to-uplink {blocking | forwarding}**

**no traffic-segmentation uplink-to-uplink**

**blocking** – Blocks traffic between uplink ports assigned to different sessions.

**forwarding** – Forwards traffic between uplink ports assigned to different sessions.

### Default Setting

Blocking

### Command Mode

Global Configuration

### Example

This example enables forwarding of traffic between uplink ports assigned to different client sessions.

```
Console(config)#traffic-segmentation uplink-to-uplink forwarding
Console(config)#
```

### show traffic-segmentation

This command displays the configured traffic segments.

#### Syntax

**show traffic-segmentation [session *session-id*]**

*session-id* – Traffic segmentation session. (Range: 1-4)

#### Command Mode

Privileged Exec

### Example

```
Console#show traffic-segmentation session 1

Traffic segmentation Status :           Enabled
Uplink-to-Uplink Mode       :           Forwarding

Session  Uplink Ports                Downlink Ports
-----  -
   1     Ethernet 1/1                 Ethernet 1/2
                                           Ethernet 1/3
                                           Ethernet 1/4

Console#
```



# Access Control Lists

Access Control Lists (ACL) provide packet filtering for IPv4 frames (based on address, protocol, Layer 4 protocol port number or TCP control code), IPv6 frames (based on address, DSCP traffic class, or next header type), or any frames (based on MAC address or Ethernet type). To filter packets, first create an access list, add the required rules, and then bind the list to a specific port. This section describes the Access Control List commands.

**Table 73: Access Control List Commands**

Command Group	Function
<a href="#">IPv4 ACLs</a>	Configures ACLs based on IPv4 addresses, TCP/UDP port number, protocol type, and TCP control code
<a href="#">IPv6 ACLs</a>	Configures ACLs based on IPv6 addresses, DSCP traffic class, or next header type
<a href="#">MAC ACLs</a>	Configures ACLs based on hardware addresses, packet format, and Ethernet type
<a href="#">ARP ACLs</a>	Configures ACLs based on ARP messages addresses
<a href="#">ACL Information</a>	Displays ACLs and associated rules; shows ACLs assigned to each port

## IPv4 ACLs

The commands in this section configure ACLs based on IPv4 addresses, TCP/UDP port number, protocol type, and TCP control code. To configure IPv4 ACLs, first create an access list containing the required permit or deny rules, and then bind the access list to one or more ports.

**Table 74: IPv4 ACL Commands**

Command	Function	Mode
<a href="#">access-list ip</a>	Creates an IP ACL and enters configuration mode for standard or extended IPv4 ACLs	GC
<a href="#">permit, deny</a>	Filters packets matching a specified source IPv4 address	IPv4-STD-ACL
<a href="#">permit, deny</a>	Filters packets meeting the specified criteria, including source and destination IPv4 address, TCP/UDP port number, protocol type, and TCP control code	IPv4-EXT-ACL
<a href="#">ip access-group</a>	Binds an IPv4 ACL to a port	IC
<a href="#">show ip access-group</a>	Shows port assignments for IPv4 ACLs	PE
<a href="#">show ip access-list</a>	Displays the rules for configured IPv4 ACLs	PE

**access-list ip** This command adds an IP access list and enters configuration mode for standard or extended IPv4 ACLs. Use the **no** form to remove the specified ACL.

### Syntax

**[no] access-list ip {standard | extended} acl-name**

**standard** – Specifies an ACL that filters packets based on the source IP address.

**extended** – Specifies an ACL that filters packets based on the source or destination IP address, and other more specific criteria.

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ When you create a new ACL or enter configuration mode for an existing ACL, use the **permit** or **deny** command to add new rules to the bottom of the list.
- ◆ To remove a rule, use the **no permit** or **no deny** command followed by the exact text of a previously configured rule.
- ◆ An ACL can contain up to 1K rules.

### Example

```
Console(config)#access-list ip standard david
Console(config-std-acl)#
```

### Related Commands

[permit, deny \(396\)](#)

[show ip access-list \(401\)](#)

**permit, deny (Standard IP ACL)** This command adds a rule to a Standard IPv4 ACL. The rule sets a filter condition for packets emanating from the specified source. Use the **no** form to remove a rule.

### Syntax

**{permit | deny} {any | source bitmask | host source}**  
**[time-range time-range-name]**

**no {permit | deny} {any | source bitmask | host source}**

**any** – Any source IP address.

*source* – Source IP address.

*bitmask* – Dotted decimal number representing the address bits to match.

**host** – Keyword followed by a specific IP address.

*time-range-name* - Name of the time range. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

Standard IPv4 ACL

### Command Usage

- ◆ New rules are appended to the end of the list.
- ◆ Address bit masks are similar to a subnet mask, containing four integers from 0 to 255, each separated by a period. The binary mask uses 1 bits to indicate “match” and 0 bits to indicate “ignore.” The bitmask is bitwise ANDed with the specified source IP address, and then compared with the address for each IP packet entering the port(s) to which this ACL has been assigned.

### Example

This example configures one permit rule for the specific address 10.1.1.21 and another rule for the address range 168.92.16.x – 168.92.31.x using a bitmask.

```
Console(config-std-acl)#permit host 10.1.1.21
Console(config-std-acl)#permit 168.92.16.0 255.255.240.0
Console(config-std-acl)#
```

### Related Commands

[access-list ip \(396\)](#)

[Time Range \(188\)](#)

**permit, deny** (Extended IPv4 ACL) This command adds a rule to an Extended IPv4 ACL. The rule sets a filter condition for packets with specific source or destination IP addresses, protocol types, source or destination protocol ports, or TCP control codes. Use the **no** form to remove a rule.

### Syntax

```
{permit | deny} [protocol-number]
  {any | source address-bitmask | host source}
  {any | destination address-bitmask | host destination}
  [precedence precedence] [dscp dscp]
  [time-range time-range-name]

no {permit | deny} [protocol-number]
  {any | source address-bitmask | host source}
  {any | destination address-bitmask | host destination}
```

```
[precedence precedence] [dscp dscp]  
[source-port sport [bitmask]]  
[destination-port dport [port-bitmask]]  
{permit | deny} [icmp | tcp | udp ]  
{any | source address-bitmask | host source}  
{any | destination address-bitmask | host destination}  
[precedence precedence] [dscp dscp]  
[source-port sport [bitmask]]  
[destination-port dport [port-bitmask]]  
[icmp-type icmp-type]  
[control-flag control-flags flag-bitmask]  
[time-range time-range-name]
```

```
no {permit | deny} [icmp | tcp | udp ]  
{any | source address-bitmask | host source}  
{any | destination address-bitmask | host destination}  
[precedence precedence] [dscp dscp]  
[source-port sport [bitmask]]  
[destination-port dport [port-bitmask]]  
[icmp-type icmp-type]  
[control-flag control-flags flag-bitmask]
```

*protocol-number* – A specific protocol number. (Range: 0-255)

*source* – Source IP address.

*destination* – Destination IP address.

*address-bitmask* – Decimal number representing the address bits to match.

**host** – Keyword followed by a specific IP address.

*dscp* – DSCP priority level. (Range: 0-63)

*precedence* – IP precedence level. (Range: 0-7)

*sport* – Protocol<sup>4</sup> source port number. (Range: 0-65535)

*dport* – Protocol<sup>4</sup> destination port number. (Range: 0-65535)

*port-bitmask* – Decimal number representing the port bits to match.  
(Range: 0-65535)

*icmp-type* – The ICMP protocol number. (Range: 0-255)

*control-flags* – Decimal number (representing a bit string) that specifies flag bits in byte 14 of the TCP header. (Range: 0-63)

*flag-bitmask* – Decimal number representing the code bits to match.

*time-range-name* - Name of the time range. (Range: 1-32 characters)

### Default Setting

None

---

4. Includes TCP, UDP or other protocol types.

## Command Mode

### Extended IPv4 ACL

## Command Usage

- ◆ All new rules are appended to the end of the list.
- ◆ Address bit masks are similar to a subnet mask, containing four integers from 0 to 255, each separated by a period. The binary mask uses 1 bits to indicate “match” and 0 bits to indicate “ignore.” The bit mask is bitwise ANDed with the specified source IP address, and then compared with the address for each IP packet entering the port(s) to which this ACL has been assigned.
- ◆ The control-code bitmask is a decimal number (representing an equivalent bit mask) that is applied to the control code. Enter a decimal number, where the equivalent binary bit “1” means to match a bit and “0” means to ignore a bit. The following bits may be specified:
  - 1 (fin) – Finish
  - 2 (syn) – Synchronize
  - 4 (rst) – Reset
  - 8 (psh) – Push
  - 16 (ack) – Acknowledgement
  - 32 (urg) – Urgent pointer

For example, use the code value and mask below to catch packets with the following flags set:

- SYN flag valid, use “control-code 2 2”
  - Both SYN and ACK valid, use “control-code 18 18”
  - SYN valid and ACK invalid, use “control-code 2 18”
- ◆ If an Extended IPv4 rule and MAC rule match the same packet, and these rules specify a “permit” entry and “deny” entry, the “deny” action takes precedence.

## Example

This example accepts any incoming packets if the source address is within subnet 10.7.1.x. For example, if the rule is matched; i.e., the rule (10.7.1.0 & 255.255.255.0) equals the masked address (10.7.1.2 & 255.255.255.0), the packet passes through.

```
Console(config-ext-acl)#permit 10.7.1.1 255.255.255.0 any
Console(config-ext-acl)#
```

This allows TCP packets from class C addresses 192.168.1.0 to any destination address when set for destination TCP port 80 (i.e., HTTP).

```
Console(config-ext-acl)#permit tcp 192.168.1.0 255.255.255.0 any destination-
port 80
Console(config-ext-acl)#
```

This permits all TCP packets from class C addresses 192.168.1.0 with the TCP control code set to "SYN."

```
Console(config-ext-acl)#permit tcp 192.168.1.0 255.255.255.0 any control-  
flag 2 2  
Console(config-ext-acl)#
```

### Related Commands

[access-list ip \(396\)](#)

[Time Range \(188\)](#)

**ip access-group** This command binds an IPv4 ACL to a port. Use the **no** form to remove the port.

### Syntax

```
ip access-group acl-name {in | out}  
[time-range time-range-name] [counter]
```

```
no ip access-group acl-name in
```

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

**in** – Indicates that this list applies to ingress packets.

**out** – Indicates that this list applies to egress packets.

*time-range-name* - Name of the time range. (Range: 1-32 characters)

**counter** – Enables counter for ACL statistics.

### Default Setting

None

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

If an ACL is already bound to a port and you bind a different ACL to it, the switch will replace the old binding with the new one.

### Example

```
Console(config)#int eth 1/2  
Console(config-if)#ip access-group david in  
Console(config-if)#
```

### Related Commands

[show ip access-list \(401\)](#)

[Time Range \(188\)](#)

**show ip access-group** This command shows the ports assigned to IP ACLs.

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip access-group
Interface ethernet 1/2
  IP access-list david in
Console#
```

**show ip access-list** This command displays the rules for configured IPv4 ACLs.

#### Syntax

**show ip access-list** {**standard** | **extended**} [*acl-name*]

**standard** – Specifies a standard IP ACL.

**extended** – Specifies an extended IP ACL.

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip access-list standard
IP standard access-list david:
  permit host 10.1.1.21
  permit 168.92.0.0 255.255.15.0
Console#
```

#### Related Commands

[permit, deny \(396\)](#)

## IPv6 ACLs

The commands in this section configure ACLs based on IPv6 addresses, DSCP traffic class, or next header type. To configure IPv6 ACLs, first create an access list containing the required permit or deny rules, and then bind the access list to one or more ports.

**Table 75: IPv6 ACL Commands**

Command	Function	Mode
<code>access-list ipv6</code>	Creates an IPv6 ACL and enters configuration mode for standard or extended IPv6 ACLs	GC
<code>permit, deny</code>	Filters packets matching a specified source IPv6 address	IPv6- STD-ACL
<code>permit, deny</code>	Filters packets meeting the specified criteria, including source or destination IPv6 address, DSCP traffic class, or next header type	IPv6- EXT-ACL
<code>ipv6 access-group</code>	Binds an IPv6 ACL to a port	IC
<code>show ipv6 access-group</code>	Shows port assignments for IPv6 ACLs	PE
<code>show ipv6 access-list</code>	Displays the rules for configured IPv6 ACLs	PE

**access-list ipv6** This command adds an IP access list and enters configuration mode for standard or extended IPv6 ACLs. Use the **no** form to remove the specified ACL.

### Syntax

**[no] access-list ipv6 {standard | extended} *acl-name***

**standard** – Specifies an ACL that filters packets based on the source IP address.

**extended** – Specifies an ACL that filters packets based on the destination IP address, and other more specific criteria.

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ When you create a new ACL or enter configuration mode for an existing ACL, use the **permit** or **deny** command to add new rules to the bottom of the list. To create an ACL, you must add at least one rule to the list.
- ◆ To remove a rule, use the **no permit** or **no deny** command followed by the exact text of a previously configured rule.

- ◆ An ACL can contain up to 64 rules.

### Example

```
Console(config)#access-list ipv6 standard david
Console(config-std-ipv6-acl)#
```

### Related Commands

[permit, deny \(Standard IPv6 ACL\) \(403\)](#)

[permit, deny \(Extended IPv6 ACL\) \(404\)](#)

[ipv6 access-group \(406\)](#)

[show ipv6 access-list \(407\)](#)

**permit, deny (Standard IPv6 ACL)** This command adds a rule to a Standard IPv6 ACL. The rule sets a filter condition for packets emanating from the specified source. Use the **no** form to remove a rule.

### Syntax

```
{permit | deny} {any | host source-ipv6-address |
source-ipv6-address[/prefix-length]}
[time-range time-range-name]
```

```
no {permit | deny} {any | host source-ipv6-address |
source-ipv6-address[/prefix-length]}
```

**any** – Any source IP address.

**host** – Keyword followed by a specific IP address.

*source-ipv6-address* - An IPv6 source address or network class. The address must be formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

*prefix-length* - A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix; i.e., the network portion of the address. (Range: 0-128)

*time-range-name* - Name of the time range. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

Standard IPv6 ACL

### Command Usage

New rules are appended to the end of the list.

### Example

This example configures one permit rule for the specific address 2009:DB9:2229::79 and another rule for the addresses with the network prefix 2009:DB9:2229:5::/64.

```
Console(config-std-ipv6-acl)#permit host 2009:DB9:2229::79
Console(config-std-ipv6-acl)#permit 2009:DB9:2229:5::/64
Console(config-std-ipv6-acl)#
```

### Related Commands

[access-list ipv6 \(402\)](#)

[Time Range \(188\)](#)

**permit, deny** (Extended IPv6 ACL) This command adds a rule to an Extended IPv6 ACL. The rule sets a filter condition for packets with specific source or destination IP addresses, or next header type. Use the **no** form to remove a rule.

### Syntax

```
{permit | deny} [next-header | icmp | tcp | udp]
  {any | host source-ipv6-address | source-ipv6-address/prefix-length}
  {any | destination-ipv6-address/prefix-length}
  [next-header next-header [[source-port sport [bitmask]]] | [destination-port
  dport [port-bitmask]]] | [time-range time-range-name] | [dscp dscp]]
  [icmp-type icmp-type]
  [time-range time-range-name]
  [dscp dscp]
```

```
no {permit | deny} [next-header | icmp | tcp | udp]
  {any | host source-ipv6-address | source-ipv6-address/prefix-length}
  {any | destination-ipv6-address/prefix-length}
  [next-header next-header [[source-port sport [bitmask]]] | [destination-port
  dport [port-bitmask]]] | [time-range time-range-name] | [dscp dscp]]
  [icmp-type icmp-type]
  [time-range time-range-name]
  [dscp dscp]
```

*next-header* - The type of header immediately following the IPv6 header.  
(Range: 0-255)

**icmp** – Specifies the next header as ICMP.

**tcp** – Specifies the next header as TCP.

**udp** – Specifies the next header as UDP.

**any** – Any IP address (an abbreviation for the IPv6 prefix ::/0).

**host** – Keyword followed by a specific source IP address.

*source-ipv6-address* - An IPv6 source address or network class. The address must be formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may

be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

*destination-ipv6-address* - An IPv6 destination address or network class. The address must be formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields. (The switch only checks the first 128 bits of the destination address.)

*prefix-length* - A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix; i.e., the network portion of the address. (Range: 0-128 for source prefix, 0-128 for destination prefix)

*dscp* - DSCP traffic class. (Range: 0-63)

*next-header* - Identifies the type of header immediately following the IPv6 header. (Range: 0-255)

*sport* - Protocol<sup>5</sup> source port number. (Range: 0-65535)

*dport* - Protocol<sup>4</sup> destination port number. (Range: 0-65535)

*port-bitmask* - Decimal number representing the port bits to match. (Range: 0-65535)

*icmp-type* - The ICMP protocol number. (Range: 0-255)

*time-range-name* - Name of the time range. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

Extended IPv6 ACL

### Command Usage

- ◆ All new rules are appended to the end of the list.
- ◆ Optional internet-layer information is encoded in separate headers that may be placed between the IPv6 header and the upper-layer header in a packet. There are a small number of such extension headers, each identified by a distinct Next Header value. IPv6 supports the values defined for the IPv4 Protocol field in RFC 1700, including these commonly used headers:

0	: Hop-by-Hop Options	(RFC 2460)
6	: TCP Upper-layer Header	(RFC 1700)
17	: UDP Upper-layer Header	(RFC 1700)
43	: Routing	(RFC 2460)
44	: Fragment	(RFC 2460)
51	: Authentication	(RFC 2402)
50	: Encapsulating Security Payload	(RFC 2406)
60	: Destination Options	(RFC 2460)

---

5. Includes TCP and UDP.

### Example

This example accepts any incoming packets if the destination address is 2009:DB9:2229::79/8.

```
Console(config-ext-ipv6-acl)#permit any 2009:db90:2229::79/8
Console(config-ext-ipv6-acl)#
```

This allows packets to any destination address when the DSCP value is 5.

```
Console(config-ext-ipv6-acl)#permit any any dscp 5
Console(config-ext-ipv6-acl)#
```

This allows any packets sent from any source to any destination when the next header is 43."

```
Console(config-ext-ipv6-acl)#permit any any next-header 43
Console(config-ext-ipv6-acl)#
```

### Related Commands

[access-list ipv6 \(402\)](#)

[Time Range \(188\)](#)

**ipv6 access-group** This command binds an IPv6 ACL to a port. Use the **no** form to remove the port.

### Syntax

```
ipv6 access-group acl-name {in | out}
[time-range time-range-name] [counter]
```

```
no ipv6 access-group acl-name {in | out}
```

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

**in** – Indicates that this list applies to ingress packets.

**out** – Indicates that this list applies to egress packets.

*time-range-name* - Name of the time range. (Range: 1-32 characters)

**counter** – Enables counter for ACL statistics.

### Default Setting

None

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

If a port is already bound to an ACL and you bind it to a different ACL, the switch will replace the old binding with the new one.

### Example

```
Console(config)#interface ethernet 1/2
Console(config-if)#ipv6 access-group standard david in
Console(config-if)#
```

### Related Commands

[show ipv6 access-list \(407\)](#)

[Time Range \(188\)](#)

**show ipv6 access-group** This command shows the ports assigned to IPv6 ACLs.

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 access-group
Interface ethernet 1/2
  IPv6 standard access-list david in
Console#
```

### Related Commands

[ipv6 access-group \(406\)](#)

**show ipv6 access-list** This command displays the rules for configured IPv6 ACLs.

### Syntax

**show ipv6 access-list** {**standard** | **extended**} [*acl-name*]

**standard** – Specifies a standard IPv6 ACL.

**extended** – Specifies an extended IPv6 ACL.

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 access-list standard
IPv6 standard access-list david:
  permit host 2009:DB9:2229::79
```

```
permit 2009:DB9:2229:5::/64  
Console#
```

### Related Commands

[permit, deny \(Standard IPv6 ACL\) \(403\)](#)  
[permit, deny \(Extended IPv6 ACL\) \(404\)](#)  
[ipv6 access-group \(406\)](#)

## MAC ACLs

The commands in this section configure ACLs based on hardware addresses, packet format, and Ethernet type. The ACLs can further specify optional IP and IPv6 addresses including protocol type and upper layer ports. To configure MAC ACLs, first create an access list containing the required permit or deny rules, and then bind the access list to one or more ports.

**Table 76: MAC ACL Commands**

Command	Function	Mode
<a href="#">access-list mac</a>	Creates a MAC ACL and enters configuration mode	GC
<a href="#">permit, deny</a>	Filters packets matching a specified source and destination address, packet format, and Ethernet type. They can be further specified using optional IP and IPv6 addresses including protocol type and upper layer ports.	MAC-ACL
<a href="#">mac access-group</a>	Binds a MAC ACL to a port	IC
<a href="#">show mac access-group</a>	Shows port assignments for MAC ACLs	PE
<a href="#">show mac access-list</a>	Displays the rules for configured MAC ACLs	PE

**access-list mac** This command enters MAC ACL configuration mode. Rules can be added to filter packets matching a specified MAC source or destination address (i.e., physical layer address), or Ethernet protocol type. Rules can also be used to filter packets based on IPv4/v6 addresses, including Layer 4 ports and protocol types. Use the **no** form to remove the specified ACL.

### Syntax

**[no] access-list mac *acl-name***

*acl-name* – Name of the ACL. (Maximum length: 32 characters,)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ When you create a new ACL or enter configuration mode for an existing ACL, use the **permit** or **deny** command to add new rules to the bottom of the list.
- ◆ To remove a rule, use the **no permit** or **no deny** command followed by the exact text of a previously configured rule.
- ◆ An ACL can contain up to 1024 rules.

### Example

```
Console(config)#access-list mac jerry
Console(config-mac-acl)#
```

### Related Commands

[permit, deny \(409\)](#)

[mac access-group \(413\)](#)

[show mac access-list \(414\)](#)

**permit, deny (MAC ACL)** This command adds a rule to a MAC ACL. The rule filters packets matching a specified MAC source or destination address (i.e., physical layer address), or Ethernet protocol type. Rules can also filter packets based on IPv4/v6 addresses, including Layer 4 ports and protocol types. Use the **no** form to remove a rule.

### Syntax

```
{permit | deny}
  {any | host source | source address}
  {any | host destination | destination address}
  [ip {any | host source-ip | source-ip network-mask}
    {any | host destination-ip | destination-ip network-mask}]
  [ipv6 {any | host source-ipv6 | source-ipv6/prefix-length}
    {any | host destination-ipv6 | destination-ipv6/prefix-length}]
  [cos cos cos-bitmask]
  [vid vid vid-bitmask]
  [ethertype ethertype [ethertype-bitmask]]
  [protocol protocol]
  [I4-source-port sport [port-bitmask]]
  [I4-destination-port dport [port-bitmask]]
  [time-range time-range-name]

no {permit | deny}
  {any | host source | source address}
  {any | host destination | destination address}
  [ip {any | host source-ip | source-ip network-mask}
    {any | host destination-ip | destination-ip network-mask}]
  [ipv6 {any | host source-ipv6 | source-ipv6/prefix-length}
    {any | host destination-ipv6 | destination-ipv6/prefix-length}]
  [cos cos cos-bitmask]
  [vid vid vid-bitmask]
```

```
[ethertype ethertype [ethertype-bitmask]]  
[protocol protocol]  
[I4-source-port sport [port-bitmask]]  
[I4-destination-port dport [port-bitmask]]
```



**Note:** The default is for Ethernet II packets.

```
{permit | deny} tagged-eth2  
  {any | host source | source address}  
  {any | host destination | destination address}  
  [ip {any | host source-ip | source-ip network-mask}  
    {any | host destination-ip | destination-ip network-mask}]  
  [ipv6 {any | host source-ipv6 | source-ipv6/prefix-length}  
    {any | host destination-ipv6 | destination-ipv6/prefix-length}]  
  [cos cos cos-bitmask] [vid vid vid-bitmask]  
  [ethertype ethertype [ethertype-bitmask]]  
  [protocol protocol]  
  [I4-source-port sport [port-bitmask]]  
  [I4-destination-port dport [port-bitmask]]  
  [time-range time-range-name]
```

```
no {permit | deny} tagged-eth2  
  {any | host source | source address}  
  {any | host destination | destination address}  
  [ip {any | host source-ip | source-ip network-mask}  
    {any | host destination-ip | destination-ip network-mask}]  
  [ipv6 {any | host source-ipv6 | source-ipv6/prefix-length}  
    {any | host destination-ipv6 | destination-ipv6/prefix-length}]  
  [cos cos cos-bitmask] [vid vid vid-bitmask]  
  [ethertype ethertype [ethertype-bitmask]]  
  [protocol protocol]  
  [I4-source-port sport [port-bitmask]]  
  [I4-destination-port dport [port-bitmask]]
```

```
{permit | deny} untagged-eth2  
  {any | host source | source address}  
  {any | host destination | destination address}  
  [ip {any | host source-ip | source-ip network-mask}  
    {any | host destination-ip | destination-ip network-mask}]  
  [ipv6 {any | host source-ipv6 | source-ipv6/prefix-length}  
    {any | host destination-ipv6 | destination-ipv6/prefix-length}]  
  [ethertype ethertype [ethertype-bitmask]]  
  [protocol protocol]  
  [I4-source-port sport [port-bitmask]]  
  [I4-destination-port dport [port-bitmask]]  
  [time-range time-range-name]
```

```
no {permit | deny} untagged-eth2
    {any | host source | source address}
    {any | host destination | destination address}
    [ip {any | host source-ip | source-ip network-mask}
        {any | host destination-ip | destination-ip network-mask}]
    [ipv6 {any | host source-ipv6 | source-ipv6/prefix-length}
        {any | host destination-ipv6 | destination-ipv6/prefix-length}]
    [ethertype ethertype [ethertype-bitmask]]
    [protocol protocol]
    [I4-source-port sport [port-bitmask]]
    [I4-destination-port dport [port-bitmask]]
```

```
{permit | deny} tagged-802.3
    {any | host source | source address}
    {any | host destination | destination address}
    [cos cos cos-bitmask] [vid vid vid-bitmask]
    [time-range time-range-name]
```

```
no {permit | deny} tagged-802.3
    {any | host source | source address}
    {any | host destination | destination address}
    [cos cos cos-bitmask] [vid vid vid-bitmask]
```

```
{permit | deny} untagged-802.3
    {any | host source | source address}
    {any | host destination | destination address}
    [time-range time-range-name]
```

```
no {permit | deny} untagged-802.3
    {any | host source | source address}
    {any | host destination | destination address}
```

**tagged-eth2** – Tagged Ethernet II packets.

**untagged-eth2** – Untagged Ethernet II packets.

**tagged-802.3** – Tagged Ethernet 802.3 packets.

**untagged-802.3** – Untagged Ethernet 802.3 packets.

**any** – Any MAC, IPv4 or IPv6 source or destination address.

**host** – A specific MAC, IPv4 or IPv6 address.

*source* – Source MAC, IPv4 or IPv6 address.

*destination* – Destination MAC, IPv4 or IPv6 address.

*network-mask* – Network mask for IP subnet. This mask identifies the host address bits used for routing to specific subnets.

*prefix-length* – Length of IPv6 prefix. A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix; i.e., the network portion of the address. (Range: 0-128)

*cos* – Class-of-Service value (Range: 0-7)

*cos-bitmask*<sup>6</sup> – Class-of-Service bitmask. (Range: 0-7)

*vid* – VLAN ID. (Range: 1-4094)

*vid-bitmask*<sup>6</sup> – VLAN bitmask. (Range: 1-4095)

*ethertype* – A specific Ethernet protocol number. (Range: 0-ffff hex)

*ethertype-bitmask*<sup>6</sup> – Protocol bitmask. (Range: 0-ffff hex)

*protocol* - IP protocol or IPv6 next header. (Range: 0-255)

For information on next headers, see [permit, deny \(Extended IPv6 ACL\)](#).

*sport*<sup>7</sup> – Protocol source port number. (Range: 0-65535)

*dport*<sup>7</sup> – Protocol destination port number. (Range: 0-65535)

*port-bitmask* – Decimal number representing the port bits to match. (Range: 0-65535)

*time-range-name* - Name of the time range. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

MAC ACL

### Command Usage

- ◆ New rules are added to the end of the list.
- ◆ The **ethertype** option can only be used to filter Ethernet II formatted packets.
- ◆ A detailed listing of Ethernet protocol types can be found in RFC 1060. A few of the more common types include the following:
  - 0800 - IP
  - 0806 - ARP
  - 8137 - IPX
- ◆ If an Extended IPv4 rule and MAC rule match the same packet, and these rules specify a “permit” entry and “deny” entry, the “deny” action takes precedence.

### Example

This rule permits packets from any source MAC address to the destination address 00-e0-29-94-34-de where the Ethernet type is 0800.

```
Console(config-mac-acl)#permit any host 00-e0-29-94-34-de ethertype 0800  
Console(config-mac-acl)#
```

### Related Commands

[access-list mac \(408\)](#)

[Time Range \(188\)](#)

6. For all bitmasks, “1” means relevant and “0” means ignore.

7. Includes TCP, UDP or other protocol types.

**mac access-group** This command binds a MAC ACL to a port. Use the **no** form to remove the port.

### Syntax

```
mac access-group acl-name {in | out}  
[time-range time-range-name] [counter]
```

```
no mac access-group acl-name {in | out}
```

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

**in** – Indicates that this list applies to ingress packets.

**out** – Indicates that this list applies to egress packets.

*time-range-name* - Name of the time range. (Range: 1-32 characters)

**counter** – Enables counter for ACL statistics.

### Default Setting

None

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

If an ACL is already bound to a port and you bind a different ACL to it, the switch will replace the old binding with the new one.

### Example

```
Console(config)#interface ethernet 1/2  
Console(config-if)#mac access-group jerry in  
Console(config-if)#
```

### Related Commands

[show mac access-list \(414\)](#)

[Time Range \(188\)](#)

**show mac access-group** This command shows the ports assigned to MAC ACLs.

### Command Mode

Privileged Exec

### Example

```
Console#show mac access-group  
Interface ethernet 1/5  
MAC access-list M5 in  
Console#
```

### Related Commands

[mac access-group \(413\)](#)

**show mac access-list** This command displays the rules for configured MAC ACLs.

### Syntax

**show mac access-list** [*acl-name*]

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

### Command Mode

Privileged Exec

### Example

```
Console#show mac access-list
MAC access-list jerry:
  permit any 00-e0-29-94-34-de ethertype 0800
Console#
```

### Related Commands

[permit, deny \(409\)](#)  
[mac access-group \(413\)](#)

---

## ARP ACLs

The commands in this section configure ACLs based on the IP or MAC address contained in ARP request and reply messages. To configure ARP ACLs, first create an access list containing the required permit or deny rules, and then bind the access list to one or more VLANs using the [ip arp inspection vlan](#) command.

Table 77: ARP ACL Commands

Command	Function	Mode
<a href="#">access-list arp</a>	Creates a ARP ACL and enters configuration mode	GC
<a href="#">permit, deny</a>	Filters packets matching a specified source or destination address in ARP messages	ARP-ACL
<a href="#">show access-list arp</a>	Displays the rules for configured ARP ACLs	PE

**access-list arp** This command adds an ARP access list and enters ARP ACL configuration mode. Use the **no** form to remove the specified ACL.

### Syntax

**[no] access-list arp** *acl-name*

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ When you create a new ACL or enter configuration mode for an existing ACL, use the **permit** or **deny** command to add new rules to the bottom of the list. To create an ACL, you must add at least one rule to the list.
- ◆ To remove a rule, use the **no permit** or **no deny** command followed by the exact text of a previously configured rule.
- ◆ An ACL can contain up to 128 rules.

### Example

```
Console(config)#access-list arp factory
Console(config-arp-acl)#
```

### Related Commands

[permit, deny \(415\)](#)

[show access-list arp \(416\)](#)

**permit, deny (ARP ACL)** This command adds a rule to an ARP ACL. The rule filters packets matching a specified source or destination address in ARP messages. Use the **no** form to remove a rule.

### Syntax

```
[no] {permit | deny}
ip {any | host source-ip | source-ip ip-address-bitmask}
{any | host destination-ip | destination-ip ip-address-bitmask}
mac {any | host source-mac | source-mac mac-address-bitmask}
[any | host destination-mac | destination-mac mac-address-bitmask] [log]
```

This form indicates either request or response packets.

```
[no] {permit | deny} request
ip {any | host source-ip | source-ip ip-address-bitmask}
{any | host destination-ip | destination-ip ip-address-bitmask}
mac {any | host source-mac | source-mac mac-address-bitmask}
[any | host destination-mac | destination-mac mac-address-bitmask] [log]
```

```
[no] {permit | deny} response
ip {any | host source-ip | source-ip ip-address-bitmask}
```

```
{any | host destination-ip | destination-ip ip-address-bitmask}  
mac {any | host source-mac | source-mac mac-address-bitmask}  
[any | host destination-mac | destination-mac mac-address-bitmask] [log]
```

*source-ip* – Source IP address.

*destination-ip* – Destination IP address with bitmask.

*ip-address-bitmask*<sup>8</sup> – IPv4 number representing the address bits to match.

*source-mac* – Source MAC address.

*destination-mac* – Destination MAC address range with bitmask.

*mac-address-bitmask*<sup>8</sup> – Bitmask for MAC address (in hexadecimal format).

**log** - Logs a packet when it matches the access control entry.

### Default Setting

None

### Command Mode

ARP ACL

### Command Usage

New rules are added to the end of the list.

### Example

This rule permits packets from any source IP and MAC address to the destination subnet address 192.168.0.0.

```
Console(config-arp-acl)#$permit response ip any 192.168.0.0 255.255.0.0 mac  
any any  
Console(config-arp-acl)#
```

### Related Commands

[access-list arp \(414\)](#)

**show access-list arp** This command displays the rules for configured ARP ACLs.

### Syntax

```
show access-list arp [acl-name]
```

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

### Command Mode

Privileged Exec

8. For all bitmasks, binary “1” means relevant and “0” means ignore.

### Example

```

Console#show access-list arp
ARP access-list factory:
  permit response ip any 192.168.0.0 255.255.0.0 mac any any
Console#

```

### Related Commands

[permit, deny \(415\)](#)

## ACL Information

This section describes commands used to display ACL information.

**Table 78: ACL Information Commands**

Command	Function	Mode
<a href="#">clear access-list hardware counters</a>	Clears hit counter for rules in all ACLs, or in a specified ACL	PE
<a href="#">show access-group</a>	Shows the ACLs assigned to each port	PE
<a href="#">show access-list</a>	Show all ACLs and associated rules	PE

**clear access-list hardware counters** This command clears the hit counter for the rules in all ACLs, or for the rules in a specified ACL.

### Syntax

```

clear access-list hardware counters
[direction in [interface interface]] |
[interface interface] | [name acl-name[direction in]]

```

**in** – Clears counter for ingress rules.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

### Command Mode

Privileged Exec

### Example

```

Console#clear access-list hardware counters
Console#

```

**show access-group** This command shows the port assignments of ACLs.

### Syntax

**show access-group [ip | ipv6 | mac]**

**ip** - Ingress or egress access groups for IP ACLs

**ipv6** - Ingress or egress access groups for IPv6 ACLs

**mac** - Ingress or egress access groups for MAC ACLs

### Command Mode

Privileged Executive

### Example

```
Console#show access-group
Interface ethernet 1/1
  IP access-list ex1 in
  IP access-list ex1 out
Interface ethernet 1/2
  IPv6 access-list i6ex in
  IPv6 access-list i6ex out
Console#
```

**show access-list** This command shows all ACLs and associated rules.

### Syntax

**show access-list**

**[[arp [acl-name]] |**

**[ip [extended [acl-name]] | standard [acl-name]] |**

**[ipv6 [extended [acl-name]] | standard [acl-name]] |**

**[mac [acl-name]] | [tcam-utilization] | [hardware counters]]**

**arp** – Shows ingress or egress rules for ARP ACLs.

**hardware counters** – Shows statistics for all ACLs.<sup>9</sup>

**ip extended** – Shows ingress or egress rules for Extended IPv4 ACLs.

**ip standard** – Shows ingress or egress rules for Standard IPv4 ACLs.

**ipv6 extended** – Shows ingress or egress rules for Extended IPv6 ACLs.

**ipv6 standard** – Shows ingress or egress rules for Standard IPv6 ACLs.

**mac** – Shows ingress or egress rules for MAC ACLs.

**tcam-utilization** – Shows the percentage of user configured ACL rules as a percentage of total ACL rules

*acl-name* – Name of the ACL. (Maximum length: 32 characters)

9. Due to a hardware limitation, this option only displays statistics for permit rules.

## Command Mode Privileged Exec

### Example

```
Console#show access-list
IP standard access-list david:
  permit host 10.1.1.21
  permit 168.92.0.0 255.255.15.0
IP extended access-list bob:
  permit TCP 192.168.1.0 255.255.255.0 any destination-port 80
  permit TCP 192.168.1.0 255.255.255.0 any control-flag 2 2
  permit 10.7.1.1 255.255.255.0 any
MAC access-list jerry:
  permit any host 00-30-29-94-34-de ethertype 800 800
  permit any any VID 1 ethertype 0000 cos 1 1
IP extended access-list A6:
  permit any any DSCP 5
  permit any any next-header 43
  permit any 2009:db90:2229::79/8
ARP access-list arpl:
  permit response ip any 192.168.0.0 255.255.0.0 mac any any
  permit ip any any mac any any
  permit ip any any mac any host 12-12-12-12-12-12 log
Console#
```



# Interface Commands

These commands are used to display or set communication parameters for an Ethernet port, aggregated link, or VLAN; or perform cable diagnostics on the specified interface.

**Table 79: Interface Commands**

Command	Function	Mode
<i>Interface Configuration</i>		
<code>interface</code>	Configures an interface type and enters interface configuration mode	GC
<code>alias</code>	Configures an alias name for the interface	IC
<code>capabilities</code>	Advertises the capabilities of a given interface for use in autonegotiation	IC
<code>description</code>	Adds a description to an interface configuration	IC
<code>discard</code>	Discards CDP, PVST, or VLAN 0 packets	IC
<code>flowcontrol</code>	Enables flow control on a given interface	IC
<code>history</code>	Configures a periodic sampling of statistics, specifying the sampling interval and number of samples	IC
<code>media-type</code>	Forces transceiver mode to use for SFP/SFP+/SFP28 ports	IC
<code>fec</code>	Configures the Forward Error Correction (FEC) mode on 25G SFP28 ports	IC
<code>negotiation</code>	Enables autonegotiation of a given interface	IC
<code>shutdown</code>	Disables an interface	IC
<code>speed-duplex</code>	Configures the speed and duplex operation of a given interface when autonegotiation is disabled	IC
<code>clear counters</code>	Clears statistics on an interface	PE
<code>show discard</code>	Displays if CDP and PVST packets are being discarded	PE
<code>show interfaces brief</code>	Displays a summary of key information, including operational status, native VLAN ID, default priority, speed/duplex mode, and port type	PE
<code>show interfaces counters</code>	Displays statistics for the specified interfaces	NE, PE
<code>show interfaces history</code>	Displays periodic sampling of statistics, including the sampling interval, number of samples, and counter values	NE, PE
<code>show interfaces status</code>	Displays status for the specified interface	NE, PE
<code>show interfaces switchport</code>	Displays the administrative and operational status of an interface	NE, PE

**Table 79: Interface Commands (Continued)**

<b>Command</b>	<b>Function</b>	<b>Mode</b>
<i>Transceiver Threshold Configuration</i>		
<code>transceiver-monitor</code>	Sends a trap when any of the transceiver's operational values fall outside specified thresholds	IC
<code>transceiver-threshold-auto</code>	Uses default threshold settings obtained from the transceiver to determine when an alarm or trap message should be sent	IC
<code>transceiver-threshold current</code>	Sets thresholds for transceiver current which can be used to trigger an alarm or warning message	IC
<code>transceiver-threshold rx-power</code>	Sets thresholds for the transceiver power level of the received signal which can be used to trigger an alarm or warning message	IC
<code>transceiver-threshold temperature</code>	Sets thresholds for the transceiver temperature which can be used to trigger an alarm or warning message	IC
<code>transceiver-threshold tx-power</code>	Sets thresholds for the transceiver power level of the transmitted signal which can be used to trigger an alarm or warning message	IC
<code>transceiver-threshold voltage</code>	Sets thresholds for the transceiver voltage which can be used to trigger an alarm or warning message	IC
<code>show interfaces transceiver</code>	Displays the temperature, voltage, bias current, transmit power, and receive power	PE
<code>show interfaces transceiver-threshold</code>	Displays the alarm/warning thresholds for temperature, voltage, bias current, transmit power, and receive power	PE
<i>Cable Diagnostics</i>		
<code>test cable-diagnostics</code>	Performs cable diagnostics on the specified port	PE
<code>test loop internal</code>	Performs internal loop back test on the specified port	PE
<code>show cable-diagnostics</code>	Shows the results of a cable diagnostics test	PE
<code>show loop internal</code>	Shows the results of a loop back test	PE
<i>Power Savings</i>		
<code>power-save</code>	Enables power savings mode on the specified port	IC
<code>show power-save</code>	Shows the configuration settings for power savings	PE

## Interface Configuration

**interface** This command configures an interface type and enters interface configuration mode. Use the **no** form with a trunk to remove an inactive interface. Use the **no** form with a Layer 3 VLAN (normal type) to change it back to a Layer 2 interface.

### Syntax

**interface** *interface*

**no interface** {**loopback** | **port-channel** *channel-id* | **vlan** *vlan-id*}

*interface*

**craft** - Management port on the front panel.

**ethernet** *unit/port-list*

*unit* - Unit identifier. (Range: 1)

*port-list* - Physical port number or list of port numbers. Separate nonconsecutive port numbers with a comma and no spaces; or use a hyphen to designate a range of port numbers. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* (Range: 1-4094)

**loopback** *interface-number* - A loopback interface. (Range: 0)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

The craft interface is provided as an out-of-band management connection which is isolated from all other ports on the switch. This interface must first be configured with an IPv4 or IPv6 address before a connection can be made through Telnet, SSH, or HTTP.

### Example

To specify several different ports, enter the following command:

```
Console(config)#interface ethernet 1/17-20,23
Console(config-if)#
```

**alias** This command configures an alias name for an interface. Use the **no** form to remove an alias name.

### Syntax

**alias** *string*

**no alias**

*string* - A mnemonic name to help you remember what is attached to this interface. (Range: 1-64 characters)

### Default Setting

None

### Command Mode

Interface Configuration (Port Channel, VLAN)

### Command Usage

The alias is displayed in the running-configuration file.

### Example

```
Console(config)#interface port-channel 4
Console(config-if)#alias finance
Console(config-if)#
```

**capabilities** This command advertises the port capabilities of a given interface during auto-negotiation. Use the **no** form with parameters to remove an advertised capability, or the **no** form without parameters to restore the default values.

### Syntax

**[no] capabilities {1000full | 100full | 100half | 10full | 10half | flowcontrol}**

**1000full** - Supports 1 Gbps full-duplex operation

**100full** - Supports 100 Mbps full-duplex operation

**100half** - Supports 100 Mbps half-duplex operation

**10full** - Supports 10 Mbps full-duplex operation

**10half** - Supports 10 Mbps half-duplex operation

**flowcontrol** - Supports flow control

### Default Setting

100BASE-T: 10half, 10full, 100half, 100full, 1000full

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ When auto-negotiation is enabled with the [negotiation](#) command, the switch will negotiate the best settings for a link based on the **capabilities** command. When auto-negotiation is disabled, you must manually specify the link attributes with the [speed-duplex](#) and [flowcontrol](#) commands.

### Example

The following example configures Ethernet port 5 capabilities to include 100half and 100full.

```
Console(config)#interface ethernet 1/5
Console(config-if)#capabilities 100half
Console(config-if)#capabilities 100full
Console(config-if)#capabilities flowcontrol
Console(config-if)#
```

### Related Commands

[negotiation \(429\)](#)

[speed-duplex \(430\)](#)

[flowcontrol \(426\)](#)

**description** This command adds a description to an interface. Use the **no** form to remove the description.

### Syntax

**description** *string*

**no description**

*string* - Comment or a description to help you remember what is attached to this interface. (Range: 1-64 characters)

### Default Setting

None

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

The description is displayed by the [show interfaces status](#) command and in the running-configuration file. An example of the value which a network manager might store in this object is the name of the manufacturer, and the product name.

**Example**

The following example adds a description to port 4.

```
Console(config)#interface ethernet 1/4
Console(config-if)#description RD-SW#3
Console(config-if)#
```

**discard** This command discards CDP, PVST, or VLAN 0 packets. Use the **no** form to forward the specified packet type to other ports configured the same way.

**Syntax**

**[no] discard {cdp | pvst | vlan0}**

**cdp** – Cisco Discovery Protocol.

**pvst** – Per-VLAN Spanning Tree.

**vlan0** – Packets with a VLAN ID of 0.

**Default Setting**

Default - Forward CDP, PVST, and VLAN 0 packets

**Command Mode**

Interface Configuration (Ethernet)

**Command Usage**

Use the **no discard** command to allow CDP, PVST, or VLAN 0 packets to be forwarded to other ports in the same VLAN which are also configured to forward the specified packet type.

**Example**

The following example forwards CDP packets entering port 5.

```
Console(config)#interface ethernet 1/5
Console(config-if)#discard cdp
Console(config-if)#
```

**flowcontrol** This command enables flow control. Use the **no** form to disable flow control.

**Syntax**

**[no] flowcontrol**

**Default Setting**

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

Flow control can eliminate frame loss by “blocking” traffic from end stations or segments connected directly to the switch when its buffers fill. When enabled, back pressure is used for half-duplex operation and IEEE 802.3-2002 (formally IEEE 802.3x) for full-duplex operation.

### Example

The following example enables flow control on port 5.

```

Console(config)#interface ethernet 1/5
Console(config-if)#flowcontrol
Console(config-if)#

```

**history** This command configures a periodic sampling of statistics, specifying the sampling interval and number of samples. Use the **no** form to remove a named entry from the sampling table.

### Syntax

**history** *name interval buckets*

**no history** [*name*]

*name* - A symbolic name for this entry in the sampling table. (Range: 1-31 characters)

*interval* - The interval for sampling statistics. (Range: 1-86400 seconds.)

*buckets* - The number of samples to take. (Range: 1-96)

### Default Setting

15min - 15 minute interval, 96 buckets

1day - 1 day interval, 7 buckets

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Example

This example sets a interval of 15 minutes for sampling standard statistical values on port 1.

```

Console(config)#interface ethernet 1/1
Console(config-if)#history 15min 15 10
Console(config-if)#

```

**media-type** This command forces the transceiver mode to use for SFP/SFP+/SFP28 ports. Use the **no** form to restore the default mode.

### Syntax

**media-type** {**copper-forced** | **sfp-forced** [*mode* | **ifmode** {**kr** | **sr\_lr**}] | **sfp-preferred-auto**}

**no media-type** [**sfp-forced ifmode**]

**copper-forced** - Always uses the built-in RJ-45 port.

**sfp-forced** - Forces transceiver mode for the SFP/SFP+/SFP28 port.

**sfp-preferred-auto** - Uses SFP/SFP+/SFP28 port if both combination types are functioning and the SFP/SFP+/SFP28 port has a valid link.

*mode*

**1000sfp** - Always uses 1000BASE SFP mode.

**10gsfp** - Always uses 10GBASE SFP mode.

**25gsfp** - Always uses 25GBASE SFP mode.

**ifmode** - Sets a specific interface mode when the media type is not automatically recognized.

**kr** - Sets the mode for DAC copper media.

**sr\_lr** - Sets the mode for optical/AOC fiber media.

### Default Setting

SFP/SFP+/SFP28 ports: None

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

Available sfp-forced modes include: 1000sfp, 10gsfp, 25gsfp

### Example

This forces the switch to use the 1000sfp mode for SFP port 28.

```
Console(config)#interface ethernet 1/28
Console(config-if)#media-type sfp-forced 1000sfp
Console(config-if)#
```

**fec** This command configures the Forward Error Correction (FEC) mode of 25G SFP28 ports. Use the **no** form to disable FEC mode.

### Syntax

**fec {rs}**

**no fec**

**rs** - Enables Reed-Solomon FEC (RS-FEC) on the port.

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Forward Error Correction (FEC) is a technique used for correcting data errors in transmission links. The use of Reed-Solomon FEC (RS-FEC) on noisy network links can improve reliability and performance. The RS-FEC mode must be enabled on both ends of a link.
- ◆ If negotiation is enabled (auto mode), this command has no effect.

### Example

```
Console(config)#interface ethernet 1/50
Console(config-if)#fec rs
Console(config-if)#
```

**negotiation** This command enables auto-negotiation for a given interface. Use the **no** form to disable auto-negotiation.

### Syntax

**[no] negotiation**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ 1000BASE-T does not support forced mode. Auto-negotiation should always be used to establish a connection over any 1000BASE-T port or trunk.
- ◆ When auto-negotiation is enabled the switch will negotiate the best settings for a link based on the [capabilities](#) command. When auto-negotiation is

disabled, you must manually specify the link attributes with the [speed-duplex](#) and [flowcontrol](#) commands.

### Example

The following example configures port 10 to use auto-negotiation.

```
Console(config)#interface ethernet 1/10
Console(config-if)#negotiation
Console(config-if)#
```

### Related Commands

[capabilities \(424\)](#)

[speed-duplex \(430\)](#)

**shutdown** This command disables an interface. To restart a disabled interface, use the **no** form.

### Syntax

**[no] shutdown**

### Default Setting

All interfaces are enabled.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

This command allows you to disable a port due to abnormal behavior (e.g., excessive collisions), and then re-enable it after the problem has been resolved. You may also want to disable a port for security reasons.

### Example

The following example disables port 5.

```
Console(config)#interface ethernet 1/5
Console(config-if)#shutdown
Console(config-if)#
```

**speed-duplex** This command configures the speed and duplex mode of a given interface when auto-negotiation is disabled. Use the **no** form to restore the default.

### Syntax

**speed-duplex {100full | 100half | 10full | 10half}**

**no speed-duplex**

**100full** - Forces 100 Mbps full-duplex operation

**100half** - Forces 100 Mbps half-duplex operation

**10full** - Forces 10 Mbps full-duplex operation

**10half** - Forces 10 Mbps half-duplex operation

### Default Setting

- ◆ Auto-negotiation is enabled by default.
- ◆ When auto-negotiation is disabled, the default speed-duplex setting is **100full** for 1000BASE-T ports.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ The 1000BASE-T standard does not support forced mode. Auto-negotiation should always be used to establish a connection over any 1000BASE-T port or trunk. If not used, the success of the link process cannot be guaranteed when connecting to other types of switches.

### Example

The following example configures port 5 to 100 Mbps, half-duplex operation.

```
Console(config)#interface ethernet 1/5
Console(config-if)#speed-duplex 100half
Console(config-if)#
```

**clear counters** This command clears statistics on an interface.

### Syntax

**clear counters** *interface*

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

**Command Usage**

Statistics are only initialized for a power reset. This command sets the base value for displayed statistics to zero for the current management session. However, if you log out and back into the management interface, the statistics displayed will show the absolute value accumulated since the last power reset.

**Example**

The following example clears statistics on port 5.

```
Console#clear counters ethernet 1/5
Console#
```

**show discard** This command displays whether or not CDP and PVST packets are being discarded.

**Command Mode**

Privileged Exec

**Example**

In this example, "Default" means that the packets are not discarded.

```
Console#show discard
Port      CDP      PVST
-----
Eth 1/ 1 No      No
Eth 1/ 2 No      No
Eth 1/ 3 No      No
Eth 1/ 4 No      No
Eth 1/ 5 No      No
Eth 1/ 6 No      No
:
```

**show interfaces brief** This command displays a summary of key information, including operational status, native VLAN ID, default priority, speed/duplex mode, and port type for all ports.

**Command Mode**

Privileged Exec

**Command Usage**

- ◆ If an SFP transceiver is inserted in a port, the Type field will show the SFP type as interpreted from Ethernet Compliance Codes (Data Byte 6 in Address A0h). The Ethernet Compliance Code is a bitmap value, of which one bit is supposedly turned on. However, if the read-out is not recognizable (e.g., 2 or more bits on, or all 0s), the Type field just displays the raw data (hexadecimal value).

- ◆ If link status is down due to an administrative setting or the result of a protocol state, the reason will be listed in the Status field (i.e., Disabled, STP LBD, BpduGuard, LinkDet, DynQoS, PortSec, LBD, ATC Bcast, ATC Mcast, UDLD, License).

### Example

```

Console#show interfaces brief
Interface Name          Status    PVID Pri Speed/Duplex  Type           Trunk
-----
Eth 1/ 1                Up        1   0 Auto-1000full 1000BASE-T     None
Eth 1/ 2                Up        1   0 Auto          1000BASE-T     None
Eth 1/ 3                Up        1   0 Auto          1000BASE-T     None
Eth 1/ 4                Up        1   0 Auto          1000BASE-T     None
Eth 1/ 5                Up        1   0 Auto          1000BASE-T     None
Eth 1/ 6                Up        1   0 Auto          1000BASE-T     None
:

```

**show interfaces counters** This command displays interface statistics.

### Syntax

**show interfaces counters** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

Shows the counters for all interfaces.

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

If no interface is specified, information on all interfaces is displayed.

### Example

```

Console#show interfaces counters ethernet 1/1
Ethernet 1/ 1
===== IF table Stats =====
                29370 Octets Input
                 3763 Octets Output
                   0 Unicast Input
                   7 Unicast Output
                   0 Discard Input
                   0 Discard Output
                   0 Error Input

```

```

0 Error Output
0 Unknown Protocols Input
0 QLen Output
===== Extended Iftable Stats =====
54 Multi-cast Input
13 Multi-cast Output
98 Broadcast Input
5 Broadcast Output
===== Ether-like Stats =====
0 Alignment Errors
0 FCS Errors
0 Single Collision Frames
0 Multiple Collision Frames
0 SQE Test Errors
0 Deferred Transmissions
0 Late Collisions
0 Excessive Collisions
0 Internal Mac Transmit Errors
0 Internal Mac Receive Errors
0 Frames Too Long
0 Carrier Sense Errors
0 Symbol Errors
0 Pause Frames Input
0 Pause Frames Output
===== RMON Stats =====
0 Drop Events
33133 Octets
177 Packets
98 Broadcast PKTS
54 Multi-cast PKTS
0 Undersize PKTS
0 Oversize PKTS
0 Fragments
0 Jabbers
0 CRC Align Errors
0 Collisions
18 Packet Size <= 64 Octets
71 Packet Size 65 to 127 Octets
17 Packet Size 128 to 255 Octets
71 Packet Size 256 to 511 Octets
0 Packet Size 512 to 1023 Octets
0 Packet Size 1024 to 1518 Octets
===== Port Utilization (recent 300 seconds) =====
0 Octets Input in kbits per second
0 Packets Input per second
0.00 % Input Utilization
0 Octets Output in kbits per second
0 Packets Output per second
0.00 % Output Utilization

Console#

```

**Table 80: show interfaces counters - display description**

Parameter	Description
<i>IF Table Stats</i>	
Octets Input	The total number of octets received on the interface, including framing characters.
Octets Output	The total number of octets transmitted out of the interface, including framing characters.

**Table 80: show interfaces counters - display description** (Continued)

Parameter	Description
Unicast Input	The number of subnetwork-unicast packets delivered to a higher-layer protocol.
Unicast Output	The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.
Discard Input	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space.
Discard Output	The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.
Error Input	The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
Error Output	The number of outbound packets that could not be transmitted because of errors.
Unknown Protocols Input	The number of packets received which were discarded because of an unknown or unsupported protocol.
QLen Output	The length of the output packet queue (in packets).
<i>Extended IF Table Stats</i>	
Multicast Input	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a multicast address at this sub-layer.
Multicast Output	The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent.
Broadcast Input	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a broadcast address at this sub-layer.
Broadcast Output	The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent.
<i>Etherlike Statistics</i>	
Alignment Errors	The number of alignment errors (missynchronized data packets).
FCS Errors	A count of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check. This count does not include frames received with frame-too-long or frame-too-short error.
Single Collision Frames	The number of successfully transmitted frames for which transmission is inhibited by exactly one collision.
Multiple Collision Frames	A count of successfully transmitted frames for which transmission is inhibited by more than one collision.
SQE Test Errors	A count of times that the SQE TEST ERROR message is generated by the PLS sublayer for a particular interface.
Deferred Transmissions	A count of frames for which the first transmission attempt on a particular interface is delayed because the medium was busy.
Late Collisions	The number of times that a collision is detected later than 512 bit-times into the transmission of a packet.

**Table 80: show interfaces counters - display description** (Continued)

Parameter	Description
Excessive Collisions	A count of frames for which transmission on a particular interface fails due to excessive collisions. This counter does not increment when the interface is operating in full-duplex mode.
Internal MAC Transmit Errors	A count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error.
Internal Mac Receive Errors	A count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error.
Frames Too Long	A count of frames received on a particular interface that exceed the maximum permitted frame size.
Carrier Sense Errors	The number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame.
Symbol Errors	For an interface operating at 100 Mb/s, the number of times there was an invalid data symbol when a valid carrier was present.  For an interface operating in half-duplex mode at 1000 Mb/s, the number of times the receiving media is non-idle (a carrier event) for a period of time equal to or greater than slotTime, and during which there was at least one occurrence of an event that causes the PHY to indicate 'Data reception error' or 'carrier extend error' on the GMII.  For an interface operating in full-duplex mode at 1000 Mb/s, the number of times the receiving media is non-idle (a carrier event) for a period of time equal to or greater than minFrameSize, and during which there was at least one occurrence of an event that causes the PHY to indicate 'Data reception error' on the GMII
Pause Frames Input	Count of pause frames received on the interface
Pause Frames Output	Count of pause frames transmitted from the interface.
<i>RMON Statistics</i>	
Drop Events	The number of events in which packets were dropped at the interface due to lack of resources.
Octets	Total number of octets of data received on the network. This statistic can be used as a reasonable indication of Ethernet utilization.
Packets	The total number of packets (including error, unicast, broadcast, multicast, unknown-unicast, etc.) received.
Broadcast PKTS	The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets.
Multicast PKTS	The total number of good packets received that were directed to this multicast address.
Undersize PKTS	The total number of packets received that were less than 64 octets long (excluding framing bits, but including FCS octets) and were otherwise well formed.
Oversize PKTS	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.
Fragments	The total number of frames received that were less than 64 octets in length (excluding framing bits, but including FCS octets) and had either an FCS or alignment error.

**Table 80: show interfaces counters - display description** (Continued)

Parameter	Description
Jabbers	The total number of frames received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS or alignment error.
CRC Align Errors	The number of frames that do not end with an even number of octets and have a bad Cyclic Redundancy Check (CRC).
Collisions	The best estimate of the total number of collisions on this Ethernet segment.
Packet Size <= 64 Octets	The total number of packets (including bad packets) received and transmitted that were less than 64 octets in length (excluding framing bits but including FCS octets).
Packet Size 65 to 127 Octets	The total number of packets (including bad packets) received and transmitted where the number of octets fall within the specified range (excluding framing bits but including FCS octets).
Packet Size 128 to 255 Octets	
Packet Size 256 to 511 Octets	
Packet Size 512 to 1023 Octets	
Packet Size 1024 to 1518 Octets	
<i>Port Utilization (recent 300 seconds) Statistics</i>	
Octets input in kbits per second	Number of octets entering this interface in kbits per second.
Packets input per second	Number of packets entering this interface in packets per second.
% Input utilization	The input utilization rate for this interface.
Octets output in kbits per second	Number of octets leaving this interface in kbits per second.
Packets output per second	Number of packets leaving this interface in packets per second.
% Output utilization	The output utilization rate for this interface.

**show interfaces history** This command displays periodic sampling of statistics, including the sampling interval, number of samples, and counter values.

### Syntax

```
show interfaces history [interface [name [current | previous index count]]
[input | output]]
```

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

*name* - Name of sample as defined in the [history](#) command.  
(Range: 1-31 characters)

**current** - Statistics recorded in current interval.

**previous** - Statistics recorded in previous intervals.

*index* - An index into the buckets containing previous samples.  
(Range: 1-96)

*count* - The number of historical samples to display. (Range: 1-96)

**input** - Ingress traffic.

**output** - Egress traffic.

### Default Setting

Shows the historical settings and status for all interfaces.

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

If no interface is specified, information on all interfaces is displayed.

### Example

```

Console#show interfaces history ethernet 1/1 15min
Interface      : Eth 1/ 1
Name           : 15min
Interval       : 900 second(s)
Buckets Requested : 96
Buckets Granted  : 17
Status         : Active

Current Entries

Start Time    %      Octets Input  Unicast      Multicast      Broadcast
-----
-
00d 04:15:00  0.00          3201         0             31             6

Errors
-----
0

%      Octets Output  Unicast      Multicast      Broadcast
-----
0.00          716         4             2             0

Discards      Errors
-----
0             0

Previous Entries

Start Time    %      Octets Input  Unicast      Multicast      Broadcast
-----
-
00d 00:00:00  0.00          52248        0             560            120
00d 00:15:00  0.00          51278        0             549            99
00d 00:30:00  0.00          51252        0             546            111
00d 00:45:00  0.00          51076        0             547            99
00d 01:00:00  0.00          51636        0             546            117
    
```

```

00d 01:15:00 0.00 55632 0 571 108
00d 01:30:00 0.00 51990 0 546 120
00d 01:45:00 0.00 51616 0 549 102
00d 02:00:00 0.00 51444 0 546 114
00d 02:15:00 0.00 51424 0 549 99
00d 02:30:00 0.00 51168 0 543 114
00d 02:45:00 0.00 51548 0 553 99
00d 03:00:00 0.00 50602 0 545 102
00d 03:15:00 0.00 52768 0 549 120
00d 03:30:00 0.00 50272 0 543 100
00d 03:45:00 0.00 52238 0 548 116
00d 04:00:00 0.00 50602 0 545 102

```

```

Start Time Discards Errors
-----
00d 00:00:00 0 0
00d 00:15:00 0 0
00d 00:30:00 0 0
00d 00:45:00 0 0
00d 01:00:00 0 0
00d 01:15:00 0 0
00d 01:30:00 0 0
00d 01:45:00 0 0
00d 02:00:00 0 0
00d 02:15:00 0 0
00d 02:30:00 0 0
00d 02:45:00 0 0
00d 03:00:00 0 0
00d 03:15:00 0 0
00d 03:30:00 0 0
00d 03:45:00 0 0
00d 04:00:00 0 0

```

Console#

**show interfaces status** This command displays the status for an interface.

### Syntax

**show interfaces status** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* (Range: 1-4094)

### Default Setting

Shows the status for all interfaces.

### Command Mode

Normal Exec, Privileged Exec

## Command Usage

If no interface is specified, information on all interfaces is displayed.

## Example

```

Console#show interfaces status ethernet 1/1
Information of Eth 1/1
Basic Information:
  Port Type           : 1000BASE-T
  MAC Address         : 90-3C-B3-8C-44-B3
Configuration:
  Name                :
  Port Admin          : Up
  Speed-duplex        : Auto
  Capabilities        : 10half, 10full, 100half, 100full, 1000full
  Broadcast Storm     : Disabled
  Broadcast Storm Limit : 500 packets/second
  Multicast Storm     : Disabled
  Multicast Storm Limit : 500 packets/second
  Unknown Unicast Storm : Disabled
  Unknown Unicast Storm Limit : 500 packets/second
  Flow Control        : Disabled
  VLAN Trunking       : Disabled
  LACP                : Disabled
  MAC Learning        : Enabled
  Media Type          : None
Current Status:
  Link Status         : Up
  Port Operation Status : Up
  Operation Speed-duplex : 1000full
  Up Time             : 0w 0d 7h 27m 37s (26857 seconds)
  Flow Control Type   : None
  Max Frame Size      : 1518 bytes (1522 bytes for tagged frames)
  MAC Learning Status : Enabled
Console#

```

**show interfaces switchport** This command displays the administrative and operational status of the specified interfaces.

## Syntax

**show interfaces switchport** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

## Default Setting

Shows all interfaces.

## Command Mode

Normal Exec, Privileged Exec

## Command Usage

If no interface is specified, information on all interfaces is displayed.

## Example

This example shows the configuration setting for port 1.

```

Console#show interfaces switchport ethernet 1/1
Information of Eth 1/1
Broadcast Threshold          : Disabled
Multicast Threshold         : Disabled
Unknown Unicast Threshold   : Disabled
LACP Status                  : Disabled
Ingress Rate Limit          : Disabled, 1000000 kbits/second
Egress Rate Limit           : Disabled, 1000000 kbits/second
VLAN Membership Mode        : Hybrid
Ingress Rule                 : Enabled
Acceptable Frame Type       : All frames
Native VLAN                  : 1
Priority for Untagged Traffic : 0
GVRP Status                  : Disabled
Allowed VLAN                 : 1 (u)
Forbidden VLAN               :
802.1Q Tunnel Status        : Disabled
802.1Q Tunnel Mode          : Normal
802.1Q Tunnel TPID          : 8100 (Hex)
Layer 2 Protocol Tunnel     : None
Console#

```

**Table 81: show interfaces switchport - display description**

Field	Description
Broadcast Threshold	Shows if broadcast storm suppression is enabled or disabled; if enabled it also shows the threshold level ( <a href="#">page 493</a> ).
Multicast Threshold	Shows if multicast storm suppression is enabled or disabled; if enabled it also shows the threshold level ( <a href="#">page 493</a> ).
Unknown Unicast Threshold	Shows if unknown unicast storm suppression is enabled or disabled; if enabled it also shows the threshold level ( <a href="#">page 493</a> ).
Storm Threshold Resolution	Shows configuration threshold for storm control commands.
LACP Status	Shows if Link Aggregation Control Protocol has been enabled or disabled ( <a href="#">page 459</a> ).
Ingress/Egress Rate Limit	Shows if rate limiting is enabled, and the current rate limit ( <a href="#">page 491</a> ).
Rate Limit Resolution	Shows configuration threshold for rate limit commands.
VLAN Membership Mode	Indicates membership mode as Trunk or Hybrid ( <a href="#">page 582</a> ).
Ingress Rule	Shows if ingress filtering is enabled or disabled ( <a href="#">page 581</a> ).
Acceptable Frame Type	Shows if acceptable VLAN frames include all types or tagged frames only ( <a href="#">page 579</a> ).
Native VLAN	Indicates the default Port VLAN ID ( <a href="#">page 583</a> ).

**Table 81: show interfaces switchport - display description** (Continued)

Field	Description
Priority for Untagged Traffic	Indicates the default priority for untagged frames ( <a href="#">page 656</a> ).
GVRP Status	Shows if GARP VLAN Registration Protocol is enabled or disabled ( <a href="#">page 573</a> ).
Allowed VLAN	Shows the VLANs this interface has joined, where “(u)” indicates untagged and “(t)” indicates tagged ( <a href="#">page 580</a> ).
Allowed VLAN	Shows the VLANs this interface has joined, where “(u)” indicates untagged and “(t)” indicates tagged ( <a href="#">page 580</a> ).
Forbidden VLAN	Shows the VLANs this interface can not join ( <a href="#">page 572</a> ).
802.1Q-tunnel Status	Shows if 802.1Q tunnel is enabled on this interface ( <a href="#">page 587</a> ).
802.1Q-tunnel Mode	Shows the tunnel mode as Normal, 802.1Q Tunnel or 802.1Q Tunnel Uplink ( <a href="#">page 588</a> ).
802.1Q-tunnel TPID	Shows the Tag Protocol Identifier used for learning and switching packets ( <a href="#">page 588</a> ).
Layer 2 Protocol Tunnel	Shows if Layer 2 Protocol tunnel is enabled ( <a href="#">page 594</a> ).

## Transceiver Threshold Configuration

**transceiver-monitor** This command sends a trap when any of the transceiver’s operational values fall outside of specified thresholds. Use the **no** form to disable trap messages.

### Syntax

**[no] transceiver-monitor**

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Example

```
Console(config)interface ethernet 1/1
Console(config-if)#transceiver-monitor
Console#
```

**transceiver-threshold-auto** This command uses default threshold settings obtained from the transceiver to determine when an alarm or warning message should be sent. Use the **no** form to disable this feature.

### Syntax

**[no ] transceiver-threshold-auto**

### Default Setting

Enabled

### Command Mode

Interface Configuration

### Example

```
Console(config)interface ethernet 1/12
Console(config-if)#transceiver-threshold-auto
Console#
```

**transceiver-threshold-current** This command sets thresholds for transceiver current which can be used to trigger an alarm or warning message. Use the **no** form to restore the default settings.

### Syntax

**transceiver-threshold current {high-alarm | high-warning | low-alarm | low-warning} threshold-value**

**high-alarm** – Sets the high current threshold for an alarm message.

**high-warning** – Sets the high current threshold for a warning message.

**low-alarm** – Sets the low current threshold for an alarm message.

**low-warning** – Sets the low current threshold for a warning message.

*threshold-value* – The threshold of the transceiver current.

(Range: 0-13100 in units of 0.01 mA)

### Default Setting

Defaults are transceiver dependent.

### Command Mode

Interface Configuration

### Command Usage

- ◆ If trap messages are enabled with the [transceiver-monitor](#) command, and a high-threshold alarm or warning message is sent if the current value is greater than or equal to the threshold, and the last sample value was less than the threshold. After a rising event has been generated, another such event will not be generated until the sampled value has fallen below the high threshold and reaches the low threshold.

- ◆ If trap messages are enabled with the `transceiver-monitor` command, and a low-threshold alarm or warning message is sent if the current value is less than or equal to the threshold, and the last sample value was greater than the threshold. After a falling event has been generated, another such event will not be generated until the sampled value has risen above the low threshold and reaches the high threshold.
- ◆ Threshold events are triggered as described above to avoid a hysteresis effect which would continuously trigger event messages if the power level were to fluctuate just above and below either the high threshold or the low threshold.
- ◆ Trap messages enabled by the `transceiver-monitor` command are sent to any management station configured by the `snmp-server host` command.
- ◆ Transceiver-Threshold Auto must be disabled.

### Example

The following example sets alarm thresholds for the transceiver current at port 9.

```
Console(config)interface ethernet 1/9
Console(config-if)#transceiver-threshold current low-alarm 100
Console(config-if)#transceiver-threshold rx-power high-alarm 700
Console#
```

**transceiver-threshold rx-power** This command sets thresholds for the transceiver power level of the received signal which can be used to trigger an alarm or warning message. Use the **no** form to restore the default settings.

### Syntax

**transceiver-threshold rx-power {high-alarm | high-warning | low-alarm | low-warning} threshold-value**

**no transceiver-threshold rx-power**

**high-alarm** – Sets the high power threshold for an alarm message.

**high-warning** – Sets the high power threshold for a warning message.

**low-alarm** – Sets the low power threshold for an alarm message.

**low-warning** – Sets the low power threshold for a warning message.

*threshold-value* – The power threshold of the received signal.

(Range: -4000 - 820 in units of 0.01 dBm)

### Default Setting

Defaults are transceiver dependent.

### Command Mode

Interface Configuration

### Command Usage

- ◆ The threshold value is the power ratio in decibels (dB) of the measured power referenced to one milliwatt (mW).
- ◆ Refer to the Command Usage section under the [transceiver-threshold current](#) command for more information on configuring transceiver thresholds.
- ◆ Trap messages enabled by the [transceiver-monitor](#) command are sent to any management station configured by the [snmp-server host](#) command.

### Example

The following example sets alarm thresholds for the signal power received at port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#transceiver-threshold rx-power low-alarm -21
Console(config-if)#transceiver-threshold rx-power high-alarm -3
Console#
```

### transceiver-threshold temperature

This command sets thresholds for the transceiver temperature which can be used to trigger an alarm or warning message. Use the **no** form to restore the default settings.

### Syntax

**transceiver-threshold temperature** {**high-alarm** | **high-warning** | **low-alarm** | **low-warning**} *threshold-value*

**no transceiver-threshold temperature**

**high-alarm** – Sets the high temperature threshold for an alarm message.

**high-warning** – Sets the high temperature threshold for a warning message.

**low-alarm** – Sets the low temperature threshold for an alarm message.

**low-warning** – Sets the low temperature threshold for a warning message.

*threshold-value* – The threshold of the transceiver temperature.  
(Range: -12800 - 12800 in units of 0.01 Celsius)

### Default Setting

Defaults are transceiver dependent.

### Command Mode

Interface Configuration

### Command Usage

- ◆ Refer to the Command Usage section under the [transceiver-threshold current](#) command for more information on configuring transceiver thresholds.

- ◆ Trap messages enabled by the [transceiver-monitor](#) command are sent to any management station configured by the [snmp-server host](#) command.

### Example

The following example sets alarm thresholds for the transceiver temperature at port 1.

```
Console(config)interface ethernet 1/1
Console(config-if)#transceiver-threshold temperature low-alarm 97
Console(config-if)#transceiver-threshold temperature high-alarm -83
Console#
```

**transceiver-threshold tx-power** This command sets thresholds for the transceiver power level of the transmitted signal which can be used to trigger an alarm or warning message. Use the **no** form to restore the default settings.

### Syntax

**transceiver-threshold tx-power {high-alarm | high-warning | low-alarm | low-warning} *threshold-value***

**no transceiver-threshold tx-power**

**high-alarm** – Sets the high power threshold for an alarm message.

**high-warning** – Sets the high power threshold for a warning message.

**low-alarm** – Sets the low power threshold for an alarm message.

**low-warning** – Sets the low power threshold for a warning message.

*threshold-value* – The power threshold of the transmitted signal.  
(Range: -4000 - 820 in units of 0.01 dBm)

### Default Setting

Defaults are transceiver dependent.

### Command Mode

Interface Configuration

### Command Usage

- ◆ The threshold value is the power ratio in decibels (dB) of the measured power referenced to one milliwatt (mW).
- ◆ Refer to the Command Usage section under the [transceiver-threshold current](#) command for more information on configuring transceiver thresholds.
- ◆ Trap messages enabled by the [transceiver-monitor](#) command are sent to any management station configured by the [snmp-server host](#) command.

### Example

The following example sets alarm thresholds for the signal power transmitted at port 9.

```

Console(config)interface ethernet 1/9
Console(config-if)#transceiver-threshold tx-power low-alarm -4000
Console(config-if)#transceiver-threshold tx-power high-alarm 820
Console#

```

### transceiver-threshold voltage

This command sets thresholds for the transceiver voltage which can be used to trigger an alarm or warning message. Use the **no** form to restore the default settings.

#### Syntax

**transceiver-threshold voltage** {**high-alarm** | **high-warning** | **low-alarm** | **low-warning**} *threshold-value*

**no transceiver-threshold voltage**

**high-alarm** – Sets the high voltage threshold for an alarm message.

**high-warning** – Sets the high voltage threshold for a warning message.

**low-alarm** – Sets the low voltage threshold for an alarm message.

**low-warning** – Sets the low voltage threshold for a warning message.

*threshold-value* – The threshold of the transceiver voltage.

(Range: 0-655 in units of 0.01 Volt)

#### Default Setting

Defaults are transceiver dependent.

#### Command Mode

Interface Configuration

#### Command Usage

- ◆ Refer to the Command Usage section under the [transceiver-threshold current](#) command for more information on configuring transceiver thresholds.
- ◆ Trap messages enabled by the [transceiver-monitor](#) command are sent to any management station configured by the [snmp-server host](#) command.

### Example

The following example sets alarm thresholds for the transceiver voltage at port 9.

```

Console(config)interface ethernet 1/9
Console(config-if)#transceiver-threshold voltage low-alarm 100
Console(config-if)#transceiver-threshold voltage high-alarm 500
Console#

```

**show interfaces transceiver** This command displays identifying information for the specified transceiver, including connector type and vendor-related parameters, as well as the temperature, voltage, bias current, transmit power, and receive power.

### Syntax

**show interfaces transceiver** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 49-54)

### Default Setting

Shows all interfaces.

### Command Mode

Privileged Exec

### Command Usage

The switch can display diagnostic information for SFP modules which support the SFF-8472 Specification for Diagnostic Monitoring Interface for Optical Transceivers. This information allows administrators to remotely diagnose problems with optical devices. This feature, referred to as Digital Diagnostic Monitoring (DDM) in the command display, provides information on transceiver parameters including temperature, supply voltage, laser bias current, laser power, and received optical power, and related alarm thresholds.

### Example

```

Console#show interfaces transceiver ethernet 1/28
Information of Eth 1/28
Connector Type       : LC
Fiber Type           : [0x00]
Eth Compliance Codes : 1000BASE-ZX
Baud Rate            : 1300 MBd
Vendor OUI           : 00-00-5F
Vendor Name          : SumitomoElectric
Vendor PN            : SCP6G94-FN-BWH
Vendor Rev           : Z
Vendor SN            : SE08T712Z00006
Date Code            : 10-09-14
DDM Information
  Temperature        : 35.64 degree C
  Vcc                 : 3.25 V
  Bias Current        : 12.13 mA
  TX Power            : 2.36 dBm
  RX Power            : -24.20 dBm
DDM Thresholds
-----
                                Low Alarm  Low Warning  High Warning  High Alarm
-----
Temperature (Celsius)          -45.00      -40.00          85.00        90.00
Voltage (Volts)                 2.90         3.00           3.60         3.70
Current (mA)                     1.00         3.00           50.00        60.00
TxPower (dBm)                   -11.50      -10.50          -2.00        -1.00

```

```

RxPower (dBm)          -23.98          -23.01          -1.00          0.00
Console#

```

**show interfaces transceiver-threshold** This command Displays the alarm/warning thresholds for temperature, voltage, bias current, transmit power, and receive power.

### Syntax

**show interfaces transceiver-threshold** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 49-54)

### Default Setting

Shows all interfaces.

### Command Mode

Privileged Exec

### Command Usage

- ◆ The switch can display diagnostic information for SFP modules which support the SFF-8472 Specification for Diagnostic Monitoring Interface for Optical Transceivers. This information allows administrators to remotely diagnose problems with optical devices. This feature, referred to as Digital Diagnostic Monitoring (DDM) in the command display, provides information on transceiver parameters including temperature, supply voltage, laser bias current, laser power, received optical power, and related alarm thresholds.
- ◆ The DDM thresholds displayed by this command only apply to ports which have a DDM-compliant transceiver inserted.

### Example

```

Console#show interfaces transceiver-threshold ethernet 1/28
Information of Eth 1/28
DDM Thresholds
Transceiver-monitor      : Disabled
Transceiver-threshold-auto : Enabled
-----
          Low Alarm  Low Warning  High Warning  High Alarm
-----
Temperature (Celsius)   -123.00      0.00          70.00         75.00
Voltage (Volts)         3.10         3.15          3.45          3.50
Current (mA)            6.00         7.00          90.00         100.00
TxPower (dBm)           -12.00       -11.50        -9.50         -9.00
RxPower (dBm)           -21.50       -21.00        -3.50         -3.00
Console#

```

## Cable Diagnostics

**test cable-diagnostics** This command performs cable diagnostics on the specified port to diagnose any cable faults (short, open, etc.) and report the cable length.

### Syntax

**test cable-diagnostics interface** *interface*

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-48)

### Command Mode

Privileged Exec

### Command Usage

- ◆ Cable diagnostics are performed using an internal Digital Signal Processing test process when the port link-up speed is 1 Gbps. The method analyses the cable by sending a pulsed signal into the cable, and then examining the reflection of that pulse. If the port link-up speed is not 1 Gbps, then Time Domain Reflectometry (TDR) test method is used. TDR also detects a cable fault by sending a signal through the cable and reading the signal that is reflected back. However, note that TDR can only determine if a link is valid or faulty.
- ◆ This cable test is only accurate for Ethernet cables 7 - 100 meters long.
- ◆ The test takes approximately 5 seconds. Use the [show cable-diagnostics](#) command to display the results of the test, including common cable failures, as well as the status and approximate length of each cable pair.
- ◆ Ports are linked down while running cable diagnostics.
- ◆ To ensure more accurate measurement of the length to a fault, first disable power-saving mode (using the [no power-save](#) command) on the link partner before running cable diagnostics.

### Example

```
Console#test cable-diagnostics interface ethernet 1/24
Console#
```

**test loop internal** This command performs an internal loop back test on the specified port.

### Syntax

**test loop internal interface** *interface*

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-48)

### Command Mode

Privileged Exec

### Command Usage

- ◆ Loopback testing can only be performed on a port that is not linked up. The internal loopback makes it possible to check that an interface is working properly without having to make any network connections.
- ◆ When performing an internal loopback test, packets from the specified interface are looped back into its internal PHY. Outgoing data is looped back to the receiver without actually being transmitted.

### Example

```
Console#test loop internal interface ethernet 1/1
Internal loopback test: succeeded
Console#
```

**show cable-diagnostics** This command shows the results of a cable diagnostics test.

### Syntax

**show cable-diagnostics interface** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-48)

### Command Mode

Privileged Exec

### Command Usage

- ◆ The results include common cable failures, as well as the status and approximate distance to a fault, or the approximate cable length if no fault is found.

- ◆ For link-down ports, the reported distance to a fault is accurate to within +/- 2 meters. For link-up ports, the accuracy is +/- 10 meters.
- ◆ Potential conditions which may be listed by the diagnostics are shown by the legend in the following example. Additional information is provided for the following test results.
  - OK: Correctly terminated pair
  - ON: Open pair, no link partner
  - ST: Shorted pair
  - IE (Impedance mismatch): Terminating impedance is not in the reference range.
  - NS (Not Supported): This message is displayed for any Gigabit Ethernet ports linked up at a speed lower than 1000 Mbps.
  - UN: Unknown Error

### Example

```

Console#show cable-diagnostics interface ethernet 1/7
TF: Test failed
OK: OK
ON: Open
ST: Short
IE: Impedance error
NC: No cable
NT: Not tested
NS: Not supported
UN: Unknown
Port      Type Link      Pair A   Pair B   Pair C   Pair D   Last
          Type Status    meters  meters  meters  meters  Updated
-----
Eth 1/ 7 GE  Up       OK (8)  OK (8)  OK (8)  OK (8)  2019-07-16 11:54:24
Console#

```

**show loop internal** This command shows the results of a loop back test.

### Syntax

**show loop internal interface** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Stack unit. (Range: 1)

*port* - Port number. (Range: 1-24/48)

### Command Mode

Privileged Exec

### Example

```

Console#show loop internal interface ethernet 1/1

```

```

Port          Test Result      Last Update
-----
Eth 1/1       Succeeded        2024-07-15 15:26:56
Console#

```

## Power Savings

**power-save** This command enables power savings mode on the specified port. Use the **no** form to disable this feature.

### Syntax

**[no] power-save**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet ports 1-24/48)

### Command Usage

- ◆ Power saving mode only applies to the Ethernet ports using copper media.
- ◆ Power savings can be enabled on Ethernet RJ-45 ports.
- ◆ The power-saving methods provided by this switch include:
  - Power saving when there is no link partner:
 

Under normal operation, the switch continuously auto-negotiates to find a link partner, keeping the MAC interface powered up even if no link connection exists. When using power-savings mode, the switch checks for energy on the circuit to determine if there is a link partner. If none is detected, the switch automatically turns off the transmitter, and most of the receive circuitry (entering Sleep Mode). In this mode, the low-power energy-detection circuit continuously checks for energy on the cable. If none is detected, the MAC interface is also powered down to save additional energy. If energy is detected, the switch immediately turns on both the transmitter and receiver functions, and powers up the MAC interface.
  - Power saving when there is a link partner:
 

Traditional Ethernet connections typically operate with enough power to support at least 100 meters of cable even though average network cable length is shorter. When power-savings mode is enabled, the switch determines whether or not it can reduce the signal amplitude used on a particular link.

- ◆ When the power-save command is enabled and traffic is reduced there is a reduction in power. For example, factory hardware component testing has shown significant power reduction >10%-45%<sup>10</sup> are realized when 1000M Ethernet ports operate at slower rates from 300 to 0 Mbps.



**Note:** Power savings can only be implemented on Ethernet ports using twisted-pair cabling. Power-savings mode on a active link only works when connection speed is 1/10 Gbps, and line length is less than 60 meters.

### Example

```
Console(config)#interface ethernet 1/24
Console(config-if)#power-save
Console(config-if)#
```

**show power-save** This command shows the configuration settings for power savings.

### Syntax

**show power-save** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-48)

### Command Mode

Privileged Exec

### Example

```
Console#show power-save interface ethernet 1/24
Power Saving Status:
 Ethernet 1/24 : Enabled
Console#
```

10. The percentage reduction is for the switch hardware interface internal component only.

# Link Aggregation Commands

Ports can be statically grouped into an aggregate link (i.e., trunk) to increase the bandwidth of a network connection or to ensure fault recovery. Or you can use the Link Aggregation Control Protocol (LACP) to automatically negotiate a trunk link between this switch and another network device. For static trunks, the switches have to comply with the Cisco EtherChannel standard. For dynamic trunks, the switches have to comply with LACP. This switch supports up to 28 trunks. For example, a trunk consisting of two 1000 Mbps ports can support an aggregate bandwidth of 4 Gbps when operating at full duplex.

**Table 82: Link Aggregation Commands**

Command	Function	Mode
<i>Manual Configuration Commands</i>		
<code>interface port-channel</code>	Configures a trunk and enters interface configuration mode for the trunk	GC
<code>port-channel load-balance</code>	Sets the load-distribution method among ports in aggregated links	GC
<code>channel-group</code>	Adds a port to a trunk	IC (Ethernet)
<i>Dynamic Configuration Commands</i>		
<code>lacp</code>	Configures LACP for the current interface	IC (Ethernet)
<code>lacp actor/partner mode (Ethernet Interface)</code>	Configures the port's LACP actor or partner negotiation activity mode	IC (Ethernet)
<code>lacp admin-key</code>	Configures a port's administration key	IC (Ethernet)
<code>lacp port-priority</code>	Configures a port's LACP port priority	IC (Ethernet)
<code>lacp system-priority</code>	Configures a port's LACP system priority	IC (Ethernet)
<code>lacp admin-key</code>	Configures an port channel's administration key	IC (Port Channel)
<code>lacp timeout</code>	Configures the timeout to wait for next LACPDU	IC (Port Channel)
<i>Trunk Status Display Commands</i>		
<code>show interfaces status port-channel</code>	Shows trunk information	NE, PE
<code>show lacp</code>	Shows LACP information	PE
<code>show port-channel load-balance</code>	Shows the load-distribution method used on aggregated links	PE
<i>Multi-Chassis Link Aggregation Group Commands</i>		
<code>m lag</code>	Enables MLAG globally	GC
<code>m lag domain peer-link</code>	Configures the MLAG domain peer link	GC
<code>m lag group member</code>	Configures MLAG domain member ports	GC

Table 82: Link Aggregation Commands

Command	Function	Mode
<code>show mlag</code>	Shows MLAG configuration settings	PE
<code>show mlag group</code>	Shows MLAG group settings	PE
<code>show mlag domain</code>	Shows MLAG domain settings	PE

### Guidelines for Creating Trunks

#### General Guidelines –

- ◆ Finish configuring trunks before you connect the corresponding network cables between switches to avoid creating a loop.
- ◆ A trunk can have up to 8 ports.
- ◆ The ports at both ends of a connection must be configured as trunk ports.
- ◆ All ports in a trunk must be configured in an identical manner, including communication mode (i.e., speed and duplex mode), VLAN assignments, and CoS settings.
- ◆ Any of the Gigabit ports on the front panel can be trunked together, including ports of different media types.
- ◆ All the ports in a trunk have to be treated as a whole when moved from/to, added or deleted from a VLAN via the specified port-channel.
- ◆ STP, VLAN, and IGMP settings can only be made for the entire trunk via the specified port-channel.

#### Dynamically Creating a Port Channel –

Ports assigned to a common port channel must meet the following criteria:

- ◆ Ports must have the same LACP system priority.
- ◆ Ports must have the same port admin key (Ethernet Interface).
- ◆ If the port channel admin key (`lacp admin key` - Port Channel) is not set when a channel group is formed (i.e., it has the null value of 0), the operational key is set to the same value as the operational key of the first member port.
- ◆ However, if the port channel admin key is set, then the port admin key must be set to the same value for a port to be allowed to join a channel group.
- ◆ If a link goes down, LACP port priority is used to select the backup link.

## Manual Configuration Commands

**port-channel load-balance** This command sets the load-distribution method among ports in aggregated links (for both static and dynamic trunks). Use the **no** form to restore the default setting.

### Syntax

```
port-channel load-balance {dst-ip | dst-mac | src-dst-ip | src-dst-mac | src-ip | src-mac}
```

**no port-channel load-balance**

**dst-ip** - Load balancing based on destination IP address.

**dst-mac** - Load balancing based on destination MAC address.

**src-dst-ip** - Load balancing based on source and destination IP address.

**src-dst-mac** - Load balancing based on source and destination MAC address.

**src-ip** - Load balancing based on source IP address.

**src-mac** - Load balancing based on source MAC address.

### Default Setting

src-dst-ip

### Command Mode

Global Configuration

### Command Usage

- ◆ This command applies to all static and dynamic trunks on the switch.
- ◆ To ensure that the switch traffic load is distributed evenly across all links in a trunk, select the source and destination addresses used in the load-balance calculation to provide the best result for trunk connections:
  - **dst-ip**: All traffic with the same destination IP address is output on the same link in a trunk. This mode works best for switch-to-router trunk links where traffic through the switch is destined for many different hosts. Do not use this mode for switch-to-server trunk links where the destination IP address is the same for all traffic.
  - **dst-mac**: All traffic with the same destination MAC address is output on the same link in a trunk. This mode works best for switch-to-switch trunk links where traffic through the switch is destined for many different hosts. Do not use this mode for switch-to-router trunk links where the destination MAC address is the same for all traffic.
  - **src-dst-ip**: All traffic with the same source and destination IP address is output on the same link in a trunk. This mode works best for switch-to-

router trunk links where traffic through the switch is received from and destined for many different hosts.

- **src-dst-mac:** All traffic with the same source and destination MAC address is output on the same link in a trunk. This mode works best for switch-to-switch trunk links where traffic through the switch is received from and destined for many different hosts.
- **src-ip:** All traffic with the same source IP address is output on the same link in a trunk. This mode works best for switch-to-router or switch-to-server trunk links where traffic through the switch is received from many different hosts.
- **src-mac:** All traffic with the same source MAC address is output on the same link in a trunk. This mode works best for switch-to-switch trunk links where traffic through the switch is received from many different hosts.

### Example

```
Console(config)#port-channel load-balance dst-ip
Console(config)#
```

**channel-group** This command adds a port to a trunk. Use the **no** form to remove a port from a trunk.

### Syntax

**channel-group** *channel-id*

**no channel-group**

*channel-id* - Trunk index (Range: 1-28)

### Default Setting

The current port is not a member of any trunk.

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ When configuring static trunks, the switches must comply with the Cisco EtherChannel standard.
- ◆ Use **no channel-group** to remove a port group from a trunk.
- ◆ Use **no interface port-channel** to remove a trunk from the switch.

**Example**

The following example creates trunk 1 and then adds port 10:

```
Console(config)#interface port-channel 1
Console(config-if)#exit
Console(config)#interface ethernet 1/10
Console(config-if)#channel-group 1
Console(config-if)#
```

**Dynamic Configuration Commands**

**lacp** This command enables 802.3ad Link Aggregation Control Protocol (LACP) for the current interface. Use the **no** form to disable it.

**Syntax**

**[no] lacp**

**Default Setting**

Disabled

**Command Mode**

Interface Configuration (Ethernet)

**Command Usage**

- ◆ The ports on both ends of an LACP trunk must be configured for full duplex.
- ◆ A trunk formed with another switch using LACP will automatically be assigned the next available port-channel ID.
- ◆ If the target switch has also enabled LACP on the connected ports, the trunk will be activated automatically.
- ◆ If more than eight ports attached to the same target switch have LACP enabled, the additional ports will be placed in standby mode, and will only be enabled if one of the active links fails.

**Example**

The following shows LACP enabled on ports 1-3. Because LACP has also been enabled on the ports at the other end of the links, the [show interfaces status port-channel 1](#) command shows that Trunk1 has been established.

```
Console(config)#interface ethernet 1/25
Console(config-if)#lacp
Console(config-if)#interface ethernet 1/26
Console(config-if)#lacp
Console(config-if)#interface ethernet 1/27
Console(config-if)#lacp
Console(config-if)#end
```

```

Console#show interfaces status port-channel 1
Information of Trunk 1
Basic Information:
  Port Type           : 10GBASE SFP+
  MAC Address         : 12-34-12-34-12-3F
Configuration:
  Name                :
  Port Admin          : Up
  Speed-duplex        : 10Gfull
  Broadcast Storm     : Enabled
  Broadcast Storm Limit : 500 packets/second
  Multicast Storm     : Disabled
  Multicast Storm Limit : 500 packets/second
  Unknown Unicast Storm : Disabled
  Unknown Unicast Storm Limit : 500 packets/second
  Storm Threshold Resolution : 1 packets/second
  Flow Control        : Disabled
  MAC Learning        : Enabled
  Link-up-down Trap   : Enabled
Current status:
  Created By          : LACP
  Link Status         : Up
  Port Operation Status : Up
  Operation Speed-duplex : 10Gfull
  Up Time             : 0w 0d 0h 0m 53s (53 seconds)
  Flow Control Type   : None
  Max Frame Size      : 1518 bytes (1522 bytes for tagged frames)
  MAC Learning Status : Enabled
  Member Ports        : Eth1/25, Eth1/26, Eth1/27,
  Active Member Ports : Eth1/25, Eth1/26, Eth1/27,
Console#

```

**lacp actor/partner mode (Ethernet Interface)** This command configures a port's LACP actor or partner negotiation activity mode. Use the **no** form to restore to the default setting.

### Syntax

**lacp {actor | partner} mode {active | passive}**

**no lacp {actor | partner} mode**

**actor** - The local side an aggregate link.

**partner** - The remote side of an aggregate link.

**mode** - Configures the negotiation activity mode.

**active** - Specifies the port's activity mode to initiate and transmit LACP negotiation packets.

**passive** - Specifies the port's activity mode to only respond to LACP negotiation packets.

### Default Setting

Actor: Active, Partner: Passive

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ An LACP trunk cannot be instantiated if both sides are set to passive.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#lACP actor mode passive
Console(config-if)#
```

**lACP admin-key** (Ethernet Interface) This command configures a port's LACP administration key. Use the **no** form to restore the default setting.

### Syntax

**lACP** {actor | partner} admin-key *key*

**no lACP** {actor | partner} admin-key

**actor** - The local side an aggregate link.

**partner** - The remote side of an aggregate link.

*key* - The port admin key must be set to the same value for ports that belong to the same link aggregation group (LAG). (Range: 0-65535)

### Default Setting

Actor: 1, Partner: 0

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Ports are only allowed to join the same LAG if (1) the LACP system priority matches, (2) the LACP port admin key matches, and (3) the LACP port channel key matches (if configured).
- ◆ If the port channel admin key (**lACP admin key** - Port Channel) is not set when a channel group is formed (i.e., it has the null value of 0), this key is set to the same value as the port admin key (**lACP admin key** - Ethernet Interface) used by the interfaces that joined the group.
- ◆ Once the remote side of a link has been established, LACP operational settings are already in use on that side. Configuring LACP settings for the partner only applies to its administrative state, not its operational state.



**Note:** Configuring the partner admin-key does not affect remote or local switch operation. The local switch just records the partner admin-key for user reference.

- ◆ If the admin key is not set, the actor's operational key is determined by port's link speed (10G - 5, 1000f - 4, 100f - 3, 10f - 2).

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#lACP actor admin-key 120
Console(config-if)#
```

**lACP port-priority** This command configures LACP port priority. Use the **no** form to restore the default setting.

### Syntax

**lACP** {**actor** | **partner**} **port-priority** *priority*

**no lACP** {**actor** | **partner**} **port-priority**

**actor** - The local side an aggregate link.

**partner** - The remote side of an aggregate link.

*priority* - LACP port priority is used to select a backup link. (Range: 0-65535)

### Default Setting

32768

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Setting a lower value indicates a higher effective priority.
- ◆ If an active port link goes down, the backup port with the highest priority is selected to replace the downed link. However, if two or more ports have the same LACP port priority, the port with the lowest physical port number will be selected as the backup port.
- ◆ If an LAG already exists with the maximum number of allowed port members, and LACP is subsequently enabled on another port using a higher priority than an existing member, the newly configured port will replace an existing port member that has a lower priority.
- ◆ Once the remote side of a link has been established, LACP operational settings are already in use on that side. Configuring LACP settings for the partner only applies to its administrative state, not its operational state, and will only take effect the next time an aggregate link is established with the partner.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#lACP actor port-priority 128
```

**lacp system-priority** This command configures a port's LACP system priority. Use the **no** form to restore the default setting.

### Syntax

**lacp {actor | partner} system-priority *priority***

**no lacp {actor | partner} system-priority**

**actor** - The local side an aggregate link.

**partner** - The remote side of an aggregate link.

*priority* - This priority is used to determine link aggregation group (LAG) membership, and to identify this device to other switches during LAG negotiations. (Range: 0-65535)

### Default Setting

32768

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Port must be configured with the same system priority to join the same LAG.
- ◆ System priority is combined with the switch's MAC address to form the LAG identifier. This identifier is used to indicate a specific LAG during LACP negotiations with other systems.
- ◆ Once the remote side of a link has been established, LACP operational settings are already in use on that side. Configuring LACP settings for the partner only applies to its administrative state, not its operational state, and will only take effect the next time an aggregate link is established with the partner.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#lacp actor system-priority 3
Console(config-if)#
```

**lacp admin-key (Port Channel)** This command configures a port channel's LACP administration key. Use the **no** form to restore the default setting.

### Syntax

**lacp admin-key *key***

**no lacp admin-key**

*key* - The port channel admin key is used to identify a specific link aggregation group (LAG) during local LACP setup on this switch. (Range: 0-65535)

### Default Setting

None

### Command Mode

Interface Configuration (Port Channel)

### Command Usage

- ◆ Ports are only allowed to join the same LAG if (1) the LACP system priority matches, (2) the LACP port admin key matches, and (3) the LACP port channel key matches (if configured).
- ◆ If the port channel admin key (**lacp admin key** - Port Channel) is not set when a channel group is formed (i.e., it has the null value of 0), the operational key is set to the same value as the operational key of the first member port. Note that when the LAG is no longer used, the port channel admin key is reset to 0.

### Example

```
Console(config)#interface port-channel 1
Console(config-if)#lacp admin-key 3
Console(config-if)#
```

**lacp timeout** This command configures the timeout to wait for the next LACP data unit (LACPDU).

### Syntax

**lacp timeout {long | short}**

**long** - Specifies a slow timeout of 90 seconds.

**short** - Specifies a fast timeout of 3 seconds.

### Default Setting

long

### Command Mode

Interface Configuration (Port Channel)

### Command Usage

- ◆ The timeout configured by this command is set in the LACP timeout bit of the Actor State field in transmitted LACPDU. When the partner switch receives an LACPDU set with a short timeout from the actor switch, the partner adjusts the transmit LACPDU interval to 1 second. When it receives an LACPDU set with a long timeout from the actor, it adjusts the transmit LACPDU interval to 30 seconds.
- ◆ If the actor does not receive an LACPDU from its partner before the configured timeout expires, the partner port information will be deleted from the LACP group.

- ◆ When a dynamic port-channel member leaves a port-channel, the default timeout value will be restored on that port.
- ◆ When a dynamic port-channel is torn down, the configured timeout value will be retained. When the dynamic port-channel is constructed again, that timeout value will be used.

### Example

```
Console(config)#interface port-channel 1
Console(config-if)#lACP timeout short
Console(config-if)#
```

## Trunk Status Display Commands

**show lacp** This command displays LACP information.

### Syntax

**show lacp** [*port-channel*] {**counters** | **internal** | **neighbors**}

*port-channel* - Local identifier for a link aggregation group. (Range: 1-28)

**counters** - Statistics for LACP protocol messages.

**internal** - Configuration settings and operational state for local side.

**neighbors** - Configuration settings and operational state for remote side.

### Default Setting

Port Channel: all

### Command Mode

Privileged Exec

### Example

```
Console#show lacp 1 counters
Port Channel: 1
Member Port           : Eth 1/14
LACPDU Sent           : 7
LACPDU Received       : 6
MarkerPDU Sent        : 0
MarkerPDU Received    : 0
MarkerResponsePDU Sent : 0
MarkerResponsePDU Received : 0
Unknown Packet Received : 0
Illegal Packet Received : 0
:
```

**Table 83: show lacp counters - display description**

Field	Description
Port Channel	The LACP port channel trunk number.
Member Port	The Ethernet interface that is a member of the LACP port-channel trunk.
LACPDU Sent	Number of valid LACPDUs transmitted from this channel group.
LACPDU Received	Number of valid LACPDUs received on this channel group.
MarkerPDU Sent	Number of valid Marker PDUs transmitted from this channel group.
MarkerPDU Received	Number of valid Marker PDUs received by this channel group.
MarkerResponsePDU Sent	Number of valid MarkerResponse PDUs transmitted from this channel group.
MarkerResponsePDU Received	Number of valid MarkerResponse PDUs received by this channel group.
Unknown Packet Received	Number of frames received that either (1) Carry the Slow Protocols Ethernet Type value, but contain an unknown PDU, or (2) are addressed to the Slow Protocols group MAC Address, but do not carry the Slow Protocols Ethernet Type.
Illegal Packet Received	Number of frames that carry the Slow Protocols Ethernet Type value, but contain a badly formed PDU or an illegal value of Protocol Subtype.

```

Console#show lacp 1 internal
Port Channel : 1
Admin Key    : 0
Oper Key     : 4
Timeout      : Long
-----
Member Port   : Eth 1/14
Periodic Time : 30 seconds
System Priority : 32768
Port Priority  : 32768
Admin Key     : 4
Oper Key      : 4
Admin State   : Defaulted, Aggregatable, Long Timeout, Active LACP
Oper State    : Distributing, Collecting, Synchronization, Aggregatable,
                Long Timeout, Active LACP
:

```

**Table 84: show lacp internal - display description**

Field	Description
Port Channel	The LACP port channel trunk number.
Admin Key	Current administrative value of the key for the aggregation port.
Oper Key	Current operational value of the key for the aggregation port.
Timeout	Time to wait for the next LACPDU before deleting partner port information.
Periodic Time	The number of seconds between periodic LACPDU transmissions.
System Priority	LACP system priority assigned to this port channel.
Port Priority	LACP port priority assigned to this interface within the channel group.

**Table 84: show lacp internal - display description (Continued)**

Field	Description
Admin State, Oper State	Administrative or operational values of the actor's state parameters: <ul style="list-style-type: none"> <li>◆ Expired – The actor's receive machine is in the expired state;</li> <li>◆ Defaulted – The actor's receive machine is using defaulted operational partner information, administratively configured for the partner.</li> <li>◆ Distributing – If false, distribution of outgoing frames on this link is disabled; i.e., distribution is currently disabled and is not expected to be enabled in the absence of administrative changes or changes in received protocol information.</li> <li>◆ Collecting – Collection of incoming frames on this link is enabled; i.e., collection is currently enabled and is not expected to be disabled in the absence of administrative changes or changes in received protocol information.</li> <li>◆ Synchronization – The System considers this link to be IN_SYNC; i.e., it has been allocated to the correct Link Aggregation Group, the group has been associated with a compatible Aggregator, and the identity of the Link Aggregation Group is consistent with the System ID and operational Key information transmitted.</li> </ul>
Admin State, Oper State (continued)	<ul style="list-style-type: none"> <li>◆ Aggregation – The system considers this link to be aggregatable; i.e., a potential candidate for aggregation.</li> <li>◆ Long timeout – Periodic transmission of LACPDUs uses a slow transmission rate.</li> <li>◆ LACP-Activity – Activity control value with regard to this link. (0: Passive; 1: Active)</li> </ul>

```

Console#show lacp 1 neighbors
Port Channel : 1
-----
Member Port           : Eth 1/14
Partner Admin System ID : 32768, 00-00-00-00-00-00
Partner Oper System ID  : 32768, FC-0A-81-B7-C7-E0
Partner Admin Port ID   : 32768, 14
Partner Oper Port ID    : 32768, 14
Partner Admin Key       : 0
Partner Oper Key        : 4
Partner Admin State     : Defaulted, Distributing, Collecting,
                          Synchronization, Long Timeout, Passive LACP
Partner Oper State      : Distributing, Collecting, Synchronization,
                          Aggregatable, Long Timeout, Active LACP
:

```

**Table 85: show lacp neighbors - display description**

Field	Description
Port Channel	The LACP port channel trunk number.
Member Port	The Ethernet interface that is a member of the LACP port-channel trunk.
Partner Admin System ID	LAG partner's system ID assigned by the user.
Partner Oper System ID	LAG partner's system ID assigned by the LACP protocol.
Partner Admin Port ID	Current administrative value of the port number for the protocol Partner.

**Table 85: show lacp neighbors - display description (Continued)**

Field	Description
Partner Oper Port ID	Operational port number assigned to this aggregation port by the port's protocol partner.
Partner Admin Key	Current administrative value of the Key for the protocol partner.
Partner Oper Key	Current operational value of the Key for the protocol partner.
Partner Admin State	Administrative values of the partner's state parameters. (See preceding table.)
Partner Oper State	Operational values of the partner's state parameters. (See preceding table.)

```

Console#show lacp sysid
Port Channel      System Priority    System MAC Address
-----
                1                32768             00-30-F1-8F-2C-A7
                2                32768             00-30-F1-8F-2C-A7
                3                32768             00-30-F1-8F-2C-A7
                4                32768             00-30-F1-8F-2C-A7
                5                32768             00-30-F1-8F-2C-A7
                6                32768             00-30-F1-8F-2C-A7
                7                32768             00-30-F1-D4-73-A0
                8                32768             00-30-F1-D4-73-A0
                9                32768             00-30-F1-D4-73-A0
               10                32768             00-30-F1-D4-73-A0
               11                32768             00-30-F1-D4-73-A0
               12                32768             00-30-F1-D4-73-A0
               :

```

**Table 86: show lacp sysid - display description**

Field	Description
Channel group	A link aggregation group configured on this switch.
System Priority*	LACP system priority for this channel group.
System MAC Address*	System MAC address.

\* The LACP system priority and system MAC address are concatenated to form the LAG system ID.

**show port-channel load-balance** This command shows the load-distribution method used on aggregated links.

**Command Mode**  
Privileged Exec

### Example

```

Console#show port-channel load-balance
Trunk Load Balance Mode: Destination IP address


Console

```

## MLAG Commands

A multi-chassis link aggregation group (MLAG) is a pair of links that terminate on two cooperating switches and appear as an ordinary link aggregation group (LAG). The cooperating switches are MLAG peer switches and communicate through an interface called a peer link. While the peer link's primary purpose is exchanging MLAG control information between peer switches, but also carries data traffic from devices that are attached to only one MLAG peer and have no alternative path. An MLAG domain consists of the peer switches and the control links that connect these switches.

**Figure 1: MLAG Domain Topology**



### MLAG Configuration

- ◆ MLAG must be enabled globally using the `m lag` command.
- ◆ The MLAG domain ID and peer link must be set using the `m lag domain peer-link` command.
- ◆ The MLAG ID, associated MLAG domain ID and MLAG member must be configured using the `m lag group member` command. The associated MLAG domain may be nonexistent, which causes MLAG to be inactive locally.
- ◆ For a port to be configured as MLAG peer link or member:
  - STP status of the port must be disabled.
  - LACP status of the port must be disabled.
  - The port must not be any type of traffic segmentation port.

*MLAG Restrictions*

- ◆ Traffic segmentation up-link/down-link port cannot be configured on an MLAG member or peer link.
- ◆ All actions which cause a port to become nonexistent, such as deleting a trunk port, adding a port to a trunk, or enabling LACP, are not allowed for an MLAG member or peer link. Also, a trunk member port is not allowed to be an MLAG member or peer link.
- ◆ STP cannot be enabled on a peer link or an MLAG member. An STP enabled port cannot be configured as a peer link or an MLAG member.

**mlag** This command enables MLAG globally on the switch. Use the **no** form to disable MLAG.

**Syntax**

**[no] mlag**

**Default Setting**

Enabled

**Command Mode**

Global Configuration

**Example**

```
Console(config)#mlag
Console(config)#
```

**mlag domain peer-link** This command configures an MLAG domain. Use the **no** form to remove the MLAG domain.

**Syntax**

**mlag domain** *domain-id* **peer-link** *interface*

**no mlag domain** *domain-id*

*domain-id* – Domain identifier. (Range: 1-16 characters)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**Command Usage**

- ◆ There shall be one and only one peer link for a pair of MLAG devices in the same MLAG domain. (See [Figure 1.](#))
- ◆ The peer link can be a normal port or a static trunk.
- ◆ MAC learning is automatically disabled for the peer link.
- ◆ An MLAG domain is active if the domain ID and a peer link are set.

**Command Mode**

Global Configuration

**Example**

```
Console(config)#mlog domain 1 peer-link ethernet 1/1
Console(config)#
```

**mlog group member** This command configures MLAG domain member ports. Use the **no** form to remove member ports.

**Syntax**

**mlog group** *mlog-id* **domain** *domain-id* **member** *interface*

**no domain** *domain-id*

*mlog-id* – MLAG identifier. (Range: 1-1000)

*domain-id* – Domain identifier. (Range: 1-16 characters)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**Command Mode**


Global Configuration

**Command Usage**

- ◆ An MLAG domain can have two and only two MLAG devices. (See [Figure 1.](#))
- ◆ An MLAG domain may have many MLAGs.
- ◆ An MLAG can belong to one and only one MLAG domain.
- ◆ The associated MLAG domain may be nonexistent, which causes the MLAG to be inactive locally.

- ◆ There can be one and only one MLAG member for each MLAG on an MLAG device.
- ◆ The MLAG member can be a normal port or a static trunk.
- ◆ An MLAG member is active if the MLAG ID is set and the associated MLAG domain is active.
- ◆ An MLAG is formed when the peer MLAG members are both active.
- ◆ The following items apply when an MLAG is formed.
  - When an MLAG member is operationally up and the MLAG peer member is not operationally down, all traffic from the peer link can not be forwarded to the MLAG member.
  - When an MLAG member is operationally up and the MLAG peer member is operationally down, all traffic from the peer link can be forwarded to the MLAG member.
  - When an MLAG member is operationally up, all updates for learned MAC addresses on the MLAG peer member will be synced to the MLAG member automatically.
  - When an MLAG member is operationally down, all updates for learned MAC addresses on the MLAG peer member will be synced through the peer link automatically.

**Figure 2: MLAG Peer Operation**



- ◆ When the MLAG peer member is down or nonexistent, learned MAC addresses synced through the peer link for the MLAG will be removed automatically.
- ◆ All updates of learned MAC addresses of non MLAG ports on a peer device shall be synced to the peer link automatically.

### Example

```
Console(config)#mlag group 1 domain 1 member ethernet 1/1
Console(config)#
```

**show mlag** This command shows MLAG configuration settings.

#### Command Mode

Privileged Exec

#### Example

```
Console#show mlag
Global Status : Enabled
Domain List   : 1,2
MLAG List     : 10,20,30-35,50
Console#
```

**show mlag group** The command shows MLAG group settings.

#### Command Mode

Privileged Exec

#### Syntax

**show mlag group** *mlag-id*

*mlag-id* – MLAG identifier. (Range: 1-1000)

#### Example

```
Console#show mlag group 1

Console#
```

**show mlag domain** The command shows MLAG domain settings.

#### Command Mode

Privileged Exec

#### Syntax

**show mlag domain** *domain-id*

*domain-id* – Domain identifier. (Range: 1-16 characters)

#### Example

```
Console#show mlag domain 1
Peer Link : Eth 1/1
MLAG List : 10,20,33-35
Console#
```



# Power over Ethernet Commands

The commands in this group control the power that can be delivered to attached PoE devices through RJ-45 ports 1-48 on the ECS4650-54P.

The switch's power management enables total switch power and individual port power to be controlled within a configured power budget. Port power can be automatically turned on and off for connected devices, and a per-port power priority can be set so that the switch never exceeds its allocated power budget. When a device is connected to a switch port, its power requirements are detected by the switch before power is supplied. If the power required by a device exceeds the power budget of the port or the whole switch, port power and priority settings are used to control the supplied power.

**Table 87: PoE Commands**

Command	Function	Mode
<code>power inline</code>	Turns power on and off for specific ports	IC
<code>power inline maximum allocation</code>	Sets the maximum power available to specific switch ports	IC
<code>power inline priority</code>	Sets the priority for power supplied to specific ports	IC
<code>show power inline status</code>	Displays the current status of power management on specific ports or all ports	PE
<code>show power inline time-range</code>	Shows the time-range and current status for specific ports or for all ports	PE
<code>show power mainpower</code>	Displays current status of power management for the switch	PE

**power inline** This command instructs the switch to automatically detect if a PoE-compliant device is connected to the specified port, and turn power on or off accordingly (optionally using an applied time range). Use the **no** form to turn off power for a port, or the **no** form with the time-range keyword to remove the time range settings.

## Syntax

**power inline** [**time-range** *time-range-name*]

**no power inline** [**time-range**]

*time-range-name* - Name of a time-range during which PoE is supplied to the attached device. (Range: 1-30 characters)

## Default Setting

Detection is enabled for PoE-compliant devices.

**Command Mode**

Interface Configuration (Ethernet RJ-45 ports)

**Command Usage**

- ◆ The switch only provides power to the Gigabit Ethernet copper-media ports.
- ◆ When detection is enabled for PoE-compliant devices, power is automatically supplied when a device is detected on the port, providing that the power demanded does not exceed the port's power budget or the switch's power budget.

**Example**

```

Console(config)#interface ethernet 1/1
Console(config-if)#power inline
Console(config-if)#exit
Console(config)#interface ethernet 1/2
Console(config-if)#no power inline
Console(config-if)#

```

**Related Commands**[time-range \(188\)](#)**power inline  
maximum allocation**

This command limits the power allocated to specific ports. Use the **no** form to restore the default setting.

**Syntax****power inline maximum allocation** *class***no power inline maximum allocation**

*class* - The maximum power classification for the port.  
(Options: 1, 2, 3, 4, 5, 6, 7, 8)

**Default Setting**

Ports 1-40: Class 4 (30000 milliwatts)

Ports 41-48: Class 8 (90000 milliwatts)

**Command Mode**

Interface Configuration (Ethernet RJ-45 ports)

**Command Usage**

- ◆ The following table define the maximum power of each PD class.

**Table 88: Maximum PoE Based on PD Classification**

PD Class	Maximum Power (Watts)
Class 1	4
Class 2	7

Table 88: Maximum PoE Based on PD Classification

PD Class	Maximum Power (Watts)
Class 3	15.4
Class 4	30
Class 5	45
Class 6	60
Class 7	75
Class 8	90

- ◆ The total PoE power delivered by all ports cannot exceed the switch's maximum power budget.
- ◆ If a device is connected to a switch port and the switch detects that it requires more than the maximum power allocated to the port, no power is supplied to the device (i.e., port power remains off).

### Example

```

Console(config)#interface ethernet 1/1
Console(config-if)#power inline maximum allocation 3
Changing maximum allocation may turn off port.Do you want to change? <y/n>y
Console(config-if)#

```

**power inline priority** This command sets the power priority for specific ports. Use the **no** form to restore the default setting.

### Syntax

**power inline priority** *priority*

**no power inline priority**

*priority* - The power priority for the port.  
Options: 1 (critical), 2 (high), or 3 (low)

### Default Setting

3 (low)

### Command Mode

Interface Configuration (Ethernet RJ-45 ports)

### Command Usage

- ◆ If the power demand from devices connected to all switch ports exceeds the power budget set for the switch, the port power priority settings are used to control the supplied power.

- If a device connected to a low-priority port causes the switch to exceed its budget, power will be dropped from low-priority ports starting in reverse sequence from the highest RJ-45 port number.

For example, with all ports low priority and ports 2-13 on, when you connect port 1, power to port 13 will turn off and power to port 1 will turn on.

- If a device is connected to a critical or high-priority port that would cause the switch to exceed its power budget as determined during bootup, power is provided to the port only if the switch can drop power to one or more lower-priority ports and thereby remain within its overall budget. Power will be dropped from lower-priority ports starting in reverse sequence from the highest RJ-45 port number..

For example, if ports 2 to 14 request 30W and ports 2-12 are low priority with ports 13-14 high priority, port 12 will turn off and ports 2-11 and 13-14 will turn on.

- If priority is not set for any ports, and PoE consumption exceeds the maximum power provided by the switch, power is shut down starting in reverse sequence from the highest RJ-45 port number.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#power inline priority 2
Console(config-if)#
```

**show power inline status** This command displays the current power status for all ports or for specific ports.

### Syntax

**show power inline status** [*interface*]

*interface*

**ethernet**

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-48)

### Command Mode

Privileged Exec

### Example

```
Console#show power inline status
Unit: 1
Compatible Mode : Enabled
Interface Admin      Time      Max      Used
----- Admin      Range    Oper    Power    Power    Priority
-----
```

```

Eth 1/ 1 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 2 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 3 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 4 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 5 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 6 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 7 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 8 Enabled -- Off 30000 mW 0 mW Low
Eth 1/ 9 Enabled -- Off 30000 mW 0 mW Low
Eth 1/10 Enabled -- Off 30000 mW 0 mW Low
Eth 1/11 Enabled -- Off 30000 mW 0 mW Low
Eth 1/12 Enabled -- Off 30000 mW 0 mW Low
:

```

Table 89: show power inline status - display description

Field	Description
Admin	The power mode set on the port (see <a href="#">power inline</a> )
Time Range	Time during which power is supplied
Oper	The current operating power status (displays on, off, or Ovld) Note that if a port status is Ovld, you have to first turn off port power ( <b>no power inline</b> ) and then turn it back on ( <b>power inline</b> ) to provide power on the port.
Max Power	The maximum power allocated to this port (see <a href="#">power inline maximum allocation</a> )
Used Power	The current power consumption on the port in milliwatts
Priority	The port's power priority setting (see <a href="#">power inline priority</a> )

**show power inline time-range** This command displays the time-range and current status for specific ports or for all ports.

### Syntax

**show power inline time-range** [*interface*]

*interface*

**ethernet**

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-48)

### Command Mode

Privileged Exec

### Example

```

Console#show power inline time-range ethernet 1/5
Interface Time Range Name Status
-----
Eth 1/ 5 r&d Inactive
Console#

```

**Related Commands**[power inline \(475\)](#)

**show power mainpower** Use this command to display the current power status for the switch.

**Command Mode**

Privileged Exec

**Example**

This example shows the maximum available PoE power and maximum allocated PoE power.

```

Console#show power mainpower
Unit 1 PoE Status
  PoE Maximum Available Power : 740.0 Watts (using main power)
  PoE Maximum Allocation Power : 740.0 Watts
  System Operation Status      : Off
  PoE Power Consumption         : 0.0 Watts
  Software Version              : Version 0007 (Hex)
Console#

```

**Table 90: show power mainpower - display description**

Field	Description
PoE Maximum Available Power	The available power budget for the switch
PoE Maximum Allocation Power	The overall maximum power which is allocated to switch ports.
System Operation Status	The current operating power status (displays on or off)
PoE Power Consumption	The current power consumption on the switch in watts
Software Version	The version of software running on the PoE controller subsystem in the switch.

# Port Mirroring Commands

Data can be mirrored from a local port on the same switch or from a remote port on another switch for analysis at the target port using software monitoring tools or a hardware probe. This switch supports the following mirroring modes.

**Table 91: Port Mirroring Commands**

Command	Function
Local Port Mirroring	Mirrors data to another port for analysis without affecting the data passing through or the performance of the monitored port
RSPAN Mirroring	Mirrors data from remote switches over a dedicated VLAN

## Local Port Mirroring Commands

This section describes how to mirror traffic from a source port to a target port.

**Table 92: Mirror Port Commands**

Command	Function	Mode
<code>port monitor</code>	Configures a mirror session	IC
<code>show port monitor</code>	Shows the configuration for a mirror port	PE

**port monitor** This command configures a mirror session. Use the **no** form to clear a mirror session.

### Syntax

```
port monitor {interface [rx | tx | both] | vlan vlan-id |
mac-address mac-address | access-list acl-name}
```

```
no port monitor {interface | vlan vlan-id |
mac-address mac-address | access-list acl-name}
```

*interface*

**ethernet** *unit/port* (source port)

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**rx** - Mirror received packets.

**tx** - Mirror transmitted packets.

**both** - Mirror both received and transmitted packets.

*vlan-id* - VLAN ID (Range: 1-4094)

*mac-address* - MAC address in the form of xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx.

*acl-name* - Name of the ACL. (Maximum length: 32 characters, no spaces or other special characters)

### Default Setting

- ◆ No mirror session is defined.
- ◆ When enabled for an interface, default mirroring is for both received and transmitted packets.
- ◆ When enabled for a VLAN or a MAC address, mirroring is restricted to received packets.

### Command Mode

Interface Configuration (Ethernet, destination port)

### Command Usage

- ◆ You can mirror traffic from any source port to a destination port for real-time analysis. You can then attach a logic analyzer or RMON probe to the destination port and study the traffic crossing the source port in a completely unobtrusive manner.
- ◆ Set the destination port by specifying an Ethernet interface with the [interface](#) configuration command, and then use the [port monitor](#) command to specify the source of the traffic to mirror. Note that the destination port cannot be a trunk or trunk member port.
- ◆ When mirroring traffic from a port, the mirror port and monitor port speeds should match, otherwise traffic may be dropped from the monitor port. When mirroring traffic from a VLAN, traffic may also be dropped under heavy loads.
- ◆ When VLAN mirroring and port mirroring are both enabled, the target port can receive a mirrored packet twice; once from the source mirror port and again from the source mirror VLAN.
- ◆ When mirroring traffic from a MAC address, ingress traffic with the specified source address entering any port in the switch, other than the target port, will be mirrored to the destination port.
- ◆ Spanning Tree BPDU packets are not mirrored to the target port.
- ◆ When mirroring VLAN traffic or packets based on a source MAC address, the target port cannot be set to the same target port as that used for basic port mirroring.

- ◆ You can create multiple mirror sessions, but all sessions must share the same destination port.
- ◆ The destination port cannot be a trunk or trunk member port.
- ◆ ACL-based mirroring is only used for ingress traffic. To mirror an ACL, follow these steps:
  1. Use the **access-list** command to add an ACL.
  2. Use the **access-group** command to add a mirrored port to access control list.
  3. Use the **port monitor access-list** command to specify the destination port to which traffic matching the ACL will be mirrored.

### Example

The following example configures the switch to mirror all packets from port 6 to 5:

```
Console(config)#interface ethernet 1/5
Console(config-if)#port monitor ethernet 1/6 both
Console(config-if)#
```

This example configures port 2 to monitor packets matching the MAC address 00-12-CF-XX-XX-XX received by port 1:

```
Console(config)#access-list mac m1
Console(config-mac-acl)#permit 00-12-cf-00-00-00 ff-ff-ff-00-00-00 any
Console(config-mac-acl)#exit
Console(config)#interface ethernet 1/1
Console(config-if)#mac access-group m1 in
Console(config-if)#interface ethernet 1/2
Console(config-if)#port monitor access-list m1
Console(config-if)#
```

**show port monitor** This command displays mirror information.

### Syntax

**show port monitor** [*interface*]

*interface* - **ethernet** *unit/port* (source port)

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

*vlan-id* - VLAN ID (Range: 1-4094)

*mac-address* - MAC address in the form of xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx.

*acl-name* – Name of the ACL. (Maximum length: 32 characters, no spaces or other special characters)

### Default Setting

Shows all sessions.

### Command Mode

Privileged Exec

### Command Usage

This command displays the currently configured source port, destination port, and mirror mode (i.e., RX, TX, RX/TX).

### Example

The following shows mirroring configured from port 6 to port 5:

```
Console(config)#interface ethernet 1/5
Console(config-if)#port monitor ethernet 1/6
Console(config-if)#end
Console#show port monitor
Port Mirroring
-----
Destination Port (listen port) : Eth 1/ 5
Source Port (monitored Port)  : Eth 1/ 6
Mode                          : RX/TX
Console#
```

## RSPAN Mirroring Commands

Remote Switched Port Analyzer (RSPAN) allows you to mirror traffic from remote switches for analysis on a local destination port.

**Table 93: RSPAN Commands**

Command	Function	Mode
<code>vlan rspan</code>	Creates a VLAN dedicated to carrying RSPAN traffic	VC
<code>rspan source</code>	Specifies the source port and traffic type to be mirrored	GC
<code>rspan destination</code>	Specifies the destination port to monitor the mirrored traffic	GC
<code>rspan remote vlan</code>	Specifies the RSPAN VLAN, switch role (source, intermediate or destination), and the uplink ports	GC
<code>no rspan session</code>	Deletes a configured RSPAN session	GC
<code>show rspan</code>	Displays the configuration settings for an RSPAN session	PE

### Configuration Guidelines

Take the following steps to configure an RSPAN session:

1. Use the `vlan rspan` command to configure a VLAN to use for RSPAN. (Default VLAN 1 and switch cluster VLAN 4093 are prohibited.)
2. Use the `rspan source` command to specify the interfaces and the traffic type (RX, TX or both) to be monitored.
3. Use the `rspan destination` command to specify the destination port for the traffic mirrored by an RSPAN session.
4. Use the `rspan remote vlan` command to specify the VLAN to be used for an RSPAN session, to specify the switch's role as a source, intermediate relay, or destination of the mirrored traffic, and to configure the uplink ports designated to carry this traffic.

### RSPAN Limitations

The following limitations apply to the use of RSPAN on this switch:

- ◆ *RSPAN Ports* – Only ports can be configured as an RSPAN source, destination, or uplink; static and dynamic trunks are not allowed. A port can only be configured as one type of RSPAN interface – source, destination, or uplink. Also, note that the source port and destination port cannot be configured on the same switch.

Only 802.1Q trunk or hybrid (i.e., general use) ports can be configured as an RSPAN uplink or destination port – access ports are not allowed (see [switchport mode](#)).

- ◆ *Local/Remote Mirror* – The destination of a local mirror session (created with the `port monitor` command) cannot be used as the destination for RSPAN traffic.
- ◆ *Spanning Tree* – If the spanning tree is disabled, BPDUs will not be flooded onto the RSPAN VLAN.

MAC address learning is not supported on RSPAN uplink ports when RSPAN is enabled on the switch. Therefore, even if spanning tree is enabled after RSPAN has been configured, MAC address learning will still not be re-started on the RSPAN uplink ports.

- ◆ *IEEE 802.1X* – RSPAN and 802.1X are mutually exclusive functions. When 802.1X is enabled globally, RSPAN uplink ports cannot be configured, even though RSPAN source and destination ports can still be configured. When RSPAN uplink ports are enabled on the switch, 802.1X cannot be enabled globally.

RSPAN uplink ports cannot be configured to use IEEE 802.1X Port Authentication, but RSPAN source ports and destination ports can be configured to use it

- ◆ *Port Security* – If port security is enabled on any port, that port cannot be set as an RSPAN uplink port, even though it can still be configured as an RSPAN source or destination port. Also, when a port is configured as an RSPAN uplink port, port security cannot be enabled on that port.

**rspan source** Use this command to specify the source port and traffic type to be mirrored remotely. Use the **no** form to disable RSPAN on the specified port, or with a traffic type keyword to disable mirroring for the specified type.

### Syntax

**[no] rspan session *session-id* source interface *interface-list* [rx | tx | both]**

*session-id* – A number identifying this RSPAN session. (Range: 1)

Three sessions are allowed, including both local and remote mirroring, using different VLANs for RSPAN sessions.

*interface-list* – One or more source ports. Use a hyphen to indicate a consecutive list of ports or a comma between non-consecutive ports.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**rx** - Mirror received packets.

**tx** - Mirror transmitted packets.

**both** - Mirror both received and transmitted packets.

### Default Setting

Both TX and RX traffic is mirrored

### Command Mode

Global Configuration

### Command Usage

- ◆ One or more source ports can be assigned to the same RSPAN session, either on the same switch or on different switches.
- ◆ Only ports can be configured as an RSPAN source – static and dynamic trunks are not allowed.
- ◆ Only 802.1Q trunk or hybrid (i.e., general use) ports can be configured as an RSPAN source port – access ports are not allowed (see [switchport mode](#)).
- ◆ The source port and destination port cannot be configured on the same switch.

### Example

The following example configures the switch to mirror received packets from port 2 and 3:

```
Console(config)#rspan session 1 source interface ethernet 1/2
Console(config)#rspan session 1 source interface ethernet 1/3
Console(config)#
```

**rspan destination** Use this command to specify the destination port to monitor the mirrored traffic. Use the **no** form to disable RSPAN on the specified port.

### Syntax

**rspan session** *session-id* **destination interface** *interface* [**tagged** | **untagged**]

**no rspan session** *session-id* **destination interface** *interface*

*session-id* – A number identifying this RSPAN session. (Range: 1)

Three sessions are allowed, including both local and remote mirroring, using different VLANs for RSPAN sessions.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**tagged** - Traffic exiting the destination port carries the RSPAN VLAN tag.

**untagged** - Traffic exiting the destination port is untagged.

### Default Setting

Traffic exiting the destination port is untagged.

### Command Mode

Global Configuration

### Command Usage

- ◆ Only one destination port can be configured on the same switch per session, but a destination port can be configured on more than one switch for the same session.
- ◆ Only 802.1Q trunk or hybrid (i.e., general use) ports can be configured as an RSPAN destination port – access ports are not allowed (see [switchport mode](#)).
- ◆ Only ports can be configured as an RSPAN destination – static and dynamic trunks are not allowed.
- ◆ The source port and destination port cannot be configured on the same switch.

- ◆ A destination port can still send and receive switched traffic, and participate in any Layer 2 protocols to which it has been assigned.

### Example

The following example configures port 4 to receive mirrored RSPAN traffic:

```
Console(config)#rspan session 1 destination interface ethernet 1/2
Console(config)#
```

**rspan remote vlan** Use this command to specify the RSPAN VLAN, switch role (source, intermediate or destination), and the uplink ports. Use the **no** form to disable the RSPAN on the specified VLAN.

### Syntax

```
[no] rspan session session-id remote vlan vlan-id
{source | intermediate | destination} uplink interface
```

*session-id* – A number identifying this RSPAN session. (Range: 1)

Three sessions are allowed, including both local and remote mirroring, using different VLANs for RSPAN sessions.

*vlan-id* - ID of configured RSPAN VLAN. (Range: 1-4094)

Use the [vlan rspan](#) command to reserve a VLAN for RSPAN mirroring before enabling RSPAN with this command.

**source** - Specifies this device as the source of remotely mirrored traffic.

**intermediate** - Specifies this device as an intermediate switch, transparently passing mirrored traffic from one or more sources to one or more destinations.

**destination** - Specifies this device as a switch configured with a destination port which is to receive mirrored traffic for this session.

**uplink** - A port configured to receive or transmit remotely mirrored traffic.

*interface*

```
ethernet unit/port
```

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Only 802.1Q trunk or hybrid (i.e., general use) ports can be configured as an RSPAN uplink port – access ports are not allowed (see [switchport mode](#)).
- ◆ Only one uplink port can be configured on a source switch, but there is no limitation on the number of uplink ports configured on an intermediate or destination switch.
- ◆ Only destination and uplink ports will be assigned by the switch as members of this VLAN. Ports cannot be manually assigned to an RSPAN VLAN with the [switchport allowed vlan](#) command. Nor can GVRP dynamically add port members to an RSPAN VLAN. Also, note that the [show vlan](#) command will not display any members for an RSPAN VLAN, but will only show configured RSPAN VLAN identifiers.

### Example

The following example enables RSPAN on VLAN 2, specifies this device as an RSPAN destination switch, and the uplink interface as port 3:

```
Console(config)#rspan session 1 remote vlan 2 destination uplink ethernet 1/3  
Console(config)#
```

**no rspan session** Use this command to delete a configured RSPAN session.

### Syntax

**no rspan session** *session-id*

*session-id* – A number identifying this RSPAN session. (Range: 1)

Three sessions are allowed, including both local and remote mirroring, using different VLANs for RSPAN sessions.

### Command Mode

Global Configuration

### Command Usage

The **no rspan session** command must be used to disable an RSPAN VLAN before it can be deleted from the VLAN database (see the [vlan](#) command).

### Example

```
Console(config)#no rspan session 1  
Console(config)#
```

**show rspan** Use this command to displays the configuration settings for an RSPAN session.

### Syntax

**show rspan session** [*session-id*]

*session-id* – A number identifying this RSPAN session. (Range: 1)

Three sessions are allowed, including both local and remote mirroring, using different VLANs for RSPAN sessions.

### Command Mode

Privileged Exec

### Example

```
Console#show rspan session
RSPAN Session ID           : 1
Source Ports (mirrored ports) : None
  RX Only                   : None
  TX Only                   : None
  BOTH                      : None
Destination Port (monitor port) : Eth 1/2
Destination Tagged Mode      : Untagged
Switch Role                  : Destination
RSPAN VLAN                   : 2
RSPAN Uplink Ports           : Eth 1/3
Operation Status             : Up
Console#
```

# Congestion Control Commands

The switch can set the maximum upload or download data transfer rate for any port. It can control traffic storms by setting a maximum threshold for broadcast traffic or multicast traffic. It can also set bounding thresholds for broadcast and multicast storms which can be used to automatically trigger rate limits or to shut down a port.

**Table 94: Congestion Control Commands**

Command Group	Function
Rate Limiting	Sets the input and output rate limits for a port.
Storm Control	Sets the traffic storm threshold for each port.
Automatic Traffic Control Commands	Sets thresholds for broadcast and multicast storms which can be used to trigger configured rate limits or to shut down a port.

## Rate Limit Commands

Rate limit commands allow the network manager to control the maximum rate for traffic transmitted or received on an interface. Rate limiting is configured on interfaces at the edge of a network to limit traffic into or out of the network. Packets that exceed the acceptable amount of traffic are dropped.

Rate limiting can be applied to individual ports or trunks. When an interface is configured with this feature, the traffic rate will be monitored by the hardware to verify conformity. Non-conforming traffic is dropped.

**Table 95: Rate Limit Commands**

Command	Function	Mode
rate-limit	Configures the maximum input or output rate for an interface	IC

**rate-limit** This command defines the rate limit for a specific interface. Use this command without specifying a rate to enable rate limiting. Use the **no** form to disable rate limiting.

### Syntax

**rate-limit** {input | output} [*rate*]

**no rate-limit** {input | output}

**input** – Input rate for specified interface

**output** – Output rate for specified interface

*rate* – Maximum value in kbps.

(Range: 64 - 100,000 kbits per second for 10/100 Mbps ports.

64 - 1,000,000 kbits per second for Gigabit Ethernet ports;

64 - 10,000,000 kbits per second for 10 Gigabit Ethernet ports)

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

Using both rate limiting and storm control on the same interface may lead to unexpected results. It is therefore not advisable to use both of these commands on the same interface.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#rate-limit input 64
Console(config-if)#
```

### Related Command

[show interfaces switchport \(440\)](#)

## Storm Control Commands

Storm control commands can be used to configure broadcast, multicast, and unknown unicast storm control thresholds. Traffic storms may occur when a device on your network is malfunctioning, or if application programs are not well designed or properly configured. If there is too much traffic on your network, performance can be severely degraded or everything can come to complete halt.

You can protect your network from traffic storms by setting a threshold for broadcast, multicast or unknown unicast traffic. Any packets exceeding the specified threshold will then be dropped.

**Table 96: Rate Limit Commands**

Command	Function	Mode
<code>switchport packet-rate</code>	Configures broadcast, multicast, and unknown unicast storm control thresholds	IC
<code>show interfaces switchport</code>	Displays the administrative and operational status of an interface	NE, PE

**switchport packet-rate** This command configures broadcast, multicast and unknown unicast storm control. Use the **no** form to restore the default setting.

### Syntax

**switchport {broadcast | multicast | unknown-unicast} packet-rate rate**

**no switchport {broadcast | multicast | unknown-unicast}**

**broadcast** - Specifies storm control for broadcast traffic.

**multicast** - Specifies storm control for multicast traffic.

**unknown-unicast** - Specifies storm control for unknown unicast traffic.

*rate* - Threshold level as a rate; i.e. (Range: 500–14881000 pps.

500-148500 pps for 10/100 Mbps ports;

500-1488000 pps for 1 Gbps ports:

1000-14881000 pps for 10 Gbps ports)

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ When traffic exceeds the threshold specified for broadcast and multicast or unknown unicast traffic, packets exceeding the threshold are dropped until the rate falls back down beneath the threshold.

- ◆ Using both rate limiting and storm control on the same interface may lead to unexpected results. It is therefore not advisable to use both of these commands on the same interface.

### Example

The following shows how to configure broadcast storm control at 600 packets per second:

```
Console(config)#interface ethernet 1/5
Console(config-if)#switchport broadcast packet-rate 600
Console(config-if)#
```

### Related Commands

[show interfaces switchport \(440\)](#)

---

## Automatic Traffic Control Commands

Automatic Traffic Control (ATC) configures bounding thresholds for broadcast and multicast storms which can be used to trigger configured rate limits or to shut down a port.

Table 97: ATC Commands

Command	Function	Mode
<i>Threshold Commands</i>		
<a href="#">auto-traffic-control apply-timer</a>	Sets the time at which to apply the control response after ingress traffic has exceeded the upper threshold	GC
<a href="#">auto-traffic-control release-timer</a>	Sets the time at which to release the control response after ingress traffic has fallen beneath the lower threshold	GC
<a href="#">auto-traffic-control*</a>	Enables automatic traffic control for broadcast or multicast storms	IC (Port)
<a href="#">auto-traffic-control action</a>	Sets the control action to limit ingress traffic or shut down the offending port	IC (Port)
<a href="#">auto-traffic-control alarm-clear-threshold</a>	Sets the lower threshold for ingress traffic beneath which a cleared storm control trap is sent	IC (Port)
<a href="#">auto-traffic-control alarm-fire-threshold</a>	Sets the upper threshold for ingress traffic beyond which a storm control response is triggered after the apply timer expires	IC (Port)
<a href="#">auto-traffic-control auto-control-release</a>	Automatically releases a control response	IC (Port)
<a href="#">auto-traffic-control control-release</a>	Manually releases a control response	PE

**Table 97: ATC Commands (Continued)**


Command	Function	Mode
<i>ATC Trap Commands</i>		
<code>snmp-server enable port-traps atc broadcast- alarm-clear</code>	Sends a trap when broadcast traffic falls beneath the lower threshold after a storm control response has been triggered	IC (Port)
<code>snmp-server enable port-traps atc broadcast- alarm-fire</code>	Sends a trap when broadcast traffic exceeds the upper threshold for automatic storm control	IC (Port)
<code>snmp-server enable port-traps atc broadcast- control-apply</code>	Sends a trap when broadcast traffic exceeds the upper threshold for automatic storm control and the apply timer expires	IC (Port)
<code>snmp-server enable port-traps atc broadcast- control-release</code>	Sends a trap when broadcast traffic falls beneath the lower threshold after a storm control response has been triggered and the release timer expires	IC (Port)
<code>snmp-server enable port-traps atc multicast- alarm-clear</code>	Sends a trap when multicast traffic falls beneath the lower threshold after a storm control response has been triggered	IC (Port)
<code>snmp-server enable port-traps atc multicast- alarm-fire</code>	Sends a trap when multicast traffic exceeds the upper threshold for automatic storm control	IC (Port)
<code>snmp-server enable port-traps atc multicast- control-apply</code>	Sends a trap when multicast traffic exceeds the upper threshold for automatic storm control and the apply timer expires	IC (Port)
<code>snmp-server enable port-traps atc multicast- control-release</code>	Sends a trap when multicast traffic falls beneath the lower threshold after a storm control response has been triggered and the release timer expires	IC (Port)
<i>ATC Display Commands</i>		
<code>show auto-traffic-control</code>	Shows global configuration settings for automatic storm control	PE
<code>show auto-traffic-control interface</code>	Shows interface configuration settings and storm control status for the specified port	PE

\* Enabling automatic storm control on a port will disable hardware-level storm control on the same port if configured by the `switchport packet-rate` command.

### Usage Guidelines

ATC includes storm control for broadcast or multicast traffic. The control response for either of these traffic types is the same, as shown in the following diagrams.


Figure 3: Storm Control by Limiting the Traffic Rate



The key elements of this diagram are described below:

- ◆ Alarm Fire Threshold – The highest acceptable traffic rate. When ingress traffic exceeds the threshold, ATC sends a Storm Alarm Fire Trap and logs it.
- ◆ When traffic exceeds the alarm fire threshold and the apply timer expires, a traffic control response is applied, and a Traffic Control Apply Trap is sent and logged.
- ◆ Alarm Clear Threshold – The lower threshold beneath which a control response can be automatically terminated after the release timer expires. When ingress traffic falls below this threshold, ATC sends a Storm Alarm Clear Trap and logs it.
- ◆ When traffic falls below the alarm clear threshold after the release timer expires, traffic control (for rate limiting) will be stopped and a Traffic Control Release Trap sent and logged. Note that if the control action has shut down a port, it can only be manually re-enabled using the [auto-traffic-control control-release](#) command).
- ◆ The traffic control response of rate limiting can be released automatically or manually. The control response of shutting down a port can only be released manually.

Figure 4: Storm Control by Shutting Down a Port



The key elements of this diagram are the same as that described in the preceding diagram, except that automatic release of the control response is not provided. When traffic control is applied, you must manually re-enable the port.

### Functional Limitations

Automatic storm control is a software level control function. Traffic storms can also be controlled at the hardware level using the `switchport packet-rate` command. However, only one of these control types can be applied to a port. Enabling automatic storm control on a port will disable hardware-level storm control on that port.

## Threshold Commands

**auto-traffic-control apply-timer** This command sets the time at which to apply the control response after ingress traffic has exceeded the upper threshold. Use the **no** form to restore the default setting.

### Syntax

**auto-traffic-control** {**broadcast** | **multicast**} **apply-timer** *seconds*

**no auto-traffic-control** {**broadcast** | **multicast**} **apply-timer**

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

*seconds* - The interval after the upper threshold has been exceeded at which to apply the control response. (Range: 5-300 seconds)

### Default Setting

300 seconds

### Command Mode

Global Configuration

### Command Usage

After the apply timer expires, a control action may be triggered as specified by the [auto-traffic-control action](#) command and a trap message sent as specified by the [snmp-server enable port-traps atc broadcast-control-apply](#) command or [snmp-server enable port-traps atc multicast-control-apply](#) command.

### Example

This example sets the apply timer to 200 seconds for all ports.

```
Console(config)#auto-traffic-control broadcast apply-timer 200
Console(config)#
```

### auto-traffic-control release-timer

This command sets the time at which to release the control response after ingress traffic has fallen beneath the lower threshold. Use the **no** form to restore the default setting.

### Syntax

**auto-traffic-control** {**broadcast** | **multicast**} **release-timer** *seconds*

**no auto-traffic-control** {**broadcast** | **multicast**} **release-timer**

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

*seconds* - The time at which to release the control response after ingress traffic has fallen beneath the lower threshold. (Range: 5-900 seconds)

### Default Setting

900 seconds

### Command Mode

Global Configuration

### Command Usage

This command sets the delay after which the control response can be terminated. The [auto-traffic-control auto-control-release](#) command must be used to enable or disable the automatic release of a control response of rate-limiting. To re-enable a port which has been shut down by automatic traffic control, you must manually re-enable the port using the [auto-traffic-control control-release](#) command.

### Example

This example sets the release timer to 800 seconds for all ports.

```
Console(config)#auto-traffic-control broadcast release-timer 800
Console(config)#
```

**auto-traffic-control** This command enables automatic traffic control for broadcast or multicast storms. Use the **no** form to disable this feature.

### Syntax

**[no] auto-traffic-control {broadcast | multicast}**

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Automatic storm control can be enabled for either broadcast or multicast traffic. It cannot be enabled for both of these traffic types at the same time.
- ◆ Automatic storm control is a software level control function. Traffic storms can also be controlled at the hardware level using the [switchport packet-rate](#) command. However, only one of these control types can be applied to a port. Enabling automatic storm control on a port will disable hardware-level storm control on that port.

### Example

This example enables automatic storm control for broadcast traffic on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#auto-traffic-control broadcast
Console(config-if)#
```

**auto-traffic-control action** This command sets the control action to limit ingress traffic or shut down the offending port. Use the **no** form to restore the default setting.

### Syntax

**auto-traffic-control {broadcast | multicast} action {rate-control | shutdown}**

**no auto-traffic-control {broadcast | multicast} action**

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

**rate-control** - If a control response is triggered, the rate of ingress traffic is limited based on the threshold configured by the [auto-traffic-control alarm-clear-threshold](#) command.

**shutdown** - If a control response is triggered, the port is administratively disabled. A port disabled by automatic traffic control can only be manually re-enabled.

### Default Setting

rate-control

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ When the upper threshold is exceeded and the apply timer expires, a control response will be triggered based on this command.
- ◆ When the control response is set to rate limiting by this command, the rate limits are determined by the [auto-traffic-control alarm-clear-threshold](#) command.
- ◆ If the control response is to limit the rate of ingress traffic, it can be automatically terminated once the traffic rate has fallen beneath the lower threshold and the release timer has expired.
- ◆ If a port has been shut down by a control response, it will not be re-enabled by automatic traffic control. It can only be manually re-enabled using the [auto-traffic-control control-release](#) command.

### Example

This example sets the control response for broadcast traffic on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#auto-traffic-control broadcast action shutdown
Console(config-if)#
```

### **auto-traffic-control alarm-clear-threshold**

This command sets the lower threshold for ingress traffic beneath which a control response for rate limiting will be released after the Release Timer expires, if so configured by the [auto-traffic-control auto-control-release](#) command. Use the **no** form to restore the default setting.

### Syntax

**auto-traffic-control** {**broadcast** | **multicast**} **alarm-clear-threshold** *threshold*

**no auto-traffic-control** {**broadcast** | **multicast**} **alarm-clear-threshold**

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

*threshold* - The lower threshold for ingress traffic beneath which a cleared storm control trap is sent. (Range: 1-255 kilo-packets per second)

### Default Setting

128 kilo-packets per second

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Once the traffic rate falls beneath the lower threshold, a trap message may be sent if configured by the `snmp-server enable port-traps atc broadcast-alarm-clear` command or `snmp-server enable port-traps atc multicast-alarm-clear` command.
- ◆ If rate limiting has been configured as a control response, it will be discontinued after the traffic rate has fallen beneath the lower threshold, and the release timer has expired. Note that if a port has been shut down by a control response, it will not be re-enabled by automatic traffic control. It can only be manually re-enabled using the `auto-traffic-control control-release` command.

### Example

This example sets the clear threshold for automatic storm control for broadcast traffic on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#auto-traffic-control broadcast alarm-clear-threshold 155
Console(config-if)#
```

### **auto-traffic-control alarm-fire-threshold**

This command sets the upper threshold for ingress traffic beyond which a storm control response is triggered after the apply timer expires. Use the **no** form to restore the default setting.

### Syntax

**auto-traffic-control** {**broadcast** | **multicast**} **alarm-fire-threshold** *threshold*

**no auto-traffic-control** {**broadcast** | **multicast**} **alarm-fire-threshold**

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

*threshold* - The upper threshold for ingress traffic beyond which a storm control response is triggered after the apply timer expires. (Range: 1-255 kilo-packets per second)

### Default Setting

128 kilo-packets per second

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Once the upper threshold is exceeded, a trap message may be sent if configured by the `snmp-server enable port-traps atc broadcast-alarm-fire` command or `snmp-server enable port-traps atc multicast-alarm-fire` command.
- ◆ After the upper threshold is exceeded, the control timer must first expire as configured by the `auto-traffic-control apply-timer` command before a control response is triggered if configured by the `auto-traffic-control action` command.

### Example

This example sets the trigger threshold for automatic storm control for broadcast traffic on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#auto-traffic-control broadcast alarm-fire-threshold 255
Console(config-if)#
```

**auto-traffic-control auto-control-release** This command automatically releases a control response of rate-limiting after the time specified in the `auto-traffic-control release-timer` command has expired.

### Syntax

**auto-traffic-control {broadcast | multicast} auto-control-release**

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ This command can be used to automatically stop a control response of rate-limiting after the specified action has been triggered and the release timer has expired.
- ◆ To release a control response which has shut down a port after the specified action has been triggered and the release timer has expired, use the `auto-traffic-control control-release` command.

### Example

```
Console(config-if)#auto-traffic-control broadcast auto-control-release
Console(config-if)#
```

**auto-traffic-control control-release** This command manually releases a control response.

#### Syntax

**auto-traffic-control {broadcast | multicast} control-release interface** *interface*

**broadcast** - Specifies automatic storm control for broadcast traffic.

**multicast** - Specifies automatic storm control for multicast traffic.

*interface*

**ethernet** *unit/port-list*

*unit* - Unit identifier. (Range: 1)

*port-list* - Physical port number or list of port numbers. Separate nonconsecutive port numbers with a comma and no spaces; or use a hyphen to designate a range of port numbers. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Command Usage

This command can be used to manually stop a control response of rate-limiting or port shutdown any time after the specified action has been triggered.

#### Example

```
Console#auto-traffic-control broadcast control-release interface ethernet 1/1  
Console#
```

## SNMP Trap Commands

**snmp-server enable port-traps atc broadcast-alarm-clear** This command sends a trap when broadcast traffic falls beneath the lower threshold after a storm control response has been triggered. Use the **no** form to disable this trap.

#### Syntax

**[no] snmp-server enable port-traps atc broadcast-alarm-clear**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc broadcast-alarm-clear
Console(config-if)#
```

### Related Commands

[auto-traffic-control action \(499\)](#)

[auto-traffic-control alarm-clear-threshold \(500\)](#)

### **snmp-server enable port-traps atc broadcast-alarm-fire**

This command sends a trap when broadcast traffic exceeds the upper threshold for automatic storm control. Use the **no** form to disable this trap.

#### Syntax

**[no] snmp-server enable port-traps atc broadcast-alarm-fire**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc broadcast-alarm-fire
Console(config-if)#
```

### Related Commands

[auto-traffic-control alarm-fire-threshold \(501\)](#)

### **snmp-server enable port-traps atc broadcast-control- apply**

This command sends a trap when broadcast traffic exceeds the upper threshold for automatic storm control and the apply timer expires. Use the **no** form to disable this trap.

#### Syntax

**[no] snmp-server enable port-traps atc broadcast-control-apply**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc broadcast-control-apply
Console(config-if)#
```

### Related Commands

[auto-traffic-control alarm-fire-threshold \(501\)](#)

[auto-traffic-control apply-timer \(497\)](#)

**snmp-server enable  
port-traps atc  
broadcast-control-  
release**

This command sends a trap when broadcast traffic falls beneath the lower threshold after a storm control response has been triggered and the release timer expires. Use the **no** form to disable this trap.

### Syntax

**[no] snmp-server enable port-traps atc  
broadcast-control-release**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc broadcast-control-
release
Console(config-if)#
```

### Related Commands

[auto-traffic-control alarm-clear-threshold \(500\)](#)

[auto-traffic-control action \(499\)](#)

[auto-traffic-control release-timer \(498\)](#)

**snmp-server enable  
port-traps atc  
multicast-alarm-clear**

This command sends a trap when multicast traffic falls beneath the lower threshold after a storm control response has been triggered. Use the **no** form to disable this trap.

### Syntax

**[no] snmp-server enable port-traps atc multicast-alarm-clear**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc multicast-alarm-clear
Console(config-if)#
```

### Related Commands

[auto-traffic-control action \(499\)](#)

[auto-traffic-control alarm-clear-threshold \(500\)](#)

### snmp-server enable port-traps atc multicast-alarm-fire

This command sends a trap when multicast traffic exceeds the upper threshold for automatic storm control. Use the **no** form to disable this trap.

### Syntax

**[no] snmp-server enable port-traps atc multicast-alarm-fire**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc multicast-alarm-fire
Console(config-if)#
```

### Related Commands

[auto-traffic-control alarm-fire-threshold \(501\)](#)

### snmp-server enable port-traps atc multicast-control- apply

This command sends a trap when multicast traffic exceeds the upper threshold for automatic storm control and the apply timer expires. Use the **no** form to disable this trap.

### Syntax

**[no] snmp-server enable port-traps atc multicast-control-apply**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc multicast-control-apply
Console(config-if)#
```

### Related Commands

[auto-traffic-control alarm-fire-threshold \(501\)](#)

[auto-traffic-control apply-timer \(497\)](#)

**snmp-server enable port-traps atc multicast-control-release** This command sends a trap when multicast traffic falls beneath the lower threshold after a storm control response has been triggered and the release timer expires. Use the **no** form to disable this trap.

### Syntax

```
[no] snmp-server enable port-traps atc
multicast-control-release
```

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#snmp-server enable port-traps atc multicast-control-
release
Console(config-if)#
```

### Related Commands

[auto-traffic-control alarm-clear-threshold \(500\)](#)

[auto-traffic-control action \(499\)](#)

[auto-traffic-control release-timer \(498\)](#)

## ATC Display Commands

**show auto-traffic-control** This command shows global configuration settings for automatic storm control.

### Command Mode

Privileged Exec

### Example

```
Console#show auto-traffic-control

Storm-control: Broadcast
```

```
Apply-timer (sec) : 300
release-timer (sec) : 900

Storm-control: Multicast
Apply-timer(sec) : 300
release-timer(sec) : 900
Console#
```

**show auto-traffic-control interface** This command shows interface configuration settings and storm control status for the specified port.

### Syntax

```
show auto-traffic-control interface [interface]
```

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Example

```
Console#show auto-traffic-control interface ethernet 1/1
Eth 1/1 Information
-----
Storm Control:          Broadcast          Multicast
State:                  Disabled          Disabled
Action:                 rate-control      rate-control
Auto Release Control:   Disabled          Disabled
Alarm Fire Threshold(Kpps): 128          128
Alarm Clear Threshold(Kpps):128          128
Trap Storm Fire:        Disabled          Disabled
Trap Storm Clear:       Disabled          Disabled
Trap Traffic Apply:     Disabled          Disabled
Trap Traffic Release:   Disabled          Disabled

Console#
```

# Loopback Detection Commands

The switch can be configured to detect general loopback conditions caused by hardware problems or faulty protocol settings. When enabled, a control frame is transmitted on the participating ports, and the switch monitors inbound traffic to see if the frame is looped back.

**Table 98: Loopback Detection Commands**

Command	Function	Mode
<code>loopback-detection</code>	Enables loopback detection globally on the switch or on a specified interface	GC, IC
<code>loopback-detection action</code>	Specifies the response to take for a detected loopback condition	GC
<code>loopback-detection recover-time</code>	Specifies the interval to wait before releasing an interface from shutdown state	GC
<code>loopback-detection transmit-interval</code>	Specifies the interval at which to transmit loopback detection control frames	GC
<code>loopback detection trap</code>	Configures the switch to send a trap when a loopback condition is detected or the switch recover from a loopback	GC
<code>loopback-detection release</code>	Manually releases all interfaces currently shut down by the loopback detection feature	PE
<code>show loopback-detection</code>	Shows loopback detection configuration settings for the switch or for a specified interface	PE

## Usage Guidelines

- ◆ The default settings for the control frame transmit interval and recover time may be adjusted to improve performance for your specific environment. The shutdown mode may also need to be changed once you determine what kind of packets are being looped back.
- ◆ When a loopback event is detected on an interface or when a interface is released from a shutdown state caused by a loopback event, a trap message is sent and the event recorded in the system log.
- ◆ Loopback detection must be enabled both globally and on an interface for loopback detection to take effect.

**loopback-detection** This command enables loopback detection globally on the switch or on a specified interface. Use the **no** form to disable loopback detection.

### Syntax

**[no] loopback-detection**

### Default Setting

Enabled

### Command Mode

Global Configuration

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Loopback detection must be enabled globally for the switch by this command and enabled for a specific interface for this function to take effect.
- ◆ Loopback detection cannot be enabled globally if ingress filtering of any port whose loopback detection is enabled cannot be enabled.
- ◆ Loopback detection cannot be enabled for a port if ingress filtering cannot be enabled.
- ◆ When loopback detection is enabled globally and for a port, the ingress filtering of the port is automatically enabled. The ingress filtering setting is restored after loopback detection is disabled globally or for the port.

### Example

This example enables general loopback detection on the switch, disables loopback detection provided for the spanning tree protocol on port 1, and then enables general loopback detection for that port.

```
Console(config)#loopback-detection
Console(config)#interface ethernet 1/1
Console(config-if)#loopback-detection
Console(config)#
```

**loopback-detection action** This command specifies the protective action the switch takes when a loopback condition is detected. Use the **no** form to restore the default setting.

### Syntax

**loopback-detection action {block | none | shutdown}**

**no loopback-detection action**

**block** - When a loopback is detected on a port which a member of a specific VLAN, packets belonging to that VLAN are dropped at the offending port.

**none** - No action is taken.

**shutdown** - Shuts down the interface.

### Default Setting

Shut down

### Command Mode

Global Configuration

### Command Usage

- ◆ When the response to a detected loopback condition is set to block user traffic, loopback detection control frames may untagged or tagged depending on the port's VLAN membership type.
- ◆ When the response to a detected loopback condition is set to block user traffic, ingress filtering for the port is enabled automatically if not already enabled by the `switchport ingress-filtering` command. The port's original setting for ingress filtering will be restored when loopback detection is disabled.
- ◆ Use the `loopback-detection recover-time` command to set the time to wait before re-enabling an interface shut down by the loopback detection process.
- ◆ When the loopback detection response is changed, any ports placed in shutdown state by the loopback detection process will be immediately restored to operation regardless of the remaining recover time.

### Example

This example sets the loopback detection mode to shut down user traffic.

```
Console(config)#loopback-detection action shutdown
Console(config)#
```

**loopback-detection recover-time** This command specifies the interval to wait before the switch automatically releases an interface from shutdown state. Use the **no** form to restore the default setting.

### Syntax

**loopback-detection recover-time** *seconds*

**no loopback-detection recover-time**

*seconds* - Recovery time from shutdown state. (Range: 60-1,000,000 seconds, or 0 to disable automatic recovery)

### Default Setting

60 seconds

**Command Mode**

Global Configuration

**Command Usage**

If the recovery time is set to zero, all ports placed in shutdown state can be restored to operation using the `loopback-detection release` command. To restore a specific port, use the `no shutdown` command.

**Example**

```
Console(config)#loopback-detection recover-time 120
Console(config-if)#
```

**loopback-detection transmit-interval** This command specifies the interval at which to transmit loopback detection control frames. Use the **no** form to restore the default setting.

**Syntax**

**loopback-detection transmit-interval** *seconds*

**no loopback-detection transmit-interval**

*seconds* - The transmission interval for loopback detection control frames.  
(Range: 1-32767 seconds)

**Default Setting**

10 seconds

**Command Mode**

Global Configuration

**Example**

```
Console(config)#loopback-detection transmit-interval 60
Console(config)#
```

**loopback detection trap** This command sends a trap when a loopback condition is detected, or when the switch recovers from a loopback condition. Use the **no** form to restore the default state.

**Syntax**

**loopback-detection trap** [**both** | **detect** | **none** | **recover**]

**no loopback-detection trap**

**both** - Sends an SNMP trap message when a loopback condition is detected, or when the switch recovers from a loopback condition.

**detect** - Sends an SNMP trap message when a loopback condition is detected.

**none** - Does not send an SNMP trap for loopback detection or recovery.

**recover** - Sends an SNMP trap message when the switch recovers from a loopback condition.

#### Default Setting

None

#### Command Mode

Global Configuration

#### Command Usage

Refer to the [loopback-detection recover-time](#) command for information on conditions which constitute loopback recovery.

#### Example

```
Console(config)#loopback-detection trap both
Console(config)#
```

**loopback-detection release** This command releases all interfaces currently shut down by the loopback detection feature.

#### Syntax

**loopback-detection release**

#### Command Mode

Privileged Exec

#### Example

```
Console#loopback-detection release
Console#
```

**show loopback-detection** This command shows loopback detection configuration settings for the switch or for a specified interface.

#### Syntax

**show loopback-detection** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel**

*channel no.* Port-channel interface number. (Range 1-28)

**Command Mode**

Privileged Exec

**Command Usage**

Although global action may be set to None, this command will still display the configured Detection Port Admin State and Information Oper State.

**Example**

```
Console#show loopback-detection
Loopback Detection Global Information
Global Status      : Enabled
Transmit Interval : 10
Recover Time      : 60
Action            : Shutdown
Trap              : None
Loopback Detection Port Information
Port      Admin State Oper State
-----  -
Eth 1/ 1  Enabled    Normal
Eth 1/ 2  Disabled   Normal
Eth 1/ 3  Disabled   Normal
:
Console#show loopback-detection ethernet 1/1
Loopback Detection Information of Eth 1/1
Admin State : Enabled
Oper State  : Normal
Looped VLAN : None
Console#
```

# UniDirectional Link Detection Commands

The switch can be configured to detect and disable unidirectional Ethernet fiber or copper links. When enabled, the protocol advertises a port's identity and learns about its neighbors on a specific LAN segment; and stores information about its neighbors in a cache. It can also send out a train of echo messages under circumstances that require fast notifications or re-synchronization of the cached information.

**Table 99: UniDirectional Link Detection Commands**

Command	Function	Mode
<code>udld detection-interval</code>	Sets the amount of time the switch remains in detection state after discovering a neighbor	GC
<code>udld message-interval</code>	Configures the message interval between UDLD probe messages	GC
<code>udld recovery</code>	Automatically recovers from UDLD disabled port state after a period specified by the <code>udld recovery-interval</code> command	GC
<code>udld recovery-interval</code>	Specifies the period after which to automatically recover from UDLD disabled port state	GC
<code>udld aggressive</code>	Sets UDLD to aggressive mode on an interface	IC
<code>udld port</code>	Enables UDLD on a port	IC
<code>show udld</code>	Shows UDLD configuration settings and operational status	PE

**udld detection-interval** This command sets the amount of time the switch remains in detection state after discovering a neighbor. Use the **no** form to restore the default setting.

## Syntax

**udld detection-interval** *detection-interval*

**no udld detection-interval**

*detection-interval* – The amount of time the switch remains in detection state after discovering a neighbor through UDLD. (Range: 5-255 seconds)

## Default Setting

5 seconds

## Command Mode

Global Configuration

### Command Usage

When a neighbor device is discovered by UDLD, the switch enters “detection state” and remains in this state for specified detection-interval. After the detection-interval expires, the switch tries to decide whether or the link is unidirectional based on the information collected during “detection state.”

### Example

```
Console(config)#udld detection-interval 10
Console(config)#
```

**udld message-interval** This command configures the message interval between UDLD probe messages for ports in the advertisement phase and determined to be bidirectional. Use the **no** form to restore the default setting.

### Syntax

**udld message-interval** *message-interval*

**no udld message-interval**

*message-interval* – The interval at which a port sends UDLD probe messages after linkup or detection phases. (Range: 7-90 seconds)

### Default Setting

15 seconds

### Command Mode

Global Configuration

### Command Usage

During the detection phase, messages are exchanged at the maximum rate of one per second. After that, if the protocol reaches a stable state and determines that the link is bidirectional, the message interval is increased to a configurable value based on a curve known as M1(t), a time-based function described in RFC 5171.

If the link is deemed anything other than bidirectional at the end of the detection phase, this curve becomes a flat line with a fixed value of Mfast (7 seconds).

If the link is instead deemed bidirectional, the curve will use Mfast for the first four subsequent message transmissions and then transition to an Mslow value for all other steady-state transmissions. Mslow is the value configured by this command.

### Example

This example sets the message interval to 10 seconds.

```
Console(config)#udld message-interval 10
Console(config)#
```

**udld recovery** This command configures the switch to automatically recover from UDLD disabled port state after a period specified by the **udld recovery-interval** command. Use the **no** form to disable this feature.

#### Syntax

**[no] udld recovery**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

When automatic recovery state is changed by this command, any ports shut down by UDLD will be reset.

#### Example

```
Console(config)#udld recovery
Console(config)#
```

**udld recovery-interval** This command specifies the period after which to automatically recover from UDLD disabled port state. Use the **no** form to restore the default setting.

**udld recovery-interval** *recovery-interval*

**no udld recovery-interval**

*recovery-interval* – The interval after which a port is reset after being placed in UDLD disabled state. (Range: 30-86400 seconds)

#### Default Setting

300 seconds

#### Command Mode

Global Configuration

#### Command Usage

- ◆ This command is only applicable when automatic recovery has been enabled with the **udld recovery** command.
- ◆ When the recovery interval is changed by this command, any ports shut down by UDLD will be reset.

### Example

```
Console(config)#udld recovery-interval 30
Console(config)#
```

**udld aggressive** This command sets UDLD to aggressive mode on an interface. Use the **no** form to restore the default setting.

### Syntax

**[no] udld aggressive**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet Port)

### Command Usage

UDLD can function in two modes: normal mode and aggressive mode.

- ◆ In normal mode, determination of link status at the end of the detection process is always based on information received in UDLD messages: whether that's information about the exchange of proper neighbor identification or the absence of such. Hence, albeit bound by a timer, normal mode determinations are always based on gleaned information, and as such are "event-based." If no such information can be obtained (e.g., because of a bidirectional loss of connectivity), UDLD follows a conservative approach to minimize false positives during the detection process and deems a port to be in "undetermined" state. In other words, normal mode will shut down a port only if it can explicitly determine that the associated link is faulty for an extended period of time.
- ◆ In aggressive mode, UDLD will also shut down a port if it loses bidirectional connectivity with the neighbor for the same extended period of time (as that mentioned above for normal mode) and subsequently fails repeated last-resort attempts to re-establish communication with the other end of the link. This mode of operation assumes that loss of communication with the neighbor is a meaningful network event in itself, and a symptom of a serious connectivity problem. Because this type of detection can be event-less, and lack of information cannot always be associated to an actual malfunction of the link, this mode is recommended only in certain scenarios (typically only on point-to-point links where no communication failure between two neighbors is admissible).

### Example

This example enables UDLD aggressive mode on port 1.

```

Console(config)#interface ethernet 1/1
Console(config-if)#udld aggressive
Console(config-if)#

```

**udld port** This command enables UDLD on a port. Use the **no** form to disable UDLD on an interface.

### Syntax

**[no] udld port**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet Port)

### Command Usage

- ◆ UDLD requires that all the devices connected to the same LAN segment be running the protocol in order for a potential mis-configuration to be detected and for prompt corrective action to be taken.
- ◆ Whenever a UDLD device learns about a new neighbor or receives a resynchronization request from an out-of-synch neighbor, it (re)starts the detection process on its side of the connection and sends N echo messages in reply. (This mechanism implicitly assumes that N packets are sufficient to get through a link and reach the other end, even though some of them might get dropped during the transmission.)

Since this behavior must be the same on all the neighbors, the sender of the echoes expects to receive an echo in reply. If the detection process ends without the proper echo information being received, the link is considered to be unidirectional.

### Example

```

Console(config)#interface ethernet 1/1
Console(config-if)#udld port
Console(config-if)#

```

**show uddl** This command shows UDLD configuration settings and operational status for the switch or for a specified interface.

### Syntax

**show uddl** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Example

```

Console#show uddl
Message Interval : 15
Detection Interval : 5 seconds
Recovery : Disabled
Recovery Interval : 300 seconds

Interface UDLD      Mode      Oper State      Msg Invl
                  Port State
-----
Eth 1/ 1  Disabled Normal      Disabled
                                           7 s
                                           Unknown
                                           5 s
Eth 1/ 2  Disabled Normal      Disabled
                                           7 s
                                           Unknown
                                           5 s
Eth 1/ 3  Disabled Normal      Disabled
                                           7 s
                                           Unknown
                                           5 s
Eth 1/ 4  Disabled Normal      Disabled
                                           7 s
                                           Unknown
                                           5 s
Eth 1/ 5  Disabled Normal      Disabled
                                           7 s
                                           Unknown
                                           5 s
:
Console#show uddl interface ethernet 1/1
Interface UDLD      Mode      Oper State      Msg Invl
                  Port State
-----
Eth 1/ 1  Disabled Normal      Disabled
                                           7 s
                                           Unknown
                                           5 s

Console#

```

**Table 100: show uddl - display description**

Field	Description
Interface	The Interface - Ethernet unit and port number.
Message Interval	The interval between UDLD probe messages for ports in advertisement phase
Detection Interval	The period the switch remains in detection state after discovering a neighbor
Recovery	Shows if automatic recovery from UDLD disabled port state is enabled

**Table 100: show uddl - display description** (Continued)

Field	Description
Recovery Interval	Shows the period after which to recover from UDLD disabled port state if automatic recovery is enabled
UDLD	Shows if UDLD is enabled or disabled on a port
Mode	Shows if UDLD is functioning in Normal or Aggressive mode
Oper State	Shows the UDLD operational state (Disabled, Link down, Link up, Advertisement, Detection, Disabled port, Advertisement - Single neighbor, Advertisement - Multiple neighbors)
Port State	Shows the UDLD port state (Unknown, Bidirectional, Unidirectional, Transmit-to-receive loop, Mismatch with neighbor state reported, Neighbor's echo is empty) The state is Unknown if the link is down or not connected to a UDLD-capable device. The state is Bidirectional if the link has a normal two-way connection to a UDLD-capable device. All other states indicate mis-wiring.
Msg Invl	The interval between UDLD probe messages used for the indicated operational state
Det Invl	The period the switch remains in detection state after discovering a neighbor



# Address Table Commands

These commands are used to configure the address table for filtering specified addresses, displaying current entries, clearing the table, or setting the aging time.

**Table 101: Address Table Commands**

Command	Function	Mode
<code>mac-address-table aging-time</code>	Sets the aging time of the address table	GC
<code>mac-address-table static</code>	Maps a static address to a port in a VLAN	GC
<code>clear mac-address-table dynamic</code>	Removes any learned entries from the forwarding database	PE
<code>show mac-address-table</code>	Displays entries in the bridge-forwarding database	PE
<code>show mac-address-table aging-time</code>	Shows the aging time for the address table	PE
<code>show mac-address-table count</code>	Shows the number of MAC addresses used and the number of available MAC addresses	PE
<code>show mac-address-table hash-lookup-depth</code>	Shows the hash lookup depth of MAC address table	PE

**mac-address-table aging-time** This command sets the aging time for entries in the address table. Use the **no** form to restore the default aging time.

## Syntax

**mac-address-table aging-time** *seconds*

**no mac-address-table aging-time**

*seconds* - Aging time. (Range: 6-7200 seconds; 0 to disable aging)

## Default Setting

300 seconds

## Command Mode

Global Configuration

## Command Usage

The aging time is used to age out dynamically learned forwarding information.

### Example

```
Console(config)#mac-address-table aging-time 100
Console(config)#
```

**mac-address-table static** This command maps a static address to a destination port in a VLAN. Use the **no** form to remove an address.

### Syntax

**mac-address-table static** *mac-address* **interface** *interface* **vlan** *vlan-id* [*action*]

**no mac-address-table static** *mac-address* **vlan** *vlan-id*

*mac-address* - MAC address.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

*vlan-id* - VLAN ID (Range: 1-4094)

*action* -

**delete-on-reset** - Assignment lasts until the switch is reset.

**permanent** - Assignment is permanent.

### Default Setting

No static addresses are defined. The default lifetime is **permanent**.

### Command Mode

Global Configuration

### Command Usage

The static address for a host device can be assigned to a specific port within a specific VLAN. Use this command to add static addresses to the MAC Address Table. Static addresses have the following characteristics:

- ◆ Static addresses will not be removed from the address table when a given interface link is down.
- ◆ Static addresses are bound to the assigned interface and will not be moved. When a static address is seen on another interface, the address will be ignored and will not be written to the address table.
- ◆ A static address cannot be learned on another port until the address is removed with the **no** form of this command.

### Example

```

Console(config)#mac-address-table static 00-e0-29-94-34-de interface ethernet
1/1 vlan 1 delete-on-reset
Console(config)#

```

**clear mac-address-table dynamic** This command removes any learned entries from the forwarding database.

### Syntax

**clear mac-address-table dynamic** *[[all] | [address mac-address [mask]] | [interface interface] | [vlan vlan-id]]*

**all** - all learned entries

**address mac-address** - MAC address.

*mask* - Bits to match in the address.

**interface interface**

**ethernet unit/port**

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel channel-id** (Range: 1-28)

**vlan vlan-id** - VLAN ID (Range: 1-4094)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```

Console#clear mac-address-table dynamic all
Console#

```

**show mac-address-table** This command shows classes of entries in the bridge-forwarding database.

### Syntax

**show mac-address-table** [**address** *mac-address* [*mask*]] [**interface** *interface*] [**vlan** *vlan-id*] [**sort** {**address** | **vlan** | **interface**}]

*mac-address* - MAC address.

*mask* - Bits to match in the address.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

*vlan-id* - VLAN ID (Range: 1-4094)

**sort** - Sort by address, vlan or interface.

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ The MAC Address Table contains the MAC addresses associated with each interface. Note that the Type field may include the following types:
  - Learn - Dynamic address entries
  - Config - Static entry
  - Security - Port Security
- ◆ The mask should be hexadecimal numbers (representing an equivalent bit mask) in the form xx-xx-xx-xx-xx-xx that is applied to the specified MAC address. Enter hexadecimal numbers, where an equivalent binary bit "0" means to match a bit and "1" means to ignore a bit. For example, a mask of 00-00-00-00-00-00 means an exact match, and a mask of FF-FF-FF-FF-FF-FF means "any."
- ◆ The maximum number of address entries is 32K.

### Example

```

Console#show mac-address-table
Interface MAC Address          VLAN Type          Life Time
-----
CPU      00-E0-00-00-00-01          1 CPU      Delete on Reset
Eth 1/ 1 00-E0-0C-10-90-09          1 Learn      Delete on Timeout
Eth 1/ 1 00-E0-29-94-34-64          1 Learn      Delete on Timeout
Console#

```

**show mac-address-table aging-time** This command shows the aging time for entries in the address table.

#### Default Setting

None

#### Command Mode

Privileged Exec

#### Example

```
Console#show mac-address-table aging-time
Aging Status : Enabled
Aging Time: 300 sec.
Console#
```

**show mac-address-table count** This command shows the number of MAC addresses used and the number of available MAC addresses for the overall system or for an interface.

#### Syntax

**show mac-address-table count** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

#### Default Setting

None

#### Command Mode

Privileged Exec

#### Example

```
Console#show mac-address-table count interface ethernet 1/1

MAC Entries for Eth 1/1
Total Address Count      :0
Static Address Count     :0
Dynamic Address Count    :0
Console#show mac-address-table count

Compute the number of MAC Address...

Maximum number of MAC Address which can be created in the system:
Total Number of MAC Address      : 32768
Number of Static MAC Address     : 1024

Current number of entries which have been created in the system:
Total Number of MAC Address      : 3
```

```
Number of Static MAC Address      : 1  
Number of Dynamic MAC Address    : 2  
Console#
```

**show mac-address-table hash-lookup-depth** This command shows the hash lookup depth used when searching the MAC address table.

#### Syntax

**show mac-address-table hash-lookup-depth**

#### Command Mode

Privileged Exec

#### Example

```
Console#show mac-address-table hash-lookup-depth  
Configured Hash Lookup Depth: 16  
Activated Hash Lookup Depth: 16  
Console#
```

## Smart Pair Concept

A smart pair consists of two ports which are paired to provide layer 2 link redundancy. The pair consists of a primary port and a backup port. All traffic is forwarded through the primary port and the backup port will be set to standby. If the primary port link goes down, the backup port is activated and all traffic is forwarded through it. If the primary port recovers, all traffic will again be forwarded through the primary port after a configured delay. (wait-to-restore delay).

These commands are used to configure the smart pair ports, set the wait to restore delay, show the smart pairs configured on the switch and restore traffic manually to a configured smart pair.

**Table 102: Address Table Commands**

Command	Function	Mode
<code>smart-pair</code>	Creates a new Smart Pair with an ID and enters into smart pair configuration mode.	GC
<code>smart-pair restore</code>	Manually restores traffic to a smart pair link that is in the up conditions.	PE
<code>primary-port</code>	Configures the Primary Port of the Smart Pair	smart pair
<code>backup-port</code>	Configures the Backup Port of the Smart Pair	smart pair
<code>wtr-delay</code>	Configures the delay time to wait to restore traffic to a smart pair link after one of the links is restored.	smart pair
<code>show smart-pair</code>	Displays all the currently configured smart pairs and their associated information.	PE

**smart-pair** This command creates a smart pair in the switch configuration distinguished by a unique identification number and enters the smart-pair configuration mode. Use the **no** form to delete the smart pair from the switch configuration.

### Syntax

**smart-pair** *ID*

**no smart-pair** *ID*

*ID* - Identification Number. (Range: 1-1000)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Use the command to create a new smart pair or to enter the smart-pair configuration mode of an existing smart pair.

### Example

```
Console(config)#smart-pair 1  
Console(config-smart-pair)#
```

**smart-pair restore** Use the smart-pair restore command to manually restore traffic to the primary port of a specified smart pair.

### Syntax

**smart-pair restore *ID***

*ID* - Identification Number. (Range: 1-1000)

### Default Setting

None

### Command Mode

Privileged Exec.

### Command Usage

The link of the primary port must be in the up condition for the command to succeed.

### Example

```
Console#smart-pair restore 1  
Console#
```

**primary-port** This command configures the primary port of a specified smart pair. Use the no form of the command to remove the configured primary port from the smart pair.

### Syntax

**primary-port** *interface*

**no primary-port**

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Smart Pair Configuration Mode

### Command Usage

When setting the primary-port of the smart pair the following limitations are enforced:

- ◆ Spanning-Tree must be disabled on the port.
- ◆ A configured primary port can only be a member of a single smart pair.
- ◆ Dynamic trunk ports cannot be configured as a smart pair port (only static trunk ports).
- ◆ When a trunk group is identified as a primary port of a smart pair, any members removed from the trunk group will not retain the smart pair settings.
- ◆ When all members of trunk group set as a primary port are removed, the primary port is also removed.
- ◆ The VLAN mode of the primary-port should not be changed after it is configured otherwise the behavior becomes unpredictable.

### Example

```
Console(config-smart-pair)#primary-port ethernet 1/1
Console(config-smart-pair)#
```

### Related Commands

["spanning-tree spanning-disabled" on page 562](#)

**backup-port** This command configures the backup port of a specified smart pair. Use the `no` form of the command to remove the configured backup port from the smart pair.

### Syntax

**backup-port** *interface*

**no backup**

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Smart Pair Configuration Mode

### Command Usage

When setting the backup-port of the smart pair the following limitations are enforced:

- ◆ Spanning-Tree must be disabled on the port.
- ◆ A configured backup port can only be a member of a single smart pair.
- ◆ Dynamic trunk ports cannot be configured as a smart pair port (only static trunk ports).
- ◆ When a trunk group is identified as a backup port of a smart pair, any members removed from the trunk group will not retain the smart pair settings.
- ◆ When all members of trunk group set as a backup port are removed, the backup port is also removed.
- ◆ The VLAN mode of the backup port should not be changed after it is configured otherwise the behavior becomes unpredictable.

### Example

```
Console(config-smart-pair)#backup-port ethernet 1/2
Console(config-smart-pair)#
```

### Related Commands

["spanning-tree spanning-disabled" on page 562](#)

**wtr-delay** This command sets the wait-to-restore delay for a smart pair. Use the no form of the command to set the delay to the default value.

### Syntax

**wtr-delay** *seconds*

*seconds* - delay in seconds (Range:0, 5-3600)

### Default Setting

None

### Command Mode

Smart Pair Configuration Mode

### Command Usage

- ◆ If the wtr-delay parameter is set to 0, traffic will not be restored after a failed port is recovered.
- ◆ If the wtr-delay is set from 5 to 3600 (seconds) and a failed smart port recovers, traffic will be restored to the port after the configured delay in seconds.

### Example

```
Console(config-smart-pair)#wtr-delay 120
Console(config-smart-pair)#
```

**show smart-pair** This command shows the configured smart pairs on the switch.

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show smart-pair
ID   Primary Port Backup Port
----
1    Eth 1/ 1     Eth 1/ 2
Console#
```



# TWAMP Commands

The Two-Way Active Measurement Protocol (TWAMP) is defined by RFC 5357. TWAMP is an open protocol for measuring network performance between any two devices that support the TWAMP protocol.

TWAMP uses the methodology and architecture of OWAMP (One-Way Active Measurement Protocol, RFC 4656), which defines an open protocol for the measurement of one-way metrics, but extends it to two-way, or round-trip, metrics. TWAMP consists of two protocols; a control protocol and a test session protocol. When starting a performance measurement session, the TWAMP control protocol is used to initiate and set up the test session. The TWAMP test protocol then uses UDP for sending and receiving the test packets for performance measurement.

**Table 103: TWAMP Commands**

Command	Function	Mode
<code>twamp reflector</code>	Enables TWAMP Session-Reflector on the switch	GC
<code>twamp reflector refwait</code>	Sets the TWAMP Reflector timeout	GC
<code>show twamp reflector</code>	Displays the TWAMP Reflector configuration and sessions on the switch	PE

**twamp reflector** This command enables the TWAMP Session-Reflector globally on the switch. Use the **no** form to disable the TWAMP reflector function.

## Syntax

**twamp reflector**

**no twamp reflector**

## Default Setting

Disabled

## Command Mode

Global Configuration

## Command Usage

The switch only supports the function of a Session-Reflector (RFC 5357). As a Reflector, the switch can receive test packets from a Session Sender and send test packet responses.

**Example**

```
Console(config)#twamp reflector
Console(config)#
```

**twamp reflector refwait** This command sets the TWAMP session timeout on the switch. Use the **no** form to restore the default.

**Syntax**

**twamp reflector refwait** *seconds*

**no twamp reflector refwait**

*seconds* - The timeout value in seconds. (Range: 30-3600)

**Default Setting**

900 seconds

**Command Mode**

Global Configuration

**Command Usage**

The Session-Reflector will discontinue any session that has been started when no packet associated with that session has been received for the timeout period.

**Example**

```
Console(config)#twamp reflector refwait 300
Console(config)#
```

**show twamp reflector** This command shows the configured TWAMP Reflector settings and sessions on the switch.

**Command Mode**

Privileged Exec

**Example**

```
Console#show twamp reflector
TWAMP Reflector Status: Enabled
TWAMP Reflector REFWAIT: 900 seconds
TWAMP Reflector Mode: Unauthenticated
Total number of sessions: 0

Sender Address      Sender Port  Reflector Address  Reflector Port
-----
Console#
```

# Spanning Tree Commands

This section includes commands that configure the Spanning Tree Algorithm (STA) globally for the switch, and commands that configure STA for the selected interface.

**Table 104: Spanning Tree Commands**

Command	Function	Mode
<code>spanning-tree</code>	Enables the spanning tree protocol	GC
<code>spanning-tree cisco-prestandard</code>	Configures spanning tree operation to be compatible with Cisco prestandard versions	GC
<code>spanning-tree forward-time</code>	Configures the spanning tree bridge forward time	GC
<code>spanning-tree hello-time</code>	Configures the spanning tree bridge hello time	GC
<code>spanning-tree max-age</code>	Configures the spanning tree bridge maximum age	GC
<code>spanning-tree mode</code>	Configures STP, RSTP or MSTP mode	GC
<code>spanning-tree mst configuration</code>	Changes to MSTP configuration mode	GC
<code>spanning-tree pathcost method</code>	Configures the path cost method for RSTP/MSTP	GC
<code>spanning-tree priority</code>	Configures the spanning tree bridge priority	GC
<code>spanning-tree system-bpdu-flooding</code>	Floods BPDUs to all other ports or just to all other ports in the same VLAN when global spanning tree is disabled	GC
<code>spanning-tree tc-prop</code>	Configures a topology change propagation domain	GC
<code>spanning-tree transmission-limit</code>	Configures the transmission limit for RSTP/MSTP	GC
<code>max-hops</code>	Configures the maximum number of hops allowed in the region before a BPDU is discarded	MST
<code>mst priority</code>	Configures the priority of a spanning tree instance	MST
<code>mst vlan</code>	Adds VLANs to a spanning tree instance	MST
<code>name</code>	Configures the name for the multiple spanning tree	MST
<code>revision</code>	Configures the revision number for the multiple spanning tree	MST
<code>spanning-tree bpdu-filter</code>	Filters BPDUs for edge ports	IC
<code>spanning-tree bpdu-guard</code>	Shuts down an edge port if it receives a BPDU	IC
<code>spanning-tree cost</code>	Configures the spanning tree path cost of an interface	IC
<code>spanning-tree edge-port</code>	Enables fast forwarding for edge ports	IC
<code>spanning-tree link-type</code>	Configures the link type for RSTP/MSTP	IC

Table 104: Spanning Tree Commands (Continued)

Command	Function	Mode
<code>spanning-tree loopback-detection</code>	Enables BPDU loopback detection for a port	IC
<code>spanning-tree loopback-detection action</code>	Configures the response for loopback detection to block user traffic or shut down the interface	IC
<code>spanning-tree loopback-detection release-mode</code>	Configures loopback release mode for a port	IC
<code>spanning-tree loopback-detection trap</code>	Enables BPDU loopback SNMP trap notification for a port	IC
<code>spanning-tree restricted-tcn</code>	Prevents a TCN from being propagated from an aggregation switch to the uplink port on access switches	IC
<code>spanning-tree mst cost</code>	Configures the path cost of an instance in the MST	IC
<code>spanning-tree mst port-priority</code>	Configures the priority of an instance in the MST	IC
<code>spanning-tree port-bpdu-flooding</code>	Floods BPDUs to other ports when global spanning tree is disabled	IC
<code>spanning-tree port-priority</code>	Configures the spanning tree priority of an interface	IC
<code>spanning-tree root-guard</code>	Prevents a designated port from passing superior BPDUs	IC
<code>spanning-tree spanning-disabled</code>	Disables spanning tree for an interface	IC
<code>spanning-tree tc-prop-stop</code>	Stops propagation of topology change information	IC
<code>spanning-tree loopback-detection release</code>	Manually releases a port placed in discarding state by loopback-detection	PE
<code>spanning-tree protocol-migration</code>	Re-checks the appropriate BPDU format	PE
<code>show spanning-tree</code>	Shows spanning tree configuration for the common spanning tree (i.e., overall bridge), a selected interface, or an instance within the multiple spanning tree	PE
<code>show spanning-tree mst configuration</code>	Shows the multiple spanning tree configuration	PE
<code>show spanning-tree tc-prop</code>	Shows configuration of topology change propagation domains	PE

**spanning-tree** This command enables the Spanning Tree Algorithm globally for the switch. Use the **no** form to disable it.

#### Syntax

**[no] spanning-tree**

#### Default Setting

Spanning tree is disabled.

#### Command Mode

Global Configuration

**Command Usage**

- ◆ The Spanning Tree Algorithm (STA) can be used to detect and disable network loops, and to provide backup links between switches, bridges or routers. This allows the switch to interact with other bridging devices (that is, an STA-compliant switch, bridge or router) in your network to ensure that only one route exists between any two stations on the network, and provide backup links which automatically take over when a primary link goes down.

**Example**

This example shows how to enable the Spanning Tree Algorithm for the switch:

```
Console(config)#spanning-tree
Console(config)#
```

**spanning-tree cisco-prestandard** This command configures spanning tree operation to be compatible with Cisco prestandard versions. Use the **no** form to restore the default setting.

**[no] spanning-tree cisco-prestandard**

**Default Setting**

Disabled

**Command Mode**

Global Configuration

**Command Usage**

Cisco prestandard versions prior to Cisco IOS Release 12.2(25)SEC do not fully follow the IEEE standard, causing some state machine procedures to function incorrectly. The command forces the spanning tree protocol to function in a manner compatible with Cisco prestandard versions.

**Example**

```
Console(config)#spanning-tree cisco-prestandard
Console(config)#
```

**spanning-tree forward-time** This command configures the spanning tree bridge forward time globally for this switch. Use the **no** form to restore the default setting.

**Syntax**

**spanning-tree forward-time** *seconds*

**no spanning-tree forward-time**

*seconds* - Time in seconds. (Range: 4 - 30 seconds)

The minimum value is the higher of 4 or  $[(\text{max-age} / 2) + 1]$ .

### Default Setting

15 seconds

### Command Mode

Global Configuration

### Command Usage

This command sets the maximum time (in seconds) a port will wait before changing states (i.e., discarding to learning to forwarding). This delay is required because every device must receive information about topology changes before it starts to forward frames. In addition, each port needs time to listen for conflicting information that would make it return to the discarding state; otherwise, temporary data loops might result.

### Example

```
Console(config)#spanning-tree forward-time 20
Console(config)#
```

**spanning-tree hello-time** This command configures the spanning tree bridge hello time globally for this switch. Use the **no** form to restore the default.

### Syntax

**spanning-tree hello-time** *time*

**no spanning-tree hello-time**

*time* - Time in seconds. (Range: 1-10 seconds).

The maximum value is the lower of 10 or  $[(\text{max-age} / 2) - 1]$ .

### Default Setting

2 seconds

### Command Mode

Global Configuration

### Command Usage

This command sets the time interval (in seconds) at which the root device transmits a configuration message.

### Example

```
Console(config)#spanning-tree hello-time 5
Console(config)#
```

### Related Commands

[spanning-tree forward-time \(539\)](#)

[spanning-tree max-age \(541\)](#)

**spanning-tree max-age** This command configures the spanning tree bridge maximum age globally for this switch. Use the **no** form to restore the default.

### Syntax

**spanning-tree max-age** *seconds*

**no spanning-tree max-age**

*seconds* - Time in seconds. (Range: 6-40 seconds)

The minimum value is the higher of 6 or [2 x (hello-time + 1)].

The maximum value is the lower of 40 or [2 x (forward-time - 1)].

### Default Setting

20 seconds

### Command Mode

Global Configuration

### Command Usage

This command sets the maximum time (in seconds) a device can wait without receiving a configuration message before attempting to reconverge. All device ports (except for designated ports) should receive configuration messages at regular intervals. Any port that ages out STA information (provided in the last configuration message) becomes the designated port for the attached LAN. If it is a root port, a new root port is selected from among the device ports attached to the network.

### Example

```
Console(config)#spanning-tree max-age 40
Console(config)#
```

### Related Commands

[spanning-tree forward-time \(539\)](#)

[spanning-tree hello-time \(540\)](#)

**spanning-tree mode** This command selects the spanning tree mode for this switch. Use the **no** form to restore the default.

### Syntax

**spanning-tree mode** {**stp** | **rstp** | **mstp**}

**no spanning-tree mode**

**stp** - Spanning Tree Protocol (IEEE 802.1D)

**rstp** - Rapid Spanning Tree Protocol (IEEE 802.1w)

**mstp** - Multiple Spanning Tree (IEEE 802.1s)

## Default Setting

rstp

## Command Mode

Global Configuration

## Command Usage

- ◆ **Spanning Tree Protocol**

This option uses RSTP set to STP forced compatibility mode. It uses RSTP for the internal state machine, but sends only 802.1D BPDUs. This creates one spanning tree instance for the entire network. If multiple VLANs are implemented on a network, the path between specific VLAN members may be inadvertently disabled to prevent network loops, thus isolating group members. When operating multiple VLANs, we recommend selecting the MSTP option.
- ◆ **Rapid Spanning Tree Protocol**

RSTP supports connections to either STP or RSTP nodes by monitoring the incoming protocol messages and dynamically adjusting the type of protocol messages the RSTP node transmits, as described below:

  - **STP Mode** – If the switch receives an 802.1D BPDU after a port's migration delay timer expires, the switch assumes it is connected to an 802.1D bridge and starts using only 802.1D BPDUs.
  - **RSTP Mode** – If RSTP is using 802.1D BPDUs on a port and receives an RSTP BPDU after the migration delay expires, RSTP restarts the migration delay timer and begins using RSTP BPDUs on that port.
- ◆ **Multiple Spanning Tree Protocol**
  - To allow multiple spanning trees to operate over the network, you must configure a related set of bridges with the same MSTP configuration, allowing them to participate in a specific set of spanning tree instances.
  - A spanning tree instance can exist only on bridges that have compatible VLAN instance assignments.
  - Be careful when switching between spanning tree modes. Changing modes stops all spanning-tree instances for the previous mode and restarts the system in the new mode, temporarily disrupting user traffic.

## Example

The following example configures the switch to use Rapid Spanning Tree:

```
Console(config)#spanning-tree mode rstp
Console(config)#
```

**spanning-tree mst configuration** This command changes to Multiple Spanning Tree (MST) configuration mode.

#### Syntax

**spanning-tree mst configuration**

#### Default Setting

No VLANs are mapped to any MST instance.  
The region name is set the switch's MAC address.

#### Command Mode

Global Configuration

#### Example

```
Console(config)#spanning-tree mst configuration
Console(config-mstp)#
```

#### Related Commands

[mst vlan \(548\)](#)  
[mst priority \(547\)](#)  
[name \(549\)](#)  
[revision \(549\)](#)  
[max-hops \(547\)](#)

**spanning-tree pathcost method** This command configures the path cost method used for Rapid Spanning Tree and Multiple Spanning Tree. Use the **no** form to restore the default.

#### Syntax

**spanning-tree pathcost method {long | short}**

**no spanning-tree pathcost method**

**long** - Specifies 32-bit based values that range from 0-200,000,000.  
This method is based on the IEEE 802.1w Rapid Spanning Tree Protocol.

**short** - Specifies 16-bit based values that range from 0-65535.  
This method is based on the IEEE 802.1D Spanning Tree Protocol.

#### Default Setting

Long method

#### Command Mode

Global Configuration

#### Command Usage

- ◆ The path cost method is used to determine the best path between devices. Therefore, lower values should be assigned to ports attached to faster media,

and higher values assigned to ports with slower media. Note that path cost (page 552) takes precedence over port priority (page 560).

- ◆ The path cost methods apply to all spanning tree modes (STP, RSTP and MSTP). Specifically, the long method can be applied to STP since this mode is supported by a backward compatible mode of RSTP.

### Example

```
Console(config)#spanning-tree pathcost method long
Console(config)#
```

**spanning-tree priority** This command configures the spanning tree priority globally for this switch. Use the **no** form to restore the default.

### Syntax

**spanning-tree priority** *priority*

**no spanning-tree priority**

*priority* - Priority of the bridge. (Range – 0-61440, in steps of 4096; Options: 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, 61440)

### Default Setting

32768

### Command Mode

Global Configuration

### Command Usage

Bridge priority is used in selecting the root device, root port, and designated port. The device with the highest priority (i.e., lower numeric value) becomes the STA root device. However, if all devices have the same priority, the device with the lowest MAC address will then become the root device.

### Example

```
Console(config)#spanning-tree priority 40960
Console(config)#
```

**spanning-tree system-bpdu-flooding** This command configures how the system floods BPDUs to other ports when spanning tree is disabled globally on the switch or disabled on specific ports. Use the **no** form to restore the default.

### Syntax

**spanning-tree system-bpdu-flooding** {**to-all** | **to-vlan**}

**no spanning-tree system-bpdu-flooding**

**to-all** - Floods BPDUs to all other spanning-tree disabled ports on the switch.

**to-vlan** - Floods BPDUs to all other spanning-tree disabled ports within the receiving port's native VLAN (i.e., as determined by port's PVID).

### Default Setting

Floods to all other spanning-tree disabled ports in the same VLAN.

### Command Mode

Global Configuration

### Command Usage

The **spanning-tree system-bpdu-flooding** command has no effect if BPDU flooding is disabled on a port (see the [spanning-tree port-bpdu-flooding](#) command).

### Example

```
Console(config)#spanning-tree system-bpdu-flooding to-all
Console(config)#
```

**spanning-tree tc-prop** This command configures a topology change propagation domain. Use the **no** form to remove a propagation domain.

### Syntax

**spanning-tree tc-prop group** *group-id* {**ethernet** *interface* | **port-channel** *trunk-id*}

*group-id* - Group identifier. (Range: 1-255)

*interface* - *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

*trunk-id* - Trunk index (Range: 1-28)

### Default Setting

All ports and trunks belong to a common group.

### Command Mode

Global Configuration

### Command Usage

A port can only belong to one group. When an interface is added to a group, it is removed from the default group. When a TCN BPDU or BPDU with the TC flag set is received on an interface, that interface will only notify members in same group to propagate this topology change.

### Example

```
Console(config)#spanning-tree tc-prop group 1 ethernet 1/1-5
Console(config)#
```

### spanning-tree transmission-limit

This command configures the maximum number of RSTP/MSTP BPDU transmissions permitted within the Hello Time interval. Use the **no** form to restore the default.

### Syntax

**spanning-tree transmission-limit** *count*

**no spanning-tree transmission-limit**

*count* - The transmission limit number. (Range: 1-10)

### Default Setting

3

### Command Mode

Global Configuration

### Command Usage

This command limits the number of BPDUs transmitted within the configured Hello Time interval.

### Example

```
Console(config)#spanning-tree transmission-limit 4
Console(config)#
```

**max-hops** This command configures the maximum number of hops in the region before a BPDU is discarded. Use the **no** form of the command to set the number of hops to the default value.

### Syntax

**max-hops** *hop-number*

**no max-hops**

*hop-number* - Maximum hop number for multiple spanning tree.  
(Range: 1-40)

### Default Setting

20

### Command Mode

MST Configuration

### Command Usage

An MSTI region is treated as a single node by the STP and RSTP protocols. Therefore, the message age for BPDUs inside an MSTI region is never changed. However, each spanning tree instance within a region, and the internal spanning tree (IST) that connects these instances use a hop count to specify the maximum number of bridges that will propagate a BPDU. Each bridge decrements the hop count by one before passing on the BPDU. When the hop count reaches zero, the message is dropped.

### Example

```
Console(config-mstp)#max-hops 30
Console(config-mstp)#
```

**mst priority** This command configures the priority of a spanning tree instance. Use the **no** form to restore the default.

### Syntax

**mst** *instance-id* **priority** *priority*

**no mst** *instance-id* **priority**

*instance-id* - Instance identifier of the spanning tree. (Range: 0-4094)

*priority* - Priority of the a spanning tree instance.

(Range: 0-61440 in steps of 4096; Options: 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, 61440)

### Default Setting

32768

**Command Mode**

MST Configuration

**Command Usage**

- ◆ MST priority is used in selecting the root bridge and alternate bridge of the specified instance. The device with the highest priority (i.e., lowest numerical value) becomes the MSTI root device. However, if all devices have the same priority, the device with the lowest MAC address will then become the root device.
- ◆ You can set this switch to act as the MSTI root device by specifying a priority of 0, or as the MSTI alternate device by specifying a priority of 16384.

**Example**

```
Console(config-mstp)#mst 1 priority 4096
Console(config-mstp)#
```

**mst vlan** This command adds VLANs to a spanning tree instance. Use the **no** form to remove the specified VLANs. Using the **no** form without any VLAN parameters to remove all VLANs.

**Syntax**

**[no] mst instance-id vlan vlan-range**

*instance-id* - Instance identifier of the spanning tree. (Range: 0-4094)

*vlan-range* - Range of VLANs. (Range: 1-4094)

**Default Setting**

none

**Command Mode**

MST Configuration

**Command Usage**

- ◆ Use this command to group VLANs into spanning tree instances. MSTP generates a unique spanning tree for each instance. This provides multiple pathways across the network, thereby balancing the traffic load, preventing wide-scale disruption when a bridge node in a single instance fails, and allowing for faster convergence of a new topology for the failed instance.
- ◆ By default all VLANs are assigned to the Internal Spanning Tree (MSTI 0) that connects all bridges and LANs within the MST region. This switch supports up to 64 instances. You should try to group VLANs which cover the same general area of your network. However, remember that you must configure all bridges within the same MSTI Region ([page 549](#)) with the same set of instances, and the same instance (on each bridge) with the same set of VLANs. Also, note that

RSTP treats each MSTI region as a single node, connecting all regions to the Common Spanning Tree.

### Example

```
Console(config-mstp)#mst 1 vlan 2-5
Console(config-mstp)#
```

**name** This command configures the name for the multiple spanning tree region in which this switch is located. Use the no form of the command to set the name to the default name.

### Syntax

**name** *name*

**no name**

*name* - Name of multiple spanning tree region. (Range: 1-32 alphanumeric characters)

### Default Setting

Switch's MAC address

### Command Mode

MST Configuration

### Command Usage

The MST region name and revision number ([page 549](#)) are used to designate a unique MST region. A bridge (i.e., spanning-tree compliant device such as this switch) can only belong to one MST region. And all bridges in the same region must be configured with the same MST instances.

### Example

```
Console(config-mstp)#name R&D
Console(config-mstp)#
```

### Related Commands

[revision \(549\)](#)

**revision** This command configures the revision number for this multiple spanning tree configuration of this switch. Use the no form of the command to set the revision number to the default value.

### Syntax

**revision** *number*

**no revision**

*number* - Revision number of the spanning tree. (Range: 0-65535)

**Default Setting**

0

**Command Mode**

MST Configuration

**Command Usage**

The MST region name ([page 549](#)) and revision number are used to designate a unique MST region. A bridge (i.e., spanning-tree compliant device such as this switch) can only belong to one MST region. And all bridges in the same region must be configured with the same MST instances.

**Example**

```
Console(config-mstp)#revision 1
Console(config-mstp)#
```

**Related Commands**

[name \(549\)](#)

**spanning-tree bpd-filter** This command allows you to avoid transmitting BPDUs on configured edge ports that are connected to end nodes. Use the **no** form to disable this feature.

**Syntax**

**[no] spanning-tree bpd-filter**

**Default Setting**

Disabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

- ◆ This command stops all Bridge Protocol Data Units (BPDUs) from being transmitted on configured edge ports to save CPU processing time. This function is designed to work in conjunction with edge ports which should only connect end stations to the switch, and therefore do not need to process BPDUs. However, note that if a trunking port connected to another switch or bridging device is mistakenly configured as an edge port, and BPDU filtering is enabled on this port, this might cause a loop in the spanning tree.
- ◆ BPDU filter can only be configured on an interface if the edge port attribute is not disabled (that is, if edge port is set to enabled or auto with the [spanning-tree edge-port](#) command).

### Example

```

Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree edge-port
Console(config-if)#spanning-tree bpdu-filter
Console(config-if)#

```

### Related Commands

[spanning-tree edge-port \(553\)](#)

**spanning-tree bpdu-guard** This command shuts down an edge port (i.e., an interface set for fast forwarding) if it receives a BPDU. Use the **no** form without any keywords to disable this feature, or with a keyword to restore the default settings.

### Syntax

**spanning-tree bpdu-guard** [**auto-recovery** [**interval** *interval*]]

**no spanning-tree bpdu-guard** [**auto-recovery** [**interval**]]

**auto-recovery** - Automatically re-enables an interface after the specified interval.

*interval* - The time to wait before re-enabling an interface. (Range: 30-86400 seconds)

### Default Setting

BPDU Guard: Disabled

Auto-Recovery: Disabled

Auto-Recovery Interval: 300 seconds

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ An edge port should only be connected to end nodes which do not generate BPDUs. If a BPDU is received on an edge port, this indicates an invalid network configuration, or that the switch may be under attack by a hacker. If an interface is shut down by BPDU Guard, it must be manually re-enabled using the **no shutdown** command if the auto-recovery interval is not specified.
- ◆ BPDU guard can only be configured on an interface if the edge port attribute is not disabled (that is, if edge port is set to enabled or auto with the [spanning-tree edge-port](#) command).

### Example

```

Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree edge-port
Console(config-if)#spanning-tree bpdu-guard
Console(config-if)#

```

**Related Commands**[spanning-tree edge-port \(553\)](#)[spanning-tree spanning-disabled \(562\)](#)

**spanning-tree cost** This command configures the spanning tree path cost for the specified interface. Use the **no** form to restore the default auto-configuration mode.

**Syntax****spanning-tree cost** *cost***no spanning-tree cost**

*cost* - The path cost for the port. (Range: 0 for auto-configuration, 1-65535 for short path cost method, 1-200,000,000 for long path cost method)<sup>11</sup>

**Table 105: Recommended STA Path Cost Range**

Port Type	Short Path Cost (IEEE 802.1D-1998)	Long Path Cost (IEEE 802.1D-2004)
Ethernet	50-600	200,000-20,000,000
Fast Ethernet	10-60	20,000-2,000,000
Gigabit Ethernet	3-10	2,000-200,000
10G Ethernet	1-5	200-20,000

**Default Setting**

By default, the system automatically detects the speed and duplex mode used on each port, and configures the path cost according to the values shown below. Path cost "0" is used to indicate auto-configuration mode. When the short path cost method is selected and the default path cost recommended by the IEEE 8021w standard exceeds 65,535, the default is set to 65,535.

**Table 106: Default STA Path Costs**

Port Type	Short Path Cost (IEEE 802.1D-1998)	Long Path Cost (IEEE 802.1D-2004)
Ethernet	65,535	1,000,000
Fast Ethernet	65,535	100,000
Gigabit Ethernet	10,000	10,000
10G Ethernet	1,000	1,000

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

11. Use the [spanning-tree pathcost method](#) command to set the path cost method. The range displayed in the CLI prompt message shows the maximum value for path cost. However, note that the switch still enforces the rules for path cost based on the specified path cost method (long or short).

### Command Usage

- ◆ This command is used by the Spanning Tree Algorithm to determine the best path between devices. Therefore, lower values should be assigned to ports attached to faster media, and higher values assigned to ports with slower media.
- ◆ Path cost takes precedence over port priority.
- ◆ When the path cost method ([page 543](#)) is set to short, the maximum value for path cost is 65,535.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree cost 50
Console(config-if)#
```

**spanning-tree edge-port** This command specifies an interface as an edge port. Use the **no** form to restore the default.

### Syntax

**spanning-tree edge-port [auto]**

**no spanning-tree edge-port**

**auto** - Automatically determines if an interface is an edge port.

### Default Setting

Auto

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ You can enable this option if an interface is attached to a LAN segment that is at the end of a bridged LAN or to an end node. Since end nodes cannot cause forwarding loops, they can pass directly through to the spanning tree forwarding state. Specifying Edge Ports provides quicker convergence for devices such as workstations or servers, retains the current forwarding database to reduce the amount of frame flooding required to rebuild address tables during reconfiguration events, does not cause the spanning tree to initiate reconfiguration when the interface changes state, and also overcomes other STA-related time out problems. However, remember that Edge Port should only be enabled for ports connected to an end-node device.
- ◆ When edge port is set as auto, the operational state is determined automatically by the Bridge Detection State Machine described in 802.1D-2004, where the edge port state may change dynamically based on environment changes (e.g., receiving a BPDU or not within the required interval).

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree edge-port
Console(config-if)#
```

**spanning-tree link-type** This command configures the link type for Rapid Spanning Tree and Multiple Spanning Tree. Use the **no** form to restore the default.

### Syntax

**spanning-tree link-type** {**auto** | **point-to-point** | **shared**}

**no spanning-tree link-type**

**auto** - Automatically derived from the duplex mode setting.

**point-to-point** - Point-to-point link.

**shared** - Shared medium.

### Default Setting

auto

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Specify a point-to-point link if the interface can only be connected to exactly one other bridge, or a shared link if it can be connected to two or more bridges.
- ◆ When automatic detection is selected, the switch derives the link type from the duplex mode. A full-duplex interface is considered a point-to-point link, while a half-duplex interface is assumed to be on a shared link.
- ◆ RSTP only works on point-to-point links between two bridges. If you designate a port as a shared link, RSTP is forbidden. Since MSTP is an extension of RSTP, this same restriction applies.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree link-type point-to-point
```

**spanning-tree loopback-detection** This command enables the detection and response to Spanning Tree loopback BPDU packets on the port. Use the **no** form to disable this feature.

#### Syntax

**[no] spanning-tree loopback-detection**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

- ◆ If Port Loopback Detection is not enabled and a port receives its own BPDU, then the port will drop the loopback BPDU according to IEEE Standard 802.1W-2001 9.3.4.
- ◆ Port Loopback Detection will not be active if Spanning Tree is disabled on the switch.

#### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree loopback-detection
```

**spanning-tree loopback-detection action** This command configures the response for loopback detection to shut down the interface. Use the **no** form to restore the default.

#### Syntax

**spanning-tree loopback-detection action {shutdown *duration*}**

**no spanning-tree loopback-detection action**

**shutdown** - Shuts down the interface.

*duration* - The duration to shut down the interface.

(Range: 60-86400 seconds)

#### Default Setting

shutdown, 60 seconds

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

- ◆ If an interface is shut down by this command, and the release mode is set to "auto" with the [spanning-tree loopback-detection release-mode](#) command, the

selected interface will be automatically enabled when the shutdown interval has expired.

- ◆ If an interface is shut down by this command, and the release mode is set to "manual," the interface can be re-enabled using the `spanning-tree loopback-detection release` command.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree loopback-detection action shutdown 600
Console(config-if)#
```

### spanning-tree loopback-detection release-mode

This command configures the release mode for a port that was placed in the discarding state because a loopback BPDU was received. Use the **no** form to restore the default.

### Syntax

**spanning-tree loopback-detection release-mode {auto | manual}**

**no spanning-tree loopback-detection release-mode**

**auto** - Allows a port to automatically be released from the discarding state when the loopback state ends.

**manual** - The port can only be released from the discarding state manually.

### Default Setting

auto

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ If the port is configured for automatic loopback release, then the port will only be returned to the forwarding state if one of the following conditions is satisfied:
  - The port receives any other BPDU except for its own, or;
  - The port's link status changes to link down and then link up again, or;
  - The port ceases to receive its own BPDUs in a forward delay interval.
- ◆ If Port Loopback Detection is not enabled and a port receives its own BPDU, then the port will drop the loopback BPDU according to IEEE Standard 802.1W-2001 9.3.4 (Note 1).
- ◆ Port Loopback Detection will not be active if Spanning Tree is disabled on the switch.

- ◆ When configured for manual release mode, then a link down / up event will not release the port from the discarding state. It can only be released using the [spanning-tree loopback-detection release](#) command.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree loopback-detection release-mode manual
Console(config-if)#
```

### spanning-tree loopback-detection trap

This command enables SNMP trap notification for Spanning Tree loopback BPDUs. Use the **no** form to restore the default.

#### Syntax

**[no] spanning-tree loopback-detection trap**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree loopback-detection trap
```

### spanning-tree restricted-tcn

This command prevents a TCN from being propagated from a switch port to other ports. Use the **no** form to restore the default setting.

#### Syntax

**[no] spanning-tree restricted-tcn**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

This command prevents a switch from propagating Topology Change Notifications (TCNs) to other ports on the switch.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree restricted-tcn
```

**spanning-tree mst cost** This command configures the path cost on a spanning instance in the Multiple Spanning Tree. Use the **no** form to restore the default auto-configuration mode.

### Syntax

**spanning-tree mst** *instance-id* **cost** *cost*

**no spanning-tree mst** *instance-id* **cost**

*instance-id* - Instance identifier of the spanning tree. (Range: 0-4094)

*cost* - Path cost for an interface. (Range: 0 for auto-configuration, 1-65535 for short path cost method<sup>12</sup>, 1-200,000,000 for long path cost method)

The recommended path cost range is listed in [Table 105 on page 552](#).

### Default Setting

By default, the system automatically detects the speed and duplex mode used on each port, and configures the path cost according to the values shown in [Table 106](#). Path cost "0" is used to indicate auto-configuration mode. When the short path cost method is selected and the default path cost recommended by the IEEE 8021w standard exceeds 65,535, the default is set to 65,535. The default path costs are listed in [Table 106 on page 552](#).

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Each spanning-tree instance is associated with a unique set of VLAN IDs.
- ◆ This command is used by the multiple spanning-tree algorithm to determine the best path between devices. Therefore, lower values should be assigned to interfaces attached to faster media, and higher values assigned to interfaces with slower media.
- ◆ Use the **no spanning-tree mst cost** command to specify auto-configuration mode.
- ◆ Path cost takes precedence over interface priority.

### Example

```
Console(config)#interface Ethernet 1/5
Console(config-if)#spanning-tree mst 1 cost 50
Console(config-if)#
```

<sup>12</sup>. Use the [spanning-tree pathcost method](#) command to set the path cost method.

**Related Commands**[spanning-tree mst port-priority \(559\)](#)

**spanning-tree mst port-priority** This command configures the interface priority on a spanning instance in the Multiple Spanning Tree. Use the **no** form to restore the default.

**Syntax**

**spanning-tree mst** *instance-id* **port-priority** *priority*

**no spanning-tree mst** *instance-id* **port-priority**

*instance-id* - Instance identifier of the spanning tree. (Range: 0-4094)

*priority* - Priority for an interface. (Range: 0-240 in steps of 16)

**Default Setting**

128

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

- ◆ This command defines the priority for the use of an interface in the multiple spanning-tree. If the path cost for all interfaces on a switch are the same, the interface with the highest priority (that is, lowest value) will be configured as an active link in the spanning tree.
- ◆ Where more than one interface is assigned the highest priority, the interface with lowest numeric identifier will be enabled.

**Example**

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree mst 1 port-priority 0
Console(config-if)#
```

**Related Commands**[spanning-tree mst cost \(558\)](#)

**spanning-tree port-bpdu-flooding** This command floods BPDUs to other ports when spanning tree is disabled globally or disabled on a specific port. Use the **no** form to restore the default setting.

**Syntax**

**[no] spanning-tree port-bpdu-flooding**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

- ◆ When enabled, BPDUs are flooded to all other spanning-tree disabled ports on the switch or within the receiving port's native VLAN as specified by the `spanning-tree system-bpdu-flooding` command.
- ◆ The `spanning-tree system-bpdu-flooding` command has no effect if BPDU flooding is disabled on a port by the **spanning-tree port-bpdu-flooding** command.

**Example**

```

Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree port-bpdu-flooding
Console(config-if)#

```

**spanning-tree port-priority** This command configures the priority for the specified interface. Use the **no** form to restore the default.

**Syntax****spanning-tree port-priority** *priority***no spanning-tree port-priority***priority* - The priority for a port. (Range: 0-240, in steps of 16)**Default Setting**

128

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

- ◆ This command defines the priority for the use of a port in the Spanning Tree Algorithm. If the path cost for all ports on a switch are the same, the port with the highest priority (that is, lowest value) will be configured as an active link in the spanning tree.
- ◆ Where more than one port is assigned the highest priority, the port with lowest numeric identifier will be enabled.
- ◆ The criteria used for determining the port role is based on root bridge ID, root path cost, designated bridge, designated port, port priority, and port number, in that order and as applicable to the role under question.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree port-priority 0
```

### Related Commands

[spanning-tree cost \(552\)](#)

**spanning-tree root-guard** This command prevents a designated port<sup>13</sup> from taking superior BPDUs into account and allowing a new STP root port to be elected. Use the **no** form to disable this feature.

### Syntax

**[no] spanning-tree root-guard**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ A bridge with a lower bridge identifier (or same identifier and lower MAC address) can take over as the root bridge at any time.
- ◆ When Root Guard is enabled, and the switch receives a superior BPDU on this port, it is set to the Discarding state until it stops receiving superior BPDUs for a fixed recovery period. While in the discarding state, no traffic is forwarded across the port.
- ◆ Root Guard can be used to ensure that the root bridge is not formed at a suboptimal location. Root Guard should be enabled on any designated port connected to low-speed bridges which could potentially overload a slower link by taking over as the root port and forming a new spanning tree topology. It could also be used to form a border around part of the network where the root bridge is allowed.
- ◆ When spanning tree is initialized globally on the switch or on an interface, the switch will wait for 20 seconds to ensure that the spanning tree has converged before enabling Root Guard.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree root-guard
Console(config-if)#
```

13. See Port Role in the *Web Management Guide*.

**spanning-tree spanning-disabled** This command disables the spanning tree algorithm for the specified interface. Use the **no** form to re-enable the spanning tree algorithm for the specified interface.

#### Syntax

**[no] spanning-tree spanning-disabled**

#### Default Setting

Enabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

When spanning tree is enabled globally (**spanning-tree** command) or enabled on an interface by this command, loopback detection is disabled.

#### Example

This example disables the spanning tree algorithm for port 5.

```
Console(config)#interface ethernet 1/5
Console(config-if)#spanning-tree spanning-disabled
Console(config-if)#
```

**spanning-tree tc-prop-stop** This command stops the propagation of topology change notifications (TCN for STP) and topology change messages (TC for RSTP/MSTP). Use the **no** form to allow propagation of TCN/TC messages.

#### Syntax

**[no] spanning-tree tc-prop-stop**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

When this command is enabled on an interface, topology change information originating from the interface will still be propagated.

This command should not be used on an interface which is purposely configured in a ring topology.

### Example

```

Console(config)#interface ethernet 1/1
Console(config-if)#spanning-tree tc-prop-stop
Console(config-if)#

```

### spanning-tree loopback-detection release

This command manually releases a port placed in discarding state by loopback-detection.

#### Syntax

**spanning-tree loopback-detection release** *interface*

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

#### Command Mode

Privileged Exec

#### Command Usage

Use this command to release an interface from discarding state if loopback detection release mode is set to “manual” by the [spanning-tree loopback-detection release-mode](#) command and BPDU loopback occurs.

### Example

```

Console#spanning-tree loopback-detection release ethernet 1/1
Console#

```

### spanning-tree protocol-migration

This command re-checks the appropriate BPDU format to send on the selected interface.

#### Syntax

**spanning-tree protocol-migration** *interface*

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**Command Mode**

Privileged Exec

**Command Usage**

If at any time the switch detects STP BPDUs, including Configuration or Topology Change Notification BPDUs, it will automatically set the selected interface to forced STP-compatible mode. However, you can also use the **spanning-tree protocol-migration** command at any time to manually re-check the appropriate BPDU format to send on the selected interfaces (i.e., RSTP or STP-compatible).

**Example**

```
Console#spanning-tree protocol-migration ethernet 1/5
Console#
```

**show spanning-tree** This command shows the configuration for the common spanning tree (CST), for all instances within the multiple spanning tree (MST), or for a specific instance within the multiple spanning tree (MST).

**Syntax**

**show spanning-tree** [*interface* | **mst** *instance-id* [**brief** | *interface*] | **brief** | **stp-enabled-only**]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

*instance-id* - Instance identifier of the multiple spanning tree.  
(Range: 0-4094)

**brief** - Shows a summary of global and interface settings.

**stp-enabled-only** - Displays global settings, and settings for interfaces for which STP is enabled.

**Default Setting**

None

**Command Mode**

Privileged Exec

**Command Usage**

- ◆ Use the **show spanning-tree** command with no parameters to display the spanning tree configuration for the switch for the Common Spanning Tree (CST) and for every interface in the tree.

- ◆ Use the **show spanning-tree interface** command to display the spanning tree configuration for an interface within the Common Spanning Tree (CST).
- ◆ Use the **show spanning-tree mst** command to display the spanning tree configuration for all instances within the Multiple Spanning Tree (MST), including global settings and settings for active interfaces.
- ◆ Use the **show spanning-tree mst instance-id** command to display the spanning tree configuration for an instance within the Multiple Spanning Tree (MST), including global settings and settings for all interfaces.

### Example

```

Console#show spanning-tree
Spanning Tree Information
-----
Spanning Tree Mode           : MSTP
Spanning Tree Enabled/Disabled : Enabled
Instance                     : 0
VLANs Configured            : 1-4094
Priority                      : 32768
Bridge Hello Time (sec.)     : 2
Bridge Max. Age (sec.)       : 20
Bridge Forward Delay (sec.)  : 15
Root Hello Time (sec.)       : 2
Root Max. Age (sec.)         : 20
Root Forward Delay (sec.)    : 15
Max. Hops                    : 20
Remaining Hops               : 20
Designated Root              : 32768.0.0001ECF8D8C6
Current Root Port            : 21
Current Root Cost             : 100000
Number of Topology Changes   : 5
Last Topology Change Time (sec.): 11409
Transmission Limit           : 3
Path Cost Method              : Long
Flooding Behavior             : To VLAN
Cisco Prestandard            : Disabled
-----

Eth 1/ 1 Information
-----
Admin Status                  : Enabled
Role                          : Disabled
State                         : Discarding
External Admin Path Cost     : 0
Internal Admin Path Cost     : 0
External Oper Path Cost      : 100000
Internal Oper Path Cost      : 100000
Priority                       : 128
Designated Cost               : 100000
Designated Port               : 128.1
Designated Root               : 32768.0.0001ECF8D8C6
Designated Bridge             : 32768.0.123412341234
Forward Transitions           : 4
Admin Edge Port               : Disabled
Oper Edge Port                : Disabled
Admin Link Type                : Auto
Oper Link Type                 : Point-to-point
Flooding Behavior              : Enabled
Spanning-Tree Status          : Enabled
Loopback Detection Status     : Enabled
Loopback Detection Release Mode : Auto

```

```

Loopback Detection Trap          : Disabled
Loopback Detection Action       : Block
Root Guard Status               : Disabled
BPDU Guard Status               : Disabled
BPDU Guard Auto Recovery        : Disabled
BPDU Guard Auto Recovery Interval : 300
BPDU Filter Status              : Disabled
TC Propagate Stop               : Disabled
Restricted TCN                   : Disabled
:
:

```

This example shows a brief summary of global and interface setting for the spanning tree.

```

Console#show spanning-tree brief
Spanning Tree Mode           : RSTP
Spanning Tree Enabled/Disabled : Enabled
Designated Root              : 32768.0000E8944000
Current Root Port (Eth)      : 1/24
Current Root Cost             : 10000

Interface Pri Designated      Designated Oper    STP   Role State Oper
              Bridge ID        Port ID   Cost    Status
-----
Eth 1/ 1  128 32768.0000E89382A0    128.1     100000 EN    DESG FWD  No
Eth 1/ 2  128 32768.0000E89382A0    128.2     10000  EN    DISB BLK No
Eth 1/ 3  128 32768.0000E89382A0    128.3     10000  EN    DISB BLK No
Eth 1/ 4  128 32768.0000E89382A0    128.4     10000  EN    DISB BLK No
Eth 1/ 5  128 32768.0000E89382A0    128.5     10000  EN    DISB BLK No
:
:

```

**show spanning-tree mst configuration**

This command shows the configuration of the multiple spanning tree.

**Command Mode**  
Privileged Exec

**Example**

```

Console#show spanning-tree mst configuration
Mstp Configuration Information
-----
Configuration Name : R&D
Revision Level     : 0

Instance VLANs
-----
0 1-4094
Console#

```

**show spanning-tree tc-prop** This command shows the configuration of topology change propagation domains.

#### Syntax

**show spanning-tree tc-prop [group *group-id*]**

*group-id* - Group identifier. (Range: 1-255)

#### Command Mode

Privileged Exec

#### Example

```
Console#show spanning-tree tc-prop group 1
Group 1
Eth 1/ 1, Eth 1/ 2, Eth 1/ 3, Eth 1/ 4, Eth 1/ 5
Console#
```



# VLAN Commands

A VLAN is a group of ports that can be located anywhere in the network, but communicate as though they belong to the same physical segment. This section describes commands used to create VLAN groups, add port members, specify how VLAN tagging is used, and enable automatic VLAN registration for the selected interface.

**Table 107: VLAN Commands**

Command Group	Function
<a href="#">GVRP and Bridge Extension Commands</a>	Configures GVRP settings that permit automatic VLAN learning; shows the configuration for bridge extension MIB
<a href="#">Editing VLAN Groups</a>	Sets up VLAN groups, including name, VID and state
<a href="#">Configuring VLAN Interfaces</a>	Configures VLAN interface parameters, including ingress and egress tagging mode, ingress filtering, and PVID
<a href="#">Displaying VLAN Information</a>	Displays VLAN groups, status, port members, and MAC addresses
<a href="#">Configuring IEEE 802.1Q Tunneling</a>	Configures 802.1Q Tunneling (QinQ Tunneling)
<a href="#">Configuring L2PT Tunneling<sup>1</sup></a>	Configures Layer 2 Protocol Tunneling (L2PT), either by discarding, processing, or transparently passing control packets across a QinQ tunnel
<a href="#">Configuring VLAN Translation<sup>2</sup></a>	Maps VLAN ID between customer and service provider for networks that do not support IEEE 802.1Q tunneling
<a href="#">Configuring Protocol-based VLANs<sup>2</sup></a>	Configures protocol-based VLANs based on frame type and protocol
<a href="#">Configuring IP Subnet VLANs<sup>2</sup></a>	Configures IP Subnet-based VLANs
<a href="#">Configuring MAC Based VLANs<sup>2</sup></a>	Configures MAC-based VLANs
<a href="#">Configuring Voice VLANs</a>	Configures VoIP traffic detection and enables a Voice VLAN
<a href="#">Configuring Excluded VLANs</a>	Configures excluded VLAN sessions

1 These functions are not compatible.

2 If a packet matches the rules defined by more than one of these functions, only one of them is applied, with the precedence being MAC-based, IP subnet-based, protocol-based, and then native port-based (see the [switchport priority default](#) command).

## GVRP and Bridge Extension Commands

GARP VLAN Registration Protocol defines a way for switches to exchange VLAN information in order to automatically register VLAN members on interfaces across the network. This section describes how to enable GVRP for individual interfaces and globally for the switch, as well as how to display default configuration settings for the Bridge Extension MIB.

**Table 108: GVRP and Bridge Extension Commands**

Command	Function	Mode
<code>bridge-ext gvrp</code>	Enables GVRP globally for the switch	GC
<code>garp timer</code>	Sets the GARP timer for the selected function	IC
<code>switchport forbidden vlan</code>	Configures forbidden VLANs for an interface	IC
<code>switchport gvrp</code>	Enables GVRP for an interface	IC
<code>show bridge-ext</code>	Shows the global bridge extension configuration	PE
<code>show garp timer</code>	Shows the GARP timer for the selected function	NE, PE
<code>show gvrp configuration</code>	Displays GVRP configuration for the selected interface	NE, PE

**bridge-ext gvrp** This command enables GVRP globally for the switch. Use the **no** form to disable it.

### Syntax

**[no] bridge-ext gvrp**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

GVRP defines a way for switches to exchange VLAN information in order to register VLAN members on ports across the network. This function should be enabled to permit automatic VLAN registration, and to support VLANs which extend beyond the local switch.

### Example

```
Console(config)#bridge-ext gvrp
Console(config)#
```

**garp timer** This command sets the values for the join, leave and leaveall timers. Use the **no** form to restore the timers' default values.

### Syntax

**garp timer {join | leave | leaveall} timer-value**

**no garp timer {join | leave | leaveall}**

**{join | leave | leaveall}** - Timer to set.

*timer-value* - Value of timer.

Ranges:

join: 20-1000 centiseconds

leave: 60-3000 centiseconds

leaveall: 500-18000 centiseconds

### Default Setting

join: 20 centiseconds

leave: 60 centiseconds

leaveall: 1000 centiseconds

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Group Address Registration Protocol is used by GVRP and GMRP to register or deregister client attributes for client services within a bridged LAN. The default values for the GARP timers are independent of the media access method or data rate. These values should not be changed unless you are experiencing difficulties with GMRP or GVRP registration/deregistration.
- ◆ Timer values are applied to GVRP for all the ports on all VLANs.
- ◆ Timer values must meet the following restrictions:
  - leave > (2 x join)
  - leaveall > leave



**Note:** Set GVRP timers on all Layer 2 devices connected in the same network to the same values. Otherwise, GVRP may not operate successfully.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#garp timer join 100
Console(config-if)#
```

**Related Commands**  
[show garp timer \(574\)](#)

**switchport forbidden vlan** This command configures forbidden VLANs. Use the **no** form to remove the list of forbidden VLANs.

**Syntax**

**switchport forbidden vlan** {**add** *vlan-list* | **remove** *vlan-list*}

**no switchport forbidden vlan**

**add** *vlan-list* - List of VLAN identifiers to add.

**remove** *vlan-list* - List of VLAN identifiers to remove.

*vlan-list* - Separate nonconsecutive VLAN identifiers with a comma and no spaces; use a hyphen to designate a range of IDs. (Range: 1-4094).

**Default Setting**

No VLANs are included in the forbidden list.

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

- ◆ This command prevents a VLAN from being automatically added to the specified interface via GVRP using the [switchport gvrp](#) command.
- ◆ If a VLAN has been added to the set of allowed VLANs for an interface, then you cannot add it to the set of forbidden VLANs for that same interface.
- ◆ GVRP cannot be enabled for ports set to Access mode (see the [switchport mode](#) command).
- ◆ This command will not be accepted if the specified VLAN does not exist on the switch.

**Example**

The following example shows how to prevent port 1 from being added to VLAN 3:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport forbidden vlan add 3
Console(config-if)#
```

**switchport gvrp** This command enables GVRP for a port. Use the **no** form to disable it.

### Syntax

**[no] switchport gvrp**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

GVRP cannot be enabled for ports set to Access mode using the [switchport mode](#) command.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport gvrp
Console(config-if)#
```

**show bridge-ext** This command shows the configuration for bridge extension commands.

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show bridge-ext
Maximum Supported VLAN Numbers      : 4094
Maximum Supported VLAN ID           : 4094
Extended Multicast Filtering Services : No
Static Entry Individual Port         : Yes
VLAN Version Number                  : 2
VLAN Learning                        : IVL
Configurable PVID Tagging            : Yes
Local VLAN Capable                   : No
Traffic Classes                      : Enabled
Global GVRP Status                   : Disabled
Console#
```

Table 109: show bridge-ext - display description

Field	Description
Maximum Supported VLAN Numbers	The maximum number of VLANs supported on this switch.
Maximum Supported VLAN ID	The maximum configurable VLAN identifier supported on this switch.
Extended Multicast Filtering Services	This switch does not support the filtering of individual multicast addresses based on GMRP (GARP Multicast Registration Protocol).
Static Entry Individual Port	This switch allows static filtering for unicast and multicast addresses. (Refer to the <a href="#">mac-address-table static</a> command.)
VLAN Version Number	Based on IEEE 802.1Q, "1" indicates Bridges that support only single spanning tree (SST) operation, and "2" indicates Bridges that support multiple spanning tree (MST) operation.
VLAN Learning	This switch uses Independent VLAN Learning (IVL), where each port maintains its own filtering database.
Configurable PVID Tagging	This switch allows you to override the default Port VLAN ID (PVID used in frame tags) and egress status (VLAN-Tagged or Untagged) on each port. (Refer to the <a href="#">switchport allowed vlan</a> command.)
Local VLAN Capable	This switch does not support multiple local bridges outside of the scope of 802.1Q defined VLANs.
Traffic Classes	This switch provides mapping of user priorities to multiple traffic classes. (Refer to "Class of Service Commands" on page 653.)
Global GVRP Status	GARP VLAN Registration Protocol defines a way for switches to exchange VLAN information in order to automatically register VLAN members on interfaces across the network. This field shows if GVRP is globally enabled or disabled. (Refer to the <a href="#">bridge-ext gvrp</a> command.)

**show garp timer** This command shows the GARP timers for the selected interface.

### Syntax

**show garp timer** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

Shows all GARP timers.

### Command Mode

Normal Exec, Privileged Exec

## Example

```
Console#show garp timer ethernet 1/1
Eth 1/ 1 GARP Timer Status:
  Join Timer      : 20 centiseconds
  Leave Timer     : 60 centiseconds
  Leave All Timer : 1000 centiseconds

Console#
```

## Related Commands

[garp timer \(571\)](#)

**show gvrp configuration** This command shows if GVRP is enabled.

### Syntax

```
show gvrp configuration [interface]
    interface
        ethernet unit/port
            unit - Unit identifier. (Range: 1)
            port - Port number. (Range: 1-28/54)
        port-channel channel-id (Range: 1-28)
```

### Default Setting

Shows both global and interface-specific configuration.

### Command Mode

Normal Exec, Privileged Exec

## Example

```
Console#show gvrp configuration ethernet 1/7
Eth 1/ 7:
  GVRP Configuration : Disabled

Console#
```

## Editing VLAN Groups

Table 110: Commands for Editing VLAN Groups

Command	Function	Mode
<a href="#">vlan database</a>	Enters VLAN database mode to add, change, and delete VLANs	GC
<a href="#">vlan</a>	Configures a VLAN, including VID, name and state	VC

**vlan database** This command enters VLAN database mode. All commands in this mode will take effect immediately.

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Use the VLAN database command mode to add, change, and delete VLANs. After finishing configuration changes, you can display the VLAN settings by entering the [show vlan](#) command.
- ◆ Use Interface Configuration mode (Ethernet, Port Channel) to define the port membership mode and add or remove ports from a VLAN. The results of these commands are written to the running-configuration file, and you can display this file by entering the [show running-config](#) command.

### Example

```
Console(config)#vlan database
Console(config-vlan)#
```

### Related Commands

[show vlan \(585\)](#)

**vlan** This command configures a VLAN. Use the **no** form to restore the default settings or delete a VLAN.

### Syntax

```
vlan vlan-id [name vlan-name] media ethernet [state {active | suspend}]  
[rspan]
```

```
no vlan vlan-id [name | state]
```

*vlan-id* - VLAN ID, specified as a single number, a range of consecutive numbers separated by a hyphen, or multiple numbers separated by commas. (Range: 1-4094)

**name** - Keyword to be followed by the VLAN name.

*vlan-name* - ASCII string from 1 to 32 characters.

**media ethernet** - Ethernet media type.

**state** - Keyword to be followed by the VLAN state.

**active** - VLAN is operational.

**suspend** - VLAN is suspended. Suspended VLANs do not pass packets.

**rspan** - Keyword to create a VLAN used for mirroring traffic from remote switches. The VLAN used for RSPAN cannot include VLAN 1 (the switch's default VLAN). Nor should it include VLAN 4093 (which is used for switch clustering). Configuring VLAN 4093 for other purposes may cause problems in the Clustering operation. For more information on configuring RSPAN through the CLI, see "[RSPAN Mirroring Commands](#)" on page 484.



---

**Note:** Ports can only be added to an RSPAN VLAN using the commands described under "[RSPAN Mirroring Commands](#)".

---

### Default Setting

By default only VLAN 1 exists and is active.

### Command Mode

VLAN Database Configuration

### Command Usage

- ◆ **no vlan** *vlan-id* deletes the VLAN.
- ◆ **no vlan** *vlan-id* **name** removes the VLAN name.
- ◆ **no vlan** *vlan-id* **state** returns the VLAN to the default state (i.e., active).
- ◆ You can configure up to 4094 VLANs on the switch.

### Example

The following example adds a VLAN, using VLAN ID 105 and name RD5. The VLAN is activated by default.

```
Console(config)#vlan database
Console(config-vlan)#vlan 105 name RD5 media ethernet
Console(config-vlan)#
```

### Related Commands

[show vlan \(585\)](#)

## Configuring VLAN Interfaces

Table 111: Commands for Configuring VLAN Interfaces

Command	Function	Mode
<a href="#">interface vlan</a>	Enters interface configuration mode for a specified VLAN	IC
<a href="#">switchport acceptable-frame-types</a>	Configures frame types to be accepted by an interface	IC
<a href="#">switchport allowed vlan</a>	Configures the VLANs associated with an interface	IC
<a href="#">switchport forbidden vlan</a>	Configures forbidden VLANs for an interface	IC
<a href="#">switchport gvrp</a>	Enables GVRP for an interface	IC
<a href="#">switchport ingress-filtering</a>	Enables ingress filtering on an interface	IC
<a href="#">switchport mode</a>	Configures VLAN membership mode for an interface	IC
<a href="#">switchport native vlan</a>	Configures the PVID (native VLAN) of an interface	IC
<a href="#">vlan-trunking</a>	Allows unknown VLAN groups to pass through a specified interface	IC
<a href="#">switchport priority default</a>	Sets a port priority for incoming untagged frames	IC

**interface vlan** This command enters interface configuration mode for VLANs, which is used to configure VLAN parameters for a physical interface. Use the **no** form to change a Layer 3 normal VLAN back to a Layer 2 interface.

### Syntax

```
[no] interface vlan vlan-id
```

*vlan-id* - ID of the configured VLAN. (Range: 1-4094)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Creating a “normal” VLAN with the `vlan` command initializes it as a Layer 2 interface. To change it to a Layer 3 interface, use the `interface` command to enter interface configuration for the desired VLAN, enter any Layer 3 configuration commands, and save the configuration settings.
- ◆ To change a Layer 3 normal VLAN back to a Layer 2 VLAN, use the `no interface` command.

### Example

The following example shows how to set the interface configuration mode to VLAN 1, and then assign an IP address to the VLAN:

```
Console(config)#interface vlan 1
Console(config-if)#ip address 192.168.1.254 255.255.255.0
Console(config-if)#
```

### Related Commands

[shutdown \(430\)](#)

[interface \(423\)](#)

[vlan \(577\)](#)

**switchport acceptable-frame-types** This command configures the acceptable frame types for a port. Use the **no** form to restore the default.

#### Syntax

**switchport acceptable-frame-types {all | tagged}**

**no switchport acceptable-frame-types**

**all** - The port accepts all frames, tagged or untagged.

**tagged** - The port only receives tagged frames.

#### Default Setting

All frame types

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

When set to receive all frame types, any received frames that are untagged are assigned to the port default VLAN if not matched to a configured MAC VLAN, IP-subnet VLAN, or protocol VLAN.

### Example

The following example shows how to restrict the traffic received on port 1 to tagged frames:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport acceptable-frame-types tagged
Console(config-if)#
```

### Related Commands

[switchport mode \(582\)](#)

**switchport allowed vlan** This command configures VLAN groups on the selected interface. Use the **no** form to restore the default.

### Syntax

**switchport allowed vlan** {*vlan-list* | **add** *vlan-list* [**tagged** | **untagged**] | **remove** *vlan-list*}

#### **no switchport allowed vlan**

*vlan-list* - If a VLAN list is entered without using the **add** option, the interface is assigned to the specified VLANs, and membership in all previous VLANs is removed. The interface is added as an untagged member if [switchport mode](#) is set to hybrid or access, or as an tagged member if switchport mode is set to trunk.

Separate nonconsecutive VLAN identifiers with a comma and no spaces; use a hyphen to designate a range of IDs. (Range: 1-4094).

**add** *vlan-list* - List of VLAN identifiers to add. When the **add** option is used, the interface is assigned to the specified VLANs, and membership in all previous VLANs is retained.

**remove** *vlan-list* - List of VLAN identifiers to remove.

**tagged** - Adds a port as a tagged member of a VLAN.

**untagged** - Adds a port as an untagged member of a VLAN.

### Default Setting

All ports are assigned to VLAN 1 by default.  
The default frame type is untagged.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ If a port or trunk has switchport mode set to **access**, then only one VLAN can be added with this command. If a VLAN list is specified, only the last VLAN in the list will be added to the interface.

- ◆ If a port or trunk has switchport mode set to **trunk** (i.e., 1Q Trunk), then you can only assign the interface to VLAN groups as a tagged member.
- ◆ Frames are always tagged within the switch. The tagged/untagged parameter used when adding a VLAN to an interface tells the switch whether to keep or remove the tag from a frame on egress.
- ◆ If none of the intermediate network devices nor the host at the other end of the connection supports VLANs, the interface should be added to these VLANs as an untagged member. Otherwise, it is only necessary to add at most one VLAN as untagged, and this should correspond to the native VLAN for the interface.
- ◆ If a VLAN on the forbidden list for an interface is manually added to that interface, the VLAN is automatically removed from the forbidden list for that interface.
- ◆ Ports can only be added to an RSPAN VLAN using the commands described under [“RSPAN Mirroring Commands”](#).

### Example

The following example shows how to add VLANs 1, 2, 5 and 6 to the allowed list as tagged VLANs for port 1:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport allowed vlan add 1,2,5,6 tagged
Console(config-if)#
```

**switchport ingress-filtering** This command enables ingress filtering for an interface. Use the **no** form to restore the default.

### Syntax

**[no] switchport ingress-filtering**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ If ingress filtering is disabled and a port receives frames classified to VLANs for which it is not a member, these frames will be flooded to all other ports that are members of the VLANs.
- ◆ If ingress filtering is enabled and a port receives frames classified to VLANs for which it is not a member, these frames will be discarded.

- ◆ Ingress filtering does not affect VLAN independent BPDU frames, such as GVRP or STA. However, they do affect VLAN dependent BPDU frames, such as GMRP.
- ◆ Ingress filtering cannot be enabled for a port if the port does not join the PVID VLAN.
- ◆ Ingress filtering cannot be disabled for a port if loopback detection on the port is active. (Both global and per port are enabled.)

### Example

The following example shows how to set the interface to port 1 and then enable ingress filtering:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport ingress-filtering
Console(config-if)#
```

**switchport mode** This command configures the VLAN membership mode for a port. Use the **no** form to restore the default.

### Syntax

**switchport mode {access | hybrid | trunk}**

**no switchport mode**

**access** - Specifies an access VLAN interface. The port transmits and receives untagged frames on a single VLAN only.

**hybrid** - Specifies a hybrid VLAN interface. The port may transmit tagged or untagged frames.

**trunk** - Specifies a port as an end-point for a VLAN trunk. A trunk is a direct link between two switches, so the port transmits tagged frames that identify the source VLAN. Note that frames belonging to the port's default VLAN (i.e., associated with the PVID) are also transmitted as tagged frames.

### Default Setting

All ports are in hybrid mode with the PVID set to VLAN 1.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Example

The following shows how to set the configuration mode to port 1, and then set the switchport mode to hybrid:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport mode hybrid
Console(config-if)#
```

### Related Commands

[switchport acceptable-frame-types \(579\)](#)

**switchport native vlan** This command configures the PVID (i.e., port VLAN ID) for a port. Use the **no** form to restore the default.

### Syntax

**switchport native vlan** *vlan-id*

**no switchport native vlan**

*vlan-id* - Default VLAN ID for a port. (Range: 1-4094)

### Default Setting

VLAN 1

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ When changing the PVID for a port using access mode, the port will automatically join the new PVID VLAN and leave the VLAN which it had joined before.
- ◆ When using Access mode, and an interface is assigned to a new VLAN, its PVID is automatically set to the identifier for that VLAN.
- ◆ The PVID can be set to any VLAN that the port does not join when using hybrid or trunk mode, and ingress filtering is disabled.
- ◆ The PVID can only be set to a VLAN that the port joins when using hybrid or trunk mode, and ingress filtering is enabled.

### Example

The following example shows how to set the PVID for port 1 to VLAN 3:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport native vlan 3
Console(config-if)#
```

**vlan-trunking** This command allows unknown VLAN groups to pass through the specified interface. Use the **no** form to disable this feature.

### Syntax

**[no] vlan-trunking**

### Default Setting

Disabled

### Command Mode


Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Use this command to configure a tunnel across one or more intermediate switches which pass traffic for VLAN groups to which they do not belong.

The following figure shows VLANs 1 and 2 configured on switches A and B, with VLAN trunking being used to pass traffic for these VLAN groups across switches C, D and E.

Figure 5: Configuring VLAN Trunking



Without VLAN trunking, you would have to configure VLANs 1 and 2 on all intermediate switches – C, D and E; otherwise these switches would drop any frames with unknown VLAN group tags. However, by enabling VLAN trunking on the intermediate switch ports along the path connecting VLANs 1 and 2, you only need to create these VLAN groups in switches A and B. Switches C, D and E automatically allow frames with VLAN group tags 1 and 2 (groups that are unknown to those switches) to pass through their VLAN trunking ports.

- ◆ VLAN trunking is mutually exclusive with the “access” switchport mode (see the [switchport mode](#) command). If VLAN trunking is enabled on an interface, then that interface cannot be set to access mode, and vice versa.
- ◆ To prevent loops from forming in the spanning tree, all unknown VLANs will be bound to a single instance (either STP/RSTP or an MSTP instance, depending on the selected STA mode).
- ◆ If both VLAN trunking and ingress filtering are disabled on an interface, packets with unknown VLAN tags will still be allowed to enter this interface and will be

flooded to all other ports where VLAN trunking is enabled. (In other words, VLAN trunking will still be effectively enabled for the unknown VLAN).

### Example

The following example enables VLAN trunking on ports 27 and 28 to establish a path across the switch for unknown VLAN groups:

```
Console(config)#interface ethernet 1/27
Console(config-if)#vlan-trunking
Console(config-if)#interface ethernet 1/28
Console(config-if)#vlan-trunking
Console(config-if)#
```

## Displaying VLAN Information

This section describes commands used to display VLAN information.

**Table 112: Commands for Displaying VLAN Information**

Command	Function	Mode
<code>show interfaces status vlan</code>	Displays status for the specified VLAN interface	NE, PE
<code>show interfaces switchport</code>	Displays the administrative and operational status of an interface	NE, PE
<code>show vlan</code>	Shows VLAN information	NE, PE

**show vlan** This command shows VLAN information.

### Syntax

**show vlan** [**id** *vlan-id* | **name** *vlan-name*]

**id** - Keyword to be followed by the VLAN ID.

*vlan-id* - ID of the configured VLAN. (Range: 1-4094)

**name** - Keyword to be followed by the VLAN name.

*vlan-name* - ASCII string from 1 to 32 characters.

### Default Setting

Shows all VLANs.

### Command Mode

Normal Exec, Privileged Exec

### Example

The following example shows how to display information for VLAN 1:

```
Console#show vlan id 1

VLAN ID          : 1
Type             : Static
Name             : DefaultVlan
Status           : Active
Ports/Port Channels : Eth1/ 1(S) Eth1/ 2(S) Eth1/ 3(S) Eth1/ 4(S) Eth1/ 5(S)
                   : Eth1/ 6(S) Eth1/ 7(S) Eth1/ 8(S) Eth1/ 9(S) Eth1/10(S)
                   : Eth1/11(S) Eth1/12(S) Eth1/13(S) Eth1/14(S) Eth1/15(S)
                   : Eth1/16(S) Eth1/17(S) Eth1/18(S) Eth1/19(S) Eth1/20(S)
                   : Eth1/21(S) Eth1/22(S) Eth1/23(S) Eth1/24(S) Eth1/25(S)
                   : Eth1/26(S) Eth1/27(S) Eth1/28(S)

Console#
```

## Configuring IEEE 802.1Q Tunneling

IEEE 802.1Q tunneling (QinQ tunneling) uses a single Service Provider VLAN (SPVLAN) for customers who have multiple VLANs. Customer VLAN IDs are preserved and traffic from different customers is segregated within the service provider's network even when they use the same customer-specific VLAN IDs. QinQ tunneling expands VLAN space by using a VLAN-in-VLAN hierarchy, preserving the customer's original tagged packets, and adding SPVLAN tags to each frame (also called double tagging).

This section describes the commands used to configure QinQ tunneling.

**Table 113: 802.1Q Tunneling Commands**

Command	Function	Mode
<code>dot1q-tunnel system-tunnel-control</code>	Configures the switch to operate in normal mode or QinQ mode	GC
<code>dot1q-tunnel tpid</code>	Configures the other tag ethertype for QinQ tunneling	GC
<code>switchport dot1q-tunnel mode</code>	Configures the QinQ tunnel port mode of an interface	IC
<code>switchport dot1q-tunnel priority map</code>	Copies inner tag priority to outer tag priority	IC
<code>switchport dot1q-tunnel service match cvid</code>	Creates a CVLAN to SPVLAN mapping entry	IC
<code>show dot1q-tunnel service</code>	Displays tunnel service subscriptions, default discard service, and discarded untagged traffic configuration	PE
<code>show dot1q-tunnel</code>	Displays the configuration of QinQ tunnel ports	PE
<code>show interfaces switchport</code>	Displays port QinQ operational status	PE

### *General Configuration Guidelines for QinQ*

1. Configure the switch to QinQ mode (`dot1q-tunnel system-tunnel-control`).
2. Create a SPVLAN (`vlan`).

3. Configure the QinQ tunnel access port to dot1Q-tunnel access mode ([switchport dot1q-tunnel mode](#)).
4. Set the Tag Protocol Identifier (TPID) value of the tunnel access port. This step is required if the attached client is using a nonstandard 2-byte ethertype to identify 802.1Q tagged frames. The standard ethertype value is 0x8100. (See [dot1q-tunnel tpid](#).)
5. Configure the QinQ tunnel access port to join the SPVLAN as an untagged member ([switchport allowed vlan](#)).
6. Configure the SPVLAN ID as the native VID on the QinQ tunnel access port ([switchport native vlan](#)).
7. Configure the QinQ tunnel uplink port to dot1Q-tunnel uplink mode ([switchport dot1q-tunnel mode](#)).
8. Configure the QinQ tunnel uplink port to join the SPVLAN as a tagged member ([switchport allowed vlan](#)).

#### *Limitations for QinQ*

- ◆ The native VLAN for the tunnel uplink ports and tunnel access ports cannot be the same. However, the same service VLANs can be set on both tunnel port types.
- ◆ IGMP Snooping should not be enabled on a tunnel access port.
- ◆ If the spanning tree protocol is enabled, be aware that a tunnel access or tunnel uplink port may be disabled if the spanning tree structure is automatically reconfigured to overcome a break in the tree. It is therefore advisable to disable spanning tree on these ports.

**dot1q-tunnel system-tunnel-control** This command sets the switch to operate in QinQ mode. Use the **no** form to disable QinQ operating mode.

#### **Syntax**

**[no] dot1q-tunnel system-tunnel-control**

#### **Default Setting**

Disabled

#### **Command Mode**

Global Configuration

### Command Usage

QinQ tunnel mode must be enabled on the switch for QinQ interface settings to be functional.

### Example

```
Console(config)#dot1q-tunnel system-tunnel-control  
Console(config)#
```

### Related Commands

[show dot1q-tunnel \(593\)](#)

[show interfaces switchport \(440\)](#)

**dot1q-tunnel tpid** Use this command to set the global setting for the QinQ outer tag ethertype field. Use the **no** form of the command to set the ethertype field to the default value.

### Syntax

**[no] dot1q-tunnel tpid** *ethertype*

*ethertype* – A specific Ethernet protocol number. (Range: 800-ffff hex)

### Default Setting

The ethertype is set to 0x8100

### Command Mode

Global Configuration

### Command Usage

Use the **dot1q-tunnel tpid** command to set the global custom 802.1Q ethertype. This feature allows the switch to interoperate with third-party switches that do not use the standard 0x8100 ethertype to identify 802.1Q-tagged frames. For example, if 0x1234 is set as the global 802.1Q ethertype, incoming frames on trunk ports containing that ethertype are assigned to the VLAN contained in the tag following the ethertype field. Frames arriving on trunk ports containing any other ethertype are looked upon as untagged frames, and assigned to the native VLAN of the port.

The specified ethertype only applies to ports configured in Uplink mode using the **switchport dot1q-tunnel mode** command. If the port is in normal mode (i.e, unspecified), the TPID is always 0x8100. If the port is in Access mode, received packets are processed as untagged packets.

### Example

```
Console(config)#dot1q-tunnel tpid 0x88A8  
Console(config)#
```

### Related Commands

[show dot1q-tunnel \(593\)](#)

[switchport dot1q-tunnel mode \(589\)](#)

**switchport dot1q-tunnel mode** This command configures an interface as a QinQ tunnel port. Use the **no** form to disable QinQ on the interface.

### Syntax

**switchport dot1q-tunnel mode {access | uplink}**

**no switchport dot1q-tunnel mode**

**access** – Sets the port as an 802.1Q tunnel access port.

**uplink** – Sets the port as an 802.1Q tunnel uplink port.

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ QinQ tunneling must be enabled on the switch using the [dot1q-tunnel system-tunnel-control](#) command before the **switchport dot1q-tunnel mode** interface command can take effect.
- ◆ When a tunnel uplink port receives a packet from a customer, the customer tag (regardless of whether there are one or more tag layers) is retained in the inner tag, and the service provider's tag added to the outer tag.
- ◆ When a tunnel uplink port receives a packet from the service provider, the outer service provider's tag is stripped off, and the packet passed on to the VLAN indicated by the inner tag. If no inner tag is found, the packet is passed onto the native VLAN defined for the uplink port.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport dot1q-tunnel mode access
Console(config-if)#
```

### Related Commands

[show dot1q-tunnel \(593\)](#)

[show interfaces switchport \(440\)](#)

**switchport dot1q-tunnel priority map** This command copies the inner tag priority to the outer tag priority. Use the **no** form to disable this feature.

#### Syntax

**[no] switchport dot1q-tunnel priority map**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

When priority bits are found in the inner tag, these are also copied to the outer tag. This allows the service provider to differentiate service based on the indicated priority and appropriate methods of queue management at intermediate nodes across the tunnel.

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport dot1q-tunnel priority map
Console(config-if)#
```

**switchport dot1q-tunnel service match cvid** This command creates a CVLAN to SPVLAN mapping entry. Use the **no** form to delete all VLAN mapping entries or a specified entry.

#### Syntax

**switchport dot1q-tunnel service svid match cvid cvid**

**no switchport dot1q-tunnel service [svid [match cvid cvid]]**

*svid* - VLAN ID for the outer VLAN tag (Service Provider VID). (Range: 1-4094)

*cvid* - VLAN ID for the inner VLAN tag (Customer VID). (Range: 1-4094)

#### Default Setting

Default mapping uses the PVID of the ingress port on the edge router for the SPVID.

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

- ◆ The inner VLAN tag of a customer packet entering the edge router of a service provider's network is mapped to an outer tag indicating the service provider VLAN that will carry this traffic across the 802.1Q tunnel. This process is performed in a transparent manner.

- ◆ When priority bits are found in the inner tag, these are also copied to the outer tag. This allows the service provider to differentiate service based on the indicated priority and appropriate methods of queue management at intermediate nodes across the tunnel.
- ◆ Rather than relying on standard service paths and priority queuing, QinQ VLAN mapping can be used to further enhance service by defining a set of differentiated service pathways to follow across the service provider's network for traffic arriving from specified inbound customer VLANs.
- ◆ Note that all customer interfaces should be configured as access interfaces (that is, a user-to-network interface) and service provider interfaces as uplink interfaces (that is, a network-to-network interface). Use the `dot1q-tunnel tpid uplink` command to set an interface to access or uplink mode.


### Example

This example sets the SVID to 99 in the outer tag for egress packets exiting port 1 when the packet's CVID is 2.

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport dot1q-tunnel service 99 match cvid 2
Console(config-if)#
```

The following example maps C-VLAN 10 to S-VLAN 100, C-VLAN 20 to S-VLAN 200 and C-VLAN 30 to S-VLAN 300 for ingress traffic on port 1 of Switches A and B.

**Figure 6: Mapping QinQ Service VLAN to Customer VLAN**



Step 1. Configure Switch A and B.

**1. Create VLANs 100, 200 and 300.**

```
Console(config)#vlan database
Console(config-vlan)#vlan 100,200,300 media ethernet state active
```

**2. Enable QinQ.**

```
Console(config)#dot1q-tunnel system-tunnel-control
```

**3. Configure port 2 as a tagged member of VLANs 100, 200 and 300 using uplink mode.**

```
Console(config)#interface ethernet 1/2
Console(config-if)#switchport allowed vlan add 100,200,300 tagged
```

```
Console(config-if)#switchport dot1q-tunnel mode uplink
```

4. Configures port 1 as an untagged member of VLANs 100, 200 and 300 using access mode.

```
Console(config)#interface ethernet 1/1  
Console(config-if)#switchport allowed vlan add 100,200,300 untagged  
Console(config-if)#switchport dot1q-tunnel mode access
```

5. Configure the following selective QinQ mapping entries.

```
Console(config)#interface ethernet 1/1  
Console(config-if)#switchport dot1q-tunnel service 100 match cvid 10  
Console(config-if)#switchport dot1q-tunnel service 200 match cvid 20  
Console(config-if)#switchport dot1q-tunnel service 300 match cvid 30
```

6. Configures port 1 as member of VLANs 10, 20 and 30 to avoid filtering out incoming frames tagged with VID 10, 20 or 30 on port 1

```
Console(config)#interface ethernet 1/1  
Console(config-if)#switchport allowed vlan add 10,20,30
```

7. Verify configuration settings.

```
Console#show dot1q-tunnel service  
802.1Q Tunnel Service Subscriptions
```

Port	Match	C-VID	S-VID
Eth 1/ 3		10	100
Eth 1/ 3		20	200
Eth 1/ 3		30	300

## Step 2. Configure Switch C.

1. Create VLAN 100, 200 and 300.

```
Console(config)#vlan database  
Console(config-vlan)#vlan 100,200,300 media ethernet state active
```

2. Configure port 1 and port 2 as tagged members of VLAN 100, 200 and 300.

```
Console(config)#interface ethernet 1/1,2  
Console(config-if)#switchport allowed vlan add 100,200,300 tagged
```

**show dot1q-tunnel service** This command shows tunnel service subscriptions, default discard service, and discarded untagged traffic configuration.

### Syntax

```
show dot1q-tunnel service [svid]
```

*svid* - VLAN ID for the outer VLAN tag (SPVID). (Range: 1-4094)

### Command Mode

Privileged Exec

## Example

```

Console#show dot1q-tunnel service
802.1Q Tunnel Service Subscriptions

Port      Match C-VID S-VID Replace
-----
Eth 1/ 3          10  100
Eth 1/ 3          20  200
Eth 1/ 3          30  300

Console(config)#show dot1q-tunnel service 100
802.1Q Tunnel Service Subscriptions

Port      Match C-VID S-VID Replace
-----
Eth 1/ 3          10  100

Console#

```

**show dot1q-tunnel** This command displays information about QinQ tunnel ports.

## Syntax

**show dot1q-tunnel** [**interface** *interface* [**service** *svid*]]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

*svid* - VLAN ID for the outer VLAN tag (SPVID). (Range: 1-4094)

## Command Mode

Privileged Exec

## Example

```

Console(config)#dot1q-tunnel system-tunnel-control
Console(config)#interface ethernet 1/1
Console(config-if)#switchport dot1q-tunnel mode access
Console(config-if)#interface ethernet 1/2
Console(config-if)#switchport dot1q-tunnel mode uplink
Console(config-if)#end
Console#show dot1q-tunnel
802.1Q Tunnel Status : Enabled
802.1Q Tunnel TPID   : 8100 (Hex)

Port      Mode      Priority Mapping
-----
Eth 1/ 1 Access Disabled
Eth 1/ 2 Uplink Disabled
Eth 1/ 3 Normal Disabled
:

```

```
Console#show dot1q-tunnel interface ethernet 1/5
802.1Q Tunnel Service Subscriptions
```

```
Port      Match C-VID S-VID Replace
-----
Eth 1/ 5          1   100
```

```
Console#show dot1q-tunnel service 100
802.1Q Tunnel Service Subscriptions
```

```
Port      Match C-VID S-VID Replace
-----
Eth 1/ 5          1   100
Eth 1/ 6          1   100
```

```
Console#
```

### Related Commands

[dot1q-tunnel tpid \(588\)](#)

## Configuring L2PT Tunneling

This section describes the commands used to configure Layer 2 Protocol Tunneling (L2PT).

Table 114: L2 Protocol Tunnel Commands

Command	Function	Mode
<a href="#">l2protocol-tunnel tunnel-dmac</a>	Configures the destination address for Layer 2 Protocol Tunneling	GC
<a href="#">switchport l2protocol-tunnel</a>	Enables Layer 2 Protocol Tunneling for the specified protocol	IC
<a href="#">show l2protocol-tunnel</a>	Shows settings for Layer 2 Protocol Tunneling	PE

**[l2protocol-tunnel tunnel-dmac](#)** This command configures the destination address for Layer 2 Protocol Tunneling (L2PT). Use the **no** form to restore the default setting.

### Syntax

**[l2protocol-tunnel tunnel-dmac](#) mac-address**

**no [l2protocol-tunnel tunnel-dmac](#)**

*mac-address* – The switch rewrites the destination MAC address in all upstream L2PT protocol packets (i.e, STP BPDUs) to this value, and forwards them on to uplink ports. The MAC address must be specified in the format xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx.

The tunnel address can be any multicast address, except for the following:

- IPv4 multicast addresses (with prefix 01-00-5E)

- IPv6 multicast addresses (with prefix 33-33-33)
- Addresses used by the spanning tree protocol.

### Default Setting

01-12-CF-00-00-02, proprietary tunnel address

### Command Mode

Global Configuration

### Command Usage

- ◆ When L2PT is not used, protocol packets (such as STP) are flooded to 802.1Q access ports on the same edge switch, but filtered from 802.1Q tunnel ports. This creates disconnected protocol domains in the customer's network.
- ◆ L2PT can be used to pass various types of protocol packets belonging to the same customer transparently across a service provider's network. In this way, normally segregated network segments can be configured to function inside a common protocol domain.
- ◆ L2PT encapsulates protocol packets entering ingress ports on the service provider's edge switch, replacing the destination MAC address with a proprietary MAC address (for example, the spanning tree protocol uses 10-12-CF-00-00-02), a reserved address for other specified protocol types (as defined in IEEE 802.1ad – Provider Bridges), or a user-defined address. All intermediate switches carrying this traffic across the service provider's network treat these encapsulated packets in the same way as normal data, forwarding them across to the tunnel's egress port. The egress port decapsulates these packets, restores the proper protocol and MAC address information, and then floods them onto the same VLANs at the customer's remote site (via all of the appropriate tunnel ports and access ports<sup>14</sup> connected to the same metro VLAN).
- ◆ The way in which L2PT processes packets is based on the following criteria – (1) packet is received on a QinQ uplink port, (2) packet is received on a QinQ access port, or (3) received packet is Cisco-compatible L2PT (i.e., as indicated by a proprietary MAC address).

#### *Processing protocol packets defined in IEEE 802.1ad – Provider Bridges*

- ◆ When an IEEE 802.1ad protocol packet is received on an uplink port (i.e., an 802.1Q tunnel ingress port connecting the edge switch to the service provider network)
  - with the destination address 01-80-C2-00-00-00,0B~0F (C-VLAN tag), it is forwarded to all QinQ uplink ports and QinQ access ports in the same S-VLAN for which L2PT is enabled for that protocol.

14. Access ports in this context are 802.1Q trunk ports.

- with the destination address 01-80-C2-00-00-01~0A (S-VLAN tag), it is filtered, decapsulated, and processed locally by the switch if the protocol is supported.
- ◆ When a protocol packet is received on an access port (i.e., an 802.1Q trunk port connecting the edge switch to the local customer network)
  - with the destination address 01-80-C2-00-00-00,0B~0F (C-VLAN), and
    - L2PT is enabled on the port, the frame is forwarded to all QinQ uplink ports and QinQ access ports on which L2PT is enabled for that protocol in the same S-VLAN.
    - L2PT is disabled on the port, the frame is decapsulated and processed locally by the switch if the protocol is supported.
  - with destination address 01-80-C2-00-00-01~0A (S-VLAN), the frame is filtered, decapsulated, and processed locally by the switch if the protocol is supported.

#### *Processing Cisco-compatible protocol packets*

- ◆ When a Cisco-compatible L2PT packet is received on an uplink port, and
  - recognized as a CDP/VTP/STP/PVST+ protocol packet (where STP means STP/RSTP/MSTP), it is forwarded to the following ports in the same S-VLAN: (a) all access ports for which L2PT has been disabled, and (b) all uplink ports.
  - recognized as a Generic Bridge PDU Tunneling (GBPT) protocol packet (i.e., having the destination address 01-00-0C-CD-CD-D0), it is forwarded to the following ports in the same S-VLAN:
    - other access ports for which L2PT is enabled after decapsulating the packet and restoring the proper protocol and MAC address information.
    - all uplink ports.
- ◆ When a Cisco-compatible L2PT packet is received on an access port, and
  - recognized as a CDP/VTP/STP/PVST+ protocol packet, and
    - L2PT is enabled on this port, it is forwarded to the following ports in the same S-VLAN: (a) other access ports for which L2PT is enabled, and (b) uplink ports after rewriting the destination address to make it a GBPT protocol packet (i.e., setting the destination address to 01-00-0C-CD-CD-D0).
    - L2PT is disabled on this port, it is forwarded to the following ports in the same S-VLAN: (a) other access ports for which L2PT is disabled, and (b) all uplink ports.

- recognized as a GBPT protocol packet (i.e., having the destination address 01-00-0C-CD-CD-D0), and
  - L2PT is enabled on this port, it is forwarded to other access ports in the same S-VLAN for which L2PT is enabled
  - L2PT is disabled on this port, it is forwarded to the following ports in the same S-VLAN: (a) other access ports for which L2PT is disabled, and (b) all uplink ports.
- ◆ For L2PT to function properly, QinQ must be enabled on the switch using the [dot1q-tunnel system-tunnel-control](#) command, and the interface configured to 802.1Q tunnel mode using the [dot1q-tunnel tpid](#) command.

### Example

```
Console(config)#dot1q-tunnel system-tunnel-control
Console(config)#l2protocol-tunnel tunnel-dmac 01-80-C2-00-00-01
Console(config)#
```

**switchport l2protocol-tunnel** This command enables Layer 2 Protocol Tunneling (L2PT) for the specified protocol. Use the **no** form to disable L2PT for the specified protocol.

### Syntax

**[no] switchport l2protocol-tunnel {cdp | lacp | lldp | pvst+ | spanning-tree | vtp}**

**cdp** - Cisco Discovery Protocol

**lacp** - Link Aggregation Control Protocol

**lldp** - Link Layer Discovery Protocol

**pvst+** - Cisco Per VLAN Spanning Tree Plus

**spanning-tree** - Spanning Tree (STP, RSTP, MSTP)

**vtp** - Cisco VLAN Trunking Protocol

### Default Setting

Disabled for all protocols

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Refer to the Command Usage section for the [l2protocol-tunnel tunnel-dmac](#) command.
- ◆ For L2PT to function properly, QinQ must be enabled on the switch using the [dot1q-tunnel system-tunnel-control](#) command, and the interface configured to 802.1Q tunnel mode using the [dot1q-tunnel tpid](#) command.

### Example

```
Console(config)#dot1q-tunnel system-tunnel-control
Console(config)#interface ethernet 1/1
Console(config-if)#switchport dot1q-tunnel mode access
Console(config-if)#switchport l2protocol-tunnel spanning-tree
Console(config-if)#
```

**show l2protocol-tunnel** This command shows settings for Layer 2 Protocol Tunneling (L2PT).

**Command Mode**  
Privileged Exec

### Example

```
Console#show l2protocol-tunnel
Layer 2 Protocol Tunnel

Tunnel MAC Address : 01-12-CF-00-00-00

Interface  Protocol
-----
Eth 1/ 1   Spanning Tree

Console#
```

## Configuring VLAN Translation

QinQ tunneling uses double tagging to preserve the customer's VLAN tags on traffic crossing the service provider's network. However, if any switch in the path crossing the service provider's network does not support this feature, then the switches directly connected to that device can be configured to swap the customer's VLAN ID with the service provider's VLAN ID for upstream traffic, or the service provider's VLAN ID with the customer's VLAN ID for downstream traffic.

This section describes commands used to configure VLAN translation.

**Table 115: VLAN Translation Commands**

Command	Function	Mode
<a href="#">switchport vlan-translation</a>	Maps VLAN IDs between the customer and service provider	IC
<a href="#">show vlan-translation</a>	Displays the configuration settings for VLAN translation	PE

**switchport vlan-translation** This command maps VLAN IDs between the customer and service provider.

### Syntax

```
switchport vlan-translation [ingress | egress] original-vlan new-vlan
```

**no switchport vlan-translation [ingress | egress] original-vlan**

**ingress** - specifies ingress only

**egress** - specifies egress only

*original-vlan* - The original VLAN ID. (Range: 1-4094)

*new-vlan* - The new VLAN ID. (Range: 1-4094)

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ If the next switch upstream does not support QinQ tunneling, then use this command to map the customer's VLAN ID to the service provider's VLAN ID for the upstream port. Similarly, if the next switch downstream does not support QinQ tunneling, then use this command to map the service provider's VLAN ID to the customer's VLAN ID for the downstream port. Note that one command maps both the *original-vlan* to *new-vlan* for ingress traffic and the *new-vlan* to *original-vlan* for egress traffic on the specified port.

For example, assume that the upstream switch does not support QinQ tunneling. If the command **switchport vlan-translation 10 100** is used to map VLAN 10 to VLAN 100 for upstream traffic entering port 1, and VLAN 100 to VLAN 10 for downstream traffic leaving port 1, then the VLAN IDs will be swapped as shown below.

**Figure 7: Configuring VLAN Translation**



- ◆ The maximum number of VLAN translation entries is 8 per port, and up to 96 for the system. However, note that configuring a large number of entries may degrade the performance of other processes that also use the TCAM, such as IP Source Guard filter rules, Quality of Service (QoS) processes, QinQ, MAC-based VLANs, VLAN translation, or traps.
- ◆ If VLAN translation is set on an interface with this command, and the same interface is also configured as a QinQ access port with the **dot1q-tunnel tpid** command, VLAN tag assignments will be determined by the QinQ process, not by VLAN translation.

### Example

This example configures VLAN translation for Port 1 as described in the Command Usage section above.

```
Console(config)#vlan database
Console(config-vlan)#vlan 10 media ethernet state active
Console(config-vlan)#vlan 100 media ethernet state active
Console(config-vlan)#exit
Console(config)#interface ethernet 1/1,2
Console(config-if)#switchport allowed vlan add 10 tagged
Console(config-if)#switchport allowed vlan add 100 tagged
Console(config-if)#interface ethernet 1/1
Console(config-if)#switchport vlan-translation 10 100
Console(config-if)#end
Console#show vlan-translation

Ingress VLAN Translation
Interface Old VID New VID
-----
Eth 1/ 1      10    100

Egress VLAN Translation
Interface Old VID New VID
-----
Eth 1/ 1      100    10

Console#
```

**show vlan-translation** This command displays the configuration settings for VLAN translation.

### Syntax

**show vlan-translation** [**egress** [**interface** *interface*]] | **ingress** [**interface** *interface*]| **interface** *interface*

**egress** - Show configuration settings for egress ports.

**ingress** - Show configuration settings for ingress ports.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

```
Console#show vlan-translation

Ingress VLAN Translation
Interface Old VID New VID
-----
Eth 1/ 1      10    100
Eth 1/ 2      100    200

Egress VLAN Translation
```

```

Interface Old VID New VID
-----
Eth 1/ 1   100    10
Eth 1/ 2   100    200
Eth 1/ 2   200    10
Console#

```

## Configuring Protocol-based VLANs

The network devices required to support multiple protocols cannot be easily grouped into a common VLAN. This may require non-standard devices to pass traffic between different VLANs in order to encompass all the devices participating in a specific protocol. This kind of configuration deprives users of the basic benefits of VLANs, including security and easy accessibility.

To avoid these problems, you can configure this switch with protocol-based VLANs that divide the physical network into logical VLAN groups for each required protocol. When a frame is received at a port, its VLAN membership can then be determined based on the protocol type in use by the inbound packets.

**Table 116: Protocol-based VLAN Commands**

Command	Function	Mode
<code>protocol-vlan protocol-group</code>	Create a protocol group, specifying the supported protocols	GC
<code>protocol-vlan protocol-group</code>	Maps a protocol group to a VLAN	IC
<code>show protocol-vlan protocol-group</code>	Shows the configuration of protocol groups	PE
<code>show interfaces protocol-vlan protocol-group</code>	Shows the interfaces mapped to a protocol group and the corresponding VLAN	PE

To configure protocol-based VLANs, follow these steps:

1. First configure VLAN groups for the protocols you want to use ([page 577](#)). Although not mandatory, we suggest configuring a separate VLAN for each major protocol running on your network. Do not add port members at this time.
2. Create a protocol group for each of the protocols you want to assign to a VLAN using the `protocol-vlan protocol-group` command (Global Configuration mode).
3. Then map the protocol for each interface to the appropriate VLAN using the `protocol-vlan protocol-group` command (Interface Configuration mode).



**Note:** Traffic which matches IP Protocol Ethernet Frames is mapped to the VLAN that has been configured with the switch's administrative IP interface (default VLAN 1). IP Protocol Ethernet traffic must not be mapped to another VLAN or you will lose administrative network connectivity to the switch. If lost in this manner, network access can be regained by removing the offending Protocol VLAN rule via the console. Alternately, the switch can be power-cycled, however all unsaved configuration changes will be lost.

**protocol-vlan  
protocol-group**  
(Configuring Groups)

This command creates a protocol group, or adds specific protocols to a group. Use the **no** form to remove a protocol group.

**Syntax**

**protocol-vlan protocol-group** *group-id* [{**add** | **remove**}  
**frame-type** *frame* **protocol-type** *protocol*]

**no protocol-vlan protocol-group** *group-id*

*group-id* - Group identifier of this protocol group. (Range: 1-2147483647)

*frame*<sup>15</sup> - Frame type used by this protocol. (Options: ethernet, rfc\_1042, llc\_other)

*protocol* - Protocol type. The only option for the llc\_other frame type is ipx\_raw. The options for all other frames types include: arp, ip, ipv6, pppoe-dis, pppoe-ses, rarp.

**Default Setting**

No protocol groups are configured.

**Command Mode**

Global Configuration

**Example**

The following creates protocol group 1, and specifies Ethernet frames with IP and ARP protocol types:

```
Console(config)#protocol-vlan protocol-group 1 add frame-type ethernet  
protocol-type ip  
Console(config)#protocol-vlan protocol-group 1 add frame-type ethernet  
protocol-type arp  
Console(config)#
```

15. SNAP frame types are not supported by this switch due to hardware limitations.

**protocol-vlan**  
**protocol-group**  
(Configuring Interfaces)

This command maps a protocol group to a VLAN for the current interface. Use the **no** form to remove the protocol mapping for this interface.

**Syntax**

**protocol-vlan protocol-group** *group-id* **vlan** *vlan-id* [**priority** *priority*]

**no protocol-vlan protocol-group** *group-id*

*group-id* - Group identifier of this protocol group. (Range: 1-2147483647)

*vlan-id* - VLAN to which matching protocol traffic is forwarded.  
(Range: 1-4094)

*priority* - The priority assigned to untagged ingress traffic.  
(Range: 0-7, where 7 is the highest priority)

**Default Setting**

No protocol groups are mapped for any interface.

Priority: 0

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

- ◆ When creating a protocol-based VLAN, only assign interfaces via this command. If you assign interfaces using any of the other VLAN commands (such as the [vlan](#) command), these interfaces will admit traffic of any protocol type into the associated VLAN.
- ◆ When MAC-based, IP subnet-based, and protocol-based VLANs are supported concurrently, priority is applied in this sequence, and then port-based VLANs last.
- ◆ When a frame enters a port that has been assigned to a protocol VLAN, it is processed in the following manner:
  - If the frame is tagged, it will be processed according to the standard rules applied to tagged frames.
  - If the frame is untagged and the protocol type matches, the frame is forwarded to the appropriate VLAN.
  - If the frame is untagged but the protocol type does not match, the frame is forwarded to the default VLAN for this interface.

### Example

The following example maps the traffic entering Port 1 which matches the protocol type specified in protocol group 1 to VLAN 2.

```
Console(config)#interface ethernet 1/1
Console(config-if)#protocol-vlan protocol-group 1 vlan 2 priority 0
Console(config-if)#
```

### show protocol-vlan protocol-group

This command shows the frame and protocol type associated with protocol groups.

#### Syntax

**show protocol-vlan protocol-group** [*group-id*] [**sort-by-type**]

*group-id* - Group identifier for a protocol group. (Range: 1-2147483647)

**sort-by-type** - Sort display information by frame type and protocol type.

#### Default Setting

All protocol groups are displayed.

#### Command Mode

Privileged Exec

### Example

This shows protocol group 1 configured for IP over Ethernet:

```
Console#show protocol-vlan protocol-group

  Protocol Group ID   Frame Type   Protocol Type
-----
                   1           ethernet    08 00
Console#
```

### show interfaces protocol-vlan protocol-group

This command shows the mapping from protocol groups to VLANs for the selected interfaces.

#### Syntax

**show interfaces protocol-vlan protocol-group** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

The mapping for all interfaces is displayed.

### Command Mode

Privileged Exec

### Example

This shows that traffic entering Port 1 that matches the specifications for protocol group 1 will be mapped to VLAN 2:

```

Console#show interfaces protocol-vlan protocol-group
Port      Protocol Group ID VLAN ID Priority
-----
Eth 1/1 1          2      1
Console#
  
```

## Configuring IP Subnet VLANs

When using IEEE 802.1Q port-based VLAN classification, all untagged frames received by a port are classified as belonging to the VLAN whose VID (PVID) is associated with that port.

When IP subnet-based VLAN classification is enabled, the source address of untagged ingress frames are checked against the IP subnet-to-VLAN mapping table. If an entry is found for that subnet, these frames are assigned to the VLAN indicated in the entry. If no IP subnet is matched, the untagged frames are classified as belonging to the receiving port's VLAN ID (PVID).

**Table 117: IP Subnet VLAN Commands**

Command	Function	Mode
<code>subnet-vlan</code>	Defines the IP Subnet VLANs	GC
<code>show subnet-vlan</code>	Displays IP Subnet VLAN settings	PE

**subnet-vlan** This command configures IP Subnet VLAN assignments. Use the **no** form to remove an IP subnet-to-VLAN assignment.

### Syntax

**subnet-vlan subnet** *ip-address mask* **vlan** *vlan-id* [**priority** *priority*]

**no subnet-vlan subnet** [*ip-address mask* | **all**]

*ip-address* – The IP address that defines the subnet. Valid IP addresses consist of four decimal numbers, 0 to 255, separated by periods.

*mask* – This mask identifies the host address bits of the IP subnet.

*vlan-id* – VLAN to which matching IP subnet traffic is forwarded.  
(Range: 1-4094)

*priority* – The priority assigned to untagged ingress traffic. (Range: 0-7, where 7 is the highest priority)

### Default Setting

Priority: 0

### Command Mode

Global Configuration

### Command Usage

- ◆ Each IP subnet can be mapped to only one VLAN ID. An IP subnet consists of an IP address and a subnet mask. The specified VLAN need not be an existing VLAN.
- ◆ When an untagged frame is received by a port, the source IP address is checked against the IP subnet-to-VLAN mapping table, and if an entry is found, the corresponding VLAN ID is assigned to the frame. If no mapping is found, the PVID of the receiving port is assigned to the frame.
- ◆ The IP subnet cannot be a broadcast or multicast IP address.
- ◆ When MAC-based, IP subnet-based, or protocol-based VLANs are supported concurrently, priority is applied in this sequence, and then port-based VLANs last.

### Example

The following example assigns traffic for the subnet 192.168.12.192, mask 255.255.255.224, to VLAN 4.

```
Console(config)#subnet-vlan subnet 192.168.12.192 255.255.255.224 vlan 4
Console(config)#
```

**show subnet-vlan** This command displays IP Subnet VLAN assignments.

### Command Mode

Privileged Exec

### Command Usage

- ◆ Use this command to display subnet-to-VLAN mappings.
- ◆ The last matched entry is used if more than one entry can be matched.

### Example

The following example displays all configured IP subnet-based VLANs.

```

Console#show subnet-vlan
IP Address      Mask                VLAN ID  Priority
-----
192.168.12.0    255.255.255.128    1        0
192.168.12.128 255.255.255.192    3        0
192.168.12.192 255.255.255.224    4        0
192.168.12.224 255.255.255.240    5        0
192.168.12.240 255.255.255.248    6        0
192.168.12.248 255.255.255.252    7        0
192.168.12.252 255.255.255.254    8        0
192.168.12.254 255.255.255.255    9        0
192.168.12.255 255.255.255.255    10       0
Console#

```

## Configuring MAC Based VLANs

When using IEEE 802.1Q port-based VLAN classification, all untagged frames received by a port are classified as belonging to the VLAN whose VID (PVID) is associated with that port.

When MAC-based VLAN classification is enabled, the source address of untagged ingress frames are checked against the MAC address-to-VLAN mapping table. If an entry is found for that address, these frames are assigned to the VLAN indicated in the entry. If no MAC address is matched, the untagged frames are classified as belonging to the receiving port's VLAN ID (PVID).

**Table 118: MAC Based VLAN Commands**

Command	Function	Mode
<code>mac-vlan</code>	Defines the IP Subnet VLANs	GC
<code>show mac-vlan</code>	Displays IP Subnet VLAN settings	PE

**mac-vlan** This command configures MAC address-to-VLAN mapping. Use the **no** form to remove an assignment.

### Syntax

**mac-vlan mac-address** *mac-address* [**mask** *mask-address*] **vlan** *vlan-id* [**priority** *priority*]

**no mac-vlan mac-address** {*mac-address* [**mask** *mask-address*] | **all**}

*mac-address* – The source MAC address to be matched. Configured MAC addresses can only be unicast addresses. The MAC address must be specified in the format xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx.

*mask-address* - Identifies a range of MAC addresses. The mask can be specified in the format xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx, where an equivalent binary value "1" means relevant and "0" means ignore.

*vlan-id* – VLAN to which the matching source MAC address traffic is forwarded. (Range: 1-4094)

*priority* – The priority assigned to untagged ingress traffic. (Range: 0-7, where 7 is the highest priority)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ The MAC-to-VLAN mapping applies to all ports on the switch.
- ◆ Source MAC addresses can be mapped to only one VLAN ID.
- ◆ Configured MAC addresses cannot be broadcast or multicast addresses.
- ◆ When MAC-based, IP subnet-based, and protocol-based VLANs are supported concurrently, priority is applied in this sequence, and then port-based VLANs last.
- ◆ The binary equivalent mask matching the characters in the front of the first non-zero character must all be 1s (e.g., 111, i.e., it cannot be 101 or 001...). A mask for the MAC address: 00-50-6e-00-5f-b1 translated into binary:  
MAC: 00000000-01010000-01101110-00000000-01011111-10110001  
could be: 11111111-11xxxxxx-xxxxxxxx-xxxxxxxx-xxxxxxxx-xxxxxxxx  
So the mask in hexadecimal for this example could be:  
ff-fx-xx-xx-xx-xx/ff-c0-00-00-00-00/ff-e0-00-00-00-00

### Example

The following example assigns traffic from source MAC address 00-00-00-11-22-33 to VLAN 10.

```
Console(config)#mac-vlan mac-address 00-00-00-11-22-33 mask FF-FF-FF-FF-00-00
vlan 10
Console(config)#
```

**show mac-vlan** This command displays MAC address-to-VLAN assignments.

### Command Mode

Privileged Exec

### Command Usage

Use this command to display MAC address-to-VLAN mappings.

### Example

The following example displays all configured MAC address-based VLANs.

```

Console#show mac-vlan
MAC Address          Mask                VLAN ID  Priority
-----
00-E0-4C-68-14-79  FF-FF-FF-FF-FF-FF  100      0
Console#

```

## Configuring Voice VLANs

The switch allows you to specify a Voice VLAN for the network and set a CoS priority for the VoIP traffic. VoIP traffic can be detected on switch ports by using the source MAC address of packets, or by using LLDP (IEEE 802.1AB) to discover connected VoIP devices. When VoIP traffic is detected on a configured port, the switch automatically assigns the port to the Voice VLAN. Alternatively, switch ports can be manually configured.

**Table 119: Voice VLAN Commands**

Command	Function	Mode
<code>voice vlan</code>	Defines the Voice VLAN ID	GC
<code>voice vlan aging</code>	Configures the aging time for Voice VLAN ports	GC
<code>voice vlan mac-address</code>	Configures VoIP device MAC addresses	GC
<code>switchport voice vlan</code>	Sets the Voice VLAN port mode	IC
<code>switchport voice vlan priority</code>	Sets the VoIP traffic priority for ports	IC
<code>switchport voice vlan rule</code>	Sets the automatic VoIP traffic detection method for ports	IC
<code>switchport voice vlan security</code>	Enables Voice VLAN security on ports	IC
<code>show voice vlan</code>	Displays Voice VLAN settings	PE

**voice vlan** This command enables VoIP traffic detection and defines the Voice VLAN ID. Use the **no** form to disable the Voice VLAN.

### Syntax

**voice vlan** *voice-vlan-id*

**no voice vlan**

*voice-vlan-id* - Specifies the voice VLAN ID. (Range: 1-4094)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ When IP telephony is deployed in an enterprise network, it is recommended to isolate the Voice over IP (VoIP) network traffic from other data traffic. Traffic isolation helps prevent excessive packet delays, packet loss, and jitter, which results in higher voice quality. This is best achieved by assigning all VoIP traffic to a single VLAN.
- ◆ VoIP traffic can be detected on switch ports by using the source MAC address of packets, or by using LLDP (IEEE 802.1AB) to discover connected VoIP devices. When VoIP traffic is detected on a configured port, the switch automatically assigns the port as a tagged member of the Voice VLAN.
- ◆ Only one Voice VLAN is supported and it must already be created on the switch before it can be specified as the Voice VLAN.
- ◆ The Voice VLAN ID cannot be modified when the global auto-detection status is enabled (see the [switchport voice vlan](#) command).

### Example

The following example enables VoIP traffic detection and specifies the Voice VLAN ID as 1234.

```
Console(config)#voice vlan 1234  
Console(config)#
```

**voice vlan aging** This command sets the Voice VLAN ID time out. Use the **no** form to restore the default.

### Syntax

**voice vlan aging** *minutes*

**no voice vlan**

*minutes* - Specifies the port Voice VLAN membership time out.  
(Range: 5-43200 minutes)

### Default Setting

1440 minutes

### Command Mode

Global Configuration

### Command Usage

The Voice VLAN aging time is the time after which a port is removed from the Voice VLAN when VoIP traffic is no longer received on the port.

The VoIP aging time starts to count down when the OUI's MAC address expires from the MAC address table. Therefore, the MAC address aging time should be added to the overall aging time. For example, if you configure the MAC address table aging time to 30 seconds, and voice VLAN aging time to 5 minutes, then after 5.5 minutes, a port will be removed from the voice VLAN when VoIP traffic is no longer received on the port. Alternatively, if you clear the MAC address table manually, then the switch will also start counting down the voice VLAN aging time.

Note that when the `switchport voice vlan` command is set to auto mode, the remaining aging time displayed by the `show voice vlan` command will be displayed. Otherwise, if the `switchport voice vlan` command is disabled or set to manual mode, the remaining aging time will display "NA."

### Example

The following example configures the Voice VLAN aging time as 3000 minutes.

```
Console(config)#voice vlan aging 3000
Console(config)#
```

**voice vlan mac-address** This command specifies MAC address ranges to add to the OUI Telephony list. Use the **no** form to remove an entry from the list.

### Syntax

**voice vlan mac-address** *mac-address* **mask** *mask-address*  
[**description** *description*]

**no voice vlan mac-address** *mac-address* **mask** *mask-address*

*mac-address* - Defines a MAC address OUI that identifies VoIP devices in the network. (Format: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx; for example, 01-23-45-00-00-00)

*mask-address* - Identifies a range of MAC addresses. (Range: 80-00-00-00-00-00 to FF-FF-FF-FF-FF-FF)

*description* - User-defined text that identifies the VoIP devices. (Range: 1-30 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ VoIP devices attached to the switch can be identified by the manufacturer's Organizational Unique Identifier (OUI) in the source MAC address of received packets. OUI numbers are assigned to manufacturers and form the first three octets of device MAC addresses. The MAC OUI numbers for VoIP equipment can be configured on the switch so that traffic from these devices is recognized as VoIP.
- ◆ Setting a mask of FF-FF-FF-00-00-00 identifies all devices with the same OUI (the first three octets). Other masks restrict the MAC address range. Setting a mask of FF-FF-FF-FF-FF-FF specifies a single MAC address.

### Example

The following example adds a MAC OUI to the OUI Telephony list.

```
Console(config)#voice vlan mac-address 00-12-34-56-78-90 mask ff-ff-ff-00-00-00 description "A new phone"
Console(config)#
```

**switchport voice vlan** This command specifies the Voice VLAN mode for ports. Use the **no** form to disable the Voice VLAN feature on the port.

### Syntax

**switchport voice vlan {manual | auto}**

**no switchport voice vlan**

**manual** - The Voice VLAN feature is enabled on the port, but the port must be manually added to the Voice VLAN.

**auto** - The port will be added as a tagged member to the Voice VLAN when VoIP traffic is detected on the port.

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Command Usage

- ◆ When auto is selected, you must select the method to use for detecting VoIP traffic, either OUI or 802.1AB (LLDP) using the [switchport voice vlan rule](#) command. When OUI is selected, be sure to configure the MAC address ranges in the Telephony OUI list using the [voice vlan mac-address](#) command.
- ◆ All ports are set to VLAN hybrid mode by default. Prior to enabling VoIP for a port (by setting the VoIP mode to Auto or Manual as described below), ensure that VLAN membership is not set to access mode using the [switchport mode](#) command.

### Example

The following example sets port 1 to Voice VLAN auto mode.

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport voice vlan auto
Console(config-if)#
```

**switchport voice vlan priority** This command specifies a CoS priority for VoIP traffic on a port. Use the **no** form to restore the default priority on a port.

### Syntax

**switchport voice vlan priority** *priority-value*

**no switchport voice vlan priority**

*priority-value* - The CoS priority value. (Range: 0-6)

### Default Setting

6

### Command Mode

Interface Configuration

### Command Usage

Specifies a CoS priority to apply to the port VoIP traffic on the Voice VLAN. The priority of any received VoIP packet is overwritten with the new priority when the Voice VLAN feature is active for the port.

### Example

The following example sets the CoS priority to 5 on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport voice vlan priority 5
Console(config-if)#
```

**switchport voice vlan rule** This command selects a method for detecting VoIP traffic on a port. Use the **no** form to disable the detection method on the port.

### Syntax

**[no] switchport voice vlan rule {oui | lldp}**

**oui** - Traffic from VoIP devices is detected by the Organizationally Unique Identifier (OUI) of the source MAC address.

**lldp** - Uses LLDP to discover VoIP devices attached to the port.

### Default Setting

OUI: Enabled  
LLDP: Disabled

### Command Mode

Interface Configuration

### Command Usage

- ◆ When OUI is selected, be sure to configure the MAC address ranges in the Telephony OUI list (see the [voice vlan mac-address](#) command). MAC address OUI numbers must be configured in the Telephony OUI list so that the switch recognizes the traffic as being from a VoIP device.
- ◆ LLDP checks that the “telephone bit” in the system capability TLV is turned on. See [“LLDP Commands” on page 811](#) for more information on LLDP.

### Example

The following example enables the OUI method on port 1 for detecting VoIP traffic.

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport voice vlan rule oui
Console(config-if)#
```

**switchport voice vlan security** This command enables security filtering for VoIP traffic on a port. Use the **no** form to disable filtering on a port.

### Syntax

**[no] switchport voice vlan security**

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Command Usage

- ◆ Security filtering discards any non-VoIP packets received on the port that are tagged with the voice VLAN ID. VoIP traffic is identified by source MAC addresses configured in the Telephony OUI list, or through LLDP that discovers VoIP devices attached to the switch. Packets received from non-VoIP sources are dropped.
- ◆ When enabled, be sure the MAC address ranges for VoIP devices are configured in the Telephony OUI list ([voice vlan mac-address](#)).

### Example

The following example enables security filtering on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport voice vlan security
Console(config-if)#
```

**show voice vlan** This command displays the Voice VLAN settings on the switch and the OUI Telephony list.

### Syntax

**show voice vlan {oui | status}**

**oui** - Displays the OUI Telephony list.

**status** - Displays the global and port Voice VLAN settings.

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

When the **switchport voice vlan** command is set to auto mode, the remaining aging time displayed by the **show voice vlan** command will be displayed (or "Not Start" will be displayed). Otherwise, if the switchport voice vlan command is disabled or set to manual mode, the remaining aging time will display "NA."

### Example

```
Console#show voice vlan status
Global Voice VLAN Status
Voice VLAN Status      : Enabled
Voice VLAN ID          : 1234
Voice VLAN aging time  : 1440 minutes

Voice VLAN Port Summary
Port      Mode      Security Rule      Priority Remaining Age
                                     (minutes)
-----
Eth 1/ 1 Auto      Enabled OUI                6 100
Eth 1/ 2 Disabled Disabled OUI            6 NA
Eth 1/ 3 Manual   Enabled OUI                5 100
Eth 1/ 4 Auto      Disabled OUI            6 Not Start
Eth 1/ 5 Disabled Disabled OUI            6 NA
Eth 1/ 6 Disabled Disabled OUI            6 NA
Eth 1/ 7 Disabled Disabled OUI            6 NA
.
.
.
```

```
Console#show voice vlan oui
OUI Address      Mask              Description
-----
00-12-34-56-78-9A FF-FF-FF-00-00-00 old phones
00-11-22-33-44-55 FF-FF-FF-00-00-00 new phones
00-98-76-54-32-10 FF-FF-FF-FF-FF-FF Chris' phone

Console#
```

## Configuring Excluded VLANs

Excluded VLANs provide port-based security and isolation between ports within an assigned session. An Excluded VLAN session contains Uplink ports that can communicate with all other ports in the session, and Downlink ports that can only communicate with Uplink ports in the session. The Uplink ports are intended to provide open access to an external network, such as the Internet, while the Downlink ports provide restricted access to local users.

Table 120: Excluded VLAN Commands

Command	Function	Mode
<code>excluded-vlan</code>	Configures an excluded VLAN session, including VLANs, uplink and downlink ports	GC
<code>show excluded-vlan</code>	Displays the configured excluded VLANs	PE

**excluded-vlan** This command configures an excluded VLAN session, including the VLAN ID, uplink ports, and downlink ports. Use the **no** form of the command to remove an excluded VLAN session.

### Syntax

**[no] excluded-vlan [session session-id] [vlan-id [vlan-mask]] {uplink interface-list [downlink interface-list] | downlink interface-list}**

*session-id* - Specifies the session ID. (Range: 1-4)

*vlan-id* - Specifies a VLAN ID. (Range: 1-4094)

*vlan-mask* - Specifies a binary bitmask that is applied to the VLAN ID to define a range of VLANs. When a bit of the VLAN Mask is 1, the value of the corresponding bit of the VLAN ID remains the same. When a bit of configured VLAN Mask is 0, the value of the corresponding bit of the VLAN ID is ignored. For example, a VLAN ID of 1 (000000000001) with a VLAN Mask of 4092 (111111111100) defines a range of VLAN IDs of 1-3. A VLAN Mask of 4095 (111111111111) defines a single VLAN ID. (Range: 0-4095)

*interface-list* -

**ethernet unit/port-list**

*unit* - Unit identifier. (Range: 1)

*port-list* - Physical port number or list of port numbers. Separate nonconsecutive port numbers with a comma and no spaces; or use a hyphen to designate a range of port numbers. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

No sessions configured.

### Command Mode

Global Configuration

### Command Usage

- ◆ An Excluded VLAN session consists of defined Downlink ports, Uplink ports, and VLANs. Up to 4 Excluded VLAN sessions can be configured on the switch, and up to 8 VLANs can be included in each session.
- ◆ Packets from a Downlink port can only be forwarded to Uplink ports in the same session.
- ◆ Packets from Uplink ports can be forwarded to any ports in the same session.
- ◆ Uplink and Dowlink interfaces can include configured port trunks.
- ◆ A specified Uplink or Dowlink interface can only be assigned to one Excluded VLAN session, it cannot be configured for multiple sessions at the same time.

### Example

```
Console(config)#excluded-vlan session 1 5 4095 uplink ethernet 1/6 downlink
ethernet 1/5

Console(config)#
```

**show excluded-vlan** This command displays the configured excluded VLANs on the switch.

### Syntax

**show excluded-vlan**

### Command Mode

Privileged Exec

### Example

```
Console#show excluded-vlan
```

Session	Uplink Ports	Downlink Ports	VLANs
1	Ethernet 1/6	Ethernet 1/5	5/4095

Console#

---

## ERPS Commands

The G.8032 recommendation, also referred to as Ethernet Ring Protection Switching (ERPS), can be used to increase the availability and robustness of Ethernet rings.

This chapter describes commands used to configure ERPS.

**Table 121: ERPS Commands**

Command	Function	Mode
<code>erps</code>	Enables ERPS globally on the switch	GC
<code>erps node-id</code>	Sets the MAC address for a ring node	GC
<code>erps vlan-group</code>	Creates ERPS VLAN groups to assign to rings or instances	GC
<code>erps ring</code>	Creates a physical ERPS ring and enters ERPS Ring Configuration mode	GC
<code>erps instance</code>	Creates an ERPS instance and enters ERPS Instance Configuration mode	GC
<code>ring-port</code>	Configures a node's connection to the ring through the east or west interface	ERPS Ring
<code>exclusion-vlan</code>	Specifies the VLANs to be excluded from the ERPS protection ring.	ERPS Ring
<code>enable (ring)</code>	Activates the current ERPS ring	ERPS Ring
<code>enable (instance)</code>	Activates the current ERPS instance	ERPS Inst
<code>meg-level</code>	Sets the Maintenance Entity Group level for a ring	ERPS Inst
<code>control-vlan</code>	Adds a Control VLAN to an ERPS ring	ERPS Inst
<code>rpl owner</code>	Configures a ring node to be the RPL owner	ERPS Inst
<code>rpl neighbor</code>	Configures a ring node to be the RPL neighbor	ERPS Inst
<code>wtr-timer</code>	Sets timer to verify that the ring has stabilized before blocking the RPL after recovery from a signal failure	ERPS Inst
<code>guard-timer</code>	Sets the timer to prevent ring nodes from receiving outdated R-APS messages	ERPS Inst
<code>holdoff-timer</code>	Sets the timer to filter out intermittent link faults	ERPS Inst
<code>major-ring</code>	Specifies the ERPS ring used for sending control packets	ERPS Inst
<code>propagate-tc</code>	Enables propagation of topology change messages from a secondary ring to the primary ring	ERPS Inst
<code>bpdu-tcn-notify</code>	Enables the transmission of TCN BPDUs on an EPRS instance	ERPS Inst
<code>non-revertive</code>	Enables non-revertive mode, which requires the protection state on the RPL to manually cleared	ERPS Inst

Table 121: ERPS Commands (Continued)

Command	Function	Mode
<code>raps-def-mac</code>	Sets the switch's MAC address to be used as the node identifier in R-APS messages	ERPS Inst
<code>raps-without-vc</code>	Terminates the R-APS channel at the primary ring to sub-ring interconnection nodes	ERPS Inst
<code>version</code>	Specifies compatibility with ERPS version 1 or 2	ERPS Inst
<code>inclusion-vlan</code>	Specifies the VLAN groups to be included in the ERPS protection ring.	ERPS Inst
<code>physical-ring</code>	Associates an ERPS instance with an existing physical ring	ERPS Inst
<code>erps forced-switch</code>	Blocks the specified ring port	PE
<code>erps manual-switch</code>	Blocks the specified ring port, in the absence of a failure or an <code>erps forced-switch</code> command	PE
<code>erps clear</code>	Manually clears protection state which has been invoked by a Forced Switch or Manual Switch command, and the node is operating under non-revertive mode; or before the WTR or WTB timer expires when the node is operating in revertive mode	PE
<code>clear erps statistics</code>	Clears statistics for all ERPS instances or a specific instance	PE
<code>show erps statistics</code>	Displays statistics for all configured instances, or for a specified instance	PE
<code>show erps</code>	Displays status information for all configured VLAN groups, rings, or instances.	PE

#### Configuration Guidelines for ERPS

1. Create an ERPS ring: Create a ring using the `erps ring` command. The ring name is used as an index in the G.8032 database.
2. Configure the east and west interfaces: Each node on the ring connects to it through two ring ports. Use the `ring-port` command to configure one port connected to the next node in the ring to the east (or clockwise direction); and then use the `ring-port` command again to configure another port facing west in the ring.
3. Configure VLAN groups to assign to specific ERPS instances using the `erps vlan-group` command.
4. Configure ERPS instances using the `erps instance` command and then associate the instances to a configured ring using the `physical-ring` command.
5. Configure the RPL owner: Configure one node in the ring as the Ring Protection Link (RPL) owner using the `rpl owner` command. When this switch is configured as the RPL owner, the west ring port is set as being connected to the RPL. Under normal operations (Idle state), the RPL is blocked to ensure that a loop cannot form in the ring. If a signal failure brings down any other link in the ring, the RPL will be unblocked (Protection state) to ensure proper connectivity among all ring nodes until the failure is recovered.

6. Configure ERPS timers: Use the `guard-timer` command to set the timer is used to prevent ring nodes from receiving outdated R-APS messages, the `holdoff-timer` command to filter out intermittent link faults, and the `wtr-timer` command to verify that the ring has stabilized before blocking the RPL after recovery from a signal failure.
7. Configure the ERPS Control VLAN (CVLAN): Use the `control-vlan` command to create the VLAN used to pass R-APS ring maintenance commands. The CVLAN must NOT be configured with an IP address. In addition, only ring ports may be added to the CVLAN (prior to configuring the VLAN as a CVLAN). No other ports can be members of this VLAN (once set as a CVLAN). Also, the ring ports of the CVLAN must be tagged. Failure to observe these restrictions can result in a loop in the network.
8. Enable ERPS: Before enabling a ring as described in the next step, first use the `erps` command to globally enable ERPS on the switch. If ERPS has not yet been enabled or has been disabled with the `no erps` command, no ERPS rings will work.
9. Enable ERPS rings and instances: Before an ERPS ring can work, it must be enabled using the `enable (ring)` command and specific instances enabled using the `enable (instance)` command. When configuration is completed and the ring enabled, R-APS messages will start flowing in the control VLAN, and normal traffic will begin to flow in the data VLANs. To stop a ring, it can be disabled on any node using the `no enable (ring)` command.
10. Display ERPS status information: Use the `show erps statistics` command to display general ERPS status information or detailed ERPS status information for a specific ring.

**erps** This command enables ERPS on the switch. Use the **no** form to disable this feature.

#### Syntax

**[no] erps**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

ERPS must be enabled globally on the switch before it can be enabled on an ERPS ring using the `enable (ring)` command.

### Example

```
Console(config)#erps
Console(config)#
```

### Related Commands

[enable \(ring\) \(626\)](#)

**erps node-id** This command sets the MAC address for a ring node. Use the **no** form to restore the default setting.

### Syntax

**erps node-id** *mac-address*

**no erps node-id**

*mac-address* – A MAC address unique to the ring node. The MAC address must be specified in the format xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx.

### Default Setting

CPU MAC address

### Command Mode

Global Configuration

### Command Usage

- ◆ The ring node identifier is used to identify a node in R-APS messages for both automatic and manual switching recovery operations.

For example, a node that has one ring port in SF condition and detects that the condition has been cleared, will continuously transmit R-APS (NR) messages with its own Node ID as priority information over both ring ports, informing its neighbors that no request is present at this node. When another recovered node holding the link blocked receives this message, it compares the Node ID information with its own. If the received R-APS (NR) message has a higher priority, this unblocks its ring ports. Otherwise, the block remains unchanged.

- ◆ The node identifier may also be used for debugging, such as to distinguish messages when a node is connected to more than one ring.

### Example

```
Console(config-erps)#node-id 00-12-CF-61-24-2D
Console(config-erps)#
```

**erps vlan-group** This command creates or modifies an ERPS VLAN group. Use the **no** form of this command to remove VLANs from a VLAN group or to delete a VLAN group.

### Syntax

**erps vlan-group** *vlan-group-name* {**add**|**remove**} *vlan-list*

**no erps vlan-group** *vlan-group-name*

*vlan-group-name* – Name of the VLAN group. (Range: 1-12 characters).

**add** – Adds VLANs to a group.

**remove** – Deletes VLANs from a group.

*vlan-list* – A single VLAN ID, a list of VLAN IDs separated by commas, or a range of VLANs defined by two VLAN IDs separated by a hyphen.

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ A set of VLANs in an Ethernet ring can be grouped into several subsets and applied to an ERPS instance.
- ◆ A VLAN group configuration is allowed to be deleted only if all associations are removed

### Example

```
Console(config)#erps vlan-group alpha add 2
Console(config)#
```

**erps ring** This command creates a physical ERPS ring and enters ERPS configuration mode for the specified ring. Use the **no** form to delete a physical ring.

### Syntax

[**no**] **erps ring** *ring-name*

*ring-name* - Name of a specific ERPS ring. (Range: 1-12 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#erps ring campus1
Console(config-erps-ring)#
```

**erps instance** This command creates an ERPS instance and enters ERPS instance configuration mode. Use the **no** form to delete an ERPS instance.

### Syntax

**erps instance** *instance-name* [**id** *ring-id*]

**no erps instance** *instance-name*

*instance-name* - Name of a specific ERPS instance. (Range: 1-12 characters)

*ring-id* - ERPS ring identifier used in R-APS messages. (Range: 1-255)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Service Instances within each ring are based on a unique maintenance association for the specific users, distinguished by the ring name, maintenance level, maintenance association's name, and assigned VLAN.
- ◆ R-APS information is carried in an R-APS PDUs. The last octet of the MAC address is designated as the Ring ID (01-19-A7-00-00-[Ring ID]). If use of the default MAC address is disabled with the **no raps-def-mac** command, then the Ring ID configured by the **erps instance** command will be used in R-APS PDUs.
- ◆ You must disable a running instance before modifying a Ring ID.

### Example

```
Console(config)#erps instance r&d id 1
Console(config-erps-inst)#
```

**ring-port** This command configures a node's connection to the ring through the east or west interface. Use the **no** form to disassociate a node from the ring.

### Syntax

**ring-port** {**east** | **west**} **interface** *interface*

**no ring-port** {**east** | **west**}

**east** - Connects to next ring node to the east.

**west** - Connects to next ring node to the west.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

Not associated

### Command Mode

ERPS Ring Configuration

### Command Usage

- ◆ Each node must be connected to two neighbors on the ring. For convenience, the ports connected are referred to as east and west ports. Alternatively, the closest neighbor to the east should be the next node in the ring in a clockwise direction, and the closest neighbor to the west should be the next node in the ring in a counter-clockwise direction.
- ◆ Note that a ring port cannot be configured as a member of a spanning tree, a dynamic trunk, or a static trunk.
- ◆ If a port channel (static trunk) is specified as a ring port, it can not be destroyed before it is removed from the domain configuration.
- ◆ A static trunk will be treated as a signal fault, if it contains no member ports or all of its member ports are in signal fault.
- ◆ If a static trunk is configured as a ring port prior to assigning any member ports, spanning tree will be disabled for the first member port assigned to the static trunk.

### Example

```
Console(config-erps-ring)#ring-port east interface ethernet 1/12
Console(config-erps-ring)#
```

**exclusion-vlan** Use this command to specify VLAN groups that are to be on the exclusion list of a physical ERPS ring. Use the **no** form of the command to remove VLAN groups from the list.

### Syntax

**[no] inclusion-vlan** *vlan-group-name*

*vlan-group-name* - Name of the VLAN group. (Range: 1-12 characters)

### Default Setting

None

### Command Mode

ERPS Ring Configuration

### Command Usage

- ◆ VLANs that are on the exclusion list are **not** protected by the ERPS ring.
- ◆ Any VLAN not listed on either the inclusion or exclusion list will be blocked on ring ports.
- ◆ Use the [show erps statistics](#) command to view the exclusion-vlan list of VLAN IDs.
- ◆ Traffic from control VLANs, inclusion VLANs, and exclusion VLANs of an ERPS ring will be forwarded by non-ERPS ring ports.

### Example

```
Console(config-erps)#exclusion-vlan vlgroup3
Console(config-erps)#
```

**enable (ring)** This command activates the current ERPS ring. Use the **no** form to disable the current ring.

### Syntax

**[no] enable**

### Default Setting

Disabled

### Command Mode

ERPS Ring Configuration

### Command Usage

- ◆ Before enabling a ring, the global ERPS function should be enabled with the [erps](#) command, the east and west ring ports configured on each node with the [ring-port](#) command, the RPL owner specified with the [rpl owner](#) command, and the control VLAN configured with the [control-vlan](#) command.

- ◆ Once enabled, the RPL owner node and non-owner node state machines will start, and the ring will enter idle state if no signal failures are detected.

### Example

```
Console(config-erps-ring)#enable
Console(config-erps-ring)#
```

### Related Commands

[erps \(621\)](#)

**enable (instance)** This command activates the current ERPS instance. Use the **no** form to disable the current instance.

### Syntax

**[no] enable**

### Default Setting

Disabled

### Command Mode

ERPS Instance Configuration

### Command Usage

- ◆ Before enabling an instance, the global ERPS function should be enabled with the [erps](#) command, the ring enabled with the [enable \(ring\)](#) command, the east and west ring ports configured on each node with the [ring-port](#) command, the RPL owner specified with the [rpl owner](#) command, and the control VLAN configured with the [control-vlan](#) command.
- ◆ Once enabled, the RPL owner node and non-owner node state machines will start, and the instance will enter idle state if no signal failures are detected.

### Example

```
Console(config-erps-inst)#enable
Console(config-erps-inst)#
```

### Related Commands

[erps \(621\)](#)

**meg-level** This command sets the Maintenance Entity Group level for an instance. Use the **no** form to restore the default setting.

### Syntax

**meg-level** *level*

**no meg-level**

*level* - The maintenance entity group (MEG) level which provides a communication channel for ring automatic protection switching (R-APS) information. (Range: 0-7)

**Default Setting**

1

**Command Mode**

ERPS Instance Configuration

**Command Usage**

- ◆ This parameter is used to ensure that received R-APS PDUs are directed for this instance. A unique level should be configured for each local instance if there are many R-APS PDUs passing through this switch.

**Example**

```
Console(config-erps) #meg-level 0
Console(config-erps) #
```

**control-vlan** This command specifies a dedicated VLAN used for sending and receiving ERPS protocol messages. Use the **no** form to remove the Control VLAN.

**Syntax**

**control-vlan** *vlan-id*

**no control-vlan**

*vlan-id* - VLAN ID (Range: 1-4094)

**Default Setting**

None

**Command Mode**

ERPS Instance Configuration

**Command Usage**

- ◆ The Control VID must be included in one of inclusion VLAN groups.
- ◆ Configure one control VLAN for each ERPS instance. First create the VLAN to be used as the control VLAN ([vlan](#), [page 577](#)), add the VLAN to an ERPS VLAN group ([erps vlan-group](#)), add the ring ports for the east and west interface as tagged members to this VLAN ([switchport allowed vlan](#), [page 580](#)), and then use the [control-vlan](#) command to add it to the ERPS instance.
- ◆ The following restrictions are recommended to avoid creating a loop in the network or other problems which may occur under some situations:

- The Control VLAN must not be configured as a Layer 3 interface (with an IP address), nor as a dynamic VLAN (with GVRP enabled).
  - In addition, only ring ports may be added to the Control VLAN. No other ports can be members of this VLAN.
  - Also, the ring ports of the Control VLAN must be tagged.
- ◆ Once the instance has been activated with the `enable (instance)` command, the configuration of the control VLAN cannot be modified. Use the `no enable (ring)` command to stop the ERPS instance before making any configuration changes to the control VLAN.

### Example

```

Console(config)#vlan database
Console(config-vlan)#vlan 2 name rdc media ethernet state active
Console(config-vlan)#exit
Console(config)#interface ethernet 1/12
Console(config-if)#switchport allowed vlan add 2 tagged
Console(config-if)#interface ethernet 1/11
Console(config-if)#switchport allowed vlan add 2 tagged
Console(config-if)#exit
Console(config)#erps vlan-group alpha add 2
Console(config)#erps instance rd1
Console(config-erps-inst)#control-vlan 2
Console(config-erps-inst)#

```

**rpl owner** This command configures a ring node to be the Ring Protection Link (RPL) owner. Use the **no** form to restore the default setting.

### Syntax

**rpl owner**

**no rpl**

### Default Setting

None (that is, neither owner nor neighbor)

### Command Mode

ERPS Instance Configuration

### Command Usage

- ◆ Only one RPL owner can be configured on an instance. The owner blocks traffic on the RPL during Idle state, and unblocks it during Protection state (that is, when a signal fault is detected on the instance or the protection state is enabled with the `erps forced-switch` or `erps manual-switch` command).
- ◆ The east and west connections to the instance must be specified for all ring nodes using the `ring-port` command. When this switch is configured as the RPL owner, the west ring port is automatically set as being connected to the RPL.

### Example

```
Console(config-erps-inst)#rpl owner
Console(config-erps-inst)#
```

**rpl neighbor** This command configures a ring node to be the Ring Protection Link (RPL) neighbor. Use the **no** form to restore the default setting.

### Syntax

**rpl neighbor**

**no rpl**

### Default Setting

None (that is, neither owner nor neighbor)

### Command Mode

ERPS Instance Configuration

### Command Usage

- ◆ The RPL neighbor node, when configured, is a ring node adjacent to the RPL that is responsible for blocking its end of the RPL under normal conditions (i.e., the instance is established and no requests are present in the instance) in addition to the block at the other end by the RPL Owner Node. The RPL neighbor node may participate in blocking or unblocking its end of the RPL, but is not responsible for activating the reversion behavior.
- ◆ Only one RPL owner can be configured on an instance. If the switch is set as the RPL owner for an ERPS ring, the west ring port is set as one end of the RPL. If the switch is set as the RPL neighbor for an ERPS ring, the east ring port is set as the other end of the RPL.
- ◆ The east and west connections to the ring must be specified for all ring nodes using the [ring-port](#) command. When this switch is configured as the RPL neighbor, the east ring port is set as being connected to the RPL.
- ◆ Note that is not mandatory to declare an RPL neighbor.

### Example

```
Console(config-erps-inst)#rpl neighbor
Console(config-erps-inst)#
```

**wtr-timer** This command sets the wait-to-restore timer which is used to verify that the ring has stabilized before blocking the RPL after recovery from a signal failure. Use the **no** form to restore the default setting.

### Syntax

**wtr-timer** *minutes*

**no wtr-timer**

*minutes* - The wait-to-restore timer is used to verify that the ring has stabilized before blocking the RPL after recovery from a signal failure. (Range: 1-12 minutes)

### Default Setting

5 minutes

### Command Mode

ERPS Instance Configuration

### Command Usage

If the switch goes into ring protection state due to a signal failure, after the failure condition is cleared, the RPL owner will start the wait-to-restore timer and wait until it expires to verify that the ring has stabilized before blocking the RPL and returning to the Idle (normal operating) state.

### Example

```
Console(config-erps-inst)#wtr-timer 10
Console(config-erps-inst)#
```

**guard-timer** This command sets the guard timer to prevent ring nodes from receiving outdated R-APS messages. Use the **no** form to restore the default setting.

### Syntax

**guard-timer** *milliseconds*

**no guard-timer**

*milliseconds* - The guard timer is used to prevent ring nodes from receiving outdated R-APS messages. During the duration of the guard timer, all received R-APS messages are ignored by the ring protection control process, giving time for old messages still circulating on the ring to expire. (Range: 10-2000 milliseconds, in steps of 10 milliseconds)

### Default Setting

500 milliseconds

### Command Mode

ERPS Instance Configuration

### Command Usage

The guard timer duration should be greater than the maximum expected forwarding delay for an R-APS message to pass around the ring. A side-effect of the guard timer is that during its duration, a node will be unaware of new or existing ring requests transmitted from other nodes.

### Example

```
Console(config-erps-inst)#guard-timer 300
Console(config-erps-inst)#
```

**holdoff-timer** This command sets the timer to filter out intermittent link faults. Use the **no** form to restore the default setting.

### Syntax

**holdoff-timer** *milliseconds*

**no holdoff-timer**

*milliseconds* - The hold-off timer is used to filter out intermittent link faults. Faults will only be reported to the ring protection mechanism if this timer expires. (Range: 0-10000 milliseconds, in steps of 100 milliseconds)

### Default Setting

0 milliseconds

### Command Mode

ERPS Instance Configuration

### Command Usage

In order to coordinate timing of protection switches at multiple layers, a hold-off timer may be required. Its purpose is to allow, for example, a server layer protection switch to have a chance to fix the problem before switching at a client layer.

When a new defect or more severe defect occurs (new Signal Failure), this event will not be reported immediately to the protection switching mechanism if the provisioned hold-off timer value is non-zero. Instead, the hold-off timer will be started. When the timer expires, whether a defect still exists or not, the timer will be checked. If one does exist, that defect will be reported to the protection switching mechanism. The reported defect need not be the same one that started the timer.

### Example

```
Console(config-erps-inst)#holdoff-timer 300
Console(config-erps-inst)#
```

**major-ring** This command specifies the ERPS ring used for sending control packets. Use the **no** form to remove the current setting.

#### Syntax

**major-ring** *instance-name*

**no major-ring**

*instance-name* - Name of the ERPS instance used for sending control packets. (Range: 1-12 characters)

#### Default Setting

None

#### Command Mode

ERPS Instance Configuration

#### Command Usage

- ◆ ERPS control packets can only be sent on one instance. This command is used to indicate that the current instance is a secondary ring, and to specify the major instance which will be used to send ERPS control packets.
- ◆ The Ring Protection Link (RPL) is the west port and can not be configured. So the physical port on a secondary instance must be the west port. In other words, if a domain has two physical ring ports, this instance can only be a major ring, not a secondary ring (or sub-domain) which can have only one physical ring port. This command will therefore fail if the east port is already configured (see the [ring-port](#) command).

#### Example

```
Console(config-erps-inst)#major-domain rd0
Console(config-erps-inst)#
```

**propagate-tc** This command enables propagation of topology change messages for a secondary ring to the primary ring. Use the **no** form to disable this feature.

#### Syntax

**[no] propagate-tc**

#### Default Setting

Disabled

#### Command Mode

ERPS Instance Configuration

**Command Usage**

- ◆ When a secondary ring detects a topology change, it can pass a message about this event to the major ring. When the major ring receives this kind of message from a secondary ring, it can clear the MAC addresses on its ring ports to help the secondary ring restore its connections more quickly through protection switching.
- ◆ When the MAC addresses are cleared, data traffic may flood onto the major ring. The data traffic will become stable after the MAC addresses are learned again. The major ring will not be broken, but the bandwidth of data traffic on the major ring may suffer for a short period of time due to this flooding behavior.

**Example**

```
Console(config-erps-inst)#propagate-tc
Console(config-erps-inst)#
```

**bpdu-tcn-notify** This command configures an ERPS instance to send BPDU TCN notifications. Use the **no** form of this command to disable BPDU TCN notifications.

**Syntax**

**[no] bpdu-tcn-notify**

**Default Setting**

Disabled

**Command Mode**

ERPS Instance Configuration

**Command Usage**

When enabled, Spanning Tree topology change notification (TCN) BPDUs are transmitted when an ERPS forwarding database (FDB) flush occurs on a ring instance.

**Example**

```
Console(config-erps-inst)#bpdu-tcn-notify
Console(config-erps-inst)#
```

**non-revertive** This command enables non-revertive mode, which requires the protection state on the RPL to manually cleared. Use the **no** form to restore the default revertive mode.

**Syntax**

**[no] non-revertive**

**Default Setting**

Disabled

**Command Mode**

ERPS Instance Configuration

**Command Usage**

- ◆ Revertive behavior allows the switch to automatically return the RPL from Protection state to Idle state through the exchange of protocol messages.

Non-revertive behavior for Protection, Forced Switch, and Manual Switch states are basically the same. Non-revertive behavior requires the [erps clear](#) command to be used to return the RPL from Protection state to Idle state.

- ◆ Recovery for Protection Switching – A ring node that has one or more ring ports in an SF (Signal Fail) condition, upon detecting the SF condition cleared, keeps at least one of its ring ports blocked for the traffic channel and for the R-APS channel, until the RPL is blocked as a result of ring protection reversion, or until there is another higher priority request (e.g., an SF condition) in the ring.

A ring node that has one ring port in an SF condition and detects the SF condition cleared, continuously transmits the R-APS (NR – no request) message with its own Node ID as the priority information over both ring ports, informing that no request is present at this ring node and initiates a guard timer. When another recovered ring node (or nodes) holding the link block receives this message, it compares the Node ID information with its own Node ID. If the received R-APS (NR) message has the higher priority, this ring node unblocks its ring ports. Otherwise, the block remains unchanged. As a result, there is only one link with one end blocked.

The ring nodes stop transmitting R-APS (NR) messages when they accept an R-APS (NR, RB – RPL Blocked), or when another higher priority request is received.

- Recovery with Revertive Mode – When all ring links and ring nodes have recovered and no external requests are active, reversion is handled in the following way:
  - a. The reception of an R-APS (NR) message causes the RPL Owner Node to start the WTR (Wait-to-Restore) timer.
  - b. The WTR timer is cancelled if during the WTR period a higher priority request than NR is accepted by the RPL Owner Node or is declared locally at the RPL Owner Node.
  - c. When the WTR timer expires, without the presence of any other higher priority request, the RPL Owner Node initiates reversion by blocking its traffic channel over the RPL, transmitting an R-APS (NR, RB) message over both ring ports, informing the ring that the RPL is blocked, and performing a flush FDB action.
  - d. The acceptance of the R-APS (NR, RB) message causes all ring nodes to unblock any blocked non-RPL link that does not have an SF condition. If

it is an R-APS (NR, RB) message without a DNF (do not flush) indication, all ring nodes flush the FDB.

- Recovery with Non-revertive Mode – In non-revertive operation, the ring does not automatically revert when all ring links and ring nodes have recovered and no external requests are active. Non-revertive operation is handled in the following way:
  - a. The RPL Owner Node does not generate a response on reception of an R-APS (NR) messages.
  - b. When other healthy ring nodes receive the NR (Node ID) message, no action is taken in response to the message.
  - c. When the operator issues the `erps clear` command for non-revertive mode at the RPL Owner Node, the non-revertive operation is cleared, the RPL Owner Node blocks its RPL port, and transmits an R-APS (NR, RB) message in both directions, repeatedly.
  - d. Upon receiving an R-APS (NR, RB) message, any blocking node should unblock its non-failed ring port. If it is an R-APS (NR, RB) message without a DNF indication, all ring nodes flush the FDB.
- ◆ Recovery for Forced Switching – An `erps forced-switch` command is removed by issuing the `erps clear` command to the same ring node where Forced Switch mode is in effect. The clear command removes any existing local operator commands, and triggers reversion if the ring is in revertive behavior mode.

The ring node where the Forced Switch was cleared keeps the ring port blocked for the traffic channel and for the R-APS channel, due to the previous Forced Switch command. This ring port is kept blocked until the RPL is blocked as a result of ring protection reversion, or until there is another higher priority request (e.g., an SF condition) in the ring.

The ring node where the Forced Switch was cleared continuously transmits the R-APS (NR) message on both ring ports, informing other nodes that no request is present at this ring node. The ring nodes stop transmitting R-APS (NR) messages when they accept an RAPS (NR, RB) message, or when another higher priority request is received.

If the ring node where the Forced Switch was cleared receives an R-APS (NR) message with a Node ID higher than its own Node ID, it unblocks any ring port which does not have an SF condition and stops transmitting R-APS (NR) message over both ring ports.

- Recovery with revertive mode is handled in the following way:
  - a. The reception of an R-APS (NR) message causes the RPL Owner Node to start the WTB timer.
  - b. The WTB timer is canceled if during the WTB period a higher priority request than NR is accepted by the RPL Owner Node or is declared locally at the RPL Owner Node.
  - c. When the WTB timer expires, in the absence of any other higher priority request, the RPL Owner Node initiates reversion by blocking the traffic

channel over the RPL, transmitting an R-APS (NR, RB) message over both ring ports, informing the ring that the RPL is blocked, and flushes the FDB.

- d. The acceptance of the R-APS (NR, RB) message causes all ring nodes to unblock any blocked non-RPL that does not have an SF condition. If it is an R-APS (NR, RB) message without a DNF indication, all ring nodes flush their FDB. This action unblocks the ring port which was blocked as a result of an operator command.
- Recovery with non-revertive mode is handled in the following way:
    - a. The RPL Owner Node, upon reception of an R-APS(NR) message and in the absence of any other higher priority request does not perform any action.
    - b. Then, after the operator issues the `erps clear` command at the RPL Owner Node, this ring node blocks the ring port attached to the RPL, transmits an R-APS (NR, RB) message on both ring ports, informing the ring that the RPL is blocked, and flushes its FDB.
    - c. The acceptance of the R-APS (NR, RB) message triggers all ring nodes to unblock any blocked non-RPL which does not have an SF condition. If it is an R-APS (NR, RB) message without a DNF indication, all ring nodes flush their FDB. This action unblocks the ring port which was blocked as result of an operator command.
- ◆ Recovery for Manual Switching – An `erps manual-switch` command is removed by issuing the `erps clear` command at the same ring node where the Manual Switch is in effect. The clear command removes any existing local operator commands, and triggers reversion if the ring is in revertive behavior mode.

The ring node where the Manual Switch was cleared keeps the ring port blocked for the traffic channel and for the R-APS channel, due to the previous Manual Switch command. This ring port is kept blocked until the RPL is blocked as a result of ring protection reversion, or until there is another higher priority request (e.g., an SF condition) in the ring.

The Ethernet Ring Node where the Manual Switch was cleared continuously transmits the R-APS (NR) message on both ring ports, informing that no request is present at this ring node. The ring nodes stop transmitting R-APS (NR) messages when they accept an RAPS (NR, RB) message, or when another higher priority request is received.

If the ring node where the Manual Switch was cleared receives an R-APS (NR) message with a Node ID higher than its own Node ID, it unblocks any ring port which does not have an SF condition and stops transmitting R-APS (NR) message on both ring ports.

- Recovery with revertive mode is handled in the following way:
  - a. The RPL Owner Node, upon reception of an R-APS (NR) message and in the absence of any other higher priority request, starts the WTB timer and waits for it to expire. While the WTB timer is running, any latent R-

APS (MS) message is ignored due to the higher priority of the WTB running signal.

- b.** When the WTB timer expires, it generates the WTB expire signal. The RPL Owner Node, upon reception of this signal, initiates reversion by blocking the traffic channel on the RPL, transmitting an R-APS (NR, RB) message over both ring ports, informing the ring that the RPL is blocked, and flushes its FDB.
  - c.** The acceptance of the R-APS (NR, RB) message causes all ring nodes to unblock any blocked non-RPL that does not have an SF condition. If it is an R-APS (NR, RB) message without a DNF indication, all Ethernet Ring Nodes flush their FDB. This action unblocks the ring port which was blocked as a result of an operator command.
- Recovery with non-revertive mode is handled in the following way:
    - a.** The RPL Owner Node, upon reception of an R-APS (NR) message and in the absence of any other higher priority request does not perform any action.
    - b.** Then, after the operator issues the `erps clear` command at the RPL Owner Node, this ring node blocks the ring port attached to the RPL, transmits an R-APS (NR, RB) message over both ring ports, informing the ring that the RPL is blocked, and flushes its FDB.
    - c.** The acceptance of the R-APS (NR, RB) message triggers all ring nodes to unblock any blocked non-RPL which does not have an SF condition. If it is an R-APS (NR, RB) message without a DNF indication, all ring nodes flush their FDB. This action unblocks the ring port which was blocked as result of an operator command.

### Example

```
Console(config-erps-inst)#non-revertive
Console(config-erps-inst)#
```

**raps-def-mac** This command sets the switch's MAC address to be used as the node identifier in R-APS messages. Use the **no** form to use the node identifier specified in the G8032 standards.

### Syntax

**[no] raps-def-mac**

### Default Setting

Enabled

### Command Mode

ERPS Instance Configuration

### Command Usage

- ◆ When ring nodes running ERPSv1 and ERPSv2 co-exist on the same ring, the Ring ID of each ring node must be configured as “1”.
- ◆ If this command is disabled, the following strings are used as the node identifier:
  - ERPSv1: 01-19-A7-00-00-01
  - ERPSv2: 01-19-A7-00-00-[Ring ID]

### Example

```
Console(config-erps-inst)#raps-def-mac
Console(config-erps-inst)#
```

**raps-without-vc** This command terminates the R-APS channel at the primary ring to sub-ring interconnection nodes. Use the **no** form to restore the default setting.

### Syntax

**[no] raps-without-vc**

### Default Setting

R-APS with Virtual Channel

### Command Mode


ERPS Instance Configuration

### Command Usage

- ◆ A sub-ring may be attached to a primary ring with or without a virtual channel. A virtual channel is used to connect two interconnection points on the sub-ring, tunneling R-APS control messages across an arbitrary Ethernet network topology. If a virtual channel is not used to cross the intermediate Ethernet network, data in the traffic channel will still flow across the network, but the all R-APS messages will be terminated at the interconnection points.
- ◆ Sub-ring with R-APS Virtual Channel – When using a virtual channel to tunnel R-APS messages between interconnection points on a sub-ring, the R-APS virtual channel may or may not follow the same path as the traffic channel over the network. R-APS messages that are forwarded over the sub-ring’s virtual channel are broadcast or multicast over the interconnected network. For this reason the broadcast/multicast domain of the virtual channel should be limited to the necessary links and nodes. For example, the virtual channel could span only the interconnecting rings or sub-rings that are necessary for forwarding R-APS messages of this sub-ring. Care must also be taken to ensure that the local RAPS messages of the sub-ring being transported over the virtual channel into the interconnected network can be uniquely distinguished from those of other interconnected ring R-APS messages. This can be achieved by, for example, by using separate VIDs for the virtual channels of different sub-rings.

Note that the R-APS virtual channel requires a certain amount of bandwidth to forward R-APS messages on the interconnected Ethernet network where a sub-ring is attached. Also note that the protection switching time of the sub-ring may be affected if R-APS messages traverse a long distance over an R-APS virtual channel.


**Figure 8: Sub-ring with Virtual Channel**



- ◆ **Sub-ring without R-APS Virtual Channel** – Under certain circumstances it may not be desirable to use a virtual channel to interconnect the sub-ring over an arbitrary Ethernet network. In this situation, the R-APS messages are terminated on the interconnection points. Since the sub-ring does not provide an R-APS channel nor R-APS virtual channel beyond the interconnection points, R-APS channel blocking is not employed on the normal ring links to avoid channel segmentation. As a result, a failure at any ring link in the sub-ring will cause the R-APS channel of the sub-ring to be segmented, thus preventing R-APS message exchange between some of the sub-ring's ring nodes.

No R-APS messages are inserted or extracted by other rings or sub-rings at the interconnection nodes where a sub-ring is attached. Hence there is no need for either additional bandwidth or for different VIDs/Ring IDs for the ring interconnection. Furthermore, protection switching time for a sub-ring is independent from the configuration or topology of the interconnected rings. In addition, this option always ensures that an interconnected network forms a tree topology regardless of its interconnection configuration. This means that it is not necessary to take precautions against forming a loop which is potentially composed of a whole interconnected network.

Figure 9: Sub-ring without Virtual Channel



### Example

```
Console(config-erps-inst)#raps-without-vc
Console(config-erps-inst)#
```

**version** This command specifies compatibility with ERPS version 1 or 2.

### Syntax

**version** {1 | 2}

**no version**

1 - ERPS version 1 based on ITU-T G.8032/Y.1344.

2 - ERPS version 2 based on ITU-T G.8032/Y.1344 Version 2.

### Default Setting

2

### Command Mode

ERPS Instance Configuration

### Command Usage

- ◆ In addition to the basic features provided by version 1, version 2 also supports:
  - Multi-ring/ladder network support
  - Revertive/Non-revertive recovery
  - Forced Switch (FS) and Manual Switch (MS) commands for manually blocking a particular ring port
  - Flush FDB (forwarding database) logic which reduces amount of flush FDB operations in the ring
  - Support of multiple ERP instances on a single ring
- ◆ Version 2 is backward compatible with Version 1. If version 2 is specified, the inputs and commands are forwarded transparently. If set to version 1, MS and FS operator commands are filtered, and the switch set to revertive mode.

- ◆ The version number is automatically set to “1” when a ring node, supporting only the functionalities of G.8032v1, exists on the same ring with other nodes that support G.8032v2.
- ◆ When ring nodes running G.8032v1 and G.8032v2 co-exist on a ring, the ring ID of each node is configured as “1”.
- ◆ In version 1, the MAC address 01-19-A7-00-00-01 is used for the node identifier. The `raps-def-mac` command has no effect.

### Example

```
Console(config-erps-inst)#version 1
Console(config-erps-inst)#
```

**inclusion-vlan** Use this command to specify VLAN groups that are to be on the inclusion list of an ERPS instance. Use the **no** form of the command to removed the VLAN from the list.

### Syntax

**[no] inclusion-vlan** *vlan-group-name*

*vlan-group-name* - Name of the VLAN group. (Range: 1-12 characters).

### Default Setting

None

### Command Mode

ERPS Instance Configuration

### Command Usage

- ◆ VLANs that are on the inclusion list are protected by the ERPS instance.
- ◆ Any VLAN not listed on either the inclusion or exclusion list will be blocked on ring ports.
- ◆ Use the `show erps statistics` command to view the inclusion-vlan list of VLAN IDs.
- ◆ Traffic from control VLANs, inclusion VLANs, and exclusion VLANs of an ERPS instance will be forwarded by non-ERPS ring ports.

### Example

```
Console(config-erps-inst)#inclusion-vlan vlgroup3
Console(config-erps-inst)#
```

**physical-ring** Use this command to associate an ERPS instance with an existing physical ring. Use the **no** form of the command to removed the association.

#### Syntax

**physical-ring** *ring-name*

**no physical-ring**

*ring-name* - Name of a specific ERPS ring. (Range: 1-12 characters)

#### Default Setting

None

#### Command Mode

ERPS Instance Configuration

#### Command Usage

The physical ring name must first be defined using the [erps ring](#) command.

#### Example

```
Console(config-erps-inst)#physical-ring campus1
Console(config-erps-inst)#
```

**erps forced-switch** This command blocks the specified ring port.

#### Syntax

**erps forced-switch instance** *instance-name* {**east** | **west**}

*instance-name* - Name of a specific ERPS instance. (Range: 1-12 characters)

**east** - East ring port.

**west** - West ring port.

#### Command Mode

Privileged Exec

#### Command Usage

- ◆ A ring with no pending request has a logical topology with the traffic channel blocked at the RPL and unblocked on all other ring links. In this situation, the **erps forced-switch** command triggers protection switching as follows:
  - a. The ring node where a forced switch command was issued blocks the traffic channel and R-APS channel on the ring port to which the command was issued, and unblocks the other ring port.
  - b. The ring node where the forced switch command was issued transmits R-APS messages indicating FS over both ring ports. R-APS (FS) messages are

continuously transmitted by this ring node while the local FS command is the ring node's highest priority command (see [Table 122 on page 644](#)). The R-APS (FS) message informs other ring nodes of the FS command and that the traffic channel is blocked on one ring port.

- c. A ring node accepting an R-APS (FS) message, without any local higher priority requests unblocks any blocked ring port. This action subsequently unblocks the traffic channel over the RPL.
  - d. The ring node accepting an R-APS (FS) message, without any local higher priority requests stops transmission of R-APS messages.
  - e. The ring node receiving an R-APS (FS) message flushes its FDB.
- ◆ Protection switching on a forced switch request is completed when the above actions are performed by each ring node. At this point, traffic flows around the ring are resumed. From this point on the following rules apply regarding processing of further forced switch commands:

While an existing forced switch request is present in a ring, any new forced switch request is accepted, except on a ring node having a prior local forced switch request. The ring nodes where further forced switch commands are issued block the traffic channel and R-APS channel on the ring port at which the forced switch was issued. The ring node where the forced switch command was issued transmits an R-APS message over both ring ports indicating FS. R-APS (FS) messages are continuously transmitted by this ring node while the local FS command is the ring node's highest priority command. As such, two or more forced switches are allowed in the ring, which may inadvertently cause the segmentation of an ring. It is the responsibility of the operator to prevent this effect if it is undesirable.

Ring protection requests, commands and R-APS signals have the priorities as specified in the following table.

**Table 122: ERPS Request/State Priority**

Request / State and Status	Type	Priority
Clear	local	highest
FS	local	
R-APS (FS)	remote	
local SF*	local	
local clear SF	local	
R-APS (SF)	remote	
R-APS (MS)	remote	
MS	local	
WTR Expires	local	
WTR Running	local	

Table 122: ERPS Request/State Priority (Continued)

Request / State and Status	Type	Priority
WTB Expires	local	
WTB Running	local	
R-APS (NR, RB)	remote	
R-APS (NR)	remote	lowest

\* If an Ethernet Ring Node is in the Forced Switch state, local SF is ignored.

- ◆ Recovery for forced switching under revertive and non-revertive mode is described under the Command Usage section for the [non-revertive](#) command.
- ◆ When a ring is under an FS condition, and the node at which an FS command was issued is removed or fails, the ring remains in FS state because the FS command can only be cleared at node where the FS command was issued. This results in an unrecoverable FS condition.

When performing a maintenance procedure (e.g., replacing, upgrading) on a ring node (or a ring link), it is recommended that FS commands be issued at the two adjacent ring nodes instead of directly issuing a FS command at the ring node under maintenance in order to avoid falling into the above mentioned unrecoverable situation.

### Example

```
Console#erps forced-switch instance r&d west
Console#
```

**erps manual-switch** This command blocks the specified ring port, in the absence of a failure or an [erps forced-switch](#) command.

### Syntax

**erps manual-switch instance** *instance-name* {**east** | **west**}

*instance-name* - Name of a specific ERPS instance. (Range: 1-12 characters)

**east** - East ring port.

**west** - West ring port.

### Command Mode

Privileged Exec

### Command Usage

- ◆ A ring with no request has a logical topology with the traffic channel blocked at the RPL and unblocked on all other ring links. In this situation, the **erps manual-switch** command triggers protection switching as follows:

- a. If no other higher priority commands exist, the ring node, where a manual switch command was issued, blocks the traffic channel and R-APS channel on the ring port to which the command was issued, and unblocks the other ring port.
  - b. If no other higher priority commands exist, the ring node where the manual switch command was issued transmits R-APS messages over both ring ports indicating MS. R-APS (MS) message are continuously transmitted by this ring node while the local MS command is the ring node's highest priority command (see [Table 122 on page 644](#)). The R-APS (MS) message informs other ring nodes of the MS command and that the traffic channel is blocked on one ring port.
  - c. If no other higher priority commands exist and assuming the ring node was in Idle state before the manual switch command was issued, the ring node flushes its local FDB.
  - d. A ring node accepting an R-APS (MS) message, without any local higher priority requests unblocks any blocked ring port which does not have an SF condition. This action subsequently unblocks the traffic channel over the RPL.
  - e. A ring node accepting an R-APS (MS) message, without any local higher priority requests stops transmitting R-APS messages.
  - f. A ring node receiving an R-APS (MS) message flushes its FDB.
- ◆ Protection switching on a manual switch request is completed when the above actions are performed by each ring node. At this point, traffic flows around the ring are resumed. From this point on, the following rules apply regarding processing of further manual switch commands:
    - a. While an existing manual switch request is present in the ring, any new manual switch request is rejected. The request is rejected at the ring node where the new request is issued and a notification is generated to inform the operator that the new MS request was not accepted.
    - b. A ring node with a local manual switch command which receives an R-APS (MS) message with a different Node ID clears its manual switch request and starts transmitting R-APS (NR) messages. The ring node keeps the ring port blocked due to the previous manual switch command.
    - c. An ring node with a local manual switch command that receives an R-APS message or a local request of higher priority than R-APS (MS) clear its manual switch request. The ring node then processes the new higher priority request.
  - ◆ Recovery for manual switching under revertive and non-revertive mode is described under the Command Usage section for the [non-revertive](#) command.

### Example

```
Console#erps manual-switch instance r&d west
Console#
```

**erps clear** This command manually clears the protection state which has been invoked by a forced switch or manual switch command, and the node is operating under non-revertive mode; or before the WTR or WTB timer expires when the node is operating in revertive mode.

### Syntax

**erps clear instance** *instance-name*

*instance-name* - Name of a specific ERPS instance. (Range: 1-12 characters)

### Command Mode

Privileged Exec

### Command Usage

- ◆ Two steps are required to make a ring operating in non-revertive mode return to Idle state from forced switch or manual switch state:
  1. Issue an **erps clear** command to remove the forced switch command on the node where a local forced switch command is active.
  2. Issue an **erps clear** command on the RPL owner node to trigger the reversion.
- ◆ The **erps clear** command will also stop the WTR and WTB delay timers and reset their values.
- ◆ More detailed information about using this command for non-revertive mode is included under the Command Usage section for the [non-revertive](#) command.

### Example

```
Console#erps clear instance r&d
Console#
```

**clear erps statistics** This command clears all statistics for a specific ERPS instance, or all instances.

### Syntax

**clear erps statistics** [**instance** *instance-name*]

*instance-name* - Name of a specific ERPS instance. (Range: 1-12 characters)

**Command Mode**

Privileged Exec

**Example**

```
Console#clear erps statistics instance r&d
Console#
```

**show erps statistics** This command displays statistics information for all configured instances, or for a specified instance.

**Syntax**

**show erps statistics [instance *instance-name*]**

*instance-name* - Name of a specific ERPS instance. (Range: 1-12 characters)

**Command Mode**

Privileged Exec

**Example**

This example displays statistics for all configured ERPS instances.

```
Console#show erps statistics
ERPS statistics for instance r&d :
Interface   Local SF   Local Clear SF
-----
(W) Eth 1/ 1 0           0
           SF      NR          NR-RB      FS          MS
-----
           Sent      0          62          948         0          0
           Received  0          0           0           0           0
           Ignored   0          0           0           0           0
           EVENT    HEALTH
-----
           Sent      0          0
           Received  0          0
           Ignored   0          0

Interface   Local SF   Local Clear SF
-----
(E) Eth 1/ 3 0           0
           SF      NR          NR-RB      FS          MS
-----
           Sent      0          62          948         0          0
           Received  0          0           0           0           0
           Ignored   0          0           0           0           0
           EVENT    HEALTH
-----
           Sent      0          0
           Received  0          0
           Ignored   0          0

Console#
```

**Table 123: show erps statistics - detailed display description**

Field	Description
Interface	The direction, and port or trunk which is configured as a ring port.
Local SF	A signal fault generated on a link to the local node.
Local Clear SF	The number of times a clear command was issued to terminate protection state entered through a forced switch or manual switch
SF	The number of signal fault messages
NR	The number of no request messages
NR-RB	The number no request - RPL blocked messages
FS	The number of forced switch messages
MS	The number of manual switch messages
EVENT	Any request/state message, excluding FS, SF, MS, and NR
HEALTH	The number of non-standard health-check messages

**show erps** This command displays status information for all configured VLAN groups, rings, and instances, or for a specified VLAN group, ring, or instance.

### Syntax

```
show erps {[vlan-group vlan-group-name] | [ring ring-name] | [instance instance-name]}
```

**vlan-group** - Keyword to display ERPS VLAN group settings.

*vlan-group-name* – Name of the VLAN group. (Range: 1-12 characters).

**ring** - Keyword to display ERPS ring configuration settings.

*ring-name* - Name of a specific ERPS ring. (Range: 1-12 characters)

**instance** - Keyword to display ERPS instance configuration settings.

*instance-name* - Name of a specific ERPS instance. (Range: 1-12 characters)

### Command Mode

Privileged Exec

### Example

This example displays a summary of all the ERPS VLAN groups configured on the switch.

```
Console#show erps vlan-group
ERPS Status           : Disabled
ERPS node-id         : B8-6A-97-41-F3-83
Number of ERPS Vgroup : 1

VLAN-group  ID  VLANs
-----
vlgrou3    1  3,6,9
```

```
Console#
```

This example displays a summary of all the ERPS rings configured on the switch.

```
Console#show erps ring
ERPS Status           : Enabled
ERPS node-id          : B8-6A-97-41-F3-83
Number of ERPS Ring   : 2

Ring      ID  Enabled West I/F  EAST I/F
-----
test1     1  No
campus1   2  Yes   Eth 1/1   Eth 1/3

Console#
```

**Table 124: show erps r ing - summary display description**

Field	Description
ERPS Status	Shows whether ERPS is enabled on the switch.
ERPS node-id	ERPS node identifier used in R-APS messages.
Number of ERPS Ring	Shows the number of ERPS rings configured on the switch.
Ring	Displays the name of each ring followed by a brief list of status information
ID	ERPS ring identifier used in R-APS messages.
Enabled	Shows if the specified ring is enabled.
West I/F	Shows information on the west ring port for this node.
East I/F	Shows information on the east ring port for this node.

This example displays a summary of all the ERPS instances configured on the switch.

```

Console#show erps instance
ERPS Status           : Disabled
ERPS node-id          : B8-6A-97-41-F3-83
Number of ERPS Inst   : 1

Instance   ID  Enabled Physical Ring Ctrl VLAN Node State Node Type
-----
test1      1  No           -----
                                     Init      None

                                     W/E  Interface Port State Local SF Local FS Local MS RPL
                                     -----
West       Unknown No      No      No      No      No
East       Unknown No      No      No      No      No

Inclusion VLAN groups
-----
None

Console#

```



# Class of Service Commands

The commands described in this section allow you to specify which data packets have greater precedence when traffic is buffered in the switch due to congestion. This switch supports CoS with eight priority queues for each port. Data packets in a port's high-priority queue will be transmitted before those in the lower-priority queues. The default priority can be set for each interface, also the queue service mode and the mapping of frame priority tags to the switch's priority queues can be configured.

**Table 125: Priority Commands**

Command Group	Function
Priority Commands (Layer 2)	Configures the queue mode, queue weights, and default priority for untagged frames
Priority Commands (Layer 3 and 4)	Sets the default priority processing method (CoS or DSCP), maps priority tags for internal processing, maps values from internal priority table to CoS values used in tagged egress packets for Layer 2 interfaces, maps internal per hop behavior to hardware queues

## Priority Commands (Layer 2)

This section describes commands used to configure Layer 2 traffic priority on the switch.

**Table 126: Priority Commands (Layer 2)**

Command	Function	Mode
<code>queue mode</code>	Sets the queue mode to Weighted Round-Robin (WRR), strict priority, or a combination of strict and weighted queuing	GC
<code>queue weight</code>	Assigns round-robin weights to the priority queues	GC
<code>switchport priority default</code>	Sets a port priority for incoming untagged frames	IC
<code>show interfaces switchport</code>	Displays the administrative and operational status of an interface	PE
<code>show queue mode</code>	Shows the current queue mode	PE
<code>show queue weight</code>	Shows weights assigned to the weighted queues	PE

**queue mode** This command sets the scheduling mode used for processing each of the class of service (CoS) priority queues. The options include strict priority, Weighted Round-Robin (WRR), or a combination of strict and weighted queuing. Use the **no** form to restore the default value.

### Syntax

**queue mode** {**strict** | **wrr** | **strict-wrr** [*queue-type-list*]}

#### **no queue mode**

**strict** - Services the egress queues in sequential order, transmitting all traffic in the higher priority queues before servicing lower priority queues. This ensures that the highest priority packets are always serviced first, ahead of all other traffic.

**wrr** - Weighted Round-Robin shares bandwidth at the egress ports by using scheduling weights (based on the [queue weight](#) command), and servicing each queue in a round-robin fashion.

**strict-wrr** - Uses strict or weighted service as specified for each queue.

*queue-type-list* - Indicates if the queue is a normal or strict type.  
(Options: 0 indicates a normal queue, 1 indicates a strict queue)

### Default Setting

WRR

### Command Mode

Global Configuration

### Command Usage

- ◆ The switch can be set to service the port queues based on strict priority, WRR, or a combination of strict and weighted queuing.
- ◆ Strict priority requires all traffic in a higher priority queue to be processed before lower priority queues are serviced.
- ◆ Weighted Round Robin (WRR) uses a predefined relative weight for each queue that determines the percentage of service time the switch services each queue before moving on to the next queue. This prevents the head-of-line blocking that can occur with strict priority queuing. Use the [queue weight](#) command to assign weights for WRR queuing to the eight priority queues.
- ◆ If Strict and WRR mode is selected, a combination of strict and weighted service is used as specified for each queue. The queues assigned to use strict or WRR priority should be specified using the *queue-type-list* parameter.
- ◆ A weight can be assigned to each of the weighted queues (and thereby to the corresponding traffic priorities). This weight sets the frequency at which each queue is polled for service, and subsequently affects the response time for software applications assigned a specific priority value.

- ◆ Service time is shared at the egress ports by defining scheduling weights for WRR, or for the queuing mode that uses a combination of strict and weighted queuing. Service time is allocated to each queue by calculating a precise number of bytes per second that will be serviced on each round.
- ◆ The specified queue mode applies to all interfaces.

### Example

The following example sets the queue mode to strict priority service mode:

```
Console(config)#queue mode strict
Console(config)#
```

### Related Commands

[queue weight \(655\)](#)  
[show queue mode \(657\)](#)

**queue weight** This command assigns weights to the eight class of service (CoS) priority queues when using weighted queuing, or one of the queuing modes that use a combination of strict and weighted queuing. Use the **no** form to restore the default weights.

### Syntax

**queue weight** *weight0...weight7*

**no queue weight**

*weight0...weight7* - The ratio of weights for queues 0 - 7 determines the weights used by the WRR scheduler. (Range: 1-255)

### Default Setting

Weights 1, 2, 4, 6, 8, 10, 12, 14 are assigned to queues 0 - 7 respectively.

### Command Mode

Global Configuration

### Command Usage

- ◆ This command shares bandwidth at the egress port by defining scheduling weights for Weighted Round-Robin, or for the queuing mode that uses a combination of strict and weighted queuing ([page 654](#)).
- ◆ Bandwidth is allocated to each queue by calculating a precise number of bytes per second that will be serviced on each round.

### Example

The following example shows how to assign round-robin weights of 1 - 8 to the CoS priority queues 0 - 7.

```
Console(config)#queue weight 1 2 3 4 5 6 7 8  
Console(config)#
```

### Related Commands

[queue mode \(654\)](#)

[show queue weight \(657\)](#)

**switchport priority default** This command sets a priority for incoming untagged frames. Use the **no** form to restore the default value.

### Syntax

**switchport priority default** *default-priority-id*

**no switchport priority default**

*default-priority-id* - The priority number for untagged ingress traffic. The priority is a number from 0 to 7. Seven is the highest priority.

### Default Setting

The priority is not set, and the default value for untagged frames received on the interface is zero.

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ The precedence for priority mapping is IP DSCP, and then default switchport priority.
- ◆ The default priority applies for an untagged frame received on a port set to accept all frame types (i.e, receives both untagged and tagged frames). This priority does not apply to IEEE 802.1Q VLAN tagged frames. If the incoming frame is an IEEE 802.1Q VLAN tagged frame, the IEEE 802.1p User Priority bits will be used.
- ◆ The switch provides eight priority queues for each port. It can be configured to use strict priority queuing, Weighted Round Robin (WRR), or a combination of strict and weighted queuing using the [queue mode](#) command. Inbound frames that do not have VLAN tags are tagged with the input port's default ingress user priority, and then placed in the appropriate priority queue at the output port. The default priority for all ingress ports is zero. Therefore, any inbound frames that do not have priority tags will be placed in queue 2 of the output port. (Note that if the output port is an untagged member of the associated VLAN, these frames are stripped of all VLAN tags prior to transmission.)

### Example

The following example shows how to set a default priority on port 3 to 5:

```
Console(config)#interface ethernet 1/3
Console(config-if)#switchport priority default 5
Console(config-if)#
```

### Related Commands

[show interfaces switchport \(440\)](#)

**show queue mode** This command shows the current queue mode.

### Syntax

**show queue mode**

### Command Mode

Privileged Exec

### Example

```
Console#show queue mode

Queue Mode : Weighted Round Robin
Console#
```

**show queue weight** This command displays the weights used for the weighted queues.

### Syntax

**show queue weight**

### Command Mode

Privileged Exec

### Example

```
Console#show queue weight
Information of Eth 1/1
Queue ID  Weight
-----  -
0         1
1         2
2         4
3         6
4         8
5        10
6        12
7        14
...

```

## Priority Commands (Layer 3 and 4)

This section describes commands used to configure Layer 3 and 4 traffic priority mapping on the switch.

**Table 127: Priority Commands (Layer 3 and 4)**

Command	Function	Mode
<code>qos map phb-queue</code>	Maps internal per-hop behavior values to hardware queues	IC
<code>qos map cos-dscp</code>	Maps CoS/CFI values in incoming packets to per-hop behavior and drop precedence values for internal priority processing	IC
<code>qos map dscp-mutation</code>	Maps DSCP values in incoming packets to per-hop behavior and drop precedence values for internal priority processing	IC
<code>qos map ip-prec-dscp</code>	Maps IP Precedence values in incoming packets to per-hop behavior and drop precedence values for internal priority processing	IC
<code>qos map trust-mode</code>	Sets QoS mapping to DSCP or CoS	IC
<code>show qos map cos-dscp</code>	Shows ingress CoS to internal DSCP map	PE
<code>show qos map dscp-mutation</code>	Shows ingress DSCP to internal DSCP map	PE
<code>show qos map ip-prec-dscp</code>	Shows ingress IP Precedence to internal DSCP map	PE
<code>show qos map phb-queue</code>	Shows internal per-hop behavior to hardware queue map	PE
<code>show qos map trust-mode</code>	Shows the QoS mapping mode	PE

\* The default settings used for mapping priority values to internal DSCP values and back to the hardware queues are designed to optimize priority services for the majority of network applications. It should not be necessary to modify any of the default settings unless a queuing problem occurs with a particular application.

**qos map phb-queue** This command determines the hardware output queues to use based on the internal per-hop behavior value. Use the **no** form to restore the default settings.

### Syntax

**qos map phb-queue** *queue-id* **from** *phb0 ... phb7*

**no map phb-queue** *phb0 ... phb7*

*phb* - Per-hop behavior, or the priority used for this router hop. (Range: 0-7)

*queue-id* - The ID of the priority queue. (Range: 0-7, where 7 is the highest priority queue)

### Default Setting

**Table 128: Mapping Internal Per-hop Behavior to Hardware Queues**

Per-hop Behavior	0	1	2	3	4	5	6	7
Hardware Queues	2	0	1	3	4	5	6	7

### Command Mode

Interface Configuration (Port, Static Aggregation)

### Command Usage

- ◆ Enter a queue identifier, followed by the keyword “from” and then up to eight internal per-hop behavior values separated by spaces.
- ◆ Egress packets are placed into the hardware queues according to the mapping defined by this command.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#qos map phb-queue 0 from 1 2 3
Console(config-if)#
```

**qos map cos-dscp** This command maps CoS/CFI values in incoming packets to per-hop behavior and drop precedence values for priority processing. Use the **no** form to restore the default settings.

### Syntax

**qos map cos-dscp** *phb drop-precedence* **from** *cos0 cfi0...cos7 cfi7*

**no qos map cos-dscp** *cos0 cfi0...cos7 cfi7*

*phb* - Per-hop behavior, or the priority used for this router hop. (Range: 0-7)

*drop-precedence* - Drop precedence used for controlling traffic congestion. (Range: 0 - Green, 3 - Yellow, 1 - Red)

*cos* - CoS value in ingress packets. (Range: 0-7)

*cfi* - Canonical Format Indicator. Set to this parameter to “0” to indicate that the MAC address information carried in the frame is in canonical format. (Range: 0-1)

### Default Setting

**Table 129: Default Mapping of CoS/CFI to Internal PHB/Drop Precedence**

CoS	CFI	0	1
0		(0,0)	(0,0)
1		(1,0)	(1,0)
2		(2,0)	(2,0)
3		(3,0)	(3,0)
4		(4,0)	(4,0)
5		(5,0)	(5,0)

**Table 129: Default Mapping of CoS/CFI to Internal PHB/Drop Precedence**

CoS	CFI	0	1
6		(6,0)	(6,0)
7		(7,0)	(7,0)

### Command Mode

Interface Configuration (Port, Static Aggregation)

### Command Usage

- ◆ The default mapping of CoS to PHB values shown in [Table 129](#) is based on the recommended settings in IEEE 802.1p for mapping CoS values to output queues.
- ◆ Enter a value pair for the internal per-hop behavior and drop precedence, followed by the keyword “from” and then up to eight CoS/CFI paired values separated by spaces.
- ◆ If a packet arrives with a 802.1Q header but it is not an IP packet, then the CoS/CFI-to-PHB/Drop Precedence mapping table is used to generate priority and drop precedence values for internal processing. Note that priority tags in the original packet are not modified by this command.
- ◆ The internal DSCP consists of three bits for per-hop behavior (PHB) which determines the queue to which a packet is sent; and two bits for drop precedence (namely color) which is used to control traffic congestion.
- ◆ The specified mapping applies to all interfaces.

### Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#qos map cos-dscp 0 0 from 0 1
Console(config-if)#
```

**qos map dscp-mutation** This command maps DSCP values in incoming packets to per-hop behavior and drop precedence values for priority processing. Use the **no** form to restore the default settings.

### Syntax

**qos map dscp-mutation** *phb drop-precedence* **from** *dscp0 ... dscp7*

**no qos map dscp-mutation** *dscp0 ... dscp7*

*phb* - Per-hop behavior, or the priority used for this router hop. (Range: 0-7)

*drop-precedence* - Drop precedence used for in controlling traffic congestion. (Range: 0 - Green, 3 - Yellow, 1 - Red)

*dscp* - DSCP value in ingress packets. (Range: 0-63)

### Default Setting

**Table 130: Default Mapping of DSCP Values to Internal PHB/Drop Values**

	ingress-dscp1	0	1	2	3	4	5	6	7	8	9
ingress-dscp10											
0		0,0	0,1	0,0	0,3	0,0	0,1	0,0	0,3	1,0	1,1
1		1,0	1,3	1,0	1,1	1,0	1,3	2,0	2,1	2,0	2,3
2		2,0	2,1	2,0	2,3	3,0	3,1	3,0	3,3	3,0	3,1
3		3,0	3,3	4,0	4,1	4,0	4,3	4,0	4,1	4,0	4,3
4		5,0	5,1	5,0	5,3	5,0	5,1	6,0	5,3	6,0	6,1
5		6,0	6,3	6,0	6,1	6,0	6,3	7,0	7,1	7,0	7,3
6		7,0	7,1	7,0	7,3						

The ingress DSCP is composed of ingress-dscp10 (most significant digit in the left column) and ingress-dscp1 (least significant digit in the top row (in other words, ingress-dscp = ingress-dscp10 \* 10 + ingress-dscp1)); and the corresponding internal-dscp is shown at the intersecting cell in the table.

The ingress DSCP is bitwise ANDed with the binary value 11 to determine the drop precedence. If the resulting value is 10 binary, then the drop precedence is set to 0.

### Command Mode

Interface Configuration (Port, Static Aggregation)

### Command Usage

- ◆ Enter a value pair for the internal per-hop behavior and drop precedence, followed by the keyword “from” and then up to eight DSCP values separated by spaces.
- ◆ This map is only used when the QoS mapping mode is set to “DSCP” by the **qos map trust-mode** command, and the ingress packet type is IPv4.
- ◆ Two QoS domains can have different DSCP definitions, so the DSCP-to-PHB/ Drop Precedence mutation map can be used to modify one set of DSCP values

to match the definition of another domain. The mutation map should be applied at the receiving port (ingress mutation) at the boundary of a QoS administrative domain.

- ◆ The specified mapping applies to all interfaces.

### Example

This example changes the priority for all packets entering port 1 which contain a DSCP value of 1 to a per-hop behavior of 3 and a drop precedence of 1. Referring to [Table 130](#), note that the DSCP value for these packets is now set to 25 ( $3 \times 2^3 + 1$ ) and passed on to the egress interface.

```
Console(config)#interface ethernet 1/5
Console(config-if)#qos map dscp-mutation 3 1 from 1
Console(config-if)#
```

**qos map ip-prec-dscp** This command maps IP precedence values in incoming packets to per-hop behavior and drop precedence values for priority processing. Use the **no** form to restore the default settings.

### Syntax

**qos map ip-prec-dscp** *phb0 drop-precedence0 ... phb7 drop-precedence7*

**no map ip-prec-dscp**

*phb* - Per-hop behavior, or the priority used for this router hop. (Range: 0-7)

*drop-precedence* - Drop precedence used for controlling traffic congestion. (Range: 0 - Green, 3 - Yellow, 1 - Red)

### Default Setting

**Table 131: Default Mapping of IP Precedence to Internal PHB/Drop Values**

IP Precedence Value	0	1	2	3	4	5	6	7
Per-hop Behavior	0	1	2	3	4	5	6	7
Drop Precedence	0	0	0	0	0	0	0	0

### Command Mode

Interface Configuration (Port, Static Aggregation)

### Command Usage

- ◆ Enter up to eight paired values for per-hop behavior and drop precedence separated by spaces. These values are used for internal priority processing, and correspond to IP Precedence values 0 - 7.
- ◆ If the QoS mapping mode is set the IP Precedence and the ingress packet type is IPv4, then the IP Precedence-to-DSCP mapping table is used to generate priority and drop precedence values for internal processing.

## Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#qos map ip-prec-dscp 7 0 6 0 5 0 4 0 3 0 2 1 1 1 0 1
Console(config-if)#
```

**qos map trust-mode** This command sets QoS mapping to DSCP or CoS. Use the **no** form to restore the default setting.

## Syntax

**qos map trust-mode {cos | dscp | ip-precedence}**

**no qos map trust-mode**

**cos** - Sets the QoS mapping mode to CoS.

**dscp** - Sets the QoS mapping mode to DSCP.

**ip-precedence** - Sets the QoS mapping mode to IP Precedence.

## Default Setting

CoS

## Command Mode

Interface Configuration (Port)

## Command Usage

- ◆ If the QoS mapping mode is set to IP Precedence with this command, and the ingress packet type is IPv4, then priority processing will be based on the IP Precedence value in the ingress packet.
- ◆ If the QoS mapping mode is set to DSCP with this command, and the ingress packet type is IPv4, then priority processing will be based on the DSCP value in the ingress packet.
- ◆ If the QoS mapping mode is set to either IP Precedence or DSCP, and a non-IP packet is received, the packet's CoS and CFI (Canonical Format Indicator) values are used for priority processing if the packet is tagged. For an untagged packet, the default port priority (see [page 656](#)) is used for priority processing.
- ◆ If the QoS mapping mode is set to CoS with this command, and the ingress packet type is IPv4, then priority processing will be based on the CoS and CFI values in the ingress packet.  
For an untagged packet, the default port priority (see [page 656](#)) is used for priority processing.

### Example

This example sets the QoS priority mapping mode to use DSCP based on the conditions described in the Command Usage section.

```
Console(config)#interface ge1/1
Console(config-if)#qos map trust-mode dscp
Console(config-if)#
```

**show qos map cos-dscp** This command shows ingress CoS/CFI to internal DSCP map.

### Syntax

**show qos map cos-dscp interface** *interface*  
*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

```
Console#show qos map cos-dscp interface ethernet 1/5
CoS Information of Eth 1/5
CoS-DSCP map. (x,y),x: phb,y: drop precedence:
CoS  : CFI  0          1
-----
0          (0,0)      (0,0)
1          (1,0)      (1,0)
2          (2,0)      (2,0)
3          (3,0)      (3,0)
4          (4,0)      (4,0)
5          (5,0)      (5,0)
6          (6,0)      (6,0)
7          (7,0)      (7,0)
Console#
```

**show qos map dscp-mutation** This command shows the ingress DSCP to internal DSCP map.

#### Syntax

**show qos map dscp-mutation interface** *interface*  
*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

#### Command Mode

Privileged Exec

#### Command Usage

This map is only used when the QoS mapping mode is set to "DSCP" by the **qos map trust-mode** command, and the ingress packet type is IPv4.

#### Example

The ingress DSCP is composed of "d1" (most significant digit in the left column) and "d2" (least significant digit in the top row (in other words, ingress DSCP = d1 \* 10 + d2); and the corresponding Internal DSCP and drop precedence is shown at the intersecting cell in the table.

```

Console#show qos map dscp-mutation interface ethernet 1/5
DSCP mutation map. (x,y), x: PHB, y: drop precedence:
d1: d2 0    1    2    3    4    5    6    7    8    9
-----
0 :   (0,0) (0,1) (0,0) (0,3) (0,0) (0,1) (0,0) (0,3) (1,0) (1,1)
1 :   (1,0) (1,3) (1,0) (1,1) (1,0) (1,3) (2,0) (2,1) (2,0) (2,3)
2 :   (2,0) (2,1) (2,0) (2,3) (3,0) (3,1) (3,0) (3,3) (3,0) (3,1)
3 :   (3,0) (3,3) (4,0) (4,1) (4,0) (4,3) (4,0) (4,1) (4,0) (4,3)
4 :   (5,0) (5,1) (5,0) (5,3) (5,0) (5,1) (6,0) (5,3) (6,0) (6,1)
5 :   (6,0) (6,3) (6,0) (6,1) (6,0) (6,3) (7,0) (7,1) (7,0) (7,3)
6 :   (7,0) (7,1) (7,0) (7,3)
Console#

```

**show qos map ip-prec-dscp** This command shows the ingress IP precedence to internal DSCP map.

#### Syntax

**show qos map ip-prec-dscp interface** *interface*  
*interface*

**ethernet** *unit/port*

*unit* - Stack unit. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

## Command Mode

Privileged Exec

## Command Usage

If the QoS mapping mode is set to IP Precedence and the ingress packet type is IPv4, then the IP Precedence-to-DSCP mapping table is used to generate per-hop behavior and drop precedence values for internal processing.

## Example

```
Console#show qos map ip-prec-dscp interface ethernet 1/5
Information of Eth 1/5
IP-prec-DSCP map:
IP-prec:      0      1      2      3      4      5      6      7
-----
PHB:          0      1      2      3      4      5      6      7
drop precedence: 0      0      0      0      0      0      0      0
Console#
```

**show qos map phb-queue** This command shows internal per-hop behavior to hardware queue map.

## Syntax

**show qos map phb-queue interface** *interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

## Command Mode

Privileged Exec

## Example

```
Console#show qos map phb-queue interface ethernet 1/5
Information of Eth 1/5
PHB-queue map:
PHB:          0      1      2      3      4      5      6      7
-----
queue:        2      0      1      3      4      5      6      7
Console#
```

**show qos map trust-mode** This command shows the QoS mapping mode.

#### Syntax

**show qos map trust-mode interface** *interface*  
*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Example

The following shows that the trust mode is set to CoS:

```
Console#show qos map trust-mode interface ethernet 1/5
Information of Eth 1/5
  CoS Map Mode:          CoS mode
Console#
```



## Quality of Service Commands

The commands described in this section are used to configure Differentiated Services (DiffServ) classification criteria and service policies. You can classify traffic based on access lists, IP Precedence or DSCP values, or VLANs. Using access lists allows you select traffic based on Layer 2, Layer 3, or Layer 4 information contained in each packet.

**Table 132: Quality of Service Commands**

Command	Function	Mode
<code>class-map</code>	Creates a class map for a type of traffic	GC
<code>description</code>	Specifies the description of a class map	CM
<code>match</code>	Defines the criteria used to classify traffic	CM
<code>rename</code>	Redefines the name of a class map	CM
<code>policy-map</code>	Creates a policy map for multiple interfaces	GC
<code>description</code>	Specifies the description of a policy map	PM
<code>class</code>	Defines a traffic classification for the policy to act on	PM
<code>rename</code>	Redefines the name of a policy map	PM
<code>police flow</code>	Defines an enforcer for classified traffic based on a metered flow rate	PM-C
<code>police srtcm-color</code>	Defines an enforcer for classified traffic based on a single rate three color meter	PM-C
<code>police trtcm-color</code>	Defines an enforcer for classified traffic based on a two rate three color meter	PM-C
<code>set cos</code>	Services IP traffic by setting a class of service value for matching packets for internal processing	PM-C
<code>set ip dscp</code>	Services IP traffic by setting a IP DSCP value for matching packets for internal processing	PM-C
<code>set phb</code>	Services IP traffic by setting a per-hop behavior value for matching packets for internal processing	PM-C
<code>service-policy</code>	Applies a policy map defined by the <code>policy-map</code> command to the input of a particular interface	IC
<code>show class-map</code>	Displays the QoS class maps which define matching criteria used for classifying traffic	PE
<code>show policy-map</code>	Displays the QoS policy maps which define classification criteria for incoming traffic, and may include policers for bandwidth limitations	PE
<code>show policy-map interface</code>	Displays the configuration of all classes configured for all service policies on the specified interface	PE

To create a service policy for a specific category of ingress traffic, follow these steps:

1. Use the **class-map** command to designate a class name for a specific category of traffic, and enter the Class Map configuration mode.
2. Use the **match** command to select a specific type of traffic based on an access list, an IPv4 DSCP value, IPv4 Precedence value, a VLAN, or a CoS value.
3. Use the **policy-map** command to designate a policy name for a specific manner in which ingress traffic will be handled, and enter the Policy Map configuration mode.
4. Use the **class** command to identify the class map, and enter Policy Map Class configuration mode. A policy map can contain up to 16 class maps.
5. Use the **set phb** or **set cos** or **set ip dscp** command to modify the per-hop behavior, the class of service value in the VLAN tag, or the priority bits in the IP header (IP DSCP value) for the matching traffic class, and use one of the **police** commands to monitor parameters such as the average flow and burst rate, and drop any traffic that exceeds the specified rate, or just reduce the DSCP service level for traffic exceeding the specified rate.
6. Use the **service-policy** command to assign a policy map to a specific interface.




---

**Note:** Create a Class Map before creating a Policy Map.

---

**class-map** This command creates a class map used for matching packets to the specified class, and enters Class Map configuration mode. Use the **no** form to delete a class map.

#### Syntax

**class-map** *class-map-name* **match-any**

**no class-map** *class-map-name*

*class-map-name* - Name of the class map. (Range: 1-32 characters)

**match-any** - Match any condition within a class map.

#### Default Setting

None

#### Command Mode

Global Configuration

### Command Usage

- ◆ First enter this command to designate a class map and enter the Class Map configuration mode. Then use [match](#) commands to specify the criteria for ingress traffic that will be classified under this class map.
- ◆ One or more class maps can be assigned to a policy map ([page 674](#)). The policy map is then bound by a service policy to an interface ([page 684](#)). A service policy defines packet classification, service tagging, and bandwidth policing.

### Example

This example creates a class map call “rd-class,” and sets it to match packets marked for DSCP service value 3:

```
Console(config)#class-map rd-class match-any
Console(config-cmap)#match ip dscp 3
Console(config-cmap)#
```

### Related Commands

[show class-map \(684\)](#)

**description** This command specifies the description of a class map or policy map. Use the no form of the command to remove the description.

### Syntax

**description** *string*

**no description**

*string* - Description of the class map or policy map. (Range: 1-64 characters)

### Command Mode

Class Map Configuration

Policy Map Configuration

### Example

```
Console(config)#class-map rd-class#1
Console(config-cmap)#description matches packets marked for DSCP service
value 3
Console(config-cmap)#
```

**match** This command defines the criteria used to classify traffic. Use the **no** form to delete the matching criteria.

### Syntax

```
[no] match {access-list acl-name | cos cos | ip dscp dscp |
ip precedence ip-precedence | ipv6 dscp dscp | source-port interface |
vlan vlan}
```

*acl-name* - Name of the access control list. Any type of ACL can be specified, including standard or extended IPv4/IPv6 ACLs and MAC ACLs.  
(Range: 1-16 characters)

*cos* - A Class of Service value. (Range: 0-7)

*dscp* - A Differentiated Service Code Point value. (Range: 0-63)

*ip-precedence* - An IP Precedence value. (Range: 0-7)

*interface*

*unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

*vlan* - A VLAN. (Range:1-4094)

### Default Setting

None

### Command Mode

Class Map Configuration

### Command Usage

- ◆ First enter the **class-map** command to designate a class map and enter the Class Map configuration mode. Then use **match** commands to specify the fields within ingress packets that must match to qualify for this class map.
- ◆ If an ingress packet matches an ACL specified by this command, any deny rules included in the ACL will be ignored.
- ◆ If match criteria includes an IP ACL or IP priority rule, then a VLAN rule cannot be included in the same class map.
- ◆ If match criteria includes a MAC ACL or VLAN rule, then neither an IP ACL nor IP priority rule can be included in the same class map.
- ◆ Up to 16 match entries can be included in a class map.

**Example**

This example creates a class map called “rd-class#1,” and sets it to match packets marked for DSCP service value 3.

```
Console(config)#class-map rd-class#1 match-any
Console(config-cmap)#match ip dscp 3
Console(config-cmap)#
```

This example creates a class map call “rd-class#2,” and sets it to match packets marked for IP Precedence service value 5.

```
Console(config)#class-map rd-class#2 match-any
Console(config-cmap)#match ip precedence 5
Console(config-cmap)#
```

This example creates a class map call “rd-class#3,” and sets it to match packets marked for VLAN 1.

```
Console(config)#class-map rd-class#3 match-any
Console(config-cmap)#match vlan 1
Console(config-cmap)#
```

**rename** This command redefines the name of a class map or policy map.

**Syntax**

**rename** *map-name*

*map-name* - Name of the class map or policy map. (Range: 1-32 characters)

**Command Mode**

Class Map Configuration

Policy Map Configuration

**Example**

```
Console(config)#class-map rd-class#1
Console(config-cmap)#rename rd-class#9
Console(config-cmap)#
```

**policy-map** This command creates a policy map that can be attached to multiple interfaces, and enters Policy Map configuration mode. Use the **no** form to delete a policy map.

### Syntax

**[no] policy-map** *policy-map-name*

*policy-map-name* - Name of the policy map. (Range: 1-32 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Use the **policy-map** command to specify the name of the policy map, and then use the **class** command to configure policies for traffic that matches the criteria defined in a class map.
- ◆ A policy map can contain multiple class statements that can be applied to the same interface with the **service-policy** command.
- ◆ Create a Class Map ([page 674](#)) before assigning it to a Policy Map.

### Example

This example creates a policy called “rd-policy,” uses the **class** command to specify the previously defined “rd-class,” uses the **set** command to classify the service that incoming packets will receive, and then uses the **police flow** command to limit the average bandwidth to 100,000 Kbps, the burst rate to 4000 bytes, and configure the response to drop any violating packets.

```
Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set cos 0
Console(config-pmap-c)#police flow 10000 4000 conform-action transmit
violate-action drop
Console(config-pmap-c)#
```

**class** This command defines a traffic classification upon which a policy can act, and enters Policy Map Class configuration mode. Use the **no** form to delete a class map.

### Syntax

**[no] class** *class-map-name*

*class-map-name* - Name of the class map. (Range: 1-32 characters)

### Default Setting

None

## Command Mode

### Policy Map Configuration

## Command Usage

- ◆ Use the **policy-map** command to specify a policy map and enter Policy Map configuration mode. Then use the **class** command to enter Policy Map Class configuration mode. And finally, use the **set** command and one of the **police** commands to specify the match criteria, where the:
  - **set phb** command sets the per-hop behavior value in matching packets. (This modifies packet priority for internal processing only.)
  - **set cos** command sets the class of service value in matching packets. (This modifies packet priority in the VLAN tag.)
  - **police** commands define parameters such as the maximum throughput, burst rate, and response to non-conforming traffic.
- ◆ Up to 16 classes can be included in a policy map.

## Example

This example creates a policy called "rd-policy," uses the **class** command to specify the previously defined "rd-class," uses the **set phb** command to classify the service that incoming packets will receive, and then uses the **police flow** command to limit the average bandwidth to 100,000 Kbps, the burst rate to 4,000 bytes, and configure the response to drop any violating packets.

```

Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set phb 3
Console(config-pmap-c)#police flow 10000 4000 conform-action transmit
violate-action drop
Console(config-pmap-c)#

```

**police flow** This command defines an enforcer for classified traffic based on the metered flow rate. Use the no form to remove a policer.

## Syntax

```

[no] police flow committed-rate committed-burst
conform-action {transmit | new-dscp}
violate-action {drop | new-dscp}

```

*committed-rate* - Committed information rate (CIR) in kilobits per second.  
(Range: 0-10000000 kbps or maximum port speed, whichever is lower)

*committed-burst* - Committed burst size (BC) in bytes.  
(Range: 64-16000000 bytes)

**conform-action** - Action to take when packet is within the CIR and BC.  
(There are enough tokens to service the packet, the packet is set green).

**violate-action** - Action to take when packet exceeds the CIR and BC. (There are not enough tokens to service the packet, the packet is set red).

**transmit** - Transmits without taking any action.

**drop** - Drops packet as required by violate-action.

*new-dscp* - Differentiated Service Code Point (DSCP) value. (Range: 0-63)

### Default Setting

None

### Command Mode

Policy Map Class Configuration

### Command Usage

- ◆ You can configure up to 16 policers (i.e., class maps) for ingress ports.
- ◆ Policing is based on a token bucket, where bucket depth (i.e., the maximum burst before the bucket overflows) is by specified the *committed-burst* field, and the average rate tokens are added to the bucket is by specified by the *committed-rate* option. Note that the token bucket functions similar to that described in RFC 2697 and RFC 2698.
- ◆ The behavior of the meter is specified in terms of one token bucket (C), the rate at which the tokens are incremented (CIR – Committed Information Rate), and the maximum size of the token bucket (BC – Committed Burst Size).

The token bucket C is initially full, that is, the token count  $Tc(0) = BC$ . Thereafter, the token count  $Tc$  is updated CIR times per second as follows:

- If  $Tc$  is less than BC,  $Tc$  is incremented by one, else
- $Tc$  is not incremented.

When a packet of size B bytes arrives at time t, the following happens:

- If  $Tc(t) - B \geq 0$ , the packet is green and  $Tc$  is decremented by B down to the minimum value of 0, else
- else the packet is red and  $Tc$  is not decremented.

### Example

This example creates a policy called “rd-policy,” uses the `class` command to specify the previously defined “rd-class,” uses the `set phb` command to classify the service that incoming packets will receive, and then uses the **police flow** command to limit the average bandwidth to 100,000 Kbps, the burst rate to 4000 bytes, and configure the response to drop any violating packets.

```
Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set phb 3
```

```

Console(config-pmap-c)#police flow 100000 4000 conform-action transmit
violate-action drop
Console(config-pmap-c)#

```

**police srtcm-color** This command defines an enforcer for classified traffic based on a single rate three color meter (srTCM). Use the **no** form to remove a policer.

### Syntax

**[no] police {srtcm-color-blind | srtcm-color-aware}**

*committed-rate committed-burst excess-burst*

**conform-action {transmit | new-dscp}**

**exceed-action {drop | new-dscp}**

**violate action {drop | new-dscp}**

**srtcm-color-blind** - Single rate three color meter in color-blind mode.

**srtcm-color-aware** - Single rate three color meter in color-aware mode.

*committed-rate* - Committed information rate (CIR) in kilobits per second.  
(Range: 0-10000000 kbps or maximum port speed, whichever is lower)

*committed-burst* - Committed burst size (BC) in bytes.  
(Range: 64-16000000 bytes)

*excess-burst* - Excess burst size (BE) in bytes. (Range: 64-16000000 bytes)

**conform-action** - Action to take when rate is within the CIR and BC. (There are enough tokens in bucket BC to service the packet, packet is set green).

**exceed-action** - Action to take when rate exceeds the CIR and BC but is within the BE. (There are enough tokens in bucket BE to service the packet, the packet is set yellow.)

**violate-action** - Action to take when rate exceeds the BE. (There are not enough tokens in bucket BE to service the packet, the packet is set red.)

**transmit** - Transmits without taking any action.

**drop** - Drops packet as required by exceed-action or violate-action.

*new-dscp* - Differentiated Service Code Point (DSCP) value. (Range: 0-63)

### Default Setting

None

### Command Mode

Policy Map Class Configuration

### Command Usage

- ◆ You can configure up to 16 policers (i.e., class maps) for ingress ports.
- ◆ The srTCM as defined in RFC 2697 meters a traffic stream and processes its packets according to three traffic parameters – Committed Information Rate (CIR), Committed Burst Size (BC), and Excess Burst Size (BE).

- ◆ The PHB label is composed of five bits, three bits for per-hop behavior, and two bits for the color scheme used to control queue congestion. A packet is marked green if it doesn't exceed the CIR and BC, yellow if it does exceed the CIR and BC, but not the BE, and red otherwise.
- ◆ The meter operates in one of two modes. In the color-blind mode, the meter assumes that the packet stream is uncolored. In color-aware mode the meter assumes that some preceding entity has pre-colored the incoming packet stream so that each packet is either green, yellow, or red. The marker (re)colors an IP packet according to the results of the meter. The color is coded in the DS field [RFC 2474] of the packet.
- ◆ The behavior of the meter is specified in terms of its mode and two token buckets, C and E, which both share the common rate CIR. The maximum size of the token bucket C is BC and the maximum size of the token bucket E is BE.

The token buckets C and E are initially full, that is, the token count  $T_c(0) = BC$  and the token count  $T_e(0) = BE$ . Thereafter, the token counts  $T_c$  and  $T_e$  are updated CIR times per second as follows:

- If  $T_c$  is less than BC,  $T_c$  is incremented by one, else
- if  $T_e$  is less than BE,  $T_e$  is incremented by one, else
- neither  $T_c$  nor  $T_e$  is incremented.

When a packet of size B bytes arrives at time t, the following happens if srTCM is configured to operate in color-blind mode:

- If  $T_c(t) - B \geq 0$ , the packet is green and  $T_c$  is decremented by B down to the minimum value of 0, else
- if  $T_e(t) - B \geq 0$ , the packets is yellow and  $T_e$  is decremented by B down to the minimum value of 0,
- else the packet is red and neither  $T_c$  nor  $T_e$  is decremented.

When a packet of size B bytes arrives at time t, the following happens if srTCM is configured to operate in color-aware mode:

- If the packet has been precolored as green and  $T_c(t) - B \geq 0$ , the packet is green and  $T_c$  is decremented by B down to the minimum value of 0, else
- If the packet has been precolored as yellow or green and if
- $T_e(t) - B \geq 0$ , the packets is yellow and  $T_e$  is decremented by B down to the minimum value of 0, else the packet is red and neither  $T_c$  nor  $T_e$  is decremented.

The metering policy guarantees a deterministic behavior where the volume of green packets is never smaller than what has been determined by the CIR and BC, that is, tokens of a given color are always spent on packets of that color. Refer to RFC 2697 for more information on other aspects of srTCM.

### Example

This example creates a policy called "rd-policy," uses the `class` command to specify the previously defined "rd-class," uses the `set phb` command to classify the service that incoming packets will receive, and then uses the `police srtcm-color-blind`

command to limit the average bandwidth to 100,000 Kbps, the committed burst rate to 4000 bytes, the excess burst rate to 6000 bytes, to remark any packets exceeding the committed burst size, and to drop any packets exceeding the excess burst size.

```

Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set phb 3
Console(config-pmap-c)#police srtcm-color-blind 100000 4000 6000 conform-
  action transmit exceed-action 0 violate-action drop
Console(config-pmap-c)#

```

**police trtcm-color** This command defines an enforcer for classified traffic based on a two rate three color meter (trTCM). Use the **no** form to remove a policer.

### Syntax

```

[no] police {trtcm-color-blind | trtcm-color-aware}
  committed-rate committed-burst peak-rate peak-burst
  conform-action {transmit | new-dscp}
  exceed-action {drop | new-dscp}
  violate action {drop | new-dscp}

```

**trtcm-color-blind** - Two rate three color meter in color-blind mode.

**trtcm-color-aware** - Two rate three color meter in color-aware mode.

*committed-rate* - Committed information rate (CIR) in kilobits per second.  
(Range: 0-10000000 kbps or maximum port speed, whichever is lower)

*committed-burst* - Committed burst size (BC) in bytes.  
(Range: 64-16000000 bytes)

*peak-rate* - Peak information rate (PIR) in kilobits per second.  
(Range: 0-1000000 kbps or maximum port speed, whichever is lower)

*peak-burst* - Peak burst size (BP) in bytes. (Range: 64-16000000 bytes)

**conform-action** - Action to take when rate is within the CIR and BP. (Packet size does not exceed BP and there are enough tokens in bucket BC to service the packet, the packet is set green.)

**exceed-action** - Action to take when rate exceeds the CIR but is within the PIR. (Packet size exceeds BC but there are enough tokens in bucket BP to service the packet, the packet is set yellow.)

**violate-action** - Action to take when rate exceeds the PIR. (There are not enough tokens in bucket BP to service the packet, the packet is set red.)

**drop** - Drops packet as required by exceed-action or violate-action.

**transmit** - Transmits without taking any action.

*new-dscp* - Differentiated Service Code Point (DSCP) value. (Range: 0-63)

**Default Setting**

None

**Command Mode**

Policy Map Class Configuration

**Command Usage**

- ◆ You can configure up to 16 policers (i.e., class maps) for ingress ports.
- ◆ The trTCM as defined in RFC 2698 meters a traffic stream and processes its packets based on two rates – Committed Information Rate (CIR) and Peak Information Rate (PIR), and their associated burst sizes - Committed Burst Size (BC) and Peak Burst Size (BP).
- ◆ The PHB label is composed of five bits, three bits for per-hop behavior, and two bits for the color scheme used to control queue congestion. A packet is marked red if it exceeds the PIR. Otherwise it is marked either yellow or green depending on whether it exceeds or doesn't exceed the CIR.  
The trTCM is useful for ingress policing of a service, where a peak rate needs to be enforced separately from a committed rate.
- ◆ The meter operates in one of two modes. In the color-blind mode, the meter assumes that the packet stream is uncolored. In color-aware mode the meter assumes that some preceding entity has pre-colored the incoming packet stream so that each packet is either green, yellow, or red. The marker (re)colors an IP packet according to the results of the meter. The color is coded in the DS field [RFC 2474] of the packet.
- ◆ The behavior of the meter is specified in terms of its mode and two token buckets, P and C, which are based on the rates PIR and CIR, respectively. The maximum size of the token bucket P is BP and the maximum size of the token bucket C is BC.
- ◆ The token buckets P and C are initially (at time 0) full, that is, the token count  $T_p(0) = BP$  and the token count  $T_c(0) = BC$ . Thereafter, the token count  $T_p$  is incremented by one PIR times per second up to BP and the token count  $T_c$  is incremented by one CIR times per second up to BC.

When a packet of size B bytes arrives at time t, the following happens if trTCM is configured to operate in color-blind mode:

- If  $T_p(t) - B < 0$ , the packet is red, else
- if  $T_c(t) - B < 0$ , the packet is yellow and  $T_p$  is decremented by B, else
- the packet is green and both  $T_p$  and  $T_c$  are decremented by B.

When a packet of size B bytes arrives at time t, the following happens if trTCM is configured to operate in color-aware mode:

- If the packet has been precolored as red or if  $T_p(t) - B < 0$ , the packet is red, else

- if the packet has been precolored as yellow or if  $Tc(t) - B < 0$ , the packet is yellow and  $Tp$  is decremented by  $B$ , else
  - the packet is green and both  $Tp$  and  $Tc$  are decremented by  $B$ .
- ◆ The trTCM can be used to mark a IP packet stream in a service, where different, decreasing levels of assurances (either absolute or relative) are given to packets which are green, yellow, or red. Refer to RFC 2698 for more information on other aspects of trTCM.

### Example

This example creates a policy called “rd-policy,” uses the `class` command to specify the previously defined “rd-class,” uses the `set phb` command to classify the service that incoming packets will receive, and then uses the `police trtcm-color-blind` command to limit the average bandwidth to 100,000 Kbps, the committed burst rate to 4000 bytes, the peak information rate to 1,000,000 kbps, the peak burst size to 6000, to remark any packets exceeding the committed burst size, and to drop any packets exceeding the peak information rate.

```
Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set phb 3
Console(config-pmap-c)#police trtcm-color-blind 100000 4000 100000 6000
    conform-action transmit exceed-action 0 violate-action drop
Console(config-pmap-c)#
```

**set cos** This command modifies the class of service (CoS) value for a matching packet (as specified by the `match` command) in the packet’s VLAN tag. Use the `no` form to remove this setting.

### Syntax

**[no] set cos** *cos-value*

*cos-value* - Class of Service value. (Range: 0-7)

### Default Setting

None

### Command Mode

Policy Map Class Configuration

### Command Usage

- ◆ The `set cos` command is used to set the CoS value in the VLAN tag for matching packets.
- ◆ The `set cos` and `set phb` command function at the same level of priority. Therefore setting either of these commands will overwrite any action already configured by the other command.

**Example**

This example creates a policy called “rd-policy,” uses the `class` command to specify the previously defined “rd-class,” uses the `set cos` command to classify the service that incoming packets will receive, and then uses the `police flow` command to limit the average bandwidth to 100,000 Kbps, the burst rate to 4000 bytes, and configure the response to drop any violating packets.

```
Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set cos 3
Console(config-pmap-c)#police flow 100000 4000 conform-action transmit
violate-action drop
Console(config-pmap-c)#
```

**set ip dscp** This command modifies the IP DSCP value in a matching packet (as specified by the `match` command). Use the `no` form to remove this traffic classification.

**Syntax**

**[no] set ip dscp** *new-dscp*

*new-dscp* - New Differentiated Service Code Point (DSCP) value.  
(Range: 0-63)

**Default Setting**

None

**Command Mode**

Policy Map Class Configuration

**Command Usage**

The **set ip dscp** command is used to set the priority values in the packet’s ToS field for matching packets.

**Example**

This example creates a policy called “rd-policy,” uses the `class` command to specify the previously defined “rd-class,” uses the `set ip dscp` command to classify the service that incoming packets will receive, and then uses the `police flow` command to limit the average bandwidth to 100,000 Kbps, the burst rate to 4000 bytes, and configure the response to drop any violating packets.

```
Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set ip dscp 3
Console(config-pmap-c)#police flow 100000 4000 conform-action transmit
violate-action drop
Console(config-pmap-c)#
```

**set phb** This command services IP traffic by setting a per-hop behavior value for a matching packet (as specified by the [match](#) command) for internal processing. Use the **no** form to remove this setting.

### Syntax

```
[no] set phb phb-value
```

*phb-value* - Per-hop behavior value. (Range: 0-7)

### Default Setting

None

### Command Mode

Policy Map Class Configuration

### Command Usage

- ◆ The **set phb** command is used to set an internal QoS value in hardware for matching packets (see [Table 129, "Default Mapping of CoS/CFI to Internal PHB/Drop Precedence"](#)). The QoS label is composed of five bits, three bits for per-hop behavior, and two bits for the color scheme used to control queue congestion by the [police srtcm-color](#) command and [police trtcm-color](#) command.
- ◆ The [set cos](#) and **set phb** command function at the same level of priority. Therefore setting either of these commands will overwrite any action already configured by the other command.

### Example

This example creates a policy called "rd-policy," uses the [class](#) command to specify the previously defined "rd-class," uses the **set phb** command to classify the service that incoming packets will receive, and then uses the [police flow](#) command to limit the average bandwidth to 100,000 Kbps, the burst rate to 4000 bytes, and configure the response to drop any violating packets.

```
Console(config)#policy-map rd-policy
Console(config-pmap)#class rd-class
Console(config-pmap-c)#set phb 3
Console(config-pmap-c)#police flow 10000 4000 conform-action transmit
violate-action drop
Console(config-pmap-c)#
```

**service-policy** This command applies a policy map defined by the **policy-map** command to the ingress side of a particular interface. Use the **no** form to remove this mapping.

### Syntax

**[no] service-policy {input | output} policy-map-name**

**input** - Apply to the input traffic.

**output** - Apply to the output traffic.

*policy-map-name* - Name of the policy map for this interface.  
(Range: 1-32 characters)

### Default Setting

No policy map is attached to an interface.

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

- ◆ Only one policy map can be assigned to an interface.
- ◆ First define a class map, then define a policy map, and finally use the **service-policy** command to bind the policy map to the required interface.
- ◆ The switch does not allow a policy map to be bound to an interface for egress traffic.

### Example

This example applies a service policy to an ingress interface.

```
Console(config)#interface ethernet 1/1
Console(config-if)#service-policy input rd-policy
Console(config-if)#
```

**show class-map** This command displays the QoS class maps which define matching criteria used for classifying traffic.

### Syntax

**show class-map [class-map-name]**

*class-map-name* - Name of the class map. (Range: 1-32 characters)

### Default Setting

Displays all class maps.

### Command Mode

Privileged Exec

### Example

```

Console#show class-map
Class Map match-any rd-class#1
Description:
  Match IP DSCP 10
  Match access-list rd-access
  Match IP DSCP 0

Class Map match-any rd-class#2
  Match IP Precedence 5

Class Map match-any rd-class#3
  Match VLAN 1

Console#

```

**show policy-map** This command displays the QoS policy maps which define classification criteria for incoming traffic, and may include policers for bandwidth limitations.

### Syntax

**show policy-map** [*policy-map-name* [**class** *class-map-name*]]

*policy-map-name* - Name of the policy map. (Range: 1-32 characters)

*class-map-name* - Name of the class map. (Range: 1-32 characters)

### Default Setting

Displays all policy maps and all classes.

### Command Mode

Privileged Exec

### Example

```

Console#show policy-map
Policy Map rd-policy
Description:
  class rd-class
  set phb 3
Console#show policy-map rd-policy class rd-class
Policy Map rd-policy
  class rd-class
  set phb 3
Console#

```

**show policy-map interface** This command displays the service policy assigned to the specified interface.

#### Syntax

**show policy-map interface** *interface* **input**

*interface*

*unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Example

```
Console#show policy-map interface 1/5 input
Service-policy rd-policy
Console#
```

# Control Plane Commands

Network control packets that are received by the switch are handled by the CPU. This traffic can potentially overwhelm the switch CPU and impact the overall system performance. To prevent the switch CPU from receiving too much traffic, QoS class maps and policy maps can be defined and applied as a service policy to ingress traffic on the CPU's "control-plane" interface.

For details on configuring QoS class maps and policy maps, see ["Quality of Service Commands" on page 669](#).

**Table 133: Control Plane Commands**

Command	Function	Mode
<a href="#">control-plane</a>	Enters control-plane interface mode	GC
<a href="#">service-policy</a>	Applies a policy map to the input of the control-plane interface	CP
<a href="#">show policy-map control-plane</a>	Shows the configuration of service policies on the control-plane interface	PE

**control-plane** Use this command to enter control-plane interface configuration mode.

## Syntax

**control-plane**

## Command Mode

Global Configuration

## Command Usage

You must enter control-plane interface configuration mode to bind a service policy to the control-plane interface.

## Example

```
Console(config)#control-plane
Console(config-cp)#
```

**service-policy** This command applies a QoS policy map defined by the **policy-map** command to the ingress side of the control-plane interface. Use the **no** form to remove this mapping.

### Syntax

**[no] service-policy input** *policy-map-name*

**input** - Apply to the input traffic.

*policy-map-name* - Name of the policy map for this interface.  
(Range: 1-32 characters)

### Default Setting

No policy map is attached to the control-plane interface.

### Command Mode

Control-Plane Interface Configuration

### Command Usage

- ◆ Only one policy map can be assigned to the control-plane interface.
- ◆ First define a class map, then define a policy map, and finally use the **service-policy** command to bind the policy map to the control-plane interface.
- ◆ The switch does not allow a policy map to be bound to an interface for egress traffic.

### Example

This example applies a service policy to the control-plane interface.

```
Console(config)#control-plane
Console(config-cp)#service-policy input cpu-policy
Console(config-cp)#
```

**show policy-map control-plane** This command displays the QoS policy map that defines classification criteria for incoming traffic on the control-plane interface.

### Syntax

**show policy-map control-plane input** [**class** *class-map-name*] [**hardware counters**]

*class-map-name* - Name of the class map. (Range: 1-32 characters)

**hardware counters** - Shows statistics for the policy or class.

### Command Mode

Privileged Exec

## Example

```
Console#show policy-map control-plane input

Console# show policy-map control-plane input class cp-class hardware counters
Service-policy cpu-rate-limit-policy
Class-map cp-class
  Receive Packets:      95
  Drop Packets:        0

Console#
```



# Multicast Filtering Commands

This switch uses IGMP (Internet Group Management Protocol) to check for any attached hosts that want to receive a specific multicast service. It identifies the ports containing hosts requesting a service and sends data out to those ports only. It then propagates the service request up to any neighboring multicast switch/router to ensure that it will continue to receive the multicast service.

**Table 134: Multicast Filtering Commands**

Command Group	Function
<a href="#">IGMP Snooping</a>	Configures multicast groups via IGMP snooping or static assignment, sets the IGMP version, enables proxy reporting, displays current snooping settings, and displays the multicast service and group members
<a href="#">Static Multicast Routing</a>	Configures static multicast router ports which forward all inbound multicast traffic to the attached VLANs
<a href="#">IGMP Filtering and Throttling</a>	Configures IGMP filtering and throttling
<a href="#">MLD Snooping</a>	Configures multicast snooping for IPv6
<a href="#">MLD Filtering and Throttling</a>	Configures MLD filtering and throttling for IPv6.
<a href="#">IGMP (Layer 3)</a>	Configures the IGMP protocol used with multicast routing in IPv4 networks
<a href="#">MVR for IPv4</a>	Configures a single network-wide multicast VLAN shared by hosts residing in other standard or private VLAN groups, preserving security and data isolation for normal traffic
<a href="#">MVR for IPv6</a>	Configures a single network-wide multicast VLAN shared by hosts residing in other standard or private VLAN groups, preserving security and data isolation for normal traffic

## IGMP Snooping

This section describes commands used to configure IGMP snooping on the switch.

**Table 135: IGMP Snooping Commands**

Command	Function	Mode
<a href="#">ip igmp snooping</a>	Enables IGMP snooping	GC
<a href="#">ip igmp snooping mrouter-forward-mode dynamic</a>	Restricts multicast stream forwarding to joined groups only	GC
<a href="#">ip igmp snooping proxy-reporting</a>	Enables IGMP Snooping with Proxy Reporting	GC

**Table 135: IGMP Snooping Commands (Continued)**

Command	Function	Mode
<code>ip igmp snooping report-suppression</code>	Configures report suppression for IGMP Snooping	GC
<code>ip igmp snooping querier</code>	Allows this device to act as the querier for IGMP snooping	GC
<code>ip igmp snooping router-alert-option-check</code>	Discards any IGMPv2/v3 packets that do not include the Router Alert option	GC
<code>ip igmp snooping router-port-expire-time</code>	Configures the querier timeout	GC
<code>ip igmp snooping tcn-flood</code>	Floods multicast traffic when a Spanning Tree topology change occurs	GC
<code>ip igmp snooping tcn-query-solicit</code>	Sends an IGMP Query Solicitation when a Spanning Tree topology change occurs	GC
<code>ip igmp snooping unregistered-data-flood</code>	Floods unregistered multicast traffic into the attached VLAN	GC
<code>ip igmp snooping unsolicited-report-interval</code>	Specifies how often the upstream interface should transmit unsolicited IGMP reports (when report suppression/proxy reporting is enabled)	GC
<code>ip igmp snooping version</code>	Configures the IGMP version for snooping	GC
<code>ip igmp snooping version-exclusive</code>	Discards received IGMP messages which use a version different to that currently configured	GC
<code>ip igmp snooping vlan general-query-suppression</code>	Suppresses general queries except for ports attached to downstream multicast hosts	GC
<code>ip igmp snooping vlan immediate-leave</code>	Immediately deletes a member port of a multicast service if a leave packet is received at that port and immediate-leave is enabled for the parent VLAN	GC
<code>ip igmp snooping vlan last-memb-query-count</code>	Configures the number of IGMP proxy query messages that are sent out before the system assumes there are no local members	GC
<code>ip igmp snooping vlan last-memb-query-intvl</code>	Configures the last-member-query interval	GC
<code>ip igmp snooping vlan mrd</code>	Sends multicast router solicitation messages	GC
<code>ip igmp snooping vlan proxy-address</code>	Configures a static address for proxy IGMP query and reporting	GC
<code>ip igmp snooping vlan proxy-reporting</code>	Enables IGMP Snooping with Proxy Reporting	GC
<code>ip igmp snooping vlan query-interval</code>	Configures the interval between sending IGMP general queries	GC
<code>ip igmp snooping vlan query-resp-intvl</code>	Configures the maximum time the system waits for a response to general queries	GC
<code>ip igmp snooping vlan static</code>	Adds an interface as a member of a multicast group	GC
<code>ip igmp snooping vlan version</code>	Configures the IGMP version for snooping	GC
<code>ip igmp snooping vlan version-exclusive</code>	Discards received IGMP messages which use a version different to that currently configured	GC

**Table 135: IGMP Snooping Commands** (Continued)

Command	Function	Mode
<code>clear ip igmp snooping groups dynamic</code>	Clears multicast group information dynamically learned through IGMP snooping	PE
<code>clear ip igmp snooping statistics</code>	Clears IGMP snooping statistics	PE
<code>show ip igmp snooping</code>	Shows the IGMP snooping, proxy, and query configuration	PE
<code>show ip igmp snooping group</code>	Shows known multicast group, source, and host port mapping	PE
<code>show ip igmp snooping mrouter</code>	Shows multicast router ports	PE
<code>show ip igmp snooping statistics</code>	Shows IGMP snooping protocol statistics for the specified interface	PE

**ip igmp snooping** This command enables IGMP snooping globally on the switch or on a selected VLAN interface. Use the **no** form to disable it.

#### Syntax

**[no] ip igmp snooping [vlan *vlan-id*]**

*vlan-id* - VLAN ID (Range: 1-4094)

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ When IGMP snooping is enabled globally, the per VLAN interface settings for IGMP snooping take precedence.
- ◆ When IGMP snooping is disabled globally, snooping can still be configured per VLAN interface, but the interface settings will not take effect until snooping is re-enabled globally.

#### Example

The following example enables IGMP snooping globally.

```
Console(config)#ip igmp snooping
Console(config)#
```

**ip igmp snooping mrouter-forward-mode dynamic** This command configures multicast router ports to forward multicast streams only when multicast groups are joined. Use the **no** form to disable it.

#### Syntax

**ip igmp snooping mrouter-forward dynamic**

**no ip igmp snooping mrouter-forward**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Example

The following example enables IGMP dynamic forwarding.

```
Console(config)#ip igmp snooping mrouter-forward dynamic
Console(config)#
```

**ip igmp snooping proxy-reporting** This command enables IGMP Snooping with Proxy Reporting. Use the **no** form to restore the default setting.

#### Syntax

**[no] ip igmp snooping proxy-reporting**

**ip igmp snooping vlan *vlan-id* proxy-reporting {enable | disable}**

**no ip igmp snooping vlan *vlan-id* proxy-reporting**

*vlan-id* - VLAN ID (Range: 1-4094)

**enable** - Enable on the specified VLAN.

**disable** - Disable on the specified VLAN.

#### Default Setting

Global: Disabled

VLAN: Based on global setting

#### Command Mode

Global Configuration

#### Command Usage

- ◆ When proxy reporting is enabled with this command, reports received from downstream hosts are summarized and used to build internal membership states. Proxy-reporting devices may use the all-zeros IP source address when forwarding any summarized reports upstream. For this reason, IGMP membership reports received by the snooping switch must not be rejected because the source IP address is set to 0.0.0.0.

- ◆ When proxy reporting is enabled with this command, the switch performs “IGMP Snooping with Proxy Reporting” (as defined in DSL Forum TR-101, April 2006), including report suppression, last leave, and query suppression. Report suppression intercepts, absorbs and summarizes IGMP reports coming from downstream hosts. Last leave sends out a proxy query when the last member leaves a multicast group, and query suppression means that specific queries are not forwarded from an upstream multicast router to hosts downstream from this device.
- ◆ If the IGMP proxy reporting is configured on a VLAN, this setting takes precedence over the global configuration.

### Example

```
Console(config)#ip igmp snooping proxy-reporting
Console(config)#
```

**ip igmp snooping report-suppression** This command enables IGMP snooping with report suppression. Use the **no** form to restore the default setting.

### Syntax

#### **[no] ip igmp snooping report-suppression**

**ip igmp snooping vlan *vlan-id* report-suppression {enable | disable}**

**no ip igmp snooping vlan *vlan-id* report-suppression**

*vlan-id* - VLAN ID (Range: 1-4094)

**enable** - Enable on the specified VLAN.

**disable** - Disable on the specified VLAN.

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ When IGMP snooping report suppression is enabled with this command, the switch performs report suppression (as defined in DSL Forum TR-101, April 2006). If proxy reporting is enabled (see [ip igmp snooping proxy-reporting](#)), report suppression will still be enabled, regardless of the configuration setting for the report suppression command.
- ◆ IGMP reports are relayed to the router port only when necessary; that is, when the first user joins a multicast group, and once only per multicast group in response to an IGMP query.

- ◆ When report suppression and proxy reporting are both disabled, all IGMP reports received by the switch are forwarded natively to the upstream multicast routers.

### Example

```
Console(config)#ip igmp snooping vlan 1 report-suppression enable
Console(config)#
```

**ip igmp snooping querier** This command enables the switch as an IGMP querier. Use the **no** form to disable it.

### Syntax

**[no] ip igmp snooping querier**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

If enabled, the switch will serve as querier if elected. The querier is responsible for asking hosts if they want to receive multicast traffic.

### Example

```
Console(config)#ip igmp snooping querier
Console(config)#
```

**ip igmp snooping router-alert-option-check** This command discards any IGMPv2/v3 packets that do not include the Router Alert option. Use the **no** form to ignore the Router Alert Option when receiving IGMP messages.

### Syntax

**[no] ip igmp snooping router-alert-option-check**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

As described in Section 9.1 of RFC 3376 for IGMP Version 3, the Router Alert Option can be used to protect against DOS attacks. One common method of attack is

launched by an intruder who takes over the role of querier, and starts overloading multicast hosts by sending a large number of group-and-source-specific queries, each with a large source list and the Maximum Response Time set to a large value.

To protect against this kind of attack, (1) routers should not forward queries. This is easier to accomplish if the query carries the Router Alert option. (2) Also, when the switch is acting in the role of a multicast host (such as when using proxy routing), it should ignore version 2 or 3 queries that do not contain the Router Alert option.

### Example

```
Console(config)#ip igmp snooping router-alert-option-check
Console(config)#
```

**ip igmp snooping router-port-expire-time** This command configures the querier timeout. Use the **no** form to restore the default.

### Syntax

**ip igmp snooping router-port-expire-time** *seconds*

**no ip igmp snooping router-port-expire-time**

*seconds* - The time the switch waits after the previous querier stops before it considers it to have expired. (Range: 1-65535;  
Recommended Range: 300-500)

### Default Setting

300 seconds

### Command Mode

Global Configuration

### Example

The following shows how to configure the timeout to 400 seconds:

```
Console(config)#ip igmp snooping router-port-expire-time 400
Console(config)#
```

**ip igmp snooping tcn-flood** This command enables flooding of multicast traffic if a spanning tree topology change notification (TCN) occurs. Use the **no** form to disable flooding.

### Syntax

**[no] ip igmp snooping tcn-flood**

### Default Setting

Disabled

## Command Mode

Global Configuration

## Command Usage

- ◆ When a spanning tree topology change occurs, the multicast membership information learned by the switch may be out of date. For example, a host linked to one port before the topology change (TC) may be moved to another port after the change. To ensure that multicast data is delivered to all receivers, by default, a switch in a VLAN (with IGMP snooping enabled) that receives a Bridge Protocol Data Unit (BPDU) with the TC bit set (by the root bridge) will enter into “multicast flooding mode” for a period of time until the topology has stabilized and the new locations of all multicast receivers are learned.
- ◆ If a topology change notification (TCN) is received, and all the uplink ports are subsequently deleted, a timeout mechanism is used to delete all of the currently learned multicast channels.
- ◆ When a new uplink port starts up, the switch sends unsolicited reports for all current learned channels out through the new uplink port.
- ◆ By default, the switch immediately enters into “multicast flooding mode” when a spanning tree topology change occurs. In this mode, multicast traffic will be flooded to all VLAN ports. If many ports have subscribed to different multicast groups, flooding may cause excessive loading on the link between the switch and the end host. Flooding may be disabled to avoid this, causing multicast traffic to be delivered only to those ports on which multicast group members have been learned.
- ◆ When the spanning tree topology changes, the root bridge sends a proxy query to quickly re-learn the host membership/port relations for multicast channels. The root bridge also sends an unsolicited Multicast Router Discover (MRD) request to quickly locate the multicast routers in this VLAN.

The proxy query and unsolicited MRD request are flooded to all VLAN ports except for the receiving port when the switch receives such packets.

## Example

The following example enables TCN flooding.

```
Console(config)#ip igmp snooping tcn-flood
Console(config)#
```

**ip igmp snooping tcn-query-solicit** This command instructs the switch to send out an IGMP general query solicitation when a spanning tree topology change notification (TCN) occurs. Use the **no** form to disable this feature.

#### Syntax

**[no] ip igmp snooping tcn-query-solicit**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ When the root bridge in a spanning tree receives a topology change notification for a VLAN where IGMP snooping is enabled, it issues a global IGMP leave message (query solicitation). When a switch receives this solicitation, it floods it to all ports in the VLAN where the spanning tree change occurred. When an upstream multicast router receives this solicitation, it will also immediately issues an IGMP general query.
- ◆ The **ip igmp snooping tcn query-solicit** command can be used to send a query solicitation whenever it notices a topology change, even if the switch is not the root bridge in the spanning tree.

#### Example

The following example instructs the switch to issue an IGMP general query whenever it receives a spanning tree topology change notification.

```
Console(config)#ip igmp snooping tcn-query-solicit
Console(config)#
```

**ip igmp snooping unregistered-data-flood** This command floods unregistered multicast traffic into the attached VLAN. Use the **no** form to drop unregistered multicast traffic.

#### Syntax

**[no] ip igmp snooping unregistered-data-flood**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

### Command Usage

Once the table used to store multicast entries for IGMP snooping and multicast routing is filled, no new entries are learned. If no router port is configured in the attached VLAN, and unregistered-flooding is disabled, any subsequent multicast traffic not found in the table is dropped, otherwise it is flooded throughout the VLAN.

### Example

```
Console(config)#ip igmp snooping unregistered-data-flood
Console(config)#
```

### **ip igmp snooping unsolicited-report- interval**

This command specifies how often the upstream interface should transmit unsolicited IGMP reports when report suppression/proxy reporting is enabled. Use the **no** form to restore the default value.

### Syntax

**ip igmp snooping unsolicited-report-interval** *seconds*

**no ip igmp snooping unsolicited-report-interval**

*seconds* - The interval at which to issue unsolicited reports. (Range: 1-65535 seconds)

### Default Setting

400 seconds

### Command Mode

Global Configuration

### Command Usage

- ◆ When a new upstream interface (that is, uplink port) starts up, the switch sends unsolicited reports for all currently learned multicast channels out through the new upstream interface.
- ◆ This command only applies when report suppression/proxy reporting is enabled (see [page 695](#) and [page 694](#)).

### Example

```
Console(config)#ip igmp snooping unsolicited-report-interval 5
Console(config)#
```

**ip igmp snooping version** This command configures the IGMP snooping version. Use the **no** form to restore the default.

### Syntax

**ip igmp snooping [vlan *vlan-id*] version {1 | 2 | 3}**

**no ip igmp [vlan *vlan-id*] snooping version**

*vlan-id* - VLAN ID (Range: 1-4094)

**1** - IGMP Version 1

**2** - IGMP Version 2

**3** - IGMP Version 3

### Default Setting

Global: IGMP Version 2

VLAN: Not configured, based on global setting

### Command Mode

Global Configuration

### Command Usage

- ◆ This command configures the IGMP report/query version used by IGMP snooping. Versions 1 - 3 are all supported, and versions 2 and 3 are backward compatible, so the switch can operate with other devices, regardless of the snooping version employed.
- ◆ If the IGMP snooping version is configured on a VLAN, this setting takes precedence over the global configuration.

### Example

The following configures the global setting for IGMP snooping to version 1.

```
Console(config)#ip igmp snooping version 1
Console(config)#
```

**ip igmp snooping version-exclusive** This command discards any received IGMP messages (except for multicast protocol packets) which use a version different to that currently configured by the **ip igmp snooping version** command. Use the **no** form to disable this feature.

### Syntax

**ip igmp snooping [vlan *vlan-id*] version-exclusive**

**no ip igmp snooping version-exclusive**

*vlan-id* - VLAN ID (Range: 1-4094)

### Default Setting

Global: Disabled  
VLAN: Using Global Status

### Command Mode

Global Configuration  
VLAN Configuration

### Command Usage

- ◆ If version exclusive is disabled on a VLAN, then this setting is based on the global setting. If it is enabled on a VLAN, then this setting takes precedence over the global setting.
- ◆ When this function is disabled, the currently selected version is backward compatible (see the [ip igmp snooping version](#) command).

### Example

```
Console(config)#ip igmp snooping version-exclusive  
Console(config)#
```

## ip igmp snooping vlan general-query- suppression

This command suppresses general queries except for ports attached to downstream multicast hosts. Use the **no** form to flood general queries to all ports except for the multicast router port.

### Syntax

**[no] ip igmp snooping vlan *vlan-id* general-query-suppression**

*vlan-id* - VLAN ID (Range: 1-4094)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ By default, general query messages are flooded to all ports, except for the multicast router through which they are received.
- ◆ If general query suppression is enabled, then these messages are forwarded only to downstream ports which have joined a multicast service.

### Example

```
Console(config)#ip igmp snooping vlan 1 general-query-suppression  
Console(config)#
```

**ip igmp snooping vlan immediate-leave** This command immediately deletes a member port of a multicast service if a leave packet is received at that port and immediate-leave is enabled for the parent VLAN. Use the **no** form to restore the default.

### Syntax

**ip igmp snooping vlan *vlan-id* immediate-leave [by-host-ip]**

**no ip igmp snooping vlan *vlan-id* immediate-leave**

*vlan-id* - VLAN ID (Range: 1-4094)

**by-host-ip** - Specifies that the member port will be deleted only when there are no hosts joining this group.

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ If immediate-leave is *not* used, a multicast router (or querier) will send a group-specific query message when an IGMPv2/v3 group leave message is received. The router/querier stops forwarding traffic for that group only if no host replies to the query within the timeout period. (The timeout for this release is defined by Last Member Query Interval (fixed at one second) \* Robustness Variable (fixed at 2) as defined in RFC 2236.)
- ◆ If immediate-leave is used, the switch assumes that only one host is connected to the interface. Therefore, immediate leave should only be enabled on an interface if it is connected to only one IGMP-enabled device, either a service host or a neighbor running IGMP snooping.
- ◆ If the “by-host-ip” option is used, the router/querier will not send out a group-specific query when an IGMPv2/v3 leave message is received. But will check if there are other hosts joining the multicast group. Only when all hosts on that port leave the group will the member port be deleted.
- ◆ This command is only effective if IGMP snooping is enabled, and IGMPv2 or IGMPv3 snooping is used.

### Example

The following shows how to enable immediate leave.

```
Console(config)#ip igmp snooping vlan 1 immediate-leave
Console(config)#
```

**ip igmp snooping vlan last-memb-query-count** This command configures the number of IGMP proxy group-specific or group-and-source-specific query messages that are sent out before the system assumes there are no more local members. Use the **no** form to restore the default.

#### Syntax

**ip igmp snooping vlan *vlan-id* last-memb-query-count *count***

**no ip igmp snooping vlan *vlan-id* last-memb-query-count**

*vlan-id* - VLAN ID (Range: 1-4094)

*count* - The number of proxy group-specific or group-and-source-specific query messages to issue before assuming that there are no more group members. (Range: 1-255)

#### Default Setting

2

#### Command Mode

Global Configuration

#### Command Usage

This command will take effect only if IGMP snooping proxy reporting or IGMP querier is enabled ([page 694](#)).

#### Example

```
Console(config)#ip igmp snooping vlan 1 last-memb-query-count 7
Console(config)#
```

**ip igmp snooping vlan last-memb-query-intvl** This command configures the last-member-query interval. Use the **no** form to restore the default.

#### Syntax

**ip igmp snooping vlan *vlan-id* last-memb-query-intvl *interval***

**no ip igmp snooping vlan *vlan-id* last-memb-query-intvl**

*vlan-id* - VLAN ID (Range: 1-4094)

*interval* - The interval to wait for a response to a group-specific or group-and-source-specific query message. (Range: 1-31744 tenths of a second)

#### Default Setting

10 (1 second)

#### Command Mode

Global Configuration

### Command Usage

- ◆ When a multicast host leaves a group, it sends an IGMP leave message. When the leave message is received by the switch, it checks to see if this host is the last to leave the group by sending out an IGMP group-specific or group-and-source-specific query message, and starts a timer. If no reports are received before the timer expires, the group record is deleted, and a report is sent to the upstream multicast router.
- ◆ A reduced value will result in reduced time to detect the loss of the last member of a group or source, but may generate more bursty traffic.
- ◆ This command will take effect only if IGMP snooping proxy reporting is enabled (page 694).

### Example

```
Console(config)#ip igmp snooping vlan 1 last-memb-query-intvl 700
Console(config)#
```

**ip igmp snooping vlan mrd** This command enables sending of multicast router solicitation messages. Use the **no** form to disable these messages.

### Syntax

**[no] ip igmp snooping vlan *vlan-id* mrd**

*vlan-id* - VLAN ID (Range: 1-4094)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Multicast Router Discovery (MRD) uses multicast router advertisement, multicast router solicitation, and multicast router termination messages to discover multicast routers. Devices send solicitation messages in order to solicit advertisement messages from multicast routers. These messages are used to discover multicast routers on a directly attached link. Solicitation messages are also sent whenever a multicast forwarding interface is initialized or re-initialized. Upon receiving a solicitation on an interface with IP multicast forwarding and MRD enabled, a router will respond with an advertisement.
- ◆ Advertisements are sent by routers to advertise that IP multicast forwarding is enabled. These messages are sent unsolicited periodically on all router interfaces on which multicast forwarding is enabled. They are sent upon the expiration of a periodic timer, as a part of a router's start up procedure, during the restart of a multicast forwarding interface, and on receipt of a solicitation

message. When the multicast services provided to a VLAN is relatively stable, the use of solicitation messages is not required and may be disabled using the **no ip igmp snooping vlan mrd** command.

- ◆ This command may also be used to disable multicast router solicitation messages when the upstream router does not support MRD, to reduce the loading on a busy upstream router, or when IGMP snooping is disabled in a VLAN.

### Example

This example disables sending of multicast router solicitation messages on VLAN 1.

```
Console(config)#no ip igmp snooping vlan 1 mrd
Console(config)#
```

**ip igmp snooping vlan proxy-address** This command configures a static source address for locally generated query and report messages used by IGMP proxy reporting. Use the **no** form to restore the default source address.

### Syntax

**no ip igmp snooping vlan *vlan-id* proxy-address *source-address***

**no ip igmp snooping vlan *vlan-id* proxy-address**

*vlan-id* - VLAN ID (Range: 1-4094)

*source-address* - The source address used for proxied IGMP query and report, and leave messages. (Any valid IP unicast address)

### Default Setting

0.0.0.0

### Command Mode

Global Configuration

### Command Usage

IGMP Snooping uses a null IP address of 0.0.0.0 for the source of IGMP query messages which are proxied to downstream hosts to indicate that it is not the elected querier, but is only proxying these messages as defined in RFC 4541. The switch also uses a null address in IGMP reports sent to upstream ports.

Many hosts do not implement RFC 4541, and therefore do not understand query messages with the source address of 0.0.0.0. These hosts will therefore not reply to the queries, causing the multicast router to stop sending traffic to them.

To resolve this problem, the source address in proxied IGMP query and report messages can be replaced with any valid unicast address (other than the router's own address) using this command.

### Rules Used for Proxy Reporting

When IGMP Proxy Reporting is disabled, the switch will use a null IP address for the source of IGMP query and report messages unless a proxy query address has been set.

When IGMP Proxy Reporting is enabled, the source address is based on the following criteria:

- ◆ If a proxy query address is configured, the switch will use that address as the source IP address in general and group-specific query messages sent to downstream hosts, and in report and leave messages sent upstream from the multicast router port.
- ◆ If a proxy query address is not configured, the switch will use the VLAN's IP address as the IP source address in general and group-specific query messages sent downstream, and use the source address of the last IGMP message received from a downstream host in report and leave messages sent upstream from the multicast router port.

### Example

The following example sets the source address for proxied IGMP query messages to 10.0.1.8.

```
Console(config)#ip igmp snooping vlan 1 proxy-address 10.0.1.8
Console(config)#
```

**ip igmp snooping vlan query-interval** This command configures the interval between sending IGMP general queries. Use the **no** form to restore the default.

### Syntax

**ip igmp snooping vlan** *vlan-id* **query-interval** *interval*

**no ip igmp snooping vlan** *vlan-id* **query-interval**

*vlan-id* - VLAN ID (Range: 1-4094)

*interval* - The interval between sending IGMP general queries.  
(Range: 2-31744 seconds)

### Default Setting

125 seconds

### Command Mode

Global Configuration

### Command Usage

- ◆ An IGMP general query message is sent by the switch at the interval specified by this command. When this message is received by downstream hosts, all receivers build an IGMP report for the multicast groups they have joined.

- ◆ This command applies when the switch is serving as the querier ([page 696](#)), or as a proxy host when IGMP snooping proxy reporting is enabled ([page 694](#)).

### Example

```
Console(config)#ip igmp snooping vlan 1 query-interval 150
Console(config)#
```

**ip igmp snooping vlan query-resp-intvl** This command configures the maximum time the system waits for a response to general queries. Use the **no** form to restore the default.

### Syntax

**ip igmp snooping vlan *vlan-id* query-resp-intvl *interval***

**no ip igmp snooping vlan *vlan-id* query-resp-intvl**

*vlan-id* - VLAN ID (Range: 1-4094)

*interval* - The maximum time the system waits for a response to general queries. (Range: 10-31740 tenths of a second)

### Default Setting

100 (10 seconds)

### Command Mode

Global Configuration

### Command Usage

This command applies when the switch is serving as the querier ([page 696](#)), or as a proxy host when IGMP snooping proxy reporting is enabled ([page 694](#)).

### Example

```
Console(config)#ip igmp snooping vlan 1 query-resp-intvl 20
Console(config)#
```

**ip igmp snooping vlan static** This command adds a port to a multicast group. Use the **no** form to remove the port.

### Syntax

**[no] ip igmp snooping vlan** *vlan-id* **static** *ip-address* *interface*

*vlan-id* - VLAN ID (Range: 1-4094)

*ip-address* - IP address for multicast group

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**uplink** - specifies an

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Static multicast entries are never aged out.
- ◆ When a multicast entry is assigned to an interface in a specific VLAN, the corresponding traffic can only be forwarded to ports within that VLAN.

### Example

The following shows how to statically configure a multicast group on a port.

```
Console(config)#ip igmp snooping vlan 1 static 228.0.0.15 ethernet 1/5
Console(config)#
```

**clear ip igmp snooping groups dynamic** This command clears multicast group information dynamically learned through IGMP snooping.

### Syntax

**clear ip igmp snooping groups dynamic**

### Command Mode

Privileged Exec

### Command Usage

This command only clears entries learned through IGMP snooping. Statically configured multicast address are not cleared.

### Example

```
Console#clear ip igmp snooping groups dynamic
Console#
```

### clear ip igmp snooping statistics

This command clears IGMP snooping statistics.

### Syntax

**clear ip igmp snooping statistics** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* - VLAN identifier (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#clear ip igmp snooping statistics
Console#
```

### show ip igmp snooping

This command shows the IGMP snooping, proxy, and query configuration settings.

### Syntax

**show ip igmp snooping** [**vlan** *vlan-id*]

*vlan-id* - VLAN ID (1-4094)

### Command Mode

Privileged Exec

### Command Usage

This command displays global and VLAN-specific IGMP configuration settings.

## Example

The following shows the current IGMP snooping configuration:

```

Console#show ip igmp snooping
IGMP Snooping                : Disabled
Router Port Expire Time      : 300 s
Router Alert Check          : Disabled
Router Port Mode             : Forward
TCN Flood                    : Disabled
TCN Query Solicit           : Disabled
Unregistered Data Flood     : Disabled
802.1p Forwarding Priority   : Disabled
Unsolicited Report Interval : 400 s
Version Exclusive            : Disabled
Version                      : 2
Proxy Reporting              : Disabled
Report Suppression          : Disabled
Querier                      : Disabled

VLAN 1:
-----
IGMP Snooping                : Disabled
IGMP Snooping Running Status : Inactive
Version                      : Using global Version (2)
Version Exclusive            : Using global status (Disabled)
Immediate Leave              : Disabled
Last Member Query Interval   : 10 (unit: 1/10s)
Last Member Query Count     : 2
General Query Suppression    : Disabled
Query Interval               : 125
Query Response Interval      : 100 (unit: 1/10s)
Proxy Query Address          : 0.0.0.0
Proxy Reporting              : Using global status (Disabled)
Report Suppression          : Using global status (Disabled)
Multicast Router Discovery    : Disabled

VLAN Static Group   Port
M: static group is for member port
U: static group is for uplink
-----
1    224.1.1.1      Eth 1/ 1(M)
:

```

**show ip igmp snooping group** This command shows known multicast group, source, and host port mappings for the specified VLAN interface, or for all interfaces if none is specified.

## Syntax

```
show ip igmp snooping group [host-ip-addr [ip-address | interface [ip-address] | vlan-id [interface [ip-address]]] | igmpsnp | sort-by-port [ip-address | interface [ip-address] | vlan-id [interface [ip-address]]] | user | vlan vlan-id [user | igmpsnp]]
```

*ip-address* - IP address for multicast group

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**igmpsnp** - Display only entries learned through IGMP snooping.

**sort-by-port** - Display entries sorted by port.

**user** - Display only the user-configured multicast entries.

*vlan-id* - VLAN ID (1-4094)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Member types displayed include IGMP or USER, depending on selected options.

### Example

The following shows the multicast entries learned through IGMP snooping for VLAN 1.

```
Console#show ip igmp snooping group vlan 1
Bridge Multicast Forwarding Entry Count:1
Flag: R - Router port, M - Group member port
      H - Host counts (number of hosts join the group on this port).
      P - Port counts (number of ports join the group).
Up time: Group elapsed time (d:h:m:s).
Expire : Group remaining time (m:s).

VLAN Group          Port          Up time      Expire Count
-----
  1 224.1.1.1
      Eth 1/ 1(R)
      Eth 1/ 2(M)
Console#
```

**show ip igmp snooping mrouter** This command displays information on statically configured and dynamically learned multicast router ports.

### Syntax

**show ip igmp snooping mrouter** [**vlan** *vlan-id*]

*vlan-id* - VLAN ID (Range: 1-4094)

**Default Setting**

Displays multicast router ports for all configured VLANs.

**Command Mode**

Privileged Exec

**Command Usage**

Multicast router port types displayed include Static or Dynamic.

**Example**

The following shows the ports in VLAN 1 which are attached to multicast routers.

```

Console#show ip igmp snooping mrouter vlan 1
VLAN M'cast Router Port Type   Expire
-----
1    Eth 1/4                Dynamic 0:4:28
1    Eth 1/10                Static
2    Eth 1/12                Dynamic
Console#

```

**show ip igmp  
snooping statistics**

This command shows IGMP snooping protocol statistics for the specified interface.

**Syntax****show ip igmp snooping statistics**

```

{input [interface interface] |
output [interface interface] |
query [vlan vlan-id]}

```

**input** - Specifies to display statistics for messages received by the interface.

**output** - Specifies to display statistics for messages sent by the interface.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* - VLAN ID (Range: 1-4094)

**query** - Displays IGMP snooping-related statistics.

**Default Setting**

None

**Command Mode**

Privileged Exec

### Example

The following shows IGMP protocol statistics input:

```

Console#show ip igmp snooping statistics input interface ethernet 1/1
Input Statistics:
Interface Report    Leave    G Query  G(-S)-S Query Drop    Join Succ Group
-----
Eth 1/ 1           23       11       4         10     5       14     5
Console#
    
```

**Table 136: show ip igmp snooping statistics input - display description**

Field	Description
Interface	Shows interface.
Report	The number of IGMP membership reports received on this interface.
Leave	The number of leave messages received on this interface.
G Query	The number of general query messages received on this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages received on this interface.
Drop	The number of times a report, leave or query was dropped. Packets may be dropped due to invalid format, rate limiting, or packet content not allowed.
Join Succ	The number of times a multicast group was successfully joined.
Group	The number of multicast groups active on this interface.

The following shows IGMP protocol statistics output:

```

Console#show ip igmp snooping statistics output interface ethernet 1/1
Output Statistics:
Interface Report    Leave    G Query  G(-S)-S Query Drop    Group
-----
Eth 1/ 1           12       0        1         0     0       0     0
Console#
    
```

**Table 137: show ip igmp snooping statistics output - display description**

Field	Description
Interface	Shows interface.
Report	The number of IGMP membership reports sent from this interface.
Leave	The number of leave messages sent from this interface.
G Query	The number of general query messages sent from this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages sent from this interface.

**Table 137: show ip igmp snooping statistics output - display description**

Field	Description
Drop	The number of times a report, leave or query was dropped. Packets may be dropped due to invalid format, rate limiting, or packet content not allowed.
Group	The number of multicast groups active on this interface.

The following shows IGMP query-related statistics for VLAN 1:

```

Console#show ip igmp snooping statistics query vlan 1
Other Querier           : None
Other Querier Expire    : 0 (m) : 0 (s)
Other Querier Uptime    : 0 (h) : 0 (m) : 0 (s)
Self Querier            : 192.168.2.12
Self Querier Expire     : 0 (m) : 0 (s)
Self Querier Uptime     : 0 (h) : 0 (m) : 0 (s)
General Query Received  : 0
General Query Sent      : 0
Specific Query Received : 0
Specific Query Sent     : 0
Warn Rate Limit         : 0 sec.
V1 Warning Count        : 0
V2 Warning Count        : 0
V3 Warning Count        : 0
Console#

```

**Table 138: show ip igmp snooping statistics vlan query - display description**

Field	Description
Other Querier	IP address of remote querier on this interface.
Other Querier Expire	Time after which remote querier is assumed to have expired.
Other Querier Uptime	Time remote querier has been up.
Self Querier	IP address of local querier on this interface.
Self Querier Expire	Time after which local querier is assumed to have expired.
Self Querier Uptime	Time local querier has been up.
General Query Received	The number of general queries received on this interface.
General Query Sent	The number of general queries sent from this interface.
Specific Query Received	The number of specific queries received on this interface.
Specific Query Sent	The number of specific queries sent from this interface.
Warn Rate Limit	The rate at which received query messages of the wrong version type cause the Vx warning count to increment. Note that "0 sec" means that the Vx warning count is incremented for each wrong message version received.
V1 Warning Count	The number of times the query version received (Version 1) does not match the version configured for this interface.

Table 138: show ip igmp snooping statistics vlan query - display description

Field	Description
V2 Warning Count	The number of times the query version received (Version 2) does not match the version configured for this interface.
V3 Warning Count	The number of times the query version received (Version 3) does not match the version configured for this interface.

## Static Multicast Routing

This section describes commands used to configure static multicast routing on the switch.

Table 139: Static Multicast Interface Commands

Command	Function	Mode
<code>ip igmp snooping vlan mrouter</code>	Adds a multicast router port	GC
<code>show ip igmp snooping mrouter</code>	Shows multicast router ports	PE

**ip igmp snooping vlan mrouter** This command statically configures a (Layer 2) multicast router port on the specified VLAN. Use the **no** form to remove the configuration.

### Syntax

**[no] ip igmp snooping vlan *vlan-id* mrouter *interface***

*vlan-id* - VLAN ID (Range: 1-4094)

*interface*

**ethernet *unit/port***

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel *channel-id*** (Range: 1-28)

### Default Setting

No static multicast router ports are configured.

### Command Mode

Global Configuration

### Command Usage

- ◆ Depending on your network connections, IGMP snooping may not always be able to locate the IGMP querier. Therefore, if the IGMP querier is a known multicast router or switch connected over the network to an interface (port or

trunk) on this switch, that interface can be manually configured to join all the current multicast groups.

- ◆ IGMP Snooping must be enabled globally on the switch (using the `ip igmp snooping` command) before a multicast router port can take effect.

### Example

The following shows how to configure port 10 as a multicast router port within VLAN 1.

```
Console(config)#ip igmp snooping vlan 1 mrouter ethernet 1/10
Console(config)#
```

## IGMP Filtering and Throttling

In certain switch applications, the administrator may want to control the multicast services that are available to end users. For example, an IP/TV service based on a specific subscription plan. The IGMP filtering feature fulfills this requirement by restricting access to specified multicast services on a switch port, and IGMP throttling limits the number of simultaneous multicast groups a port can join.

**Table 140: IGMP Filtering and Throttling Commands**

Command	Function	Mode
<code>ip igmp filter</code>	Enables IGMP filtering and throttling on the switch	GC
<code>ip igmp profile</code>	Sets a profile number and enters IGMP filter profile configuration mode	GC
<code>permit, deny</code> <code>range</code>	Sets a profile access mode to permit or deny Specifies one or a range of multicast addresses for a profile	IPC
<code>ip igmp authentication</code>	Enables RADIUS authentication for IGMP JOIN requests.	IC
<code>ip igmp filter</code>	Assigns an IGMP filter profile to an interface	IC
<code>ip igmp max-groups</code>	Specifies an IGMP throttling number for an interface	IC
<code>ip igmp max-groups action</code>	Sets the IGMP throttling action for an interface	IC
<code>ip igmp query-drop</code>	Drops any received IGMP query packets	IC
<code>ip multicast-data-drop</code>	Drops all multicast data packets	IC
<code>show ip igmp authentication</code>	Displays IGMP authentication settings for interfaces	PE
<code>show ip igmp filter</code>	Displays the IGMP filtering status	PE
<code>show ip igmp profile</code>	Displays IGMP profiles and settings	PE
<code>show ip igmp query-drop</code>	Shows if the interface is configured to drop IGMP query packets	PE

Table 140: IGMP Filtering and Throttling Commands (Continued)

Command	Function	Mode
<code>show ip igmp throttle interface</code>	Displays the IGMP throttling setting for interfaces	PE
<code>show ip multicast-data-drop</code>	Shows if the interface is configured to drop multicast data packets	PE

**ip igmp filter** (Global Configuration) This command globally enables IGMP filtering and throttling on the switch. Use the **no** form to disable the feature.

### Syntax

**[no] ip igmp filter**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ IGMP filtering enables you to assign a profile to a switch port that specifies multicast groups that are permitted or denied on the port. An IGMP filter profile can contain one or more, or a range of multicast addresses; but only one profile can be assigned to a port. When enabled, IGMP join reports received on the port are checked against the filter profile. If a requested multicast group is permitted, the IGMP join report is forwarded as normal. If a requested multicast group is denied, the IGMP join report is dropped.
- ◆ IGMP filtering and throttling only applies to dynamically learned multicast groups, it does not apply to statically configured groups.
- ◆ The IGMP filtering feature operates in the same manner when MVR is used to forward multicast traffic.

### Example

```
Console(config)#ip igmp filter
Console(config)#
```

**ip igmp profile** This command creates an IGMP filter profile number and enters IGMP profile configuration mode. Use the **no** form to delete a profile number.

#### Syntax

**[no] ip igmp profile** *profile-number*

*profile-number* - An IGMP filter profile number. (Range: 1-4294967295)

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

A profile defines the multicast groups that a subscriber is permitted or denied to join. The same profile can be applied to many interfaces, but only one profile can be assigned to one interface. Each profile has only one access mode; either permit or deny.

#### Example

```
Console(config)#ip igmp profile 19
Console(config-igmp-profile)#
```

**permit, deny** This command sets the access mode for an IGMP filter profile.

#### Syntax

**{permit | deny}**

#### Default Setting

Deny

#### Command Mode

IGMP Profile Configuration

#### Command Usage

- ◆ Each profile has only one access mode; either permit or deny.
- ◆ When the access mode is set to permit, IGMP join reports are processed when a multicast group falls within the controlled range. When the access mode is set to deny, IGMP join reports are only processed when a multicast group is not in the controlled range.

### Example

```
Console(config)#ip igmp profile 19
Console(config-igmp-profile)#permit
Console(config-igmp-profile)#
```

**range** This command specifies multicast group addresses for a profile. Use the **no** form to delete addresses from a profile.

### Syntax

**[no] range** *low-ip-address high-ip-address*

*low-ip-address* - A valid IP address of a multicast group or start of a group range.

*high-ip-address* - A valid IP address for the end of a multicast group range.

### Default Setting

None

### Command Mode

IGMP Profile Configuration

### Command Usage

Enter this command multiple times to specify more than one multicast address or address range for a profile.

### Example

```
Console(config)#ip igmp profile 19
Console(config-igmp-profile)#range 239.2.3.1 239.2.3.100
Console(config-igmp-profile)#
```

**ip igmp authentication** This command enables IGMP authentication on the specified interface. When enabled and an IGMP JOIN request is received, an authentication request is sent to a configured RADIUS server. Use the **no** form to disable IGMP authentication.

### Syntax

**[no] ip igmp authentication**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ If IGMP authentication is enabled on an interface, and a join report is received on the interface, the switch will send an access request to the RADIUS server to perform authentication.
- ◆ Only when the RADIUS server responds with an authentication success message will the switch learn the group report. Once the group is learned, the switch will not send an access request to the RADIUS server when receiving the same report again within a one (1) day period.
- ◆ If the RADIUS server responds that authentication failed or the timer expires, the report will be dropped and the group will not be learned. The entry (host MAC, port number, VLAN ID, and group IP) will be put in the “authentication failed list”.
- ◆ The “authentication failed list” is valid for the period of the interval defined by the command `ip igmp snooping vlan query-interval`. When receiving the same report during this interval, the switch will not send the access request to the RADIUS server.
- ◆ If the interface leaves the group and subsequently rejoins the same group, the join report needs to again be authenticated.
- ◆ When receiving an IGMP v3 report message, the switch will send the access request to the RADIUS server only when the record type is either IS\_EX or TO\_EX, and the source list is empty. Other types of packets will not initiate RADIUS authentication.

IS\_EX (MODE\_IS\_EXCLUDE) - Indicates that the interface’s filter mode is EXCLUDE for the specified multicast address. The Source Address fields in this Group Record contain the interface’s source list for the specified multicast address, if not empty.

TO\_EX (CHANGE\_TO\_EXCLUDE\_MODE) - Indicates that the interface has changed to EXCLUDE filter mode for the specified multicast address. The Source Address fields in this Group Record contain the interface’s new source list for the specified multicast address, if not empty.

- ◆ When a report is received for the first time and is being authenticated, whether authentication succeeds or fails, the report will still be sent to the multicast-router port.
- ◆ The following table shows the RADIUS server Attribute Value Pairs used for authentication:

**Table 141: IGMP Authentication RADIUS Attribute Value Pairs**

Attribute Name	AVP Type	Entry
USER_NAME	1	User MAC address
USER_PASSWORD	2	User MAC address
NAS_IP_ADDRESS	4	Switch IP address

Table 141: IGMP Authentication RADIUS Attribute Value Pairs

Attribute Name	AVP Type	Entry
NAS_PORT	5	User Port Number
FRAMED_IP_ADDRESS	8	Multicast Group ID

### Example

This example shows how to enable IGMP Authentication on all of the switch's Ethernet interfaces.

```
Console(config)#interface ethernet 1/1-28
Console(config-if)#ip igmp authentication
Console#
```

### Related Commands

[show ip igmp authentication](#)

**ip igmp filter** (Interface Configuration) This command assigns an IGMP filtering profile to an interface on the switch. Use the **no** form to remove a profile from an interface.

### Syntax

**ip igmp filter** *profile-number*

**no ip igmp filter**

*profile-number* - An IGMP filter profile number. (Range: 1-4294967295)

### Default Setting

None

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ The IGMP filtering profile must first be created with the [ip igmp profile](#) command before being able to assign it to an interface.
- ◆ Only one profile can be assigned to an interface.
- ◆ A profile can also be assigned to a trunk interface. When ports are configured as trunk members, the trunk uses the filtering profile assigned to the first port member in the trunk.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ip igmp filter 19
Console(config-if)#
```

**ip igmp max-groups** This command sets the IGMP throttling number for an interface on the switch. Use the **no** form to restore the default setting.

### Syntax

**ip igmp max-groups** *number*

**no ip igmp max-groups**

*number* - The maximum number of multicast groups an interface can join at the same time. (Range: 1-1024)

### Default Setting

1024

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ IGMP throttling sets a maximum number of multicast groups that a port can join at the same time. When the maximum number of groups is reached on a port, the switch can take one of two actions; either “deny” or “replace” (see the [ip igmp max-groups action](#) command). If the action is set to deny, any new IGMP join reports will be dropped. If the action is set to replace, the switch randomly removes an existing group and replaces it with the new multicast group.
- ◆ IGMP throttling can also be set on a trunk interface. When ports are configured as trunk members, the trunk uses the throttling settings of the first port member in the trunk.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ip igmp max-groups 10
Console(config-if)#
```

**ip igmp max-groups action** This command sets the IGMP throttling action for an interface on the switch. Use the no form of the command to restore the action to the default value.

#### Syntax

**ip igmp max-groups action {deny | replace}**

**no ip igmp max-groups action**

**deny** - The new multicast group join report is dropped.

**replace** - The new multicast group replaces an existing group.

#### Default Setting

Deny

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

When the maximum number of groups is reached on a port, the switch can take one of two actions; either “deny” or “replace.” If the action is set to deny, any new IGMP join reports will be dropped. If the action is set to replace, the switch randomly removes an existing group and replaces it with the new multicast group.

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ip igmp max-groups action replace
Console(config-if)#
```

**ip igmp query-drop** This command drops any received IGMP query packets. Use the no form to restore the default setting.

#### Syntax

**[no] ip igmp query-drop [vlan *vlan-id*]**

*vlan-id* - VLAN ID (Range: 1-4094)

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

This command can be used to drop any query packets received on the specified interface. If this switch is acting as a Querier, this prevents it from being affected by messages received from another Querier.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ip igmp query-drop
Console(config-if)#
```

**ip multicast-data-drop** This command drops all multicast data packets. Use the **no** form to disable this feature.

### Syntax

**[no] ip multicast-data-drop**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

This command can be used to stop multicast services from being forwarded to users attached to the downstream port (i.e., the interfaces specified by this command).

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ip multicast-data-drop
Console(config-if)#
```

**show ip igmp authentication** This command displays the interface settings for IGMP authentication.

### Syntax

**show ip igmp authentication interface** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Using this command without specifying an interface displays information for all interfaces.

### Example

```
Console#show ip igmp authentication
Ethernet 1/1: Enabled
Ethernet 1/2: Enabled
Ethernet 1/3: Enabled
:
Ethernet 1/27: Enabled
Ethernet 1/28: Enabled
Other ports/port channels are Disable
Console#
```

**show ip igmp filter** This command displays the global and interface settings for IGMP filtering.

### Syntax

**show ip igmp filter** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show ip igmp filter
IGMP Filter enabled
Console#show ip igmp filter interface ethernet 1/1
Ethernet 1/1 information
-----
IGMP Profile 19
Deny
Range 239.1.1.1 239.1.1.1
Range 239.2.3.1 239.2.3.100
Console#
```

**show ip igmp profile** This command displays IGMP filtering profiles created on the switch.

### Syntax

**show ip igmp profile** [*profile-number*]

*profile-number* - An existing IGMP filter profile number.  
(Range: 1-4294967295)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show ip igmp profile
IGMP Profile 19
Deny
Range 239.1.1.1          239.1.1.1
Range 239.2.3.1          239.2.3.100
IGMP Profile 50
Deny
Range 239.1.1.1          239.1.1.12
Console#show ip igmp profile 19
IGMP Profile 19
Deny
Range 239.1.1.1          239.1.1.1
Range 239.2.3.1          239.2.3.100
Console#
```

**show ip igmp query-drop** This command shows if the specified interface is configured to drop IGMP query packets.

### Syntax

**show ip igmp query-drop** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Using this command without specifying an interface displays the query drop configuration for all interfaces.

### Example

```
Console#show ip igmp query-drop interface ethernet 1/1
Ethernet 1/1: Enabled
Console#
```

**show ip igmp throttle interface** This command displays the interface settings for IGMP throttling.

### Syntax

**show ip igmp throttle interface** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Using this command without specifying an interface displays information for all interfaces.

### Example

```
Console#show ip igmp throttle interface ethernet 1/1
Eth 1/1 Information
                Status : FALSE
                Action : Deny
                Max Multicast Groups : 1024
                Current Multicast Groups : 0

Console#
```

**show ip multicast-data-drop** This command shows if the specified interface is configured to drop multicast data packets.

### Syntax

**show ip multicast-data-drop** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Using this command without specifying an interface displays information for all interfaces.

### Example

```
Console#show ip multicast-data-drop interface ethernet 1/1
Ethernet 1/1: Enabled
Console#
```

---

## MLD Snooping

Multicast Listener Discovery (MLD) snooping operates on IPv6 traffic and performs a similar function to IGMP snooping for IPv4. That is, MLD snooping dynamically configures switch ports to limit IPv6 multicast traffic so that it is forwarded only to ports with users that want to receive it. This reduces the flooding of IPv6 multicast packets in the specified VLANs.

There are two versions of the MLD protocol, version 1 and version 2. MLDv1 control packets include Listener Query, Listener Report, and Listener Done messages (equivalent to IGMPv2 query, report, and leave messages). MLDv2 control packets include MLDv2 query and report messages, as well as MLDv1 report and done messages.

Remember that IGMP Snooping and MLD Snooping are independent functions, and can therefore both function at the same time.

**Table 142: MLD Snooping Commands**

<b>Command</b>	<b>Function</b>	<b>Mode</b>
<code>ipv6 mld snooping</code>	Enables MLD Snooping globally	GC
<code>ipv6 mld snooping proxy-reporting</code>	Enables MLD Snooping with Proxy Reporting	GC
<code>ipv6 mld snooping querier</code>	Allows the switch to act as the querier for MLD snooping	GC
<code>ipv6 mld snooping query-interval</code>	Configures the interval between sending MLD general query messages	GC
<code>ipv6 mld snooping query-max-response-time</code>	Configures the maximum response time for a general queries	GC
<code>ipv6 mld snooping robustness</code>	Configures the robustness variable	GC
<code>ipv6 mld snooping router-port-expire-time</code>	Configures the router port expire time	GC
<code>ipv6 mld snooping unknown-multicast mode</code>	Sets an action for unknown multicast packets	GC
<code>ipv6 mld snooping unsolicited-report-interval</code>	Specifies how often the upstream interface should transmit unsolicited MLD snooping reports (when proxy reporting is enabled)	GC
<code>ipv6 mld snooping version</code>	Configures the MLD Snooping version	GC
<code>ipv6 mld snooping vlan immediate-leave</code>	Removes a member port of an IPv6 multicast service if a leave packet is received at that port and MLD immediate-leave is enabled for the parent VLAN	GC
<code>ipv6 mld snooping vlan mrouter</code>	Adds an IPv6 multicast router port	GC
<code>ipv6 mld snooping vlan static</code>	Adds an interface as a member of a multicast group	GC
<code>clear ipv6 mld snooping groups dynamic</code>	Clears multicast group information dynamically learned through MLD snooping	PE
<code>clear ipv6 mld snooping statistics</code>	Clears MLD snooping statistics	PE
<code>show ipv6 mld snooping</code>	Displays MLD Snooping configuration	PE
<code>show ipv6 mld snooping group</code>	Displays the learned groups	PE
<code>show ipv6 mld snooping group source-list</code>	Displays the learned groups and corresponding source list	PE
<code>show ipv6 mld snooping mrouter</code>	Displays the information of multicast router ports	PE
<code>show ipv6 mld snooping statistics</code>	Shows IGMP snooping protocol statistics for the specified interface	PE

**ipv6 mld snooping** This command enables MLD Snooping globally on the switch. Use the **no** form to disable MLD Snooping.

#### Syntax

**[no] ipv6 mld snooping**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Example

The following example enables MLD Snooping:

```
Console(config)#ipv6 mld snooping  
Console(config)#
```

**ipv6 mld snooping proxy-reporting** This command enables MLD Snooping with Proxy Reporting. Use the **no** form to restore the default setting.

#### Syntax

**[no] ipv6 mld snooping proxy-reporting**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ When proxy reporting is enabled with this command, reports received from downstream hosts are summarized and used to build internal membership states. Proxy-reporting devices may use the IPv6 address configured on this VLAN or Source IP address from received report message as source address when forwarding any summarized reports upstream.

#### Example

```
Console(config)#ipv6 mld snooping proxy-reporting  
Console(config)#
```

**ipv6 mld snooping querier** This command allows the switch to act as the querier for MLDv2 snooping. Use the **no** form to disable this feature.

#### Syntax

**[no] ipv6 mld snooping querier**

#### Default Setting

Disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ If enabled, the switch will serve as querier if elected. The querier is responsible for asking hosts if they want to receive multicast traffic.
- ◆ An IPv6 address must be configured on the VLAN interface from which the querier will act if elected. When serving as the querier, the switch uses its own IPv6 address as the query source address.
- ◆ The querier will not start or will disable itself after having started if it detects an IPv6 multicast router on the network.

#### Example

```
Console(config)#ipv6 mld snooping querier  
Console(config)#
```

**ipv6 mld snooping query-interval** This command configures the interval between sending MLD general queries. Use the **no** form to restore the default.

#### Syntax

**ipv6 mld snooping query-interval *interval***

**no ipv6 mld snooping query-interval**

*interval* - The interval between sending MLD general queries.  
(Range: 60-125 seconds)

#### Default Setting

125 seconds

#### Command Mode

Global Configuration

#### Command Usage

- ◆ This command applies when the switch is serving as the querier.

- ◆ An MLD general query message is sent by the switch at the interval specified by this command. When this message is received by downstream hosts, all receivers build an MLD report for the multicast groups they have joined.

### Example

```
Console(config)#ipv6 mld snooping query-interval 150
Console(config)#
```

### ipv6 mld snooping query-max-response-time

This command configures the maximum response time advertised in MLD general queries. Use the **no** form to restore the default.

#### Syntax

**ipv6 mld snooping query-max-response-time** *seconds*

**no ipv6 mld snooping query-max-response-time**

*seconds* - The maximum response time allowed for MLD general queries.  
(Range: 5-25 seconds)

#### Default Setting

10 seconds

#### Command Mode

Global Configuration

#### Command Usage

This command controls how long the host has to respond to an MLD Query message before the switch deletes the group if it is the last member.

### Example

```
Console(config)#ipv6 mld snooping query-max-response-time 15
Console(config)#
```

### ipv6 mld snooping robustness

This command configures the MLD Snooping robustness variable. Use the **no** form to restore the default value.

#### Syntax

**ipv6 mld snooping robustness** *value*

**no ipv6 mld snooping robustness**

*value* - The number of the robustness variable. (Range: 2-10)

#### Default Setting

2

### Command Mode

Global Configuration

### Command Usage

A port will be removed from the receiver list for a multicast service when no MLD reports are detected in response to a number of MLD queries. The robustness variable sets the number of queries on ports for which there is no report.

### Example

```
Console(config)#ipv6 mld snooping robustness 2  
Console(config)#
```

### ipv6 mld snooping router-port- expire-time

This command configures the MLD query timeout. Use the **no** form to restore the default.

### Syntax

**ipv6 mld snooping router-port-expire-time** *time*

**no ipv6 mld snooping router-port-expire-time**

*time* - Specifies the timeout of a dynamically learned router port.  
(Range: 300-500 seconds)

### Default Setting

300 seconds

### Command Mode

Global Configuration

### Command Usage

The router port expire time is the time the switch waits after the previous querier stops before it considers the router port (i.e., the interface that had been receiving query packets) to have expired.

### Example

```
Console(config)#ipv6 mld snooping router-port-expire-time 300  
Console(config)#
```

**ipv6 mld snooping unknown-multicast mode** This command sets the action for dealing with unknown multicast packets. Use the **no** form to restore the default.

#### Syntax

**ipv6 mld snooping unknown-multicast mode {flood | to-router-port}**

**no ipv6 mld snooping unknown-multicast mode**

**flood** - Floods the unknown multicast data packets to all ports.

**to-router-port** - Forwards the unknown multicast data packets to router ports.

#### Default Setting

to-router-port

#### Command Mode

Global Configuration

#### Command Usage

- ◆ When set to “flood,” any received IPv6 multicast packets that have not been requested by a host are flooded to all ports in the VLAN.
- ◆ When set to “router-port,” any received IPv6 multicast packets that have not been requested by a host are forwarded to ports that are connected to a detected multicast router.

#### Example

```
Console(config)#ipv6 mld snooping unknown-multicast mode flood
Console(config)#
```

**ipv6 mld snooping unsolicited-report-interval** This command specifies how often the upstream interface should transmit unsolicited MLD snooping reports when proxy reporting is enabled. Use the **no** form to restore the default value.

#### Syntax

**ipv6 mld snooping unsolicited-report-interval *seconds***

**no ipv6 mld snooping unsolicited-report-interval**

*seconds* - The interval at which to issue unsolicited reports.  
(Range: 1-65535 seconds)

#### Default Setting

400 seconds

#### Command Mode

Global Configuration

### Command Usage

- ◆ When a new upstream interface (that is, uplink port) starts up, the switch sends unsolicited reports for all currently learned multicast channels out through the new upstream interface.
- ◆ This command only applies when `ipv6 mld snooping proxy-reporting` is enabled.

### Example

```
Console(config)#ipv6 mld snooping unsolicited-report-interval 5  
Console(config)#
```

**ipv6 mld snooping version** This command configures the MLD snooping version. Use the **no** form to restore the default.

### Syntax

**ipv6 mld snooping version {1 | 2}**

**no ipv6 mld snooping version**

**1** - MLD version 1.

**2** - MLD version 2.

### Default Setting

Version 1

### Command Mode

Global Configuration

### Example

```
Console(config)#ipv6 mld snooping version 2  
Console(config)#
```

**ipv6 mld snooping vlan immediate-leave** This command immediately deletes a member port of an IPv6 multicast service when a leave packet is received at that port and immediate-leave is enabled for the parent VLAN. Use the **no** form to restore the default.

### Syntax

**ipv6 mld snooping vlan *vlan-id* immediate-leave [by-host-ip]**

**no ipv6 mld snooping vlan *vlan-id* immediate-leave**

*vlan-id* - VLAN ID (Range: 1-4094)

**by-host-ip** - Specifies that the member port will be deleted only when there are no hosts joining this group.

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ If MLD immediate-leave is *not* used, a multicast router (or querier) will send a group-specific query message when an MLD group leave message is received. The router/querier stops forwarding traffic for that group only if no host replies to the query within the specified timeout period.
- ◆ If MLD immediate-leave is enabled, the switch assumes that only one host is connected to the interface. Therefore, immediate leave should only be enabled on an interface if it is connected to only one MLD-enabled device, either a service host or a neighbor running MLD snooping.
- ◆ If the “by-host-ip” option is used, the router/querier will not send out a group-specific query when an MLD leave message is received, but will check if there are other hosts joining the multicast group. Only when all hosts on that port leave the group will the member port be deleted.

### Example

The following shows how to enable MLD immediate leave.

```
Console(config)#ipv6 mld snooping vlan 1 immediate-leave
Console(config)#
```

**ipv6 mld snooping vlan mrouter** This command statically configures an IPv6 multicast router port. Use the **no** form to remove the configuration.

### Syntax

**[no] ipv6 mld snooping vlan** *vlan-id* **mrouter** *interface*

*vlan-id* - VLAN ID (Range: 1-4094)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

No static multicast router ports are configured.

### Command Mode

Global Configuration

### Command Usage

Depending on your network connections, MLD snooping may not always be able to locate the MLD querier. Therefore, if the MLD querier is a known multicast router/switch connected over the network to an interface (port or trunk) on the switch, you can manually configure that interface to join all the current multicast groups.

### Example

The following shows how to configure port 1 as a multicast router port within VLAN 1:

```
Console(config)#ipv6 mld snooping vlan 1 mrouter ethernet 1/1
Console(config)#
```

**ipv6 mld snooping vlan static** This command adds a port to an IPv6 multicast group. Use the **no** form to remove the port.

### Syntax

**[no] ipv6 mld snooping vlan *vlan-id* static *ipv6-address* *interface***

*vlan* - VLAN ID (Range: 1-4094)

*ipv6-address* - An IPv6 address of a multicast group. (Format: X:X:X::X)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#ipv6 mld snooping vlan 1 static ff05:0:1:2:3:4:5:6 ethernet
1/6
Console(config)#
```

**clear ipv6 mld snooping groups dynamic** This command clears multicast group information dynamically learned through MLD snooping.

#### Syntax

**clear ipv6 mld snooping groups dynamic**

#### Command Mode

Privileged Exec

#### Command Usage

This command only clears entries learned through MLD snooping. Statically configured multicast addresses are not cleared.

#### Example

```
Console#clear ipv6 mld snooping groups dynamic
Console#
```

**clear ipv6 mld snooping statistics** This command clears MLD snooping statistics.

#### Syntax

**clear ipv6 mld snooping statistics** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* - VLAN identifier (Range: 1-4094)

#### Command Mode

Privileged Exec

#### Example

```
Console#clear ipv6 mld snooping statistics
Console#
```

**show ipv6 mld snooping** This command shows the current global MLD Snooping configuration and can be used with the `vlan` keyword to show the VLAN specific configuration.

### Syntax

```
show ipv6 mld snooping [vlan [vlan-id]]  
vlan vlan-id - VLAN ID (1-4094)
```

### Command Mode

Privileged Exec

### Command Usage

This command displays global and VLAN-specific MLD snooping configuration settings.

### Example

The following shows MLD Snooping configuration information using the global form of the command first and then the command is executed with keyword `vlan` to show specific VLAN MLD configuration.

```
Console#show ipv6 mld snooping  
Service Status           : Disabled  
Proxy Reporting          : Disabled  
Querier Status           : Disabled  
Robustness                : 2  
Query Interval           : 125 sec  
Query Max Response Time  : 10 sec  
Router Port Expiry Time  : 300 sec  
Unsolicited Report Interval : 400 sec  
Immediate Leave          : Disabled on all VLAN  
Immediate Leave By Host  : Disabled on all VLAN  
Unknown Flood Behavior   : To Router Port  
MLD Snooping Version     : Version 2  
  
VLAN Group IPv6 Address          Port  
-----  
1                ff05:0:1:2:3:4:5:6 Eth 1/1  
  
Console#show ipv6 mld snooping vlan  
VLAN 1  
Immediate Leave           : Disabled  
Unknown Flood Behavior   : To Router Port  
Console#
```

**show ipv6 mld snooping group** This command shows known multicast groups, member ports, and the means by which each group was learned.

### Syntax

**show ipv6 mld snooping group** [*mld-group* | **host-ip-addr** | **sort-by-port** | **vlan** *vlan-id*]

*mld-group* - X:X:X:X show only the groups by the specified IPv6 address

**host-ip-addr** - Displays the ip address of the subscribers of each group.

**sort-by-port** - Displays groups sorted by port number.

**vlan** *vlan-id* - VLAN ID (1-4094), displays the groups of the specified VLAN.

### Command Mode

Privileged Exec

### Example

The following shows MLD Snooping group configuration information:

```

Console#show ipv6 mld snooping group

Total Entries 3, limit 255

VLAN Multicast IPv6 Address                Member Port Type
-----
  1          FF02::01:01:01:01 Eth 1/1    MLD Snooping
  1          FF02::01:01:01:02 Eth 1/1    Multicast Data
  1          FF02::01:01:01:02 Eth 1/1    User

Console#

```

**show ipv6 mld snooping group source-list** This command shows known multicast groups, member ports, the means by which each group was learned, and the corresponding source list.

### Syntax

**show ipv6 mld snooping group source-list** [*ipv6-address* | **vlan** *vlan-id*]

*ipv6-address* - An IPv6 address of a multicast group. (Format: X:X:X:X::X)

*vlan-id* - VLAN ID (1-4094)

### Command Mode

Privileged Exec

### Example

The following shows MLD Snooping group mapping information:

```
Console#show ipv6 mld snooping group source-list

VLAN ID                : 1
Multicast IPv6 Address : FF02::01:01:01:01
Member Port            : Eth 1/1
MLD Snooping           : Multicast Data
Filter Mode            : Include
(if exclude filter mode)
Filter Timer Elapse    : 10 sec.
Request List           : ::01:02:03:04, ::01:02:03:05, ::01:02:03:06,
                        ::01:02:03:07
Exclude List           : ::02:02:03:04, ::02:02:03:05, ::02:02:03:06,
                        ::02:02:03:07
(if include filter mode)
Include List           : ::02:02:03:04, ::02:02:03:05, ::02:02:03:06,
                        ::02:02:03:06

Option:
  Filter Mode: Include, Exclude

Console#
```

**show ipv6 mld snooping mrouter** This command shows MLD Snooping multicast router information.

### Syntax

**show ipv6 mld snooping mrouter** [vlan *vlan-id*]

*vlan-id* - A VLAN identification number. (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 mld snooping mrouter vlan 1
VLAN Multicast Router Port Type      Expire
---- -
  1 Eth 1/ 2                      Static
Console#
```

**show ipv6 mld  
snooping statistics**

This command shows MLD snooping protocol statistics for the specified interface.

**Syntax****show ipv6 mld snooping statistics**

```
{input [interface interface] |
output [interface interface] |
query [vlan vlan-id] |
summary interface interface}
```

**input** - Specifies to display statistics for messages received by the interface.

**output** - Specifies to display statistics for messages sent by the interface.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* - VLAN ID (Range: 1-4094)

**query** - Displays MLD snooping query-related statistics.

**Default Setting**

None

**Command Mode**

Privileged Exec

**Example**

The following shows MLD snooping input-related message statistics:

```
Console#show ipv6 mld snooping statistics input interface ethernet 1/1
Input Statistics:
Interface Report   Leave   G Query   G(-S)-S Query Drop   Join Succ Group
-----
Eth 1/ 1          4       0         0             0         0         0         2
Console#
```

**Table 143: show ipv6 MLD snooping statistics input - display description**

Field	Description
Interface	The unit/port or VLAN interface.
Report	The number of MLD membership reports received on this interface.
Leave	The number of leave messages received on this interface.
G Query	The number of general query messages received on this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages received on this interface.

**Table 143: show ipv6 mld snooping statistics input - display description**

Field	Description
Drop	The number of times a report, leave or query was dropped. Packets may be dropped due to invalid format, rate limiting, packet content not allowed, or MLD group report received.
Join Succ	The number of times a multicast group was successfully joined.
Group	The number of MLD groups active on this interface.

The following shows MLD snooping output-related message statistics:

```

Console#show ipv6 mld snooping statistics output interface ethernet 1/1
Output Statistics:
Interface Report   Leave   G Query   G(-S)-S Query Drop   Group
-----
Eth 1/ 1           0       0         5           0       0       2

Console#

```

**Table 144: show ipv6 mld snooping statistics output - display description**

Field	Description
Interface	The unit/port or VLAN interface.
Report	The number of MLD membership reports transmitted from this interface.
Leave	The number of leave messages transmitted from this interface.
G Query	The number of general query messages transmitted from this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages transmitted from this interface.
Drop	The number of times a report, leave or query was dropped. Packets may be dropped due to invalid format, rate limiting, packet content not allowed, or MLD group report received.
Join Succ	The number of times a multicast group was successfully joined.
Group	The number of MLD groups active on this interface.

The following shows MLD snooping query-related message statistics:

```

Console#show ipv6 mld snooping statistics query vlan 1
Other Querier Address      : None
Other Querier Expire      : 0 (m) : 0 (s)
Other Querier Uptime      : 0 (h) : 0 (m) : 0 (s)
Self Querier Address      : ::
Self Querier Expire Time  : 1 (m) : 49 (s)
Self Querier UpTime       : 0 (h) : 9 (m) : 6 (s)
General Query Received    : 0
General Query Sent        : 6
Specific Query Received   : 0
Specific Query Sent       : 0

Console#

```

**Table 145: show ipv6 MLD snooping statistics query - display description**

Field	Description
Other Querier Address	IP address of remote querier on this interface.
Other Querier Expire	Time after which remote querier is assumed to have expired.
Other Querier Uptime	Time remote querier has been up.
Self Querier	IP address of local querier on this interface.
Self Querier Expire	Time after which local querier is assumed to have expired.
Self Querier Uptime	Time local querier has been up.
General Query Received	The number of general queries received on this interface.
General Query Sent	The number of general queries sent from this interface.
Specific Query Received	The number of group specific queries received on this interface.
Specific Query Sent	The number of group specific queries sent from this interface.

The following shows MLD snooping summary statistics:

```

Console#show ipv6 mld snooping statistics summary interface e 1/1
Number of Groups: 1
Querier:          :                               Report & Leave:  :
  Transmit       :                               Transmit       :
    General      : 6                               Report         : 0
    Group Specific: 0                               Leave          : 0
Recieved         :                               Recieved       :
  General        : 0                               Report         : 4
  Group Specific: 0                               Leave          : 0
                                                       join Success   : 0
                                                       Filter Drop    : 0
                                                       Source Port Drop: 0
                                                       Others Drop    : 0

Console#show ipv6 mld snooping statistics summary interface vlan 1
Number of Groups: 1
Querier:          :                               Report & Leave:  :
  Other Querier  : None                               Host Addr      : None
                                                       Unsolicit Expire : 0 sec

  Other Uptime   : 0 (h) : 0 (m) : 0 (s)
  Other Expire   : 0 (m) : 0 (s)
  Self Addr      : None
  Self Expire    : 2 (m) : 3 (s)
  Self Uptime    : 0 (h) : 10 (m) : 58 (s)
  Transmit      :                               Transmit       :
    General      : 7                               Report         : 0
    Group Specific: 0                               Leave          : 0
Recieved         :                               Recieved       :
  General        : 0                               Report         : 4
  Group Specific: 0                               Leave          : 0
                                                       join Success   : 0
                                                       Filter Drop    : 0
                                                       Source Port Drop: 0
                                                       Others Drop    : 0

Console#

```

**Table 146: show ipv6 MLD snooping statistics summary - display description**

Field	Description
Number of Groups	Number of active MLD groups active on the specified interface.
<i>Physical Interface (Port/Trunk)</i>	
<i>Querier:</i>	
<i>Transmit</i>	
General	The number of general queries sent from this interface.
Group Specific	The number of group specific queries sent from this interface.
<i>Recieved</i>	
General	The number of general queries received on this interface.
Group Specific	The number of group specific queries received on this interface.
<i>Report &amp; Leave</i>	
<i>Transmit</i>	
Report	The number of MLD membership reports sent from this interface.
Leave	The number of leave messages sent from this interface.
<i>Recieved</i>	
Report	The number of MLD membership reports received on this interface.
Leave	The number of leave messages received on this interface.
join Success	The number of times a multicast group was successfully joined.
Filter Drop	The number of messages dropped by an MLD filtering profile.
Source Port Drop	The number of dropped messages that are received on MVR source port or mrouter port.
Others Drop	The number of received invalid messages.
<i>Logical Interface (VLAN)</i>	The following additional parameters are included for a VLAN interface
<i>Querier:</i>	
Other Querier	IPv6 address of remote querier on this interface.
Other Uptime	Time remote querier has been up.
Other Expire	Time after which remote querier is assumed to have expired.
Self Addr	IPv6 address of local querier on this interface.
Self Expire	Time after which local querier is assumed to have expired.
Self Uptime	Time local querier has been up.
<i>Report &amp; Leave</i>	
Host Addr	The link-local or global IPv6 address that is assigned on that VLAN.
Unsolicit Expire	The number of group leaves resulting from timeouts instead of explicit leave messages.

## MLD Filtering and Throttling

In certain switch applications, the administrator may want to control the multicast services that are available to end users. For example, an IP/TV service based on a specific subscription plan. The MLD filtering feature fulfills this requirement by restricting access to specified multicast services on a switch port, and MLD throttling limits the number of simultaneous multicast groups a port can join.

**Table 147: MLD Filtering and Throttling Commands**

Command	Function	Mode
<code>ipv6 mld filter</code>	Enables MLD filtering and throttling on the switch	GC
<code>ipv6 mld profile</code>	Sets a profile number and enters MLD filter profile configuration mode	GC
<code>permit, deny</code>	Sets a profile access mode to permit or deny	IPC
<code>range</code>	Specifies one or a range of multicast addresses for a profile	IPC
<code>ipv6 mld filter</code>	Assigns an MLD filter profile to an interface	IC
<code>ipv6 mld max-groups</code>	Specifies an M:D throttling number for an interface	IC
<code>ipv6 mld max-groups action</code>	Sets the MLD throttling action for an interface	IC
<code>ipv6 mld query-drop</code>	Drops any received MLD query packets	IC
<code>ipv6 multicast-data-drop</code>	Enable multicast data guard mode on a port interface	IC
<code>show ipv6 mld filter</code>	Displays the MLD filtering status	PE
<code>show ipv6 mld profile</code>	Displays MLD profiles and settings	PE
<code>show ipv6 mld query-drop</code>	Shows if the interface is configured to drop MLD query packets	PE
<code>show ipv6 mld throttle interface</code>	Displays the MLD throttling setting for interfaces	PE

**ipv6 mld filter** (Global Configuration) This command globally enables MLD filtering and throttling on the switch. Use the **no** form to disable the feature.

### Syntax

**[no] ipv6 mld filter**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ MLD filtering enables you to assign a profile to a switch port that specifies multicast groups that are permitted or denied on the port. An MLD filter profile can contain one or more, or a range of multicast addresses; but only one profile can be assigned to a port. When enabled, MLD join reports received on the port are checked against the filter profile. If a requested multicast group is permitted, the MLD join report is forwarded as normal. If a requested multicast group is denied, the MLD join report is dropped.
- ◆ MLD filtering and throttling only applies to dynamically learned multicast groups, it does not apply to statically configured groups.
- ◆ The MLD filtering feature operates in the same manner when MVR6 is used to forward multicast traffic.

### Example

```
Console(config)#ipv6 mld filter  
Console(config)#
```

### Related Commands

[show ipv6 mld filter](#)

**ipv6 mld profile** This command creates an MLD filter profile number and enters MLD profile configuration mode. Use the **no** form to delete a profile number.

### Syntax

**[no] ipv6 mld profile** *profile-number*

*profile-number* - An MLD filter profile number. (Range: 1-4294967295)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

A profile defines the multicast groups that a subscriber is permitted or denied to join. The same profile can be applied to many interfaces, but only one profile can be assigned to one interface. Each profile has only one access mode; either permit or deny.

### Example

```
Console(config)#ipv6 mld profile 19  
Console(config-mld-profile)#
```

**Related Commands**  
[show ipv6 mld profile](#)

**permit, deny** This command sets the access mode for an MLD filter profile.

**Syntax**

**{permit | deny}**

**Default Setting**

deny

**Command Mode**

MLD Profile Configuration

**Command Usage**

- ◆ Each profile has only one access mode; either permit or deny.
- ◆ When the access mode is set to permit, MLD join reports are processed when a multicast group falls within the controlled range. When the access mode is set to deny, MLD join reports are only processed when a multicast group is not in the controlled range.

**Example**

```
Console(config)#ipv6 mld profile 19
Console(config-mld-profile)#permit
Console(config-mld-profile)#
```

**range** This command specifies multicast group addresses for a profile. Use the **no** form to delete addresses from a profile.

**Syntax**

**[no] range** *low-ipv6-address high-ipv6-address*

*low-ipv6-address* - A valid IPv6 address (X:X:X:X::X) of a multicast group or start of a group range.

*high-ipv6-address* - A valid IPv6 address (X:X:X:X::X) for the end of a multicast group range.

**Default Setting**

None

**Command Mode**

MLD Profile Configuration

### Command Usage

Enter this command multiple times to specify more than one multicast address or address range for a profile.

### Example

```
Console(config-mld-profile)#range ff01::0101 ff01::0202
Console(config-mld-profile)#
```

**ipv6 mld filter (Interface Configuration)** This command assigns an MLD filtering profile to an interface on the switch. Use the **no** form to remove a profile from an interface.

### Syntax

**ipv6 mld filter** *profile-number*

**no ipv6 mld filter**

*profile-number* - An MLD filter profile number. (Range: 1-4294967295)

### Default Setting

None

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ The MLD filtering profile must first be created with the [ipv6 mld profile](#) command before being able to assign it to an interface.
- ◆ Only one profile can be assigned to an interface.
- ◆ A profile can also be assigned to a trunk interface. When ports are configured as trunk members, the trunk uses the filtering profile assigned to the first port member in the trunk.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ipv6 mld filter 19
Console(config-if)#
```

**ipv6 mld max-groups** This command configures the maximum number of MLD groups that an interface can join. Use the **no** form to restore the default setting.

### Syntax

**ipv6 mld max-groups** *number*

**no ipv6 mld max-groups**

*number* - The maximum number of multicast groups an interface can join at the same time. (Range: 1-255)

### Default Setting

255

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ MLD throttling sets a maximum number of multicast groups that a port can join at the same time. When the maximum number of groups is reached on a port, the switch can take one of two actions; either “deny” or “replace.” If the action is set to deny, any new MLD join reports will be dropped. If the action is set to replace, the switch randomly removes an existing group and replaces it with the new multicast group.
- ◆ MLD throttling can also be set on a trunk interface. When ports are configured as trunk members, the trunk uses the throttling settings of the first port member in the trunk.
- ◆ If the maximum number of MLD groups is set to the default value, the running status of MLD throttling will change to false. This means that any configuration for MLD throttling will have no effect until the maximum number of MLD groups is configured to another value.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ipv6 mld max-groups 10
Console(config-if)#
```

**ipv6 mld max-groups action** This command sets the MLD throttling action for an interface on the switch. Use the **no** form of the command to set the action to the default.

### Syntax

**ipv6 mld max-groups action** {deny | replace}

**no ipv6 mld max-groups action**

**deny** - The new multicast group join report is dropped.

**replace** - The new multicast group replaces an existing group.

### Default Setting

Deny

### Command Mode

Interface Configuration (Ethernet)

### Command Usage

When the maximum number of groups is reached on a port, the switch can take one of two actions; either “deny” or “replace.” If the action is set to deny, any new MLD join reports will be dropped. If the action is set to replace, the switch randomly removes an existing group and replaces it with the new multicast group.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ipv6 mld max-groups action replace
Console(config-if)#
```

**ipv6 mld query-drop** This command drops any received MLD query packets. Use the no form to restore the default setting.

### Syntax

**[no] ipv6 mld query-drop**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

This command can be used to drop any query packets received on the specified interface. If this switch is acting as a Querier, this prevents it from being affected by messages received from another Querier.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ipv6 mld query-drop
Console(config-if)#
```

**ipv6 multicast-data-drop** Use this command to enable multicast data drop mode on a port interface. Use the **no** form of the command to disable multicast data drop.

### Syntax

**[no] ipv6 multicast-data-drop**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet)

### Example

```
Console(config)#interface ethernet 1/3
Console(config-if)#ipv6 multicast-data-drop
Console(config-if)#
```

**show ipv6 mld filter** This command displays the global and interface settings for MLD filtering.

### Syntax

**show ipv6 mld filter** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 mld filter
MLD filter Enabled
Console#show ipv6 mld filter interface ethernet 1/3
Ethernet 1/3 information
-----
MLD Profile 19
Deny
Range ff01::101          ff01::faa
Console#
```

**show ipv6 mld profile** This command displays MLD filtering profiles created on the switch.

### Syntax

**show ipv6 mld profile** [*profile-number*]

*profile-number* - An existing MLD filter profile number.  
(Range: 1-4294967295)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 mld profile
MLD Profile 19
MLD Profile 50
Console#show ipv6 mld profile 19
MLD Profile 19
Deny
Range ff01::101          ff01::faa
Console#
```

**show ipv6 mld query-drop** This command shows if the specified interface is configured to drop MLD query packets.

### Syntax

**show ipv6 mld query-drop** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Using this command without specifying an interface displays all interfaces.

### Example

```
Console#show ipv6 mld query-drop interface ethernet 1/1
Ethernet 1/1: Enabled
Console#
```

**show ipv6 mld throttle interface** This command displays the interface settings for MLD throttling.

### Syntax

**show ipv6 mld throttle interface** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Using this command without specifying an interface displays information for all interfaces.

### Example

```
Console#show ipv6 mld throttle interface ethernet 1/3
Eth 1/3 Information
  Status                : TRUE
  Action                 : Replace
  Max Multicast Groups  : 10
  Current Multicast Groups : 0

Console#
```

## IGMP (Layer 3)

This section describes commands used to configure Layer 3 Internet Group Management Protocol (IGMP) on the switch.

**Table 148: IGMP Commands (Layer 3)**

Command	Function	Mode
<code>ip igmp</code>	Enables IGMP for the specified interface	IC
<code>ip igmp last-member-query-interval</code>	Configures the frequency at which to send query messages in response to receiving a leave message	IC
<code>ip igmp max-resp-interval</code>	Configures the maximum host response time	IC
<code>ip igmp query-interval</code>	Configures frequency for sending host query messages	IC
<code>ip igmp static-group</code>	Configures the router to be a static member of a multicast group on the specified VLAN interface	IC
<code>ip igmp version</code>	Configures IGMP version used on this interface	IC
<code>clear ip igmp group</code>	Deletes entries from the IGMP cache	PE
<code>show ip igmp groups</code>	Displays information for IGMP groups	PE
<code>show ip igmp interface</code>	Displays multicast information for the specified interface	PE

**ip igmp** This command enables IGMP on a VLAN interface. Use the **no** form of this command to disable IGMP on the specified interface.

### Syntax

**[no] ip igmp**

### Default Setting

Disabled

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ IGMP (including query functions) can be enabled for specific VLAN interfaces at Layer 3 through the **ip igmp** command.
- ◆ When a multicast routing protocol, such as PIM, is enabled, IGMP is also enabled.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip igmp
Console(config-if)#end
Console#show ip igmp interface
IGMP                               : Enabled
```

```
IGMP Version           : 2
IGMP Proxy             : Disabled
IGMP Unsolicited Report Interval : 400 sec
Robustness Variable    : 2
Query Interval         : 125 sec
Query Max Response Time : 100 (resolution in 0.1 sec)
Last Member Query Interval : 10 (resolution in 0.1 sec)
Querier                : 0.0.0.0
Joined Groups          :
Static Groups          :
```

```
Console#
```

### Related Commands

[ip igmp snooping \(693\)](#)

[show ip igmp snooping \(710\)](#)

**ip igmp last-member-query-interval** This command configures the frequency at which to send IGMP group-specific or IGMPv3 group-source-specific query messages in response to receiving a group-specific or group-source-specific leave message. Use the **no** form to restore the default setting.

### Syntax

**ip igmp last-member-query-interval** *seconds*

**no ip igmp last-member-query-interval**

*seconds* - The frequency at which the switch sends group-specific or group-source-specific queries upon receipt of a leave message. (Range: 1-255 tenths of a second)

### Default Setting

10 (1 second)

### Command Mode

Interface Configuration (VLAN)

### Command Usage

When the switch receives an IGMPv2 or IGMPv3 leave message from a host that wants to leave a multicast group, source or channel, it sends a number of group-specific or group-source-specific query messages at intervals defined by this command. If no response is received after this period, the switch stops forwarding for the group, source or channel.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip igmp last-member-query-interval 20
Console(config-if)#
```

**ip igmp max-resp-interval** This command configures the maximum response time advertised in IGMP queries. Use the **no** form of this command to restore the default.

#### Syntax

**ip igmp max-resp-interval** *seconds*

**no ip igmp max-resp-interval**

*seconds* - The report delay advertised in IGMP queries.  
(Range: 1-65535 tenths of a second)

#### Default Setting

100 (10 seconds)

#### Command Mode

Interface Configuration (VLAN)

#### Command Usage

- ◆ By varying the Maximum Response Interval, the burstiness of IGMP messages passed on the subnet can be tuned; where larger values make the traffic less bursty, as host responses are spread out over a larger interval.
- ◆ The number of seconds represented by the maximum response interval must be less than the Query Interval ([page 758](#)).

#### Example

The following shows how to configure the maximum response time to 20 seconds.

```
Console(config-if)#ip igmp query-max-response-time 200
Console(config-if)#
```

#### Related Commands

[ip igmp version \(760\)](#)

[ip igmp query-interval \(758\)](#)

**ip igmp query-interval** This command configures the frequency at which host query messages are sent. Use the **no** form to restore the default.

#### Syntax

**ip igmp query-interval** *seconds*

**no ip igmp query-interval**

*seconds* - The frequency at which the switch sends IGMP host-query messages. (Range: 1-255 seconds)

#### Default Setting

125 seconds

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Multicast routers send host query messages to determine the interfaces that are connected to downstream hosts requesting a specific multicast service. Only the designated multicast router for a subnet sends host query messages, which are addressed to the multicast address 224.0.0.1, and uses a time-to-live (TTL) value of 1.
- ◆ For IGMP Version 2 and 3, the designated querier is the lowest IP-addressed multicast router on the subnet.

### Example

The following shows how to configure the query interval to 100 seconds.

```
Console(config-if)#ip igmp query-interval 100
Console(config-if)#
```

### Related Commands

[ip igmp max-resp-interval \(758\)](#)

**ip igmp static-group** This command configures the router to be a static member of a multicast group on the specified VLAN interface. Use the **no** form to remove the static mapping.

### Syntax

**ip igmp static-group** *group-address* [**source** *source-address*]

**no ip igmp static-group**

*group-address* - IP multicast group address. (The group addresses specified cannot be in the range of 224.0.0.1 - 239.255.255.255.)

*source-address* - Source address for a multicast server transmitting traffic to the corresponding multicast group address.

### Default Setting

None

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Group addresses within the entire multicast group address range can be specified with this command. However, if any address within the source-specific multicast (SSM) address range (default 232/8) is specified, but no source address is included in the command, the request to join the multicast group will fail unless the next node up the reverse path tree has statically

mapped this group to a specific source address. Also, if an address outside of the SSM address range is specified, and a specific source address is included in the command, the request to join the multicast group will also fail if the next node up the reverse path tree has enabled the PIM-SSM protocol.

- ◆ If a static group is configured for an any-source multicast (\*,G), a source address cannot subsequently be defined for this group without first deleting the entry.
- ◆ If a static group is configured for one or more source-specific multicasts (S,G), an any-source multicast (\*,G) cannot subsequently be defined for this group without first deleting all of the associated (S,G) entries.
- ◆ Using the **no** form of this command to delete a static group without specifying the source address will delete all any-source and source-specific multicast entries for the specified group.
- ◆ The switch supports a maximum of 16 static group entries.

### Example

The following example assigns VLAN 1 as a static member of the specified multicast group.

```
Console(config)#interface vlan1  
Console(config-if)#ip igmp static-group 225.1.1.1
```

**ip igmp version** This command configures the IGMP version used on an interface. Use the **no** form of this command to restore the default.

### Syntax

**ip igmp version {2 | 3}**

**no ip igmp version**

**2** - IGMP Version 2

**3** - IGMP Version 3

### Default Setting

IGMP Version 2

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ All routers on the subnet must support the same version. However, the multicast hosts on the subnet may support any of the IGMP versions 1 - 3.

- ◆ If the switch receives an IGMP Version 1 Membership Report, it sets a timer to note that there are version 1 hosts which are members of the group for which it heard the report.

If there are Version 1 hosts present for a particular group, the switch will ignore any Leave Group messages that it receives for that group.

- ◆ The switch must be set to version 3 to enable support for source-specific multicasting (SSM).

### Example

```
Console(config-if)#ip igmp version 3
Console(config-if)#
```

**clear ip igmp group** This command deletes entries from the IGMP cache.

### Syntax

**clear ip igmp group**

### Default Setting

Deletes all entries in the cache.

### Command Mode

Privileged Exec

### Example

```
Console#clear ip igmp interface
Console#
```

**show ip igmp groups** This command displays information on multicast groups active on the switch and learned through IGMP.

### Syntax

**show ip igmp groups** [{*group-address* | *interface*} [**detail**] | **detail**]

*group-address* - IP multicast group address.

*interface*

**vlan** *vlan-id* - VLAN ID. (Range: 1-4094)

**detail** - Displays detailed information about the multicast process and source addresses when available.

### Command Mode

Privileged Exec

### Command Usage

To display information about multicast groups, IGMP must first be enabled on the interface to which a group has been assigned using the `ip igmp` command, and multicast routing must be enabled globally on the system using the `ip multicast-routing` command.

### Example

The following shows options for displaying IGMP group information by interface, group address, and static listing.

```

Console#show ip igmp groups
Group Address      Interface VLAN  Last Reporter  Uptime  Expire  V1 Timer
-----
      224.0.17.17           1    192.168.1.10   0:0:1   0:4:19   0:0:0
Console#show ip igmp groups 234.5.6.8
Group Address      Interface VLAN  Last Reporter  Uptime  Expire  V1 Timer
-----
      224.0.17.17           1    192.168.1.10   0:0:1   0:4:19   0:0:0
Console#show ip igmp groups interface vlan 1
Group Address      Interface VLAN  Last Reporter  Uptime  Expire  V1 Timer
-----
      224.0.17.17           1    192.168.1.10   0:0:1   0:4:19   0:0:0
Console#
    
```

**Table 149: show ip igmp groups - display description**

Field	Description
Group Address	IP multicast group address with subscribers directly attached or downstream from the switch.
Interface VLAN	The interface on the switch that has received traffic directed to the multicast group address.
Last Reporter	The IP address of the source of the last membership report received for this multicast group address on this interface.
Uptime	The time elapsed since this entry was created.
Expire	The time remaining before this entry will be aged out. (The default is 260 seconds.) This field displays “stopped” if the Group Mode is INCLUDE.
V1 Timer	The time remaining until the switch assumes that there are no longer any IGMP Version 1 members on the IP subnet attached to this interface. <ul style="list-style-type: none"> <li>◆ If the switch receives an IGMP Version 1 Membership Report, it sets a timer to note that there are Version 1 hosts present which are members of the group for which it heard the report.</li> <li>◆ If there are Version 1 hosts present for a particular group, the switch will ignore any Leave Group messages that it receives for that group.</li> </ul>

The following shows the information displayed in a detailed listing for a dynamically learned multicast group.

```

Console#show ip igmp groups detail
Interface          : VLAN 1
    
```

```

Group           : 224.1.1.2.3
Uptime          : 0h:0m:12s
Group mode      : Include
Last reporter   : 0.0.0.0
Group Source List:
Source Address  Uptime      v3 Exp      Fwd
-----
          192.1.1.2.3  0h:0m:12s  0h:0m:0s  Yes
Console#

```

**Table 150: show ip igmp groups detail - display description**

Field	Description
Interface	The interface on the switch that has received traffic directed to the multicast group address.
Group	IP multicast group address with subscribers directly attached or downstream from the switch, or a static multicast group assigned to this interface.
Uptime	The time elapsed since this entry was created.
Group mode	In INCLUDE mode, reception of packets sent to the specified multicast address is requested only from those IP source addresses listed in the source-list parameter. In EXCLUDE mode, reception of packets sent to the given multicast address is requested from all IP source addresses except for those listed in the source-list parameter, and where the source timer status has expired. Note that EXCLUDE mode does not apply to SSM addresses.
Last Reporter	The IP address of the source of the last membership report received for this multicast group address on this interface.
Group Source List	A list of zero or more IP unicast addresses from which multicast reception is desired or not desired, depending on the filter mode.
Source Address	The address of one of the multicast servers transmitting traffic to the specified group.
Uptime	The time elapsed since this entry was created.
v3 Exp	The time remaining before this entry will be aged out. The V3 label indicates that the expire time is only provided for sources learned through IGMP Version 3. (The default is 260 seconds.)
Fwd	Indicates whether or not traffic will be forwarded from the multicast source.

**show ip igmp interface** This command shows multicast information for the specified interface.

**Syntax**

**show ip igmp interface** *[interface]*

*interface*

vlan *vlan-id* - VLAN ID. (Range: 1-4094)

**Default Setting**

None

## Command Mode

Privileged Exec

### Example

The following example shows the IGMP configuration for VLAN 1, as well as the device currently serving as the IGMP querier for active multicast services on this interface.

```
switch#show ip igmp interface vlan 1
Vlan 1 : up
  IGMP                               : Disabled
  IGMP Version                       : 2
  IGMP Proxy                         : Enabled
  IGMP Unsolicited-report-interval   : 400 sec
  Robustness variable                : 2
  Query Interval                     : 125 sec
  Query Max Response Time            : 100 (resolution in 0.1 sec)
  Last Member Query Interval         : 10 (resolution in 0.1 sec)
  Querier                            : 0.0.0.0
  Joined Groups :
  Static Groups :
switch#
```

## MVR for IPv4

This section describes commands used to configure Multicast VLAN Registration for IPv4 (MVR). A single network-wide VLAN can be used to transmit multicast traffic (such as television channels) across a service provider's network. Any multicast traffic entering an MVR VLAN is sent to all subscribers. This can significantly reduce to processing overhead required to dynamically monitor and establish the distribution tree for a normal multicast VLAN. Also note that MVR maintains the user isolation and data security provided by VLAN segregation by passing only multicast traffic into other VLANs to which the subscribers belong.

**Table 151: Multicast VLAN Registration for IPv4 Commands**

Command	Function	Mode
<a href="#">mvr</a>	Globally enables MVR	GC
<a href="#">mvr associated-profile</a>	Binds the MVR group addresses specified in a profile to an MVR domain	GC
<a href="#">mvr domain</a>	Enables MVR for a specific domain	GC
<a href="#">mvr profile</a>	Maps a range of MVR group addresses to a profile	GC
<a href="#">mvr proxy-query-interval</a>	Configures the interval at which the receiver port sends out general queries.	GC
<a href="#">mvr proxy-switching</a>	Enables MVR proxy switching, where the source port acts as a host, and the receiver port acts as an MVR router with querier service enabled	GC

**Table 151: Multicast VLAN Registration for IPv4 Commands** (Continued)

Command	Function	Mode
<code>mvr robustness-value</code>	Configures the expected packet loss, and thereby the number of times to generate report and group-specific queries	GC
<code>mvr source-port-mode</code>	Configures the switch to only forward multicast streams that a source port has dynamically joined	GC
<code>mvr upstream-source-ip</code>	Configures the source IP address assigned to all control packets sent upstream	GC
<code>mvr vlan</code>	Specifies the VLAN through which MVR multicast data is received	GC
<code>mvr immediate-leave</code>	Enables immediate leave capability	IC
<code>mvr type</code>	Configures an interface as an MVR receiver or source port	IC
<code>mvr vlan group</code>	Statically binds a multicast group to a port	IC
<code>clear mvr groups dynamic</code>	Clears multicast group information dynamically learned through MVR	PE
<code>clear mvr statistics</code>	Clears MVR statistics	PE
<code>show mvr</code>	Shows information about MVR domain settings, including MVR operational status, the multicast VLAN, the current number of group addresses, and the upstream source IP address	PE
<code>show mvr associated-profile</code>	Shows the profiles bound the specified domain	PE
<code>show mvr interface</code>	Shows MVR settings for interfaces attached to the MVR VLAN	PE
<code>show mvr members</code>	Shows information about the current number of entries in the forwarding database, or detailed information about a specific multicast address	PE
<code>show mvr profile</code>	Shows all configured MVR profiles	PE
<code>show mvr statistics</code>	Shows MVR protocol statistics for the specified interface	PE

**mvr** This command enables Multicast VLAN Registration (MVR) globally on the switch. Use the **no** form of this command to globally disable MVR.

### Syntax

**[no] mvr**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

Only IGMP version 2 or 3 hosts can issue multicast join or leave messages. If MVR must be configured for an IGMP version 1 host, the multicast groups must be statically assigned using the **mvr vlan group** command.

### Example

The following example enables MVR globally.

```
Console(config)#mvr
Console(config)#
```

**mvr associated-profile** This command binds the MVR group addresses specified in a profile to an MVR domain. Use the **no** form of this command to remove the binding.

### Syntax

**[no] mvr domain *domain-id* associated-profile *profile-name***

*domain-id* - An independent multicast domain. (Range: 1-5)

*profile-name* - The name of a profile containing one or more MVR group addresses. (Range: 1-21 characters)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Example

The following an MVR group address profile to domain 1:

```
Console(config)#mvr domain 1 associated-profile rd
Console(config)#
```

## Related Commands

[mvr profile \(767\)](#)

**mvr domain** This command enables Multicast VLAN Registration (MVR) for a specific domain. Use the **no** form of this command to disable MVR for a domain.

### Syntax

```
[no] mvr domain domain-id
```

*domain-id* - An independent multicast domain. (Range: 1-5)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

Only IGMP version 2 or 3 hosts can issue multicast join or leave messages. If MVR must be configured for an IGMP version 1 host, the multicast groups must be statically assigned using the [mvr vlan group](#) command.

### Example

The following example enables MVR for domain 1:

```
Console(config)#mvr domain 1
Console(config)#
```

**mvr profile** This command maps a range of MVR group addresses to a profile. Use the **no** form of this command to remove the profile.

### Syntax

```
mvr profile profile-name start-ip-address end-ip-address
```

```
no mvr profile profile-name
```

*profile-name* - The name of a profile containing one or more MVR group addresses. (Range: 1-21 characters)

*start-ip-address* - Starting IPv4 address for an MVR multicast group. (Range: 224.0.1.0 - 239.255.255.255)

*end-ip-address* - Ending IPv4 address for an MVR multicast group. (Range: 224.0.1.0 - 239.255.255.255)

### Default Setting

No profiles are defined

### Command Mode

Global Configuration

### Command Usage

- ◆ Use this command to statically configure all multicast group addresses that will join the MVR VLAN. Any multicast data associated an MVR group is sent from all source ports to all receiver ports that have registered to receive data from that multicast group.
- ◆ The IP address range from 224.0.0.0 to 239.255.255.255 is used for multicast streams. MVR group addresses cannot fall within the reserved IP multicast address range of 224.0.0.x.
- ◆ IGMP snooping and MVR share a maximum number of 1024 groups. Any multicast streams received in excess of this limitation will be flooded to all ports in the associated domain.

### Example

The following example maps a range of MVR group addresses to a profile:

```
Console(config)#mvr profile rd 228.1.23.1 228.1.23.10  
Console(config)#
```

**mvr proxy-query-interval** This command configures the interval at which the receiver port sends out general queries. Use the **no** form to restore the default setting.

### Syntax

**mvr proxy-query-interval** *interval*

**no mvr proxy-query-interval**

*interval* - The interval at which the receiver port sends out general queries.  
(Range: 2-31744 seconds)

### Default Setting

125 seconds

### Command Mode

Global Configuration

### Command Usage

This command sets the general query interval at which active receiver ports send out general queries. This interval is only effective when proxy switching is enabled with the [mvr proxy-switching](#) command.

### Example

This example sets the proxy query interval for MVR proxy switching.

```
Console(config)#mvr proxy-query-interval 250  
Console(config)#
```

**mvr proxy-switching** This command enables MVR proxy switching, where the source port acts as a host, and the receiver port acts as an MVR router with querier service enabled. Use the **no** form to disable this function.

### Syntax

**[no] mvr proxy-switching**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Command Usage

- ◆ When MVR proxy-switching is enabled, an MVR source port serves as the upstream or host interface. The source port performs only the host portion of MVR by sending summarized membership reports, and automatically disables MVR router functions.
- ◆ Receiver ports are known as downstream or router interfaces. These interfaces perform the standard MVR router functions by maintaining a database of all MVR subscriptions on the downstream interface. Receiver ports must therefore be configured on all downstream interfaces which require MVR proxy service.
- ◆ When the source port receives report and leave messages, it only forwards them to other source ports.
- ◆ When receiver ports receive any query messages, they are dropped.
- ◆ When changes occurring in the downstream MVR groups are learned by the receiver ports through report and leave messages, an MVR state change report is created and sent to the upstream source port, which in turn forwards this information upstream.
- ◆ When MVR proxy switching is disabled:
  - Any membership reports received from receiver/source ports are forwarded to all source ports.
  - When a source port receives a query message, it will be forwarded to all downstream receiver ports.
  - When a receiver port receives a query message, it will be dropped.

### Example

The following example enable MVR proxy switching.

```
Console(config)#mvr proxy-switching  
Console(config)#
```

### Related Commands

[mvr robustness-value \(770\)](#)

**mvr robustness-value** This command configures the expected packet loss, and thereby the number of times to generate report and group-specific queries. Use the **no** form to restore the default setting.

### Syntax

**mvr robustness-value** *value*

**no mvr robustness-value**

*value* - The robustness used for all interfaces. (Range: 1-255)

### Default Setting

2

### Command Mode

Global Configuration

### Command Usage

- ◆ This command is used to set the number of times report messages are sent upstream when changes are learned about downstream groups, and the number of times group-specific queries are sent to downstream receiver ports.
- ◆ This command only takes effect when MVR proxy switching is enabled.

### Example

```
Console(config)#mvr robustness-value 5  
Console(config)#
```

### Related Commands

[mvr proxy-switching \(769\)](#)

**mvr source-port-mode** This command configures the switch to forward only multicast streams that a source port has dynamically joined or to forward all multicast groups. Use the **no** form to restore the default setting.

### Syntax

**mvr source-port-mode {dynamic | forward}**

**no mvr source-port-mode**

**dynamic** - Configures source ports to only forward dynamically-joined MVR group multicast streams.

**forward** - Configures source ports to always forward MVR groups.

### Default Setting

Forwards all multicast streams which have been specified in a profile and bound to a domain.

### Command Mode

Global Configuration

### Command Usage

- ◆ By default, the switch forwards any multicast streams within the address range set by a profile, and bound to a domain. The multicast streams are sent to all source ports on the switch and to all receiver ports that have elected to receive data on that multicast address.
- ◆ When the **mvr source-port-mode dynamic** command is used, the switch only forwards multicast streams which the source port has dynamically joined. In other words, both the receiver port and source port must subscribe to a multicast group before a multicast stream is forwarded to any attached client. Note that the requested streams are still restricted to the address range which has been specified in a profile and bound to a domain.

### Example

```
Console(config)#mvr source-port-mode dynamic
Console(config)#
```

**mvr upstream-source-ip** This command configures the source IP address assigned to all MVR control packets sent upstream on all domains or on a specified domain. Use the **no** form to restore the default setting.

#### Syntax

**mvr** [**domain** *domain-id*] **upstream-source-ip** *source-ip-address*

**no mvr** [**domain** *domain-id*] **upstream-source-ip**

*domain-id* - An independent multicast domain. (Range: 1-5)

*source-ip-address* - The source IPv4 address assigned to all MVR control packets sent upstream.

#### Default Setting

All MVR reports sent upstream use a null source IP address

#### Command Mode

Global Configuration

#### Example

```
Console(config)#mvr domain 1 upstream-source-ip 192.168.0.3
Console(config)#
```

**mvr vlan** This command specifies the VLAN through which MVR multicast data is received. Use the **no** form of this command to restore the default MVR VLAN.

#### Syntax

**mvr** [**domain** *domain-id*] **vlan** *vlan-id*

**no mvr** [**domain** *domain-id*] **vlan**

*domain-id* - An independent multicast domain. (Range: 1-5)

*vlan-id* - Specifies the VLAN through which MVR multicast data is received. This is also the VLAN to which all source ports must be assigned. (Range: 1-4094)

#### Default Setting

VLAN 1

#### Command Mode

Global Configuration

#### Command Usage

- ◆ This command specifies the VLAN through which MVR multicast data is received. This is the VLAN to which all source ports must be assigned.

- ◆ The VLAN specified by this command must be an existing VLAN configured with the `vlan` command.
- ◆ MVR source ports can be configured as members of the MVR VLAN using the `switchport allowed vlan` command and `switchport native vlan` command, but MVR receiver ports should not be statically configured as members of this VLAN.

### Example

The following example sets the MVR VLAN to VLAN 2:

```
Console(config)#mvr
Console(config)#mvr domain 1 vlan 2
Console(config)#
```

**mvr immediate-leave** This command causes the switch to immediately remove an interface from a multicast stream as soon as it receives a leave message for that group. Use the **no** form to restore the default settings.

### Syntax

**mvr** [**domain** *domain-id*] **immediate-leave** [**by-host-ip**]

**no mvr** [**domain** *domain-id*] **immediate-leave**

*domain-id* - An independent multicast domain. (Range: 1-5)

**by-host-ip** - Specifies that the member port will be deleted only when there are no hosts joining this group.

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Immediate leave applies only to receiver ports. When enabled, the receiver port is immediately removed from the multicast group identified in the leave message. When immediate leave is disabled, the switch follows the standard rules by sending a group-specific query to the receiver port and waiting for a response to determine if there are any remaining subscribers for that multicast group before removing the port from the group list.
- ◆ If the “by-host-ip” option is used, the router/querier will not send out a group-specific query when an IGMPv2/v3 leave message is received (the same as it would without this option having been used). Instead of immediately deleting that group, it will look up the record, and only delete the group if there are no other subscribers for it on the member port. Only when all hosts on that port leave the group will the member port be deleted.

- ◆ Using immediate leave can speed up leave latency, but should only be enabled on a port attached to only one multicast subscriber to avoid disrupting services to other group members attached to the same interface.
- ◆ Immediate leave does not apply to multicast groups which have been statically assigned to a port with the `mvr vlan group` command.

### Example

The following enables immediate leave on a receiver port.

```
Console(config)#interface ethernet 1/5
Console(config-if)#mvr domain 1 immediate-leave
Console(config-if)#
```

**mvr type** This command configures an interface as an MVR receiver or source port. Use the **no** form to restore the default settings.

### Syntax

**[no] mvr [domain *domain-id*] type {receiver | source}**

*domain-id* - An independent multicast domain. (Range: 1-5)

**receiver** - Configures the interface as a subscriber port that can receive multicast data.

**source** - Configures the interface as an uplink port that can send and receive multicast data for the configured multicast groups.

### Default Setting

The port type is not defined.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ A port which is not configured as an MVR receiver or source port can use IGMP snooping to join or leave multicast groups using the standard rules for multicast filtering.
- ◆ Receiver ports can belong to different VLANs, but should not normally be configured as a member of the MVR VLAN. IGMP snooping can also be used to allow a receiver port to dynamically join or leave multicast groups not sourced through the MVR VLAN. Also, note that VLAN membership for MVR receiver ports cannot be set to access mode (see the `switchport mode` command).
- ◆ One or more interfaces may be configured as MVR source ports. A source port is able to both receive and send data for multicast groups which it has joined through the MVR protocol or which have been assigned through the `mvr vlan group` command.

- ◆ Only IGMP version 2 or 3 hosts can issue multicast join or leave messages. If MVR must be configured for an IGMP version 1 host, the multicast groups must be statically assigned using the `mvr vlan group` command.

### Example

The following configures one source port and several receiver ports on the switch.

```
Console(config)#interface ethernet 1/5
Console(config-if)#mvr domain 1 type source
Console(config-if)#exit
Console(config)#interface ethernet 1/6
Console(config-if)#mvr domain 1 type receiver
Console(config-if)#exit
Console(config)#interface ethernet 1/7
Console(config-if)#mvr domain 1 type receiver
Console(config-if)#
```

**mvr vlan group** This command statically binds a multicast group to a port which will receive long-term multicast streams associated with a stable set of hosts. Use the **no** form to restore the default settings.

### Syntax

**[no] mvr [domain *domain-id*] vlan *vlan-id* group *ip-address***

*domain-id* - An independent multicast domain. (Range: 1-5)

*vlan-id* - Receiver VLAN to which the specified multicast traffic is flooded. (Range: 1-4094)

**group** - Defines a multicast service sent to the selected port.

*ip-address* - Statically configures an interface to receive multicast traffic from the IPv4 address specified for an MVR multicast group. (Range: 224.0.1.0 - 239.255.255.255)

### Default Setting

No receiver port is a member of any configured multicast group.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Multicast groups can be statically assigned to a receiver port using this command.
- ◆ The IP address range from 224.0.0.0 to 239.255.255.255 is used for multicast streams. MVR group addresses cannot fall within the reserved IP multicast address range of 224.0.0.x.

- ◆ Only IGMP version 2 or 3 hosts can issue multicast join or leave messages. If MVR must be configured for an IGMP version 1 host, the multicast groups must be statically assigned using the **mvr vlan group** command.
- ◆ The MVR VLAN cannot be specified as the receiver VLAN for static bindings.

### Example

The following statically assigns a multicast group to a receiver port:

```
Console(config)#interface ethernet 1/7
Console(config-if)#mvr domain 1 type receiver
Console(config-if)#mvr domain 1 vlan 3 group 225.0.0.5
Console(config-if)#
```

**clear mvr groups dynamic** This command clears multicast group information dynamically learned through MVR.

### Syntax

**clear mvr groups dynamic** [*domain-id*]

*domain-id* - The MVR domain ID - Range: 1-5

### Command Mode

Privileged Exec

### Command Usage

This command only clears entries learned through MVR. Statically configured multicast address are not cleared.

### Example

```
Console#clear mvr groups dynamic
Console#
```

**clear mvr statistics** This command clears MVR statistics.

### Syntax

**clear mvr statistics** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* - VLAN identifier (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#clear mvr statistics
Console#
```

**show mvr** This command shows information about MVR domain settings, including MVR operational status, the multicast VLAN, the current number of group addresses, and the upstream source IP address.

### Syntax

**show mvr** [**domain** *domain-id*]

*domain-id* - An independent multicast domain. (Range: 1-5)

### Default Setting

Displays configuration settings for all MVR domains.

### Command Mode

Privileged Exec

### Example

The following shows the MVR settings:

```
Console#show mvr
MVR Proxy Switching           : Enabled
MVR Robustness Value          : 1
MVR Proxy Query Interval      : 125(sec.)
MVR Source Port Mode          : Always Forward

MVR Domain                     : 1
MVR Config Status             : Enabled
MVR Running Status            : Active
MVR Multicast VLAN            : 1
MVR Current Learned Groups    : 10
MVR Upstream Source IP        : 192.168.0.3
:
```

**Table 152: show mvr - display description**

Field	Description
MVR Proxy Switching	Shows if MVR proxy switching is enabled
MVR Robustness Value	Shows the number of reports or query messages sent when proxy switching is enabled

Table 152: show mvr - display description (Continued)

Field	Description
MVR Proxy Query Interval	Shows the interval at which the receiver port sends out general queries
MVR Source Port Mode	Shows if the switch forwards all multicast streams, or only those which the source port has dynamically joined
MVR Domain	An independent multicast domain.
MVR Config Status	Shows if MVR is globally enabled on the switch.
MVR Running Status	Indicates whether or not all necessary conditions in the MVR environment are satisfied. (Running status is true as long as MVR Status is enabled, and the specified MVR VLAN exists.)
MVR Multicast VLAN	Shows the VLAN used to transport all MVR multicast traffic.
MVR Current Learned Groups	The current number of MVR group addresses
MVR Upstream Source IP	The source IP address assigned to all upstream control packets.

**show mvr associated-profile** This command shows the profiles bound the specified domain.

#### Syntax

**show mvr [domain *domain-id*] associated-profile**

*domain-id* - An independent multicast domain. (Range: 1-5)

#### Default Setting

Displays profiles bound to all MVR domains.

#### Command Mode

Privileged Exec

#### Example

The following displays the profiles bound to domain 1:

```
Console#show mvr domain 1 associated-profile
Domain ID : 1
MVR Profile Name      Start IP Addr.  End IP Addr.
-----
rd                    228.1.23.1     228.1.23.10
testing               228.2.23.1     228.2.23.10
Console#
```

**show mvr interface** This command shows MVR configuration settings for interfaces attached to the MVR VLAN.

### Syntax

**show mvr [domain *domain-id*] interface**

*domain-id* - An independent multicast domain. (Range: 1-5)

### Default Setting

Displays configuration settings for all attached interfaces.

### Command Mode

Privileged Exec

### Example

The following displays information about the interfaces attached to the MVR VLAN in domain 1:

```

Console#show mvr domain 1 interface
MVR Domain : 1
Flag: H - Immediate Leave By Host IP
Port      Type      Status              Immediate      Static Group Address
-----
Eth 1/ 1 Source  Active/Forwarding
Eth 1/ 2 Receiver Inactive/Discarding Disabled        234.5.6.8 (VLAN2)
Eth 1/ 3 Source  Inactive/Discarding
Eth 1/ 1 Receiver Active/Forwarding  Disabled        225.0.0.1 (VLAN1)
                                                225.0.0.9 (VLAN3)
Eth 1/ 4 Receiver Active/Discarding  Disabled
Console#
    
```

**Table 153: show mvr interface - display description**

Field	Description
MVR Domain	An independent multicast domain.
Port	Shows interfaces attached to the MVR.
Type	Shows the MVR port type.
Status	Shows the MVR status and interface status. MVR status for source ports is "ACTIVE" if MVR is globally enabled on the switch. MVR status for receiver ports is "ACTIVE" only if there are subscribers receiving multicast traffic from one of the MVR groups, or a multicast group has been statically assigned to an interface. Also shows if MVR traffic is being forwarded or discarded.
Immediate	Shows if immediate leave is enabled or disabled.
Static Group Address	Shows any static MVR group assigned to an interface, and the receiver VLAN.

**show mvr members** This command shows information about the current number of entries in the forwarding database, detailed information about a specific multicast address, the IP address of the hosts subscribing to all active multicast groups, or the multicast groups associated with each port.

### Syntax

```
show mvr [domain domain-id] members [ip-address |  
host-ip-address [ip-address | ds-vlan vlan-id [ip-address | interface ip-address]  
| interface ip-address] | igmp | sort-by-port [ip-address | ds-vlan vlan-id [ip-  
address | interface ip-address] | interface ip-address] | unknown | user]
```

*domain-id* - An independent multicast domain. (Range: 1-5)

*ip-address* - IPv4 address for an MVR multicast group.  
(Range: 224.0.1.0 - 239.255.255.255)

**members** - The multicast groups assigned to the MVR VLAN.

**host-ip-address** - The subscriber IP addresses.

**ds-vlan** - Downstream VLAN ID (Range: 1-4094)

**igmp** - Entry created by IGMP protocol.

**sort-by-port** - The multicast groups associated with an interface.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**unknown** - Entry created by receiving a multicast stream.

**user** - Snooping entry learned from user's configuration settings.

Default Setting

Displays configuration settings for all domains and all forwarding entries.

### Command Mode

Privileged Exec

### Example

The following shows information about the number of multicast forwarding entries currently active in domain 1:

```
Console#show mvr domain 1 members
MVR Domain : 1
MVR Forwarding Entry Count :1
Flag: S - Source port, R - Receiver port.
      H - Host counts (number of hosts joined to group on this port).
      P - Port counts (number of ports joined to group).
Up time: Group elapsed time (d:h:m:s).
Expire : Group remaining time (m:s).
```

```

Group Address  VLAN Port          Up time      Expire Count
-----
234.5.6.7     1                00:00:09:17      2 (P)
                1 Eth 1/ 1(S)
                2 Eth 1/ 2(R)

```

Console#

The following example shows detailed information about a specific multicast address:

```

Console#show mvr domain 1 members 234.5.6.7
MVR Domain : 1
MVR Forwarding Entry Count :1
Flag: S - Source port, R - Receiver port.
      H - Host counts (number of hosts joined to group on this port).
      P - Port counts (number of ports joined to group).
Up time: Group elapsed time (d:h:m:s).
Expire : Group remaining time (m:s).

```

```

Group Address  VLAN Port          Up time      Expire Count
-----
234.5.6.7     1                00:00:09:17      2 (P)
                1 Eth 1/ 1(S)
                2 Eth 1/ 2(R)

```

Console#

**Table 154: show mvr members - display description**

Field	Description
Group Address	Multicast group address.
VLAN	VLAN to which this address is forwarded.
Port	Port to which this address is forwarded.
Uptime	Time that this multicast group has been known.
Expire	The time until this entry expires.
Count	The number of times this address has been learned by IGMP snooping.

**show mvr profile** This command shows all configured MVR profiles.

#### Command Mode

Privileged Exec

#### Example

The following shows all configured MVR profiles:

```
Console#show mvr profile
MVR Profile Name      Start IP Addr.  End IP Addr.
-----
rd                    228.1.23.1     228.1.23.10
testing               228.2.23.1     228.2.23.10
Console#
```

**show mvr statistics** This command shows MVR protocol-related statistics for the specified interface.

#### Syntax

```
show mvr [domain domain-id] statistics
{input [interface interface] | output [interface interface] |
query | summary interface [interface | mvr-vlan]}
```

**input** - Specifies to display statistics for messages received by the interface.

**output** - Specifies to display statistics for messages sent by the interface.

*domain-id* - An independent multicast domain. (Range: 1-5)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* - VLAN ID (Range: 1-4094)

**query** - Displays MVR query-related statistics.

**summary** - Displays summary of MVR statistics.

**mvr vlan** - Displays summary statistics for the MVR VLAN.

#### Default Setting

Displays statistics for all domains.

#### Command Mode

Privileged Exec

### Example

The following shows MVR protocol-related statistics received:

```

Console#show mvr domain 1 statistics input
MVR Domain : 1 , MVR VLAN: 2
Input Statistics:
Interface Report    Leave    G Query  G(-S)-S Query Drop    Join Succ Group
-----
Eth 1/ 1           23       11        4          10      5       20    9
Eth 1/ 2           12       15        8           3      5       19    4
DVLAN  1            2         0         0           2      2       20    9
MVLAN  1            2         0         0           2      2       20    9
Console#

```

**Table 155: show mvr statistics input - display description**

Field	Description
Interface	Shows interfaces attached to the MVR.
Report	The number of IGMP membership reports received on this interface.
Leave	The number of leave messages received on this interface.
G Query	The number of general query messages received on this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages received on this interface.
Drop	The number of times a report, leave or query was dropped. Packets may be dropped due to invalid format, rate limiting, packet content not allowed, or MVR group report received
Join Succ	The number of times a multicast group was successfully joined.
Group	The number of MVR groups active on this interface.

The following shows MVR protocol-related statistics sent:

```

Console#show mvr domain 1 statistics output
MVR Domain : 1 , MVR VLAN: 2
Output Statistics:
Interface Report    Leave    G Query  G(-S)-S Query Drop    Group
-----
Eth 1/ 1           12         0         1           0      0       0    0
Eth 1/ 1           12         0         1           0      0       0    0
Eth 1/ 2            5         1         4           1      0       0    0
DVLAN  1            7         2         3           0      0       0    0
MVLAN  1            7         2         3           0      0       0    0
Console#

```

**Table 156: show mvr statistics output - display description**

Field	Description
Interface	Shows interfaces attached to the MVR.
Report	The number of IGMP membership reports sent from this interface.

**Table 156: show mvr statistics output - display description** (Continued)

Field	Description
Leave	The number of leave messages sent from this interface.
G Query	The number of general query messages sent from this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages sent from this interface.
Drop	The number of times a report, leave or query was dropped. Packets may be dropped due to invalid format, rate limiting, or packet content not allowed.
Group	The number of multicast groups active on this interface.

The following shows MVR query-related statistics:

```

Console#show mvr domain 1 statistics query
Domain 1:
  Other Querier           : None
  Other Querier Expire    : 0 (m) :0 (s)
  Other Querier Uptime    : 0 (h) :0 (m) :0 (s)
  Self Querier            : 192.168.2.4
  Self Querier Expire     : 0 (m) :30 (s)
  Self Querier Uptime     : 0 (h) :9 (m) :55 (s)
  General Query Received  : 0
  General Query Sent      : 0
  Specific Query Received : 0
  Specific Query Sent     : 0
  Warn Rate Limit        : 0 sec.
  V1 Warning Count       : 0
  V2 Warning Count       : 0
  V3 Warning Count       : 0
Console#

```

**Table 157: show mvr statistics query - display description**

Field	Description
Other Querier	The IP address of the querier on this interface.
Other Querier Expire	The time after which this querier is assumed to have expired.
Other Querier Uptime	Other querier's time up.
Self Querier	This querier's IP address.
Self Querier Expire	This querier's expire time.
Self Querier Uptime	This querier's time up.
General Query Received	The number of general queries received on this interface.
General Query Sent	The number of general queries sent from this interface.
Specific Query Received	The number of specific queries received on this interface.
Specific Query Sent	The number of specific queries sent from this interface.

**Table 157: show mvr statistics query - display description (Continued)**

Field	Description
Warn Rate Limit	Count down from 15 seconds after receiving a Query different from the configured version.
V# Warning Count	Number of queries received on MVR that were configured for IGMP version 1, 2 or 3.

The following shows MVR summary statistics for an interface:

```

Console#show mvr domain 1 statistics summary interface ethernet 1/1
Domain 1:
Number of Groups: 0
Querier:          :          Report & Leave:  :
Transmit         :          Transmit         :
  General        : 0          Report         : 7
  Group Specific : 0          Leave          : 4
Received         :          Received         :
  General        : 0          Report         : 0
  Group Specific : 0          Leave          : 0
V1 Warning Count: 0          Join Success  : 0
V2 Warning Count: 0          Filter Drop   : 0
V3 Warning Count: 0
                                   Source Port Drop: 0
                                   Others Drop     : 0

Console#

```

**Table 158: show mvr statistics summary interface - display description**

Field	Description
Domain	An independent multicast domain.
Number of Groups	Number of groups learned on this port.
Querier	
Transmit	
General	Number of general queries transmitted.
Group Specific	Number of group specific queries transmitted.
Received	
General	Number of general queries received.
Group Specific	Number of group specific queries received.
V# Warning Count	Number of queries received on MVR that were configured for IGMP version 1, 2 or 3.
Report & Leave	
Transmit	
Report	Number of transmitted reports.
Leave	Number of transmitted leaves.
Received	

**Table 158: show mvr statistics summary interface - display description**

Field	Description
Report	Number of reports received.
Leave	Number of leaves received.
Join Success	Number of join reports processed successfully.
Filter Drop	Number of report/leave messages dropped by IGMP filter.
Source Port Drop	Number of report/leave messages dropped by MVR source port.
Others Drop	Number of report/leave messages dropped for other reasons.

The following shows MVR summary statistics for the MVR VLAN:

```

Console#show mvr domain 1 statistics summary interface mvr-vlan
Domain 1:
Number of Groups: 0
Querier: : Report & Leave: :
Other Querier : None Host IP Addr : 192.168.0.66
Other Expire : 0(m):0(s) Unsolicit Expire : 5(m):4(s)
Other Uptime : 0(h):0(m):0(s)
Self Querier : None
Self Expire : 1(m):45(s)
Self Uptime : 0(h):14(m):54(s)
Transmit : Transmit :
General : 11 Report : 7
Group Specific : 3 Leave : 4
Received : Received :
General : 0 Report : 6
Group Specific : 0 Leave : 0
V1 Warning Count: 0 Join Success : 6
V2 Warning Count: 0 Filter Drop : 0
V3 Warning Count: 0 Source Port Drop: 0
Others Drop : 0
Console#

```

**Table 159: show mvr statistics summary interface mvr vlan - description**

Field	Description
Domain	An independent multicast domain.
Number of Groups	Number of groups learned on this port.
Querier	
Other Querier	Other IGMP querier's IP address.
Other Expire	Other querier's expire time.
Other Uptime	Other querier's time up.
Self Querier	This querier's IP address.
Self Expire	This querier's expire time.
Self Uptime	This querier's time up.
Transmit	

**Table 159: show mvr statistics summary interface mvr vlan - description**

Field	Description
General	Number of general queries sent from receiver port.
Group Specific	Number of group specific queries sent from receiver port.
Received	
General	Number of general queries received.
Group Specific	Number of group specific queries received.
V# Warning Count	Number of queries received on MVR that were configured by IGMP version 1, 2 or 3.
Report & Leave	
Host IP Addr	Source IP address used to send report/leave messages from source port.
Unsolicit Expire	Expiration time for unsolicit reports sent out from source port
Transmit	
Report	Number of reports sent out from source port.
Leave	Number of leaves sent out from source port.
Received	
Report	Number of reports received.
Leave	Number of leaves received.
Join Success	Number of join reports processed successfully.
Filter Drop	Number of report/leave messages dropped by IGMP filter.
Source Port Drop	Number of report/leave messages dropped by MVR source port.
Others Drop	Number of report/leave messages dropped for other reasons.

## MVR for IPv6

This section describes commands used to configure Multicast VLAN Registration for IPv6 (MVR6). A single network-wide VLAN can be used to transmit multicast traffic (such as television channels) across a service provider's network. Any multicast traffic entering an MVR6 VLAN is sent to all subscribers. This can significantly reduce to processing overhead required to dynamically monitor and establish the distribution tree for a normal multicast VLAN. Also note that MVR6 maintains the user isolation and data security provided by VLAN segregation by passing only multicast traffic into other VLANs to which the subscribers belong.

**Table 160: Multicast VLAN Registration for IPv6 Commands**

Command	Function	Mode
<code>mvr6 associated-profile</code>	Binds the MVR6 group addresses specified in a profile to an MVR6 domain	GC
<code>mvr6 domain</code>	Enables MVR6 for a specific domain	GC
<code>mvr6 profile</code>	Maps a range of MVR6 group addresses to a profile	GC
<code>mvr6 proxy-query-interval</code>	Configures the interval at which the receiver port sends out general queries.	GC
<code>mvr6 proxy-switching</code>	Enables MVR6 proxy switching, where the source port acts as a host, and the receiver port acts as an MVR6 router with querier service enabled	GC
<code>mvr6 robustness-value</code>	Configures the expected packet loss, and thereby the number of times to generate report and group-specific queries	GC
<code>mvr6 source-port-mode dynamic</code>	Configures the switch to only forward multicast streams which the source port has dynamically joined	GC
<code>mvr6 upstream-source-ip</code>	Configures the source IP address assigned to all control packets sent upstream	GC
<code>mvr6 vlan</code>	Specifies the VLAN through which MVR6 multicast data is received	GC
<code>mvr6 immediate-leave</code>	Enables immediate leave capability	IC
<code>mvr6 type</code>	Configures an interface as an MVR6 receiver or source port	IC
<code>mvr6 vlan group</code>	Statically binds a multicast group to a port	IC
<code>clear mvr6 groups dynamic</code>	Clears multicast group information dynamically learned through MVR6	PE
<code>clear mvr6 statistics</code>	Clears the MVR6 statistics globally or on a per-interface basis	PE
<code>show mvr6</code>	Shows information about MVR6 domain settings, including MVR6 operational status, the multicast VLAN, the current number of group addresses, and the upstream source IP address	PE
<code>show mvr6 associated-profile</code>	Shows the profiles bound the specified domain	PE
<code>show mvr6 interface</code>	Shows MVR6 settings for interfaces attached to the MVR6 VLAN	PE

**Table 160: Multicast VLAN Registration for IPv6 Commands** (Continued)

Command	Function	Mode
<code>show mvr6 members</code>	Shows information about the current number of entries in the forwarding database, or detailed information about a specific multicast address in all domain IDs	PE
<code>show mvr6 domain</code>	Shows information about the current number of entries in the forwarding database, or detailed information about a specific multicast address for a specific domain ID.	
<code>show mvr6 profile</code>	Shows all configured MVR6 profiles	PE
<code>show mvr6 statistics</code>	Shows MVR6 protocol statistics for the specified interface	PE

**mvr6 associated-profile** This command binds the MVR6 group addresses specified in a profile to an MVR6 domain. Use the **no** form of this command to remove the binding.

### Syntax

**[no] mvr6 domain** *domain-id* **associated-profile** *profile-name*

*domain-id* - An independent multicast domain. (Range: 1-5)

*profile-name* - The name of a profile containing one or more MVR6 group addresses. (Range: 1-21 characters)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

MVR6 domains can be associated with more than one MVR6 profile. But since MVR6 domains cannot share the group range, an MVR6 profile can only be associated with one MVR6 domain.

### Example

The following an MVR6 group address profile to domain 1:

```
Console(config)#mvr6 domain 1 associated-profile rd
Console(config)#
```

**mvr6 domain** This command enables Multicast VLAN Registration for IPv6 (MVR6) for a specific domain. Use the **no** form of this command to disable MVR6 for a domain.

### Syntax

**[no] mvr6 domain** *domain-id*

*domain-id* - An independent multicast domain. (Range: 1-5)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

When MVR6 is enabled on a domain, any multicast data associated with an MVR6 group is sent from all designated source ports, to all receiver ports that have registered to receive data from that multicast group.

### Example

The following example enables MVR6 for domain 1:

```
Console(config)#mvr6 domain 1
Console(config)#
```

**mvr6 profile** This command maps a range of MVR6 group addresses to a profile. Use the **no** form of this command to remove the profile.

### Syntax

**mvr6 profile** *profile-name start-ip-address end-ip-address*

**no mvr6 profile** *profile-name*

*profile-name* - The name of a profile containing one or more MVR6 group addresses. (Range: 1-21 characters)

*start-ip-address* - Starting IPv6 address for an MVR6 multicast group. This parameter must be a full IPv6 address including the network prefix and host address bits.

*end-ip-address* - Ending IPv6 address for an MVR6 multicast group. This parameter must be a full IPv6 address including the network prefix and host address bits.

### Default Setting

No profiles are defined

### Command Mode

Global Configuration

### Command Usage

- ◆ Use this command to statically configure all multicast group addresses that will join the MVR6 VLAN. Any multicast data associated with an MVR6 group is sent from all source ports, and to all receiver ports that have registered to receive data from that multicast group.
- ◆ IGMP snooping and MVR6 share a maximum number of 1024 groups. Any multicast streams received in excess of this limitation will be flooded to all ports in the associated domain.
- ◆ All IPv6 addresses must be according to RFC 2373 “IPv6 Addressing Architecture,” using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields. (Note that the IP address ff02::X is reserved.)
- ◆ The MVR6 group address range assigned to a profile cannot overlap with the group address range of any other profile.

### Example

The following example maps a range of MVR6 group addresses to a profile:

```
Console(config)#mvr6 profile rd ff01:0:0:0:0:0:fe ff01:0:0:0:0:0:ff
Console(config)#
```

**mvr6 proxy-query-interval** This command configures the interval at which the receiver port sends out general queries. Use the **no** form to restore the default setting.

### Syntax

**mvr6 proxy-query-interval** *interval*

**no mvr6 proxy-query-interval**

*interval* - The interval at which the receiver port sends out general queries.  
(Range: 2-31744 seconds)

### Default Setting

125 seconds

### Command Mode

Global Configuration

### Command Usage

This command sets the general query interval at which active receiver ports send out general queries. This interval is only effective when proxy switching is enabled with the [mvr6 proxy-switching](#) command.

### Example

This example sets the proxy query interval for MVR6.

```
Console(config)#mvr6 proxy-query-interval 1000  
Console(config)#
```

**mvr6 proxy-switching** This command enables MVR6 proxy switching, where the source port acts as a host, and the receiver port acts as an MVR6 router with querier service enabled. Use the **no** form to disable this function.

### Syntax

**[no] mvr6 proxy-switching**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Command Usage

- ◆ When MVR6 proxy-switching is enabled, an MVR6 source port serves as the upstream or host interface, and the MVR6 receiver port serves as the querier. The source port performs only the host portion of MVR6 by sending summarized membership reports, and automatically disables MVR6 router functions.
- ◆ Receiver ports are known as downstream or router interfaces. These interfaces perform the standard MVR6 router functions by maintaining a database of all MVR6 subscriptions on the downstream interface. Receiver ports must therefore be configured on all downstream interfaces which require MVR6 proxy service.
- ◆ When the source port receives report and leave messages, it only forwards them to other source ports.
- ◆ When receiver ports receive any query messages, they are dropped.
- ◆ When changes occurring in the downstream MVR6 groups are learned by the receiver ports through report and leave messages, an MVR6 state change report is created and sent to the upstream source port, which in turn forwards this information upstream.
- ◆ When MVR6 proxy switching is disabled:
  - Any membership reports received from receiver/source ports are forwarded to all source ports.

- When a source port receives a query message, it will be forwarded to all downstream receiver ports.
- When a receiver port receives a query message, it will be dropped.

### Example

The following example enable MVR6 proxy switching.

```
Console(config)#mvr6 proxy-switching  
Console(config)#
```

### Related Commands

[mvr6 robustness-value \(793\)](#)

**mvr6 robustness-value** This command configures the expected packet loss, and thereby the number of times to generate report and group-specific queries. Use the **no** form to restore the default setting.

### Syntax

**mvr6 robustness-value** *value*

**no mvr6 robustness-value**

*value* - The robustness used for all interfaces. (Range: 1-10)

### Default Setting

2

### Command Mode

Global Configuration

### Command Usage

- ◆ This command sets the number of times report messages are sent upstream when changes are learned about downstream groups, and the number of times group-specific queries are sent to downstream receiver ports.
- ◆ This command only takes effect when MVR6 proxy switching is enabled.

### Example

```
Console(config)#mvr6 robustness-value 5  
Console(config)#
```

### Related Commands

[mvr6 proxy-switching \(792\)](#)

**mvr6 source-port-mode dynamic** This command configures the switch to only forward multicast streams which the source port has dynamically joined. Use the **no** form to restore the default setting.

#### Syntax

```
mvr6 source-port-mode dynamic  
no mvr6 source-port-mode
```

#### Default Setting

Forwards all multicast streams which have been specified in a profile and bound to a domain.

#### Command Mode

Global Configuration

#### Command Usage

- ◆ By default, the switch forwards any multicast streams within the address range set by a profile, and bound to a domain. The multicast streams are sent to all source ports on the switch and to all receiver ports that have elected to receive data on that multicast address.
- ◆ When the **mvr6 source-port-mode dynamic** command is used, the switch only forwards multicast streams which the source port has dynamically joined. In other words, both the receiver port and source port must subscribe to a multicast group before a multicast stream is forwarded to any attached client. Note that the requested streams are still restricted to the address range which has been specified in a profile and bound to a domain.

#### Example

```
Console(config)#mvr6 source-port-mode dynamic  
Console(config)#
```

**mvr6 upstream-source-ip** This command configures the source IPv6 address assigned to all MVR6 control packets sent upstream on the specified domain. Use the **no** form to restore the default setting.

#### Syntax

```
mvr6 domain domain-id upstream-source-ip source-ip-address  
no mvr6 domain domain-id upstream-source-ip
```

*domain-id* - An independent multicast domain. (Range: 1-5)

*source-ip-address* – The source IPv6 address assigned to all MVR6 control packets sent upstream. This parameter must be a full IPv6 address including the network prefix and host address bits.

### Default Setting

All MVR6 reports sent upstream use a null source IP address

### Command Mode

Global Configuration

### Command Usage

All IPv6 addresses must be according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields. (Note that the IP address ff02::X is reserved.)

### Example

```
Console(config)#mvr6 domain 1 upstream-source-ip 2001:DB8:2222:7223::72  
Console(config)#
```

**mvr6 vlan** This command specifies the VLAN through which MVR6 multicast data is received. Use the **no** form of this command to restore the default MVR6 VLAN.

### Syntax

**mvr6 domain** *domain-id* **vlan** *vlan-id*

**no mvr6 domain** *domain-id* **vlan**

*domain-id* - An independent multicast domain. (Range: 1-5)

*vlan-id* - Specifies the VLAN through which MVR6 multicast data is received. This is also the VLAN to which all source ports must be assigned. (Range: 1-4094)

### Default Setting

VLAN 1

### Command Mode

Global Configuration

### Command Usage

MVR6 source ports can be configured as members of the MVR6 VLAN using the [switchport allowed vlan](#) command and [switchport native vlan](#) command, but MVR6 receiver ports should not be statically configured as members of this VLAN.

### Example

The following example sets the MVR6 VLAN to VLAN 1:

```
Console(config)#mvr6 domain 1 vlan 1  
Console(config)#
```

**mvr6 immediate-leave** This command causes the switch to immediately remove an interface from a multicast stream as soon as it receives a leave message for that group. Use the **no** form to restore the default settings.

### Syntax

**[no] mvr6 domain** *domain-id* **immediate-leave** [**by-host-ip**]

*domain-id* - An independent multicast domain. (Range: 1-5)

**by-host-ip** - Specifies that the member port will be deleted only when there are no hosts joining this group.

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Immediate leave applies only to receiver ports. When enabled, the receiver port is immediately removed from the multicast group identified in the leave message. When immediate leave is disabled, the switch follows the standard rules by sending a group-specific query to the receiver port and waiting for a response to determine if there are any remaining subscribers for that multicast group before removing the port from the group list.
- ◆ If the “by-host-ip” option is used, the router/querier will not send out a group-specific query when an MLDv1/v2 Listener Done message is received (the same as it would without this option having been used). Instead of immediately deleting that group, it will look up the record, and only delete the group if there are no other subscribers for it on the member port. Only when all hosts on that port leave the group will the member port be deleted.
- ◆ Using immediate leave can speed up leave latency, but should only be enabled on a port attached to only one multicast subscriber to avoid disrupting services to other group members attached to the same interface.
- ◆ Immediate leave does not apply to multicast groups which have been statically assigned to a port with the **mvr6 vlan group** command.

### Example

The following enables immediate leave on a receiver port.

```
Console(config)#interface ethernet 1/5
Console(config-if)#mvr6 domain 1 immediate-leave
Console(config-if)#
```

**mvr6 type** This command configures an interface as an MVR6 receiver or source port. Use the **no** form to restore the default settings.

### Syntax

**mvr6 domain** *domain-id* **type** {**receiver** | **source**}

**no mvr6 domain** *domain-id* **type**

*domain-id* - An independent multicast domain. (Range: 1-5)

**receiver** - Configures the interface as a subscriber port that can receive multicast data.

**source** - Configures the interface as an uplink port that can send and receive multicast data for the configured multicast groups. Note that the source port must be manually configured as a member of the MVR6 VLAN using the [switchport allowed vlan](#) command.

### Default Setting

The port type is not defined.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ A port configured as an MVR6 receiver or source port can join or leave multicast groups configured under MVR6. A port which is not configured as an MVR6 receiver or source port can use MLD snooping to join or leave multicast groups using the standard rules for multicast filtering (see [“MLD Snooping” on page 729](#)).
- ◆ Receiver ports can belong to different VLANs, but should not be configured as a member of the MVR6 VLAN. MLD snooping can be used to allow a receiver port to dynamically join or leave multicast groups not sourced through the MVR6 VLAN. Also, note that VLAN membership for MVR6 receiver ports cannot be set to access mode (see the [switchport mode](#) command).
- ◆ One or more interfaces may be configured as MVR6 source ports. A source port is able to both receive and send data for multicast groups which it has joined through the MVR6 protocol or which have been assigned through the [mvr6 vlan group](#) command.  
All source ports must belong to the MVR6 VLAN.  
Subscribers should not be directly connected to source ports.
- ◆ The same port cannot be configured as a source port in one MVR6 domain and as a receiver port in another domain.

### Example

The following configures one source port and several receiver ports on the switch.

```
Console(config)#interface ethernet 1/5
Console(config-if)#mvr6 domain 1 type source
Console(config-if)#exit
Console(config)#interface ethernet 1/6
Console(config-if)#mvr6 domain 1 type receiver
Console(config-if)#exit
Console(config)#interface ethernet 1/7
Console(config-if)#mvr6 domain 1 type receiver
Console(config-if)#
```

**mvr6 vlan group** This command statically binds a multicast group to a port which will receive long-term multicast streams associated with a stable set of hosts. Use the **no** form to restore the default settings.

### Syntax

**[no] mvr6 domain** *domain-id* **vlan** *vlan-id* **group** *ip-address*

*domain-id* - An independent multicast domain. (Range: 1-5)

*vlan-id* - Receiver VLAN to which the specified multicast traffic is flooded. (Range: 1-4094)

**group** - Defines a multicast service sent to the selected port.

*ip-address* - Statically configures an interface to receive multicast traffic from the IPv6 address specified for an MVR6 multicast group. This parameter must be a full IPv6 address including the network prefix and host address bits.

### Default Setting

No receiver port is a member of any configured multicast group.

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Multicast groups can be statically assigned to a receiver port using this command. The assigned address must fall within the range set by the [mvr6 associated-profile](#) command.
- ◆ All IPv6 addresses must be according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields. (Note that the IP address ff02::X is reserved.)
- ◆ The MVR6 VLAN cannot be specified as the receiver VLAN for static bindings.

### Example

The following statically assigns a multicast group to a receiver port:

```
Console(config)#interface ethernet 1/2
Console(config-if)#mvr6 domain 1 type receiver
Console(config-if)#mvr6 domain 1 vlan 2 group ff00::1
Console(config-if)#
```

**clear mvr6 groups dynamic** This command clears multicast group information dynamically learned through MVR6.

### Syntax

**clear mvr6 groups dynamic** *domain-id*

*domain-id* - An independent multicast domain. (Range: 1-5)

### Command Mode

Privileged Exec

### Command Usage

This command only clears entries learned through MVR6. Statically configured multicast addresses are not cleared.

### Example

```
Console#clear mvr6 groups dynamic
Console#
```

**clear mvr6 statistics** This command clears MVR6 statistics.

### Syntax

**clear mvr6 statistics** [**interface** *interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**vlan** *vlan-id* - VLAN identifier (Range: 1-4094)

### Command Mode

Privileged Exec

### Command Usage

If the interface option is not used then all MVR6 statistics are cleared. Otherwise using the interface option will only clear MVR6 statistics for the specified interface.

### Example

```
Console#clear mvr6 statistics
Console#
```

**show mvr6** This command shows information about MVR6 domain settings, including MVR6 operational status, the multicast VLAN, the current number of group addresses, and the upstream source IP address.

### Syntax

**show mvr6** [**domain** *domain-id*]

*domain-id* - An independent multicast domain. (Range: 1-5)

### Default Setting

Displays configuration settings for all MVR6 domains.

### Command Mode

Privileged Exec

### Example

The following shows the MVR6 settings:

```
Console#show mvr6
MVR6 Proxy Switching           : Enabled
MVR6 Robustness Value          : 1
MVR6 Proxy Query Interval      : 125(sec.)
MVR6 Source Port Mode          : Always Forward

Domain                          : 1
MVR6 Config Status              : Enabled
MVR6 Running Status             : Active
MVR6 Multicast VLAN             : 1
MVR6 Current Learned Groups     : 0
MVR6 Upstream Source IP         : FF05::25
Console#
```

**Table 161: show mvr6 - display description**

Field	Description
MVR6 Proxy Switching	Shows if MVR6 proxy switching is enabled
MVR6 Robustness Value	Shows the number of reports or query messages sent when proxy switching is enabled
MVR6 Proxy Query Interval	The interval at which the receiver port sends out general queries

**Table 161: show mvr6 - display description** (Continued)

Field	Description
MVR6 Source Port Mode	Shows if the switch only forwards multicast streams which the source port has dynamically joined or always forwards multicast streams
Domain	An independent multicast domain.
MVR6 Config Status	Shows if MVR6 is globally enabled on the switch.
MVR6 Running Status	Indicates whether or not all necessary conditions in the MVR6 environment are satisfied. (Running status is true as long as MVR6 Status is enabled, and the specified MVR6 VLAN exists, and a source port with a valid link has been configured (using the <code>mvr6 type</code> command.)
MVR6 Multicast VLAN	Shows the VLAN used to transport all MVR6 multicast traffic.
MVR Current Learned Groups	The current number of MVR group addresses
MVR6 Upstream Source IP	The source IP address assigned to all upstream control packets.

**show mvr6 associated-profile**

This command shows the profiles bound the specified domain.

**Syntax**

**show mvr6 [domain *domain-id*] associated-profile**

*domain-id* - An independent multicast domain. (Range: 1-5)

**Default Setting**

Displays profiles bound to all MVR6 domains.

**Command Mode**

Privileged Exec

**Example**

The following displays the profiles bound to domain 1:

```

Console#show mvr6 domain 1 associated-profile
Domain ID : 1
MVR6 Profile Name      Start IPv6 Addr.      End IPv6 Addr.
-----
rd                      ff01::fe              ff01::ff
Console#

```

**show mvr6 interface** This command shows MVR6 configuration settings for interfaces attached to the MVR6 VLAN.

### Syntax

**show mvr6 [domain *domain-id*] interface**

*domain-id* - An independent multicast domain. (Range: 1-5)

### Default Setting

Displays configuration settings for all attached interfaces.

### Command Mode

Privileged Exec

### Example

The following displays information about the interfaces attached to the MVR6 VLAN in domain 1:

```
Console#show mvr6 domain 1 interface
MVR6 Domain : 1
Port      Type      Status                Immediate Leave  Static Group Address
-----
Eth1/ 1   Source   Active/Forwarding
Eth1/ 2   Receiver Active/Forwarding   Disabled          ff00::1 (VLAN1)
Console#
```

**Table 162: show mvr6 interface - display description**

Field	Description
Port	Shows interfaces attached to the MVR6.
Type	Shows the MVR6 port type.
Status	Shows the MVR6 status and interface status. MVR6 status for source ports is "ACTIVE" if MVR6 is globally enabled on the switch. MVR6 status for receiver ports is "ACTIVE" only if there are subscribers receiving multicast traffic from one of the MVR6 groups, or a multicast group has been statically assigned to an interface.
Immediate Leave	Shows if immediate leave is enabled or disabled.
Static Group Address	Shows any static MVR6 group assigned to an interface, and the receiver VLAN.

**show mvr6 members** This command shows information about the current number of entries in the forwarding database, or detailed information about a specific multicast address.

**show mvr6 members { [*ip-address*] **host-ip-address** [*ip-address*] | **ds-vlan** *vlan-id* [*ip-address*] | **interface** *ip-address*] | **interface** *ip-address*] | **mld** | **sort-by-port** [*ip-address*] | **ds-vlan** *vlan-id* [*ip-address*] | **interface** *ip-address*] | **interface** *ip-address*] | **unknown**}}**

*ip-address* - IPv6 address for an MVR6 multicast group.

**host-ip-address** - Show entries by subscriber IPv6 address

**mld** - Show entries created by MLD protocol.

**sort-by-port** - Show entries with groups sorted by port.

**unknown** - Show entries created by receiving multicast streams.

**user** - Show user configured entries.

**ds-vlan** - Downstream VLAN ID (Range: 1-4094)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

Displays configuration settings for all domains and all forwarding entries.

### Command Mode

Privileged Exec

### Example

The following shows information about the current number of multicast forwarding entries in all domains.

```
Console#show mvr6 members
MVR6 Domain : 1
MVR6 Forwarding Entry Count :0

MVR6 Domain : 2
MVR6 Forwarding Entry Count :0

MVR6 Domain : 3
MVR6 Forwarding Entry Count :0

MVR6 Domain : 4
MVR6 Forwarding Entry Count :0

MVR6 Domain : 5
MVR6 Forwarding Entry Count :0

Console#
```

**show mvr6 domain** This command shows information about the current number of entries in the forwarding database, or detailed information about a specific multicast address for a specific domain ID.

### Syntax

```
show mvr6 domain domain-id {members [ip-address]} host-ip-address [ip-address | ds-vlan vlan-id [ip-address | interface ip-address] | interface ip-address ] | mld | sort-by-port [ip-address | ds-vlan vlan-id [ip-address | interface ip-address] | interface ip-address ] | unknown}]
```

*domain-id* - An independent multicast domain. (Range 1-5)

*ip-address* - IPv6 address for an MVR6 multicast group.

**host-ip-address** - Show entries by subscriber IPv6 address

**mld** - Show entries created by MLD protocol.

**sort-by-port** - Show entries with groups sorted by port.

**unknown** - Show entries created by receiving multicast streams.

**user** - Show user configured entries.

**ds-vlan** - Downstream VLAN ID (Range: 1-4094)

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

Displays configuration settings for the specified domain and all its forwarding entries.

### Command Mode

Privileged Exec

### Example

The following shows information about the number of multicast forwarding entries currently active in domain 1:

```
Console#show mvr6 domain 1 members
MVR6 Domain : 1
MVR6 Forwarding Entry Count :1
Flag: S - Source port, R - Receiver port.
      H - Host counts (number of hosts join the group on this port).
      P - Port counts (number of forwarding ports).
Up time: Group elapsed time (d:h:m:s).
Expire : Group remaining time (m:s).

Group Address                VLAN Port                Up time                Expire Count
-----
```

```

ff05::101                2                00:00:00:19        2 (P)
                        2 Eth1/ 1(S)
                        1 Eth1/ 2(R)                0 (H)
Console#

```

The following example shows detailed information about a specific multicast address:

```

Console#show mvr6 domain 1 members ff00::1
MVR6 Domain : 1
MVR6 Forwarding Entry Count :1
Flag: S - Source port, R - Receiver port.
      H - Host counts (number of hosts join the group on this port).
      P - Port counts (number of forwarding ports).
Up time: Group elapsed time (d:h:m:s).
Expire : Group remaining time (m:s).

Group Address          VLAN Port          Up time          Expire Count
-----
ff05::1                2                00:00:03:18        2 (P)
                        2 Eth1/ 2(S)
                        1 Eth1/ 4(R)                0 (H)
Console#

```

**Table 163: show mvr6 members - display description**

Field	Description
Group Address	Multicast group address.
VLAN	VLAN to which this address is forwarded.
Port	Port to which this address is forwarded.
Up time	Time that this multicast group has been known.
Expire	The time until this entry expires.
Count	The number of times this address has been learned by MVR6.

**show mvr6 profile** This command shows all configured MVR6 profiles.

### Command Mode

Privileged Exec

### Example

The following shows all configured MVR6 profiles:

```

Console#show mvr6 profile
MVR6 Profile Name      Start IPv6 Addr.      End IPv6 Addr.
-----
rd                      ff01::fe              ff01::ff
Console#

```

**show mvr6 statistics** This command shows MVR6 protocol-related statistics for the specified interface.

### Syntax

```
show mvr6 [domain domain-id] statistics {input [interface interface] |  
output [interface interface] | query | summary {interface [ethernet unit/  
port | mvr-vlan | port-channel channel-id]}}
```

**input** - Specifies to display statistics for messages received by the interface.

**output** - Specifies to display statistics for messages sent by the interface.

*domain-id* - An independent multicast domain. (Range: 1-5)

*interface*

**ethernet *unit/port***

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel *channel-id*** (Range: 1-28)

**vlan *vlan-id*** - VLAN ID (Range: 1-4094)

**query** - Displays MVR query-related statistics.

**summary** - Displays MVR6 summary information.

**mvr vlan** - Displays summary statistics for the MVR6 VLAN.

### Default Setting

Displays statistics for all domains.

### Command Mode

Privileged Exec

### Example

The following shows MVR6 protocol-related statistics received:

```
Console#show mvr6 domain 1 statistics input  
MVR6 Domain 1, MVR6 VLAN 2:  
Input Statistics:  
Interface Report    Leave    G Query  G(-S)-S Query Drop    Join Succ Group  
-----  
Eth 1/ 1           23      11      4        10      5      20      9  
Eth 1/ 2           12      15      8         3       5      19      4  
DVLAN 1            2       0       0         2       2      20      9  
MVLAN 2            2       0       0         2       2      20      9  
Console#
```

**Table 164: show mvr6 statistics input - display description**

Field	Description
Interface	Shows interfaces attached to the MVR6.
Report	The number of IGMP membership reports received on this interface.
Leave	The number of leave messages received on this interface.
G Query	The number of general query messages received on this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages received on this interface.
Drop	The number of times a report, leave or query was dropped. Packets may be dropped due to invalid format, rate limiting, packet content not allowed, or MVR6 group report received
Join Succ	The number of times a multicast group was successfully joined.
Group	The number of MVR6 groups active on this interface.

The following shows MVR6 protocol-related statistics sent:

```

Console#show mvr6 domain 1 statistics output
MVR6 Domain 1, MVR6 VLAN 2:
Output Statistics:
Interface  Report    Done      G Query  G(-S)-S Query  Drop      Group
-----
Eth 1/ 1    12           0         1         0              0         0
Eth 1/ 3     5           1         4         1              0         0
DVLAN  1     7           2         3         0              0         0
MVLAN  2     7           2         3         0              0         0
Console#

```

**Table 165: show mvr6 statistics output - display description**

Field	Description
Interface	Shows interfaces attached to the MVR6.
Report	The number of IGMP membership reports sent from this interface.
Leave	The number of leave messages sent from this interface.
G Query	The number of general query messages sent from this interface.
G(-S)-S Query	The number of group specific or group-and-source specific query messages sent from this interface.
Group	The number of MVR6 groups active on this interface.

The following shows MVR6 query-related statistics:

```

Console#show mvr6 domain 1 statistics query
Other Querier Address      : None
Other Querier Uptime      : 0(h):0(m):0(s)
Other Querier Expire Time : 0(m):0(s)
Self Querier Address      : 2001:db8:2222:7272::
Self Querier Uptime       : 0(h):0(m):0(s)

```

```

Self Querier Expire Time : 0(m):0(s)
General Query Received  : 0
General Query Sent      : 0
Specific Query Received : 0
Specific Query Sent     : 0
Console#

```

**Table 166: show mvr6 statistics query - display description**

Field	Description
Other Querier Address	The IPv6 address of the querier on this interface.
Other Querier Uptime	Other querier's time up.
Other Querier Expire Time	The time after which this querier is assumed to have expired.
Self Querier Address	This querier's IPv6 address.
Self Querier Uptime	This querier's time up.
Self Querier Expire Time	This querier's expire time.
General Query Received	The number of general queries received on this interface.
General Query Sent	The number of general queries sent from this interface.
Specific Query Received	The number of specific queries received on this interface.
Specific Query Sent	The number of specific queries sent from this interface.

The following shows MVR6 summary statistics for an interface:

```

Console#show mvr6 domain 1 statistics summary interface ethernet 1/1
Domain 1:
Number of Groups: 0
Querier:          :
  Transmit       :
    General      : 0
    Group Specific : 0
  Recieved       :
    General      : 0
    Group Specific : 0
Report & Leave:  :
  Transmit       :
    Report       : 7
    Leave        : 4
  Recieved       :
    Report       : 0
    Leave        : 0
  Join Success   : 0
  Filter Drop    : 0
  Source Port Drop: 0
  Others Drop    : 0
Console#

```

**Table 167: show mvr6 statistics summary interface - display description**

Field	Description
Domain	An independent multicast domain.
Number of Groups	Number of groups learned on this port.
Querier	
Transmit	
General	Number of general queries transmitted.

**Table 167: show mvr6 statistics summary interface - display description**

Field	Description
Group Specific	Number of group specific queries transmitted.
Received	
General	Number of general queries received.
Group Specific	Number of group specific queries received.
Report & Leave	
Transmit	
Report	Number of transmitted reports.
Leave	Number of transmitted leaves.
Received	
Report	Number of reports received.
Leave	Number of leaves received.
Join Success	Number of join reports processed successfully.
Filter Drop	Number of report/leave messages dropped by IGMP filter.
Source Port Drop	Number of report/leave messages dropped by MVR source port.
Others Drop	Number of report/leave messages dropped for other reasons.

The following shows MVR6 summary statistics for the MVR6 VLAN:

```

Console#show mvr6 domain 1 statistics summary interface mvr-vlan
Domain 1:
Number of Groups: 0
Querier:          :                               Report & Leave:  :
  Other Addr      : None
                                     Host Addr       : None
  Other Expire    : 0(m): 0(s)           Unsolicit Expire : 0 sec
  Other Uptime    : 0(h): 0(m): 0(s)
  Self Addr       : None
  Self Expire     : 0(m): 0(s)
  Self Uptime     : 0(h): 0(m): 0(s)
Transmit         :                               Transmit         :
  General         : 0                               Report           : 0
  Group Specific  : 0                               Leave            : 0
Recieved        :                               Recieved         :
  General         : 0                               Report           : 0
  Group Specific  : 0                               Leave            : 0
                                     join Success     : 0
                                     Filter Drop       : 0
                                     Source Port Drop : 0
                                     Others Drop       : 0
Console#

```

**Table 168: show mvr6 statistics summary interface mvr vlan - description**

<b>Field</b>	<b>Description</b>
Domain	An independent multicast domain.
Number of Groups	Number of groups learned on this port.
Querier	
Other Addr	Other IGMP querier's IP address.
Other Expire	Other querier's expire time.
Other Uptime	Other querier's time up.
Self Addr	This querier's IP address.
Self Expire	This querier's expire time.
Self Uptime	This querier's time up.
Transmit	
General	Number of general queries sent from receiver port.
Group Specific	Number of group specific queries sent from receiver port.
Received	
General	Number of general queries received.
Group Specific	Number of group specific queries received.
Report & Leave	
Host Addr	Source IP address used to send report/leave messages from source port.
Unsolicit Expire	Expiration time for unsolicit reports sent out from source port
Transmit	
Report	Number of reports sent out from source port.
Leave	Number of leaves sent out from source port.
Received	Field header
Report	Number of reports received.
Leave	Number of leaves received.
Join Success	Number of join reports processed successfully.
Filter Drop	Number of report/leave messages dropped by IGMP filter.
Source Port Drop	Number of report/leave messages dropped by MVR source port.
Others Drop	Number of report/leave messages dropped for other reasons.

## LLDP Commands

Link Layer Discovery Protocol (LLDP) is used to discover basic information about neighboring devices on the local broadcast domain. LLDP is a Layer 2 protocol that uses periodic broadcasts to advertise information about the sending device. Advertised information is represented in Type Length Value (TLV) format according to the IEEE 802.1AB standard, and can include details such as device identification, capabilities and configuration settings. LLDP also defines how to store and maintain information gathered about the neighboring network nodes it discovers.

Link Layer Discovery Protocol - Media Endpoint Discovery (LLDP-MED) is an extension of LLDP intended for managing endpoint devices such as Voice over IP phones and network switches. The LLDP-MED TLVs advertise information such as network policy, power, inventory, and device location details. LLDP and LLDP-MED information can be used by SNMP applications to simplify troubleshooting, enhance network management, and maintain an accurate network topology.

**Table 169: LLDP Commands**

Command	Function	Mode
<code>lldp</code>	Enables LLDP globally on the switch	GC
<code>lldp holdtime-multiplier</code>	Configures the time-to-live (TTL) value sent in LLDP advertisements	GC
<code>lldp med-fast-start-count</code>	Configures how many medFastStart packets are transmitted	GC
<code>lldp notification-interval</code>	Configures the allowed interval for sending SNMP notifications about LLDP changes	GC
<code>lldp refresh-interval</code>	Configures the periodic transmit interval for LLDP advertisements	GC
<code>lldp reinit-delay</code>	Configures the delay before attempting to re-initialize after LLDP ports are disabled or the link goes down	GC
<code>lldp tx-delay</code>	Configures a delay between the successive transmission of advertisements initiated by a change in local LLDP MIB variables	GC
<code>lldp admin-status</code>	Enables LLDP transmit, receive, or transmit and receive mode on the specified port	IC
<code>lldp basic-tlv management-ip-address</code>	Configures an LLDP-enabled port to advertise the management address for this device	IC
<code>lldp basic-tlv management-ipv6-address</code>	Configures an LLDP-enabled port to advertise the management address for this device	IC
<code>lldp basic-tlv port-description</code>	Configures an LLDP-enabled port to advertise its port description	IC

Table 169: LLDP Commands (Continued)

Command	Function	Mode
<code>lldp basic-tlv system-capabilities</code>	Configures an LLDP-enabled port to advertise its system capabilities	IC
<code>lldp basic-tlv system-description</code>	Configures an LLDP-enabled port to advertise the system description	IC
<code>lldp basic-tlv system-name</code>	Configures an LLDP-enabled port to advertise its system name	IC
<code>lldp dot1-tlv proto-ident*</code>	Configures an LLDP-enabled port to advertise the supported protocols	IC
<code>lldp dot1-tlv proto-vid*</code>	Configures an LLDP-enabled port to advertise port-based protocol related VLAN information	IC
<code>lldp dot1-tlv pvid*</code>	Configures an LLDP-enabled port to advertise its default VLAN ID	IC
<code>lldp dot1-tlv vlan-name*</code>	Configures an LLDP-enabled port to advertise its VLAN name	IC
<code>lldp dot3-tlv link-agg</code>	Configures an LLDP-enabled port to advertise its link aggregation capabilities	IC
<code>lldp dot3-tlv mac-phy</code>	Configures an LLDP-enabled port to advertise its MAC and physical layer specifications	IC
<code>lldp dot3-tlv max-frame</code>	Configures an LLDP-enabled port to advertise its maximum frame size	IC
<code>lldp dot3-tlv poe</code>	Configures an LLDP-enabled port to advertise its Power-over-Ethernet capabilities	IC
<code>lldp med-location civic-addr</code>	Configures an LLDP-MED-enabled port to advertise its location identification details	IC
<code>lldp med-notification</code>	Enables the transmission of SNMP trap notifications about LLDP-MED changes	IC
<code>lldp med-tlv ext-poe</code>	Configures an LLDP-MED-enabled port to advertise its extended Power over Ethernet configuration and usage information	IC
<code>lldp med-tlv inventory</code>	Configures an LLDP-MED-enabled port to advertise its inventory identification details	IC
<code>lldp med-tlv location</code>	Configures an LLDP-MED-enabled port to advertise its location identification details	IC
<code>lldp med-tlv med-cap</code>	Configures an LLDP-MED-enabled port to advertise its Media Endpoint Device capabilities	IC
<code>lldp med-tlv network-policy</code>	Configures an LLDP-MED-enabled port to advertise its network policy configuration	IC
<code>lldp notification</code>	Enables the transmission of SNMP trap notifications about LLDP changes	IC
<code>show lldp config</code>	Shows LLDP configuration settings for all ports	PE
<code>show lldp info local-device</code>	Shows LLDP global and interface-specific configuration settings for this device	PE
<code>show lldp info remote-device</code>	Shows LLDP global and interface-specific configuration settings for remote devices	PE
<code>show lldp info statistics</code>	Shows statistical counters for all LLDP-enabled interfaces	PE

\* Vendor-specific options may or may not be advertised by neighboring devices.

**lldp** This command enables LLDP globally on the switch. Use the **no** form to disable LLDP.

#### Syntax

**[no] lldp**

#### Default Setting

Enabled

#### Command Mode

Global Configuration

#### Example

```
Console(config)#lldp
Console(config)#
```

**lldp holdtime-multiplier** This command configures the time-to-live (TTL) value sent in LLDP advertisements. Use the **no** form to restore the default setting.

#### Syntax

**lldp holdtime-multiplier** *value*

**no lldp holdtime-multiplier**

*value* - Calculates the TTL in seconds based on the following rule:  
minimum of ((Transmission Interval \* Holdtime Multiplier), or 65536)

(Range: 2 - 10)

#### Default Setting

Holdtime multiplier: 4

TTL: 4\*30 = 120 seconds

#### Command Mode

Global Configuration

#### Command Usage

- ◆ The time-to-live tells the receiving LLDP agent how long to retain all information pertaining to the sending LLDP agent if it does not transmit updates in a timely manner.

#### Example

```
Console(config)#lldp holdtime-multiplier 10
Console(config)#
```

**lldp med-fast-start-count** This command specifies the amount of MED Fast Start LLDPDUs to transmit during the activation process of the LLDP-MED Fast Start mechanism. Use the **no** form to restore the default setting.

#### Syntax

**lldp med-fast-start-count** *packet-number*

**no lldp med-fast-start-count**

*packet-number* - Amount of packets. (Range: 1-10 packets;  
Default: 4 packets)

#### Default Setting

4 packets

#### Command Mode

Global Configuration

#### Command Usage

This parameter is part of the timer which ensures that the LLDP-MED Fast Start mechanism is active for the port. LLDP-MED Fast Start is critical to the timely startup of LLDP, and therefore integral to the rapid availability of Emergency Call Service.

#### Example

```
Console(config)#lldp med-fast-start-count 6
Console(config)#
```

**lldp notification-interval** This command configures the allowed interval for sending SNMP notifications about LLDP MIB changes. Use the **no** form to restore the default setting.

#### Syntax

**lldp notification-interval** *seconds*

**no lldp notification-interval**

*seconds* - Specifies the periodic interval at which SNMP notifications are sent. (Range: 5 - 3600 seconds)

#### Default Setting

5 seconds

#### Command Mode

Global Configuration

#### Command Usage

- ◆ This parameter only applies to SNMP applications which use data stored in the LLDP MIB for network monitoring or management.

- ◆ Information about changes in LLDP neighbors that occur between SNMP notifications is not transmitted. Only state changes that exist at the time of a notification are included in the transmission. An SNMP agent should therefore periodically check the value of `IldpStatsRemTableLastChangeTime` to detect any `IldpRemTablesChange` notification-events missed due to throttling or transmission loss.

### Example

```
Console(config)#lldp notification-interval 30
Console(config)#
```

**lldp refresh-interval** This command configures the periodic transmit interval for LLDP advertisements. Use the **no** form to restore the default setting.

### Syntax

**lldp refresh-interval** *seconds*

**no lldp refresh-delay**

*seconds* - Specifies the periodic interval at which LLDP advertisements are sent. (Range: 5 - 32768 seconds)

### Default Setting

30 seconds

### Command Mode

Global Configuration

### Example

```
Console(config)#lldp refresh-interval 60
Console(config)#
```

**lldp reinit-delay** This command configures the delay before attempting to re-initialize after LLDP ports are disabled or the link goes down. Use the **no** form to restore the default setting.

### Syntax

**lldp reinit-delay** *seconds*

**no lldp reinit-delay**

*seconds* - Specifies the delay before attempting to re-initialize LLDP. (Range: 1 - 10 seconds)

### Default Setting

2 seconds

**Command Mode**

Global Configuration

**Command Usage**

When LLDP is re-initialized on a port, all information in the remote systems LLDP MIB associated with this port is deleted.

**Example**

```
Console(config)#lldp reinit-delay 10
Console(config)#
```

**lldp tx-delay** This command configures a delay between the successive transmission of advertisements initiated by a change in local LLDP MIB variables. Use the **no** form to restore the default setting.

**Syntax**

**lldp tx-delay** *seconds*

**no lldp tx-delay**

*seconds* - Specifies the transmit delay. (Range: 1 - 8192 seconds)

**Default Setting**

2 seconds

**Command Mode**

Global Configuration

**Command Usage**

- ◆ The transmit delay is used to prevent a series of successive LLDP transmissions during a short period of rapid changes in local LLDP MIB objects, and to increase the probability that multiple, rather than single changes, are reported in each transmission.
- ◆ This attribute must comply with the following rule:  
 $(4 * \text{tx-delay}) \leq \text{refresh-interval}$

**Example**

```
Console(config)#lldp tx-delay 10
Console(config)#
```

**lldp admin-status** This command enables LLDP transmit, receive, or transmit and receive mode on the specified port. Use the **no** form to disable this feature.

#### Syntax

**lldp admin-status {rx-only | tx-only | tx-rx}**

**no lldp admin-status**

**rx-only** - Only receive LLDP PDUs.

**tx-only** - Only transmit LLDP PDUs.

**tx-rx** - Both transmit and receive LLDP Protocol Data Units (PDUs).

#### Default Setting

tx-rx

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp admin-status rx-only
Console(config-if)#
```

**lldp basic-tlv management-ip-address** This command configures an LLDP-enabled port to advertise the management address for this device. Use the **no** form to disable this feature.

#### Syntax

**[no] lldp basic-tlv management-ip-address**

#### Default Setting

Enabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

- ◆ The management address protocol packet includes the IPv4 address of the switch. If no management address is available, the address should be the MAC address for the CPU or for the port sending this advertisement.
- ◆ The management address TLV may also include information about the specific interface associated with this address, and an object identifier indicating the type of hardware component or protocol entity associated with this address. The interface number and OID are included to assist SNMP applications to perform network discovery by indicating enterprise specific or other starting points for the search, such as the Interface or Entity MIB.

- ◆ Since there are typically a number of different addresses associated with a Layer 3 device, an individual LLDP PDU may contain more than one management address TLV.
- ◆ Every management address TLV that reports an address that is accessible on a port and protocol VLAN through the particular port should be accompanied by a port and protocol VLAN TLV that indicates the VLAN identifier (VID) associated with the management address reported by this TLV.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp basic-tlv management-ip-address
Console(config-if)#
```

**lldp basic-tlv management-ipv6-address** This command configures an LLDP-enabled port to advertise the management IPv6 address for this device. Use the **no** form to disable this feature.

### Syntax

**[no] lldp basic-tlv management-ipv6-address**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ If both the management-ip-address and the IPv4 address of a VLAN interface is configured, the primary IPv4 address of the VLAN ID will be sent in the Management Address TLV of the LLDP PDU transmitted.
- ◆ If both the management-ipv6-address and the IPv6 address of a VLAN interface is configured, the IPv6 address of the VLAN ID will be sent in the Management Address TLV of the LLDP PDU transmitted.
- ◆ Two Management Address TLVs in the LLDP PDU will be sent if both of the two conditions below are true:
  - The interface has both commands configured i.e. management-ip-address and management-ipv6-address.
  - The VLAN interface has both IPv4 and IPv6 addresses set.
 One address will be the IPv4 address and the other will be the IPv6 address.
- ◆ If either or both the management-ip-address or management-ipv6-address are configured
  - and -

Neither the IPv4 address nor the IPv6 address of a VLAN interface is configured.

The CPU MAC address (or device MAC address) will be sent in the Management Address TLV of the LLDP PDU transmitted.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp basic-tlv management-ipv6-address
Console(config-if)#
```

**lldp basic-tlv port-description** This command configures an LLDP-enabled port to advertise its port description. Use the **no** form to disable this feature.

### Syntax

**[no] lldp basic-tlv port-description**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

The port description is taken from the ifDescr object in RFC 2863, which includes information about the manufacturer, the product name, and the version of the interface hardware/software.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp basic-tlv port-description
Console(config-if)#
```

**lldp basic-tlv system-capabilities** This command configures an LLDP-enabled port to advertise its system capabilities. Use the **no** form to disable this feature.

### Syntax

**[no] lldp basic-tlv system-capabilities**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

The system capabilities identifies the primary function(s) of the system and whether or not these primary functions are enabled. The information advertised by this TLV is described in IEEE 802.1AB.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp basic-tlv system-capabilities
Console(config-if)#
```

**lldp basic-tlv system-description** This command configures an LLDP-enabled port to advertise the system description. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp basic-tlv system-description**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

The system description is taken from the sysDescr object in RFC 3418, which includes the full name and version identification of the system's hardware type, software operating system, and networking software.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp basic-tlv system-description
Console(config-if)#
```

**lldp basic-tlv system-name** This command configures an LLDP-enabled port to advertise the system name. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp basic-tlv system-name**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

### Command Usage

The system name is taken from the sysName object in RFC 3418, which contains the system's administratively assigned name, and is in turn based on the [hostname](#) command.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp basic-tlv system-name
Console(config-if)#
```

**lldp dot1-tlv proto-ident** This command configures an LLDP-enabled port to advertise the supported protocols. Use the **no** form to disable this feature.

### Syntax

**[no] lldp dot1-tlv proto-ident**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

This option advertises the protocols that are accessible through this interface.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp dot1-tlv proto-ident
Console(config-if)#
```

**lldp dot1-tlv proto-vid** This command configures an LLDP-enabled port to advertise port-based protocol VLAN information. Use the **no** form to disable this feature.

### Syntax

**[no] lldp dot1-tlv proto-vid**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

This option advertises the port-based protocol VLANs configured on this interface (see [“Configuring Protocol-based VLANs” on page 601](#)).

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp dot1-tlv proto-vid
Console(config-if)#
```

**lldp dot1-tlv pvid** This command configures an LLDP-enabled port to advertise its default VLAN ID. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp dot1-tlv pvid**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

The port's default VLAN identifier (PVID) indicates the VLAN with which untagged or priority-tagged frames are associated (see the [switchport native vlan](#) command).

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp dot1-tlv pvid
Console(config-if)#
```

**lldp dot1-tlv vlan-name** This command configures an LLDP-enabled port to advertise its VLAN name. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp dot1-tlv vlan-name**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

This option advertises the name of all VLANs to which this interface has been assigned. See “[switchport allowed vlan](#)” on page 580 and “[protocol-vlan protocol-group \(Configuring Interfaces\)](#)” on page 603.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp dot1-tlv vlan-name
Console(config-if)#
```

**lldp dot3-tlv link-agg** This command configures an LLDP-enabled port to advertise link aggregation capabilities. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp dot3-tlv link-agg**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

This option advertises link aggregation capabilities, aggregation status of the link, and the 802.3 aggregated port identifier if this interface is currently a link aggregation member.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp dot3-tlv link-agg
Console(config-if)#
```

**lldp dot3-tlv mac-phy** This command configures an LLDP-enabled port to advertise its MAC and physical layer capabilities. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp dot3-tlv mac-phy**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

This option advertises MAC/PHY configuration/status which includes information about auto-negotiation support/capabilities, and operational Multistation Access Unit (MAU) type.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#no lldp dot3-tlv mac-phy
Console(config-if)#
```

**lldp dot3-tlv max-frame** This command configures an LLDP-enabled port to advertise its maximum frame size. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp dot3-tlv max-frame**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

Refer to [“Frame Size” on page 133](#) for information on configuring the maximum frame size for this switch.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp dot3-tlv max-frame
Console(config-if)#
```

**lldp dot3-tlv poe** This command configures an LLDP-enabled port to advertise its Power-over-Ethernet (PoE) capabilities. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp dot3-tlv poe**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ This command only applies to the ECS4650-54P.
- ◆ This option advertises Power-over-Ethernet capabilities, including whether or not PoE is supported, currently enabled, if the port pins through which power is delivered can be controlled, the port pins selected to deliver power, and the power class.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp dot3-tlv poe
Console(config-if)#
```

**lldp med-location civic-addr** This command configures an LLDP-MED-enabled port to advertise its location identification details. Use the **no** form to restore the default settings.

### Syntax

**lldp med-location civic-addr** [[**country** *country-code*] | [**what** *device-type*] | [*ca-type ca-value*]]

**no lldp med-location civic-addr** [[**country**] | [**what**] | [*ca-type*]]

*country-code* – The two-letter ISO 3166 country code in capital ASCII letters. (Example: DK, DE or US)

*device-type* – The type of device to which the location applies.

0 – Location of DHCP server.

1 – Location of network element closest to client.

2 – Location of client.

*ca-type* – A one-octet descriptor of the data civic address value. (Range: 0-255)

*ca-value* – Description of a location. (Range: 1-32 characters)

### Default Setting

Not advertised  
No description

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ Use this command without any keywords to advertise location identification details.

- ◆ Use the *ca-type* to advertise the physical location of the device, that is the city, street number, building and room information. The address location is specified as a type and value pair, with the civic address (CA) type being defined in RFC 4776. The following table describes some of the CA type numbers and provides examples.

Table 170: LLDP MED Location CA Types

CA Type	Description	CA Value Example
0	The ISO 639 language code used for presenting the address information.	en
1	National subdivisions (state, canton, province)	California
2	County, parish	Orange
3	City, township	Irvine
4	City division, borough, city district	West Irvine
5	Neighborhood, block	Riverside
6	Group of streets below the neighborhood level	Exchange
18	Street suffix or type	Avenue
19	House number	320
20	House number suffix	A
21	Landmark or vanity address	Tech Center
26	Unit (apartment, suite)	Apt 519
27	Floor	5
28	Room	509B

Any number of CA type and value pairs can be specified for the civic address location, as long as the total does not exceed 250 characters.

- ◆ For the location options defined for *device-type*, normally option **2** is used to specify the location of the client device. In situations where the client device location is not known, **0** and **1** can be used, providing the client device is physically close to the DHCP server or network element.

### Example

The following example enables advertising location identification details.

```

Console(config)#interface ethernet 1/1
Console(config-if)#lldp med-location civic-addr
Console(config-if)#lldp med-location civic-addr 1 California
Console(config-if)#lldp med-location civic-addr 2 Orange
Console(config-if)#lldp med-location civic-addr 3 Irvine
Console(config-if)#lldp med-location civic-addr 4 West Irvine
Console(config-if)#lldp med-location civic-addr 6 Exchange
Console(config-if)#lldp med-location civic-addr 18 Avenue
Console(config-if)#lldp med-location civic-addr 19 320
Console(config-if)#lldp med-location civic-addr 27 5

```

```

Console(config-if)#lldp med-location civic-addr 28 509B
Console(config-if)#lldp med-location civic-addr country US
Console(config-if)#lldp med-location civic-addr what 2
Console(config-if)#

```

**lldp med-notification** This command enables the transmission of SNMP trap notifications about LLDP-MED changes. Use the **no** form to disable LLDP-MED notifications.

### Syntax

**[no] lldp med-notification**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ This option sends out SNMP trap notifications to designated target stations at the interval specified by the [lldp notification-interval](#) command. Trap notifications include information about state changes in the LLDP MIB (IEEE 802.1AB), the LLDP-MED MIB (ANSI/TIA 1057), or organization-specific LLDP-EXT-DOT1 and LLDP-EXT-DOT3 MIBs.
- ◆ SNMP trap destinations are defined using the [snmp-server host](#) command.
- ◆ Information about additional changes in LLDP neighbors that occur between SNMP notifications is not transmitted. Only state changes that exist at the time of a trap notification are included in the transmission. An SNMP agent should therefore periodically check the value of `IldpStatsRemTableLastChangeTime` to detect any `IldpRemTablesChange` notification-events missed due to throttling or transmission loss.

### Example

```

Console(config)#interface ethernet 1/1
Console(config-if)#lldp med-notification
Console(config-if)#

```

**lldp med-tlv ext-poe** This command configures an LLDP-MED-enabled port to advertise and accept Extended Power-over-Ethernet configuration and usage information. Use the **no** form to disable this feature.

### Syntax

**[no] lldp med-tlv ext-poe**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

- ◆ This command only applies to the ECS4650-54P.
- ◆ This option advertises extended Power-over-Ethernet capability details, such as power availability from the switch, and power state of the switch, including whether the switch is operating from primary or backup power (the Endpoint Device could use this information to decide to enter power conservation mode). Note that this device does not support PoE capabilities.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#no lldp med-tlv ext-poe
Console(config-if)#
```

**lldp med-tlv inventory** This command configures an LLDP-MED-enabled port to advertise its inventory identification details. Use the **no** form to disable this feature.

**Syntax**

**[no] lldp med-tlv inventory**

**Default Setting**

Enabled

**Command Mode**

Interface Configuration (Ethernet, Port Channel)

**Command Usage**

This option advertises device details useful for inventory management, such as manufacturer, model, software version and other pertinent information.

**Example**

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp med-tlv inventory
Console(config-if)#
```

**lldp med-tlv location** This command configures an LLDP-MED-enabled port to advertise its location identification details. Use the **no** form to disable this feature.

#### Syntax

**[no] lldp med-tlv location**

#### Default Setting

Enabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

This option advertises location identification details.

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp med-tlv location
Console(config-if)#
```

**lldp med-tlv med-cap** This command configures an LLDP-MED-enabled port to advertise its Media Endpoint Device capabilities. Use the **no** form to disable this feature.

#### Syntax

**[no] lldp med-tlv med-cap**

#### Default Setting

Enabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

This option advertises LLDP-MED TLV capabilities, allowing Media Endpoint and Connectivity Devices to efficiently discover which LLDP-MED related TLVs are supported on the switch.

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp med-tlv med-cap
Console(config-if)#
```

**lldp med-tlv network-policy** This command configures an LLDP-MED-enabled port to advertise its network policy configuration. Use the **no** form to disable this feature.

#### Syntax

**[no] lldp med-tlv network-policy**

#### Default Setting

Enabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

This option advertises network policy configuration information, aiding in the discovery and diagnosis of VLAN configuration mismatches on a port. Improper network policy configurations frequently result in voice quality degradation or complete service disruption.

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp med-tlv network-policy
Console(config-if)#
```

**lldp notification** This command enables the transmission of SNMP trap notifications about LLDP changes in remote neighbors. Use the **no** form to disable LLDP notifications.

#### Syntax

**[no] lldp notification**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (Ethernet, Port Channel)

#### Command Usage

- ◆ This option sends out SNMP trap notifications to designated target stations at the interval specified by the [lldp notification-interval](#) command. Trap notifications include information about state changes in the LLDP MIB (IEEE 802.1AB), or organization-specific LLDP-EXT-DOT1 and LLDP-EXT-DOT3 MIBs.
- ◆ SNMP trap destinations are defined using the [snmp-server host](#) command.
- ◆ Information about additional changes in LLDP neighbors that occur between SNMP notifications is not transmitted. Only state changes that exist at the time of a trap notification are included in the transmission. An SNMP agent should

therefore periodically check the value of `lldpStatsRemTableLastChangeTime` to detect any `lldpRemTablesChange` notification-events missed due to throttling or transmission loss.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#lldp notification
Console(config-if)#
```

**show lldp config** This command shows LLDP configuration settings for all ports.

### Syntax

**show lldp config** [**detail** *interface*]

**detail** - Shows configuration summary.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

The following example shows the basic LLDP parameters for Port 1.

```
Console#show lldp config detail ethernet 1/1

LLDP Port Configuration Detail
Port                               : Eth 1/1
Admin Status                       : Tx-Rx
Notification Enabled               : True
Basic TLVs Advertised              : port-description
                                   system-name
                                   system-description
                                   system-capabilities
                                   management-ip-address
802.1 specific TLVs Advertised    : port-vid
                                   vlan-name
                                   proto-vlan
                                   proto-ident
802.3 specific TLVs Advertised    : mac-phy
                                   link-agg
                                   max-frame
MED Notification Status            : Disabled
MED Enabled TLVs Advertised       : med-cap
                                   network-policy
                                   location
                                   inventory
```

```

MED Location Identification
Location Data Format : Civic Address LCI
Country Name       : DK
What               : 2 - DHCP Client
CA Type 1         : 12
CA Type 13        : 13

```

```
Console#
```

**show lldp info local-device** This command shows LLDP global and interface-specific configuration settings for this device.

### Syntax

**show lldp info local-device** [**detail** *interface*]

**detail** - Shows configuration summary.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

```

Console#show lldp info local-device
LLDP Local Global Information
Chassis Type : MAC Address
Chassis ID   : 00-01-02-03-04-05
System Name  :
System Description : ECS4650-54P
System Capabilities Support : Bridge
System Capabilities Enabled : Bridge
Management Address : 192.168.0.101 (IPv4)

LLDP Port Information
Port      Port ID Type      Port ID      Port Description
-----
Eth 1/1   MAC Address      00-12-CF-DA-FC-E9 Ethernet Port on unit 1, port 1
Eth 1/2   MAC Address      00-12-CF-DA-FC-EA Ethernet Port on unit 1, port 2
Eth 1/3   MAC Address      00-12-CF-DA-FC-EB Ethernet Port on unit 1, port 3
Eth 1/4   MAC Address      00-12-CF-DA-FC-EC Ethernet Port on unit 1, port 4
.
.
.
Console#show lldp info local-device detail ethernet 1/1
LLDP Local Port Information Detail
Port           : Eth 1/1
Port ID Type   : MAC Address
Port ID        : 00-12-CF-DA-FC-E9
Port Description : Ethernet Port on unit 1, port 1
MED Capability : LLDP-MED Capabilities
                Network Policy
                Location Identification

```

## Inventory

Console#

**show lldp info remote-device** This command shows LLDP global and interface-specific configuration settings for remote devices attached to an LLDP-enabled port.

**Syntax**

**show lldp info remote-device** [**detail** *interface*]

**detail** - Shows detailed information.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

**Command Mode**

Privileged Exec

**Example**

Note that an IP phone or other end-node device which advertises LLDP-MED capabilities must be connected to the switch for information to be displayed in the “LLDP-MED Capability” and other related fields.

```

Console#show lldp info remote-device
LLDP Remote Devices Information
  Local Port Chassis ID      Port ID      System Name
  -----
  Eth 1/1    00-E0-0C-00-00-FD 00-E0-0C-00-01-02

Console#show lldp info remote-device detail ethernet 1/1
LLDP Remote Devices Information Detail
-----
Index           : 2
Chassis Type    : MAC Address
Chassis ID     : 70-72-CF-91-1C-B2
Port ID Type    : MAC Address
Port ID        : 70-72-CF-91-1C-B4
Time To Live   : 120 seconds
Port Description : Ethernet Port on unit 1, port 2
System Description : ECS4650-54T
System Capabilities : Bridge
Enabled Capabilities : Bridge

Management Address : 192.168.0.4 (IPv4)

Port VLAN ID : 1

Port and Protocol VLAN ID : supported, disabled

VLAN Name : VLAN    1 - DefaultVlan

```

```

Protocol Identity (Hex) : 88-CC

MAC/PHY Configuration/Status
Port Auto-neg Supported      : Yes
Port Auto-neg Enabled       : Yes
Port Auto-neg Advertised Cap (Hex) : 6C00
Port MAU Type                : 16

Power via MDI
Power Class                  : PSE
Power MDI Supported         : Yes
Power MDI Enabled           : Yes
Power Pair Controllable    : No
Power Pairs                  : Spare
Power Classification        : Class 1

Link Aggregation
Link Aggregation Capable   : Yes
Link Aggregation Enable    : No
Link Aggregation Port ID   : 0

Max Frame Size : 1522

Console#

```

The following example shows information which is displayed for end-node device which advertises LLDP-MED TLVs.

```

...
LLDP-MED Capability :
  Device Class      : Network Connectivity
  Supported Capabilities : LLDP-MED Capabilities
                        Network Policy
                        Location Identification
                        Extended Power via MDI - PSE
                        Inventory

  Current Capabilities : LLDP-MED Capabilities
                        Location Identification
                        Extended Power via MDI - PSE
                        Inventory

Location Identification :
  Location Data Format   : Civic Address LCI
  Country Name         : TW
  What                  : 2

Extended Power via MDI :
  Power Type           : PSE
  Power Source         : Unknown
  Power Priority        : Unknown
  Power Value          : 0 Watts

Inventory :
  Hardware Revision    : R0A
  Firmware Revision    : 1.2.6.0
  Software Revision    : 1.2.6.0
  Serial Number        : S123456
  Manufacture Name     : Prye
  Model Name           : VP101
  Asset ID             : 340937

Console#

```

**show lldp info statistics** This command shows statistics based on traffic received through all attached LLDP-enabled interfaces.

### Syntax

**show lldp info statistics** [**detail** *interface*]

**detail** - Shows configuration summary.

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

```

Console#show lldp info statistics
LLDP Global Statistics
Neighbor Entries List Last Updated : 485 seconds
New Neighbor Entries Count          : 2
Neighbor Entries Deleted Count      : 1
Neighbor Entries Dropped Count      : 0
Neighbor Entries Ageout Count       : 1

LLDP Port Statistics
Port      NumFramesRecvd  NumFramesSent  NumFramesDiscarded
-----
Eth 1/1   12              12             0
Eth 1/2   17              17             0
Eth 1/3   0               0              0
Eth 1/4   0               0              0
Eth 1/5   0               0              0
:

Console#show lldp info statistics detail ethernet 1/1
LLDP Port Statistics Detail
Port Name      : Eth 1/1
Frames Discarded : 0
Frames Invalid  : 0
Frames Received : 12
Frames Sent     : 12
TLVs Unrecognized : 0
TLVs Discarded  : 0
Neighbor Ageouts : 1
Console#

```



## CFM Commands

Connectivity Fault Management (CFM) is an OAM protocol that includes proactive connectivity monitoring using continuity check messages, fault verification through loop back messages, and fault isolation by examining end-to-end connections between provider edge devices or between customer edge devices.

CFM is implemented as a service level protocol based on service instances which encompass only that portion of the metropolitan area network supporting a specific customer. CFM can also provide controlled management access to a hierarchy of maintenance domains (such as the customer, service provider, and equipment operator).

The following list of commands support functions for defining the CFM structure, including domains, maintenance associations, and maintenance access points. It also provides commands for fault detection through continuity check messages for all known maintenance points, and cross-check messages for statically configured maintenance points located on other devices. Fault verification is supported through loop back messages, and fault isolation through link trace messages. Fault notification is also provided by SNMP alarms which are automatically generated by maintenance points when connectivity faults or configuration errors are detected in the local maintenance domain.

**Table 171: CFM Commands**

Command	Function	Mode
<i>Defining CFM Structures</i>		
<code>ethernet cfm ais level</code>	Configures the maintenance level at which Alarm Indication Signal information will be sent	GC
<code>ethernet cfm ais ma</code>	Enables the MEPs within the specified MA to send frames with AIS information	GC
<code>ethernet cfm ais period</code>	Configures the interval at which AIS information is sent	GC
<code>ethernet cfm ais suppress alarm</code>	Suppresses AIS messages following the detection of defect conditions	GC
<code>ethernet cfm domain</code>	Defines a CFM maintenance domain, sets the authorized maintenance level, and enters CFM configuration mode; also specifies the MIP creation method for MAs within this domain	GC
<code>ethernet cfm enable</code>	Enables CFM processing globally on the switch	GC
<code>ma index name</code>	Creates a maintenance association within the current maintenance domain, maps it to a customer service instance, and sets the manner in which MIPs are created for this service instance	CFM

Table 171: CFM Commands (Continued)

Command	Function	Mode
<code>ma index name-format</code>	Specifies the name format for the maintenance association as IEEE 802.1ag character based, or ITU-T SG13/SG15 Y.1731 defined ICC-based format	CFM
<code>ethernet cfm mep</code>	Sets an interface as a domain boundary, defines it as a maintenance end point (MEP), and sets direction of the MEP in regard to sending and receiving CFM messages	IC
<code>ethernet cfm port-enable</code>	Enables CFM processing on an interface	IC
<code>clear ethernet cfm ais mpid</code>	Clears AIS defect information for the specified MEP	PE
<code>show ethernet cfm configuration</code>	Displays CFM configuration settings, including global settings, SNMP traps, and interface settings	PE
<code>show ethernet cfm md</code>	Displays configured maintenance domains	PE
<code>show ethernet cfm ma</code>	Displays configured maintenance associations	PE
<code>show ethernet cfm maintenance-points local</code>	Displays maintenance points configured on this device	PE
<code>show ethernet cfm maintenance-points local detail mep</code>	Displays detailed CFM information about a specified local MEP in the continuity check database	PE
<code>show ethernet cfm maintenance-points remote detail</code>	Displays detailed CFM information about a specified remote MEP in the continuity check database	PE
<i>Continuity Check Operations</i>		
<code>ethernet cfm cc ma interval</code>	Sets the transmission delay between continuity check messages	GC
<code>ethernet cfm cc enable</code>	Enables transmission of continuity check messages within a specified maintenance association	GC
<code>snmp-server enable traps ethernet cfm cc</code>	Enables SNMP traps for CFM continuity check events	GC
<code>mep archive-hold-time</code>	Sets the time that data from a missing MEP is kept in the continuity check database before being purged	CFM
<code>clear ethernet cfm maintenance-points remote</code>	Clears the contents of the continuity check database	PE
<code>clear ethernet cfm errors</code>	Clears continuity check errors logged for the specified maintenance domain and maintenance level	PE
<code>show ethernet cfm errors</code>	Displays CFM continuity check errors logged on this device	PE
<i>Cross Check Operations</i>		
<code>ethernet cfm mep crosscheck start-delay</code>	Sets the maximum delay that a device waits for remote MEPs to come up before starting the cross-check operation	GC
<code>snmp-server enable traps ethernet cfm crosscheck</code>	Enables SNMP traps for CFM continuity check events, in relation to the cross-check operations between statically configured MEPs and those learned via continuity check messages	GC
<code>mep crosscheck mpid</code>	Statically defines a remote MEP in a maintenance association	CFM

Table 171: CFM Commands (Continued)

Command	Function	Mode
<code>ethernet cfm mep crosscheck</code>	Enables cross-checking between the list of configured remote MEPs within a maintenance association and MEPs learned through continuity check messages	PE
<code>show ethernet cfm maintenance-points remote crosscheck</code>	Displays information about remote maintenance points configured statically in a cross-check list	PE
<i>Link Trace Operations</i>		
<code>ethernet cfm linktrace cache</code>	Enables caching of CFM data learned through link trace messages	GC
<code>ethernet cfm linktrace cache hold-time</code>	Sets the hold time for CFM link trace cache entries	GC
<code>ethernet cfm linktrace cache size</code>	Sets the maximum size for the link trace cache	GC
<code>ethernet cfm linktrace</code>	Sends CFM link trace messages to the MAC address for a MEP	PE
<code>clear ethernet cfm linktrace-cache</code>	Clears link trace messages logged on this device	PE
<code>show ethernet cfm linktrace-cache</code>	Displays the contents of the link trace cache	PE
<i>Loopback Operations</i>		
<code>ethernet cfm loopback</code>	Sends CFM loopback messages to a MAC address for a MEP or MIP	PE
<i>Fault Generator Operations</i>		
<code>mep fault-notify alarm-time</code>	Sets the time a defect must exist before a fault alarm is issued	CFM
<code>mep fault-notify lowest-priority</code>	Sets the lowest priority defect that is allowed to generate a fault alarm	CFM
<code>mep fault-notify reset-time</code>	Configures the time after a fault alarm has been issued, and no defect exists, before another fault alarm can be issued	CFM
<code>show ethernet cfm fault-notify-generator</code>	Displays configuration settings for the fault notification generator	PE
<i>Delay Measure Operations</i>		
<code>ethernet cfm delay-measure two-way</code>	Sends periodic delay-measure requests to a specified MEP within a maintenance association	PE

*Basic Configuration Steps for CFM*

1. Configure the maintenance domains with the `ethernet cfm domain` command.
2. Configure the maintenance associations with the `ma index name` command.
3. Configure the local maintenance end points (MEPs) which will serve as the domain service access points for the specified maintenance association using the `ethernet cfm mep` command.

4. Enter a static list of MEPs assigned to other devices within the same maintenance association using the `mep crosscheck mpid` command. This allows CFM to automatically verify the functionality of these remote end points by cross-checking the static list configured on this device against information learned through continuity check messages.
5. Enable CFM globally on the switch with the `ethernet cfm enable` command.
6. Enable CFM on the local MEPs with the `ethernet cfm port-enable` command.
7. Enable continuity check operations with the `ethernet cfm cc enable` command.
8. Enable cross-check operations with the `ethernet cfm mep crosscheck` command.

Other configuration changes may be required for your particular environment, such as adjusting the interval at which continuity check messages are sent (page 857), or setting the start-up delay for the cross-check operation (page 863). You can also enable SNMP traps for events discovered by continuity check messages (page 859) or cross-check messages (page 863).

## Defining CFM Structures

**ethernet cfm ais level** This command configures the maintenance level at which Alarm Indication Signal (AIS) information will be sent within the specified MA. Use the **no** form to restore the default setting.

### Syntax

**ethernet cfm ais level** *level-id* **md** *domain-name* **ma** *ma-name*

**no ethernet cfm ais level md** *domain-name* **ma** *ma-name*

*level-id* – Maintenance level at which AIS information will be sent.  
(Range: 0-7)

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

### Default Setting

Level 0

### Command Mode

Global Configuration

### Command Usage

The configured AIS level must be higher than the maintenance level of the domain containing the specified MA.

### Example

This example sets the maintenance level for sending AIS messages within the specified MA.

```

Console(config)#ethernet cfm ais level 4 md voip ma rd
Console(config)#

```

**ethernet cfm ais ma** This command enables the MEPs within the specified MA to send frames with AIS information following detection of defect conditions. Use the **no** form to disable this feature.

### Syntax

**[no] ethernet cfm ais md** *domain-name* **ma** *ma-name*

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name<sup>16</sup>. (Range: 1-43 alphanumeric characters)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Each MA name must be unique within the CFM domain.
- ◆ Frames with AIS information can be issued at the client's maintenance level by a MEP upon detecting defect conditions. For example, defect conditions may include:
  - Signal failure conditions if continuity checks are enabled.
  - AIS condition or LCK condition if continuity checks are disabled.
- ◆ A MEP continues to transmit periodic frames with AIS information until the defect condition is removed.

### Example

This example enables the MEPs within the specified MA to send frames with AIS information.

```

Console(config)#ethernet cfm ais md voip ma rd
Console(config)#

```

16. The total length of the MD name and MA name cannot exceed 44 characters.

**ethernet cfm ais period** This command configures the interval at which AIS information is sent. Use the **no** form to restore the default setting.

#### Syntax

**ethernet cfm ais period** *period* **md** *domain-name* **ma** *ma-name*

**no ethernet cfm ais period md** *domain-name* **ma** *ma-name*

*period* – The interval at which AIS information is sent.  
(Options: 1 second, 60 seconds)

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

#### Default Setting

1 second

#### Command Mode

Global Configuration

#### Example

This example sets the interval for sending frames with AIS information at 60 seconds.

```
Console(config)#ethernet cfm ais period 60 md voip ma rd
Console(config)#
```

**ethernet cfm ais suppress alarm** This command suppresses sending frames containing AIS information following the detection of defect conditions. Use the **no** form to restore the default setting.

#### Syntax

**[no] ethernet cfm ais suppress alarm md** *domain-name* **ma** *ma-name*

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

#### Default Setting

Suppression is disabled

#### Command Mode

Global Configuration

#### Command Usage

- ◆ For multipoint connectivity, a MEP cannot determine the specific maintenance level entity that has encountered defect conditions upon receiving a frame

with AIS information. More importantly, it cannot determine the associated subset of its peer MEPs for which it should suppress alarms since the received AIS information does not contain that information. Therefore, upon reception of a frame with AIS information, the MEP will suppress alarms for all peer MEPs whether there is still connectivity or not.

- ◆ However, for a point-to-point connection, a MEP has only a single peer MEP for which to suppress alarms when it receives frames with AIS information.
- ◆ If suppression is enabled by this command, upon receiving a frame with AIS information, a MEP detects an AIS condition and suppresses loss of continuity alarms associated with all its peer MEPs. A MEP resumes loss of continuity alarm generation upon detecting loss of continuity defect conditions in the absence of AIS messages.

### Example

This example suppresses sending frames with AIS information.

```
Console(config)#ethernet cfm ais suppress alarm md voip ma rd
Console(config)#
```

**ethernet cfm domain** This command defines a CFM maintenance domain, sets the authorized maintenance level, and enters CFM configuration mode. Use the **no** form to delete a CFM maintenance domain.

### Syntax

**ethernet cfm domain index** *index* **name** *domain-name* **level** *level-id*  
[**mip-creation** *type*]

**no ethernet cfm domain index** *index*

*index* – Domain index. (Range: 1-65535)

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*level-id* – Authorized maintenance level for this domain. (Range: 0-7)

*type* – Specifies the CFM protocol's creation method for maintenance intermediate points (MIPs) in this domain:

**default** – MIPs can be created for any maintenance association (MA) configured in this domain on any bridge port through which the MA's VID can pass.

**explicit** – MIPs can be created for any MA configured in this domain only on bridge ports through which the MA's VID can pass, and only if a maintenance end point (MEP) is created at some lower MA Level.

**none** – No MIP can be created for any MA configured in this domain.

**Default Setting**

No maintenance domains are configured.  
No MIPs are created for any MA in the specified domain.

**Command Mode**

Global Configuration

**Command Usage**

- ◆ A domain can only be configured with one name.
- ◆ Where domains are nested, an upper-level hierarchical domain must have a higher maintenance level than the ones it encompasses. The higher to lower level domain types commonly include entities such as customer, service provider, and operator.
- ◆ More than one domain can be configured at the same maintenance level, but a single domain can only be configured with one maintenance level.
- ◆ If MEPs or MAs are configured for a domain using the `ethernet cfm mep` command or `ma index name` command, they must first be removed before you can remove the domain.
- ◆ Maintenance domains are designed to provide a transparent method of verifying and resolving connectivity problems for end-to-end connections. By default, these connections run between the domain service access points (DSAPs) within each MA defined for a domain, and are manually configured using the `ethernet cfm mep` command.

In contrast, MIPs are interconnection points that make up all possible paths between the DSAPs within an MA. MIPs are automatically generated by the CFM protocol when the `mip-creation` option in this command is set to “default” or “explicit,” and the MIP creation state machine is invoked (as defined in IEEE 802.1ag). The default option allows MIPs to be created for all interconnection points within an MA, regardless of the domain’s level in the maintenance hierarchy (e.g., customer, provider, or operator). While the explicit option only generates MIPs within an MA if its associated domain is not at the bottom of the maintenance hierarchy. This option is used to hide the structure of network at the lowest domain level.

The diagnostic functions provided by CFM can be used to detect connectivity failures between any pair of MEPs in an MA. Using MIPs allows these failures to be isolated to smaller segments of the network.

Allowing the CFM to generate MIPs exposes more of the network structure to users at higher domain levels, but can speed up the process of fault detection and recovery. This trade-off should be carefully considered when designing a CFM maintenance structure.

Also note that while MEPs are active agents which can initiate consistency check messages (CCMs), transmit loop back or link trace messages, and maintain the local CCM database. MIPs, on the other hand are passive agents

which can only validate received CFM messages, and respond to loop back and link trace messages.

The MIP creation method defined by the `ma index name` command takes precedence over the method defined by this command.

### Example

This example creates a maintenance domain set to maintenance level 3, and enters CFM configuration mode for this domain.

```
Console(config)#ethernet cfm domain index 1 name voip level 3 mip-creation
explicit
Console(config-ether-cfm)#
```

### Related Commands

[ma index name \(846\)](#)

**ethernet cfm enable** This command enables CFM processing globally on the switch. Use the **no** form to disable CFM processing globally.

### Syntax

**[no] ethernet cfm enable**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Command Usage

- ◆ To avoid generating an excessive number of traps, the complete CFM maintenance structure and process parameters should be configured prior to globally enabling CFM processing with this command. Specifically, the maintenance domains, maintenance associations, and MEPs should be configured on each participating bridge.
- ◆ When CFM is enabled, hardware resources are allocated for CFM processing.

### Example

This example enables CFM globally on the switch.

```
Console(config)#ethernet cfm enable
Console(config)#
```

**ma index name** This command creates a maintenance association (MA) within the current maintenance domain, maps it to a customer service instance (S-VLAN), and sets the manner in which MIPs are created for this service instance. Use the **no** form with the **vlan** keyword to remove the S-VLAN from the specified MA. Or use the **no** form with only the **index** keyword to remove the MA from the current domain.

### Syntax

**ma index** *index name* *ma-name* [**vlan** *vlan-list* [**mip-creation** *type*]]

**no ma index** *index* [**vlan** *vlan-list*]

*index* – MA identifier. (Range: 1-2147483647)

*ma-name* – MA name. (Range: 1-43 alphanumeric characters)

*vlan-list* - Separate nonconsecutive VLAN identifiers with a comma and no spaces; use a hyphen to designate a range of IDs. (Range: 1-4094).

*type* – Specifies the CFM protocol's creation method for maintenance intermediate points (MIPs) in this MA:

**default** – MIPs can be created for this MA on any bridge port through which the MA's VID can pass.

**explicit** – MIPs can be created this MA only on bridge ports through which the MA's VID can pass, and only if a maintenance end point (MEP) is created at some lower MA Level.

**none** – No MIP can be created for this MA.

### Default Setting

None

### Command Mode

CFM Domain Configuration

### Command Usage

- ◆ The maintenance domain used to enter CFM domain configuration mode, the MA name and VLAN identifier specified by this command, and the DSAPs configured with the [mep crosscheck mpid](#) command create a unique service instance for each customer.
- ◆ If only the MA index and name are entered for this command, the MA will be recorded in the domain database, but will not function. No MEPs can be created until the MA is associated with a service VLAN.
- ◆ Note that multiple domains at the same maintenance level (see the [ethernet cfm domain](#) command) cannot have an MA on the same VLAN. Also, each MA name must be unique within the CFM-managed network.
- ◆ The first VLAN entered in the list by this command is the primary VLAN, and is the VLAN on which all CFM functions are executed.

- ◆ Before removing an MA, first remove all the MEPs configured for it (see the [mep crosscheck mpid](#) command).
- ◆ If the MIP creation method is not defined by this command, the creation method defined by the [ethernet cfm domain](#) command is applied to this MA. For a detailed description of the MIP types, refer to the Command Usage section under the [ethernet cfm domain](#) command.

### Example

This example creates a maintenance association, binds it to VLAN 1, and allows MIPs to be created within this MA using the default method.

```
Console(config)#ethernet cfm domain index 1 name voip level 3
Console(config-ether-cfm)#ma index 1 name rd vlan 1 mip-creation default
Console(config-ether-cfm)#
```

**ma index name-format** This command specifies the name format for the maintenance association as IEEE 802.1ag character based, or ITU-T SG13/SG15 Y.1731 defined ICC-based format. Use the **no** form to restore the default setting.

### Syntax

**ma index** *index* **name-format** {**character-string** | **icc-based**}

**no ma index** *index* **name-format**

*index* – MA identifier. (Range: 1-2147483647)

**character-string** – IEEE 802.1ag defined character string format. This is an IETF RFC 2579 DisplayString.

**icc-based** – ITU-T SG13/SG15 Y.1731 defined ICC based format.

### Default Setting

character-string

### Command Mode

CFM Domain Configuration

### Example

This example specifies the name format as character string.

```
Console(config)#ethernet cfm domain index 1 name voip level 3
Console(config-ether-cfm)#ma index 1 name-format character-string
Console(config-ether-cfm)#
```

**ethernet cfm mep** This command sets an interface as a domain boundary, defines it as a maintenance end point (MEP), and sets direction of the MEP in regard to sending and receiving CFM messages. Use the **no** form to delete a MEP.

### Syntax

**ethernet cfm mep mpid** *mpid* **md** *domain-name* **ma** *ma-name* [**up**]

**no ethernet cfm mep mpid** *mpid* **ma** *ma-name*

*mpid* – Maintenance end point identifier. (Range: 1-8191)

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

**up** – Indicates that the MEP faces inward toward the switch cross-connect matrix, and transmits CFM messages towards, and receives them from, the direction of the internal bridge relay mechanism. If the **up** keyword is not included in this command, then the MEP is facing away from the switch, and transmits CFM messages towards, and receives them from, the direction of the physical medium.

### Default Setting

No MEPs are configured.  
The MEP faces outward (down).

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ CFM elements must be configured in the following order: (1) maintenance domain at the same level as the MEP to be configured (using the [ethernet cfm domain](#) command), (2) maintenance association within the domain (using the [ma index name](#) command), and (3) finally the MEP using this command.
- ◆ An interface may belong to more than one domain. This command can be used to configure an interface as a MEP for different MAs in different domains.
- ◆ To change the MEP's MA or the direction it faces, first delete the MEP, and then create a new one.

### Example

This example sets port 1 as a DSAP for the specified maintenance association.

```
Console(config)#interface ethernet 1/1
Console(config-if)#ethernet cfm mep mpid 1 md voip ma rd
Console(config-if)#
```

**ethernet cfm port-enable** This command enables CFM processing on an interface. Use the **no** form to disable CFM processing on an interface.

### Syntax

**[no] ethernet cfm port-enable**

### Default Setting

Enabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ An interface must be enabled before a MEP can be created with the [ethernet cfm mep](#) command.
- ◆ If a MEP has been configured on an interface with the [ethernet cfm mep](#) command, it must first be deleted before CFM can be disabled on that interface.
- ◆ When CFM is disabled, hardware resources previously used for CFM processing on that interface are released, and all CFM frames entering that interface are forwarded as normal data traffic.

### Example

This example enables CFM on port 1.

```
Console(config)#interface ethernet 1/1
Console(config-if)#ethernet cfm port-enable
Console(config-if)#
```

**clear ethernet cfm ais mpid** This command clears AIS defect information for the specified MEP.

### Syntax

**clear ethernet cfm ais mpid *mpid* *md* *domain-name* *ma* *ma-name***

*mpid* – Maintenance end point identifier. (Range: 1-8191)

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

This command can be used to clear AIS defect entries if a MEP does not exit the AIS state when all errors are resolved.

### Example

This example clears AIS defect entries on port 1.

```
Console#clear ethernet cfm ais mpid 1 md voip ma rd
Console#
```

**show ethernet cfm configuration** This command displays CFM configuration settings, including global settings, SNMP traps, and interface settings.

### Syntax

**show ethernet cfm configuration** {**global** | **traps** | **interface** *interface*}

**global** – Displays global settings including CFM global status, cross-check start delay, and link trace parameters.

**traps** – Displays the status of all continuity check and cross-check traps.

*interface* – Displays CFM status for the specified interface.

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

This example shows the global settings for CFM.

```
Console#show ethernet cfm configuration global
CFM Global Status      : Enabled
Crosscheck Start Delay : 10 seconds
Linktrace Cache Status : Enabled
Linktrace Cache Hold Time : 100 minutes
Linktrace Cache Size   : 100 entries
Console#
```

This example shows the configuration status for continuity check and cross-check traps.

```

Console#show ethernet cfm configuration traps
CC MEP Up Trap           :Disabled
CC MEP Down Trap        :Disabled
CC Configure Trap       :Disabled
CC Loop Trap            :Disabled
Cross Check MEP Unknown Trap :Disabled
Cross Check MEP Missing Trap :Disabled
Cross Check MA Up       :Disabled
Console#

```

**Table 172: show ethernet cfm configuration traps - display description**

Field	Description
CC MEP Up Trap	Sends a trap if a remote MEP is discovered and added to the local database, the port state of a previously discovered remote MEP changes, or a CCM is received from a remote MEP which as an expired entry in the archived database.
CC Mep Down Trap	Sends a trap if this device loses connectivity with a remote MEP, or connectivity has been restored to a remote MEP which has recovered from an error condition.
CC Configure Trap	Sends a trap if this device receives a CCM with the same MPID as its own but with a different source MAC address, indicating that a CFM configuration error exists.
CC Loop Trap	Sends a trap if this device receives a CCM with the same source MAC address and MPID as its own, indicating that a forwarding loop exists.
Cross Check MEP Unknown Trap	A CCM is received from a MEP that has not been configured as a DSAP (see the <a href="#">ethernet cfm mep</a> command), manually configured as a remote MEP (see the <a href="#">mep crosscheck mpid</a> command), nor learned through previous CCM messages.
Cross Check MEP Missing Trap	This device failed to receive three consecutive CCMs from another MEP in the same MA.
Cross Check MA Up	Generates a trap when all remote MEPs belonging to an MA come up.

This example shows the CFM status for port 1.

```

Console#show ethernet cfm configuration interface ethernet 1/1
Ethernet 1/1 CFM Status:Enabled
Console#

```

**show ethernet cfm md** This command displays the configured maintenance domains.

### Syntax

**show ethernet cfm md** [**level** *level*]

*level* – Maintenance level. (Range: 0-7)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

This example shows all configured maintenance domains.

```

Console#show ethernet cfm md
MD Index  MD Name          Level  MIP Creation  Archive Hold Time (m.)
-----
          1 rd              0  default              100
Console#

```

**show ethernet cfm ma** This command displays the configured maintenance associations.

### Syntax

**show ethernet cfm ma** [**level** *level*]

*level* – Maintenance level. (Range: 0-7)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

For a description of the values displayed in the CC Interval field, refer to the [ethernet cfm cc ma interval](#) command.

### Example

This example shows all configured maintenance associations.

```

Console#show ethernet cfm ma
MD Name      MA Index MA Name      Primary VID  CC Interval MIP Creation
-----
steve                1 voip              1              4 Default
Console#

```

**show ethernet cfm maintenance-points local** This command displays the maintenance points configured on this device.

#### Syntax

#### **show ethernet cfm maintenance-points local**

```
{mep [domain domain-name | interface interface | level level-id] | mip
[domain domain-name | level level-id]}
```

**mep** – Displays only local maintenance end points.

**mip** – Displays only local maintenance intermediate points.

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*interface* – Displays CFM status for the specified interface.

#### **ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### **port-channel** *channel-id* (Range: 1-28)

*level-id* – Maintenance level for this domain. (Range: 0-7)

#### Default Setting

None

#### Command Mode

Privileged Exec

#### Command Usage

- ◆ Use the **mep** keyword with this command to display the MEPs configured on this device as DSAPs through the [ethernet cfm mep](#) command.
- ◆ Using the **mip** keyword with this command to display the MIPs generated on this device by the CFM protocol when the mip-creation method is set to either "default" or "explicit" by the [ethernet cfm domain](#) command or the [ma index name](#) command.

#### Example

This example shows all MEPs configured on this device for maintenance domain rd.

```
Console#show ethernet cfm maintenance-points local mep
MPID MD Name          Level Direct VLAN Port      CC Status MAC Address
-----
  1 rd                0 UP          1 Eth 1/ 1 Enabled 00-12-CF-3A-A8-C0
Console#
```

**show ethernet cfm maintenance-points local detail mep** This command displays detailed CFM information about a local MEP in the continuity check database.

#### Syntax

##### **show ethernet cfm maintenance-points local detail mep**

**[domain *domain-name* | interface *interface* | level *level-id*]**

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*interface* – Displays CFM status for the specified interface.

##### **ethernet *unit/port***

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

##### **port-channel *channel-id*** (Range: 1-28)

*level-id* – Maintenance level for this domain. (Range: 0-7)

#### Default Setting

None

#### Command Mode

Privileged Exec

#### Example

This example shows detailed information about the local MEP on port 1.

```

Console#show ethernet cfm maintenance-points local detail mep interface
 ethernet 1/1
MEP Settings:
-----
MPID                : 1
MD Name             : vopu
MA Name             : r&d
MA Name Format       : Character String
Level               : 0
Direction           : Up
Interface           : Eth 1/ 1
CC Status           : Enabled
MAC Address         : 00-E0-0C-00-00-FD
Defect Condition    : No Defect
Received RDI        : False
AIS Status          : Enabled
AIS Period          : 1 seconds
AIS Transmit Level  : Default
Suppress Alarm      : Disabled
Suppressing Alarms  : Disabled

Console#

```

**Table 173: show ethernet cfm maintenance-points local detail mep - display**

Field	Description
MPID	MEP identifier
MD Name	The maintenance domain for this entry.
MA Name	Maintenance association to which this remote MEP belongs
MA Name Format	The format of the Maintenance Association name, including primary VID, character string, unsigned Integer 16, or RFC 2865 VPN ID
Level	Maintenance level of the local maintenance point
Direction	The direction in which the MEP faces on the Bridge port (up or down).
Interface	The port to which this MEP is attached.
CC Status	Shows if the MEP will generate CCM messages.
MAC Address	MAC address of the local maintenance point. (If a CCM for the specified remote MEP has never been received or the local MEP record times out, the address will be set to the initial value of all Fs.)
Defect Condition	Shows the defect detected on the MEP.
Received RDI	Receive status of remote defect indication (RDI) messages on the MEP.
AIS Status	Shows if MEPs within the specified MA are enabled to send frames with AIS information following detection of defect conditions.
AIS Period	The interval at which AIS information is sent.
AIS Transmit Level	The maintenance level at which AIS information will be sent for the specified MEP.
Suppress Alarm	Shows if the specified MEP is configured to suppress sending frames containing AIS information following the detection of defect conditions.
Suppressing Alarms	Shows if the specified MEP is currently suppressing sending frames containing AIS information following the detection of defect conditions.

### show ethernet cfm maintenance-points remote detail

This command displays detailed CFM information about a remote MEP in the continuity check database.

#### Syntax

##### show ethernet cfm maintenance-points remote detail

```
{mac mac-address | mpid mpid}  
[domain domain-name | level level-id]
```

*mac-address* – MAC address of a remote maintenance point.  
This address can be entered in either of the following formats: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx

*mpid* – Maintenance end point identifier. (Range: 1-8191)

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*level-id* – Authorized maintenance level for this domain. (Range: 0-7)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Use the **mpid** keyword with this command to display information about a specific maintenance point, or use the **mac** keyword to display information about all maintenance points that have the specified MAC address.

### Example

This example shows detailed information about the remote MEP designated by MPID 2.

```

Console#show ethernet cfm maintenance-points remote detail mpid 2
MAC Address           : 00-0D-54-FC-A2-73
Domain/Level          : voip / 3
MA Name               : rd
Primary VLAN          : 1
MPID                  : 2
Incoming Port         : Eth 1/ 2
CC Lifetime           : 645 seconds
Age of Last CC Message : 2 seconds
Frame Loss            : 137
CC Packet Statistics  : 647/1
Port State            : Up
Interface State       : Up
Crosscheck Status     : Enabled

Console#

```

**Table 174: show ethernet cfm maintenance-points remote detail - display**

Field	Description
MAC Address	MAC address of the remote maintenance point. (If a CCM for the specified remote MEP has never been received or the remote MEP record times out, the address will be set to the initial value of all Fs.)
Domain/Level	Maintenance domain and level of the remote maintenance point
MA Name	Maintenance association to which this remote MEP belongs
Primary VLAN	VLAN to which this MEP belongs
MPID	MEP identifier
Incoming Port	Port to which this remote MEP is attached.
CC Lifetime	Length of time to hold messages about this MEP in the CCM database
Age of Last CC Message	Length of time the last CCM message about this MEP has been in the CCM database
Frame Loss	Percentage of transmitted frames lost
CC Packet Statistics (received/error)	The number of CCM packets received successfully and those with errors

**Table 174: show ethernet cfm maintenance-points remote detail - display**

Field	Description
Port State	Port states include: Up – The port is functioning normally. Blocked – The port has been blocked by the Spanning Tree Protocol. No port state – Either no CCM has been received, or no port status TLV was received in the last CCM.
Interface State	Interface states include: No Status – Either no CCM has been received, or no interface status TLV was received in the last CCM. Up – The interface is ready to pass packets. Down – The interface cannot pass packets. Testing – The interface is in some test mode. Unknown – The interface status cannot be determined for some reason. Dormant – The interface is not in a state to pass packets but is in a pending state, waiting for some external event. Not Present – Some component of the interface is missing. isLowerLayerDown – The interface is down due to state of the lower layer interfaces.
Crosscheck Status	Shows if crosscheck function has been enabled.

## Continuity Check Operations

**ethernet cfm cc ma interval** This command sets the transmission delay between continuity check messages (CCMs). Use the **no** form to restore the default settings.

### Syntax

**ethernet cfm cc md** *domain-name* **ma** *ma-name* **interval** *interval-level*

**no ethernet cfm cc ma** *ma-name* **interval**

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

*interval-level* – The transmission delay between connectivity check messages. The setting for this parameter is expressed as levels 4 through 7, which in turn map to specific intervals of time. (CCM interval field options: 4 - 1 second, 5 - 10 seconds, 6 - 1 minute, 7 - 10 minutes)

### Default Setting

4 (1 second)

### Command Mode

Global Configuration

### Command Usage

- ◆ CCMs provide a means to discover other MEPs and to detect connectivity failures in an MA. If any MEP fails to receive three consecutive CCMs from any other MEPs in its MA, a connectivity failure is registered. The interval at which

CCMs are issued should therefore be configured to detect connectivity problems in a timely manner, as dictated by the nature and size of the MA.

- ◆ The maintenance of a MIP CCM database by a MIP presents some difficulty for bridges carrying a large number of Service Instances, and for whose MEPs are issuing CCMs at a high frequency. For this reason, slower CCM transmission rates may have to be used.

### Example

This example sets the transmission delay for continuity check messages to level 7 (60 seconds).

```
Console(config)#ethernet cfm cc md voip ma rd interval 7
Console(config)#
```

### Related Commands

[ethernet cfm cc enable \(858\)](#)

**ethernet cfm cc enable** This command enables the transmission of continuity check messages (CCMs) within a specified maintenance association. Use the **no** form to disable the transmission of these messages.

### Syntax

**[no] ethernet cfm cc enable md** *domain-name* **ma** *ma-name*

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

### Default Setting

Enabled

### Command Mode

Global Configuration

### Command Usage

- ◆ CCMs are multicast periodically by a MEP in order to discover other MEPs in the same MA, and to assure connectivity to all other MEPs/MIPs in the MA.
- ◆ Each CCM received is checked to verify that the MEP identifier field sent in the message does not match its own MEPID, which would indicate a duplicate MEP or network loop. If these error types are not found, the CCM is stored in the MEP's local database until aged out.
- ◆ If a maintenance point fails to receive three consecutive CCMs from any other MEP in the same MA, a connectivity failure is registered.

- ◆ If a maintenance point receives a CCM with an invalid MEPID or MA level or an MA level lower than its own, a failure is registered which indicates a configuration error or cross-connect error (i.e., overlapping MAs).

### Example

This example enables continuity check messages for the specified maintenance association.

```
Console(config)#ethernet cfm cc enable md voip ma rd
Console(config)#
```

**snmp-server enable traps ethernet cfm cc** This command enables SNMP traps for CFM continuity check events. Use the **no** form to disable these traps.

### Syntax

**[no] snmp-server enable traps ethernet cfm cc [config | loop | mep-down | mep-up]**

**config** – Sends a trap if this device receives a CCM with the same MPID as its own but with a different source MAC address, indicating that a CFM configuration error exists.

**loop** – Sends a trap if this device receives a CCM with the same source MAC address and MPID as its own, indicating that a forwarding loop exists.

**mep-down** – Sends a trap if this device loses connectivity with a remote MEP, or connectivity has been restored to a remote MEP which has recovered from an error condition.

**mep-up** – Sends a trap if a remote MEP is discovered and added to the local database, the port state of a previously discovered remote MEP changes, or a CCM is received from a remote MEP which has an expired entry in the archived database.

### Default Setting

All continuity checks are disabled.

### Command Mode

Global Configuration

### Command Usage

All mep-up traps are suppressed when cross-checking of MEPs is enabled because cross-check traps include more detailed status information.

**Example**

This example enables SNMP traps for mep-up events.

```
Console(config)#snmp-server enable traps ethernet cfm cc mep-up
Console(config)#
```

**Related Commands**

[ethernet cfm mep crosscheck \(865\)](#)

**mep archive-hold-time** This command sets the time that data from a missing MEP is retained in the continuity check message (CCM) database before being purged. Use the **no** form to restore the default setting.

**Syntax**

**mep archive-hold-time** *hold-time*

*hold-time* – The time to retain data for a missing MEP.  
(Range: 1-65535 minutes)

**Default Setting**

100 minutes

**Command Mode**

CFM Domain Configuration

**Command Usage**

A change to the hold time only applies to entries stored in the database after this command is entered.

**Example**

This example sets the aging time for missing MEPs in the CCM database to 30 minutes.

```
Console(config)#ethernet cfm domain index 1 name voip level 3
Console(config-ether-cfm)#mep archive-hold-time 30
Console(config-ether-cfm)#
```

**clear ethernet cfm maintenance-points remote** This command clears the contents of the continuity check database.

**Syntax**

**clear ethernet cfm maintenance-points remote** [**domain** *domain-name* | **level** *level-id*]

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*level-id* – Maintenance level. (Range: 0-7)

**Default Setting**

None

**Command Mode**

Privileged Exec

**Command Usage**

Use this command without any keywords to clear all entries in the CCM database. Use the **domain** keyword to clear the CCM database for a specific domain, or the **level** keyword to clear it for a specific maintenance level.

**Example**

```
Console#clear ethernet cfm maintenance-points remote domain voip
Console#
```

**clear ethernet cfm errors** This command clears continuity check errors logged for the specified maintenance domain or maintenance level.

**Syntax**

**clear ethernet cfm errors** [**domain** *domain-name* | **level** *level-id*]

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*level-id* – Maintenance level. (Range: 0-7)

**Default Setting**

None

**Command Mode**

Privileged Exec

**Command Usage**

Use this command without any keywords to clear all entries in the error database. Use the **domain** keyword to clear the error database for a specific domain, or the **level** keyword to clear it for a specific maintenance level.

**Example**

```
Console#clear ethernet cfm errors domain voip
Console#
```

**show ethernet cfm errors** This command displays the CFM continuity check errors logged on this device.

### Syntax

**show ethernet cfm errors** [**domain** *domain-name* | **level** *level-id*]

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*level-id* – Authorized maintenance level for this domain. (Range: 0-7)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

```

Console#show ethernet cfm errors
Level VLAN MPID Interface Remote MAC          Reason          MA Name
-----
5      2      40 Eth 1/1  ab.2f.9c.00.05.01 LEAK             provider_1_2
Console#

```

**Table 175: show ethernet cfm errors - display description**

Field	Description
Level	Maintenance level associated with this entry.
VLAN	VLAN in which this error occurred.
MPID	Identifier of remote MEP.
Interface	Port at which the error was recorded
Remote MAC	MAC address of remote MEP.
Reason	<p>Error types include:</p> <p>LEAK – MA <i>x</i> is associated with a specific VID list*, one or more of the VIDs in this MA can pass through the bridge port, no MEP is configured facing outward (down) on any bridge port for this MA, and some other MA <i>y</i>, at a higher maintenance level, and associated with at least one of the VID(s) also in MA <i>x</i>, does have a MEP configured on the bridge port.</p> <p>VIDS – MA <i>x</i> is associated with a specific VID list* on this MA on the bridge port, and some other MA <i>y</i>, associated with at least one of the VID(s) also in MA <i>x</i>, also has an Up MEP configured facing inward (up) on some bridge port.</p> <p>EXCESS_LEV – The number of different MD levels at which MIPs are to be created on this port exceeds the bridge's capabilities.</p> <p>OVERLAP_LEV – A MEP is created for one VID at one maintenance level, but a MEP is configured on another VID at an equivalent or higher level, exceeding the bridge's capabilities.</p>
MA	The maintenance association for this entry.

\* This definition is based on the IEEE 802.1ag standard. Current software for this switch only supports a single VLAN per MA. However, since it may interact with other devices which support multiple VLAN assignments per MA, this error message may be reported.

## Cross Check Operations

**ethernet cfm mep crosscheck start-delay** This command sets the maximum delay that a device waits for remote MEPs to come up before starting the cross-check operation. Use the **no** form to restore the default setting.

### Syntax

**ethernet cfm mep crosscheck start-delay** *delay*

**no ethernet cfm mep crosscheck start-delay**

*delay* – The time a device waits for remote MEPs to come up before the cross-check is started. (Range: 1-65535 seconds)

### Default Setting

10 seconds

### Command Mode

Global Configuration

### Command Usage

- ◆ This command sets the delay that a device waits for a remote MEP to come up, and it starts cross-checking the list of statically configured remote MEPs in the local maintenance domain against the MEPs learned through CCMs.
- ◆ The cross-check start delay should be configured to a value greater than or equal to the continuity check message interval to avoid generating unnecessary traps.

### Example

This example sets the maximum delay before starting the cross-check process.

```
Console(config)#ethernet cfm mep crosscheck start-delay 60
Console(config)#
```

**snmp-server enable traps ethernet cfm crosscheck** This command enables SNMP traps for CFM continuity check events, in relation to the cross-check operations between statically configured MEPs and those learned via continuity check messages (CCMs). Use the **no** form to restore disable these traps.

### Syntax

**[no] snmp-server enable traps ethernet cfm crosscheck [ma-up | mep-missing | mep-unknown]**

**ma-up** – Sends a trap when all remote MEPs in an MA come up.

**mep-missing** – Sends a trap if the cross-check timer expires and no CCMs have been received from a remote MEP configured in the static list.

**mep-unknown** – Sends a trap if an unconfigured MEP comes up.

#### Default Setting

All continuity checks are enabled.

#### Command Mode

Global Configuration

#### Command Usage

- ◆ For this trap type to function, cross-checking must be enabled on the required maintenance associations using the `ethernet cfm mep crosscheck` command.
- ◆ A mep-missing trap is sent if cross-checking is enabled (with the `ethernet cfm mep crosscheck` command), and no CCM is received for a remote MEP configured in the static list (with the `mep crosscheck mpid` command).
- ◆ A mep-unknown trap is sent if cross-checking is enabled, and a CCM is received from a remote MEP that is not configured in the static list.
- ◆ A ma-up trap is sent if cross-checking is enabled, and a CCM is received from all remote MEPs configured in the static list for this maintenance association.

#### Example

This example enables SNMP traps for mep-unknown events detected in cross-check operations.

```
Console(config)#snmp-server enable traps ethernet cfm crosscheck mep-unknown
Console(config)#
```

**mep crosscheck mpid** This command statically defines a remote MEP in a maintenance association. Use the **no** form to remove a remote MEP.

#### Syntax

**[no] mep crosscheck mpid mpid ma ma-name**

*mpid* – Identifier for a maintenance end point which exists on another CFM-enabled device within the same MA. (Range: 1-8191)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

#### Default Setting

No remote MEPs are configured.

#### Command Mode

CFM Domain Configuration

### Command Usage

- ◆ Use this command to statically configure remote MEPs that exist inside the maintenance association. These remote MEPs are used in the cross-check operation to verify that all endpoints in the specified MA are operational.
- ◆ Remote MEPs can only be configured with this command if domain service access points (DSAPs) have already been created with the [ethernet cfm mep](#) command at the same maintenance level and in the same MA. DSAPs are MEPs that exist on the edge of the domain, and act as primary service access points for end-to-end cross-check, loop-back, and link-trace functions.

### Example

This example defines a static MEP for the specified maintenance association.

```
Console(config)#ethernet cfm domain index 1 name voip level 3
Console(config-ether-cfm)#ma index 1 name rd vlan 1
Console(config-ether-cfm)#mep crosscheck mpid 2 ma rd
Console(config-ether-cfm)#
```

**ethernet cfm mep crosscheck** This command enables cross-checking between the static list of MEPs assigned to other devices within the same maintenance association and the MEPs learned through continuity check messages (CCMs). Use the **disable** keyword to stop the cross-check process.

### Syntax

**ethernet cfm mep crosscheck** {**enable** | **disable**} **md** *domain-name*  
**ma** *ma-name*

**enable** – Starts the cross-check process.

**disable** – Stops the cross-check process.

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – MA name. (Range: 1-43 alphanumeric characters)

### Default Setting

Enabled

### Command Mode

Privileged Exec

### Command Usage

- ◆ Before using this command to start the cross-check process, first configure the remote MEPs that exist on other devices inside the maintenance association using the [mep crosscheck mpid](#) command. These remote MEPs are used in the cross-check operation to verify that all endpoints in the specified MA are operational.

- ◆ The cross-check process is disabled by default, and must be manually started using this command with the **enable** keyword.

### Example

This example enables cross-checking within the specified maintenance association.

```
Console#ethernet cfm mep crosscheck enable md voip ma rd
Console#
```

### show ethernet cfm maintenance-points remote crosscheck

This command displays information about remote MEPs statically configured in a cross-check list.

### Syntax

#### show ethernet cfm maintenance-points remote crosscheck

[**domain** *domain-name* | **mpid** *mpid*]

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*mpid* – Maintenance end point identifier. (Range: 1-8191)

### Default Setting

None

### Command Mode

Privileged Exec

### Example

This example shows all remote MEPs statically configured on this device.

```
Console#show ethernet cfm maintenance-points remote crosscheck
MPID  MA Name                Level  VLAN  MEP Up  Remote MAC
-----
    2  downtown                4      2    Yes    00-0D-54-FC-A2-73
Console#
```

## Link Trace Operations

### ethernet cfm linktrace cache

This command enables caching of CFM data learned through link trace messages. Use the **no** form to disable caching.

### Syntax

[**no**] **ethernet cfm linktrace cache**

### Default Setting

Enabled

### Command Mode

Global Configuration

### Command Usage

- ◆ A link trace message is a multicast CFM frame initiated by a MEP, and forwarded from MIP to MIP, with each MIP generating a link trace reply, up to the point at which the link trace message reaches its destination or can no longer be forwarded.
- ◆ Use this command to enable the link trace cache to store the results of link trace operations initiated on this device. Use the [ethernet cfm linktrace](#) command to transmit a link trace message.
- ◆ Link trace responses are returned from each MIP along the path and from the target MEP. Information stored in the cache includes the maintenance domain name, MA name, MEPID, sequence number, and TTL value.

### Example

This example enables link trace caching.

```

Console(config)#ethernet cfm linktrace cache
Console(config)#

```

**ethernet cfm linktrace cache hold-time** This command sets the hold time for CFM link trace cache entries. Use the **no** form to restore the default setting.

### Syntax

**ethernet cfm linktrace cache hold-time** *minutes*

**no ethernet cfm linktrace cache hold-time**

*minutes* – The aging time for entries stored in the link trace cache.  
(Range: 1-65535 minutes)

### Default Setting

100 minutes

### Command Mode

Global Configuration

### Command Usage

Before setting the aging time for cache entries, the cache must first be enabled with the [ethernet cfm linktrace cache](#) command.

**Example**

This example sets the aging time for entries in the link trace cache to 60 minutes.

```
Console(config)#ethernet cfm linktrace cache hold-time 60
Console(config)#
```

**ethernet cfm linktrace cache size** This command sets the maximum size for the link trace cache. Use the **no** form to restore the default setting.

**Syntax**

**ethernet cfm linktrace cache size** *entries*

**no ethernet cfm linktrace cache size**

*entries* – The number of link trace responses stored in the link trace cache.  
(Range: 1-4095 entries)

**Default Setting**

100 entries

**Command Mode**

Global Configuration

**Command Usage**

- ◆ Before setting the cache size, the cache must first be enabled with the [ethernet cfm linktrace cache](#) command.
- ◆ If the cache reaches the maximum number of specified entries, or the size is set to a value less than the current number of stored entries, no new entries are added. To add additional entries, the cache size must first be increased with this command, or purged with the [clear ethernet cfm linktrace-cache](#) command.

**Example**

This example limits the maximum size of the link trace cache to 500 entries.

```
Console(config)#ethernet cfm linktrace cache size 500
Console(config)#
```

**ethernet cfm linktrace** This command sends CFM link trace messages to the MAC address of a remote MEP.

### Syntax

```
ethernet cfm linktrace {dest-mep destination-mpid | src-mep source-mpid
  {dest-mep destination-mpid | mac-address} | mac-address} md domain-name
ma ma-name [ttl number | priority level]
```

*destination-mpid* – The identifier of a remote MEP that is the target of the link trace message. (Range: 1-8191)

*source-mpid* – The identifier of a source MEP that will send the link trace message. (Range: 1-8191)

*mac-address* – MAC address of a remote MEP that is the target of the link trace message. This address can be entered in either of the following formats: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

*number* – The time to live of the linktrace message. (Range: 0-255 hops)

*level* – The priority level for sending the link trace messages. (Range: 0-7, 7 highest)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ Link trace messages can be targeted to MEPs, not MIPs. Before sending a link trace message, be sure you have configured the target MEP for the specified MA.
- ◆ If the MAC address of target MEP has not been learned by any local MEP, then the linktrace may fail. Use the [show ethernet cfm maintenance-points remote crosscheck](#) command to verify that a MAC address has been learned for the target MEP.
- ◆ Link trace messages (LTMs) are sent as multicast CFM frames, and forwarded from MIP to MIP, with each MIP generating a link trace reply, up to the point at which the LTM reaches its destination or can no longer be forwarded.
- ◆ Link trace messages are used to isolate faults. However, this task can be difficult in an Ethernet environment, since each node is connected through multipoint links. Fault isolation is even more challenging since the MAC address of the target node can age out in several minutes. This can cause the traced path to vary over time, or connectivity lost if faults cause the target MEP to be isolated from other MEPs in an MA.

- ◆ When using the command line or web interface, the source MEP used by to send a link trace message is chosen by the CFM protocol. However, when using SNMP, the source MEP can be specified by the user.

### Example

This example sends a link trace message to the specified MEP with a maximum hop count of 25.

```
Console#linktrace ethernet dest-mep 2 md voip ma rd ttl 25
Console#
```

**clear ethernet cfm linktrace-cache** This command clears link trace messages logged on this device.

### Command Mode

Privileged Exec

### Example

```
Console#clear ethernet cfm linktrace-cache
Console#
```

**show ethernet cfm linktrace-cache** This command displays the contents of the link trace cache.

### Command Mode

Privileged Exec

### Example

```
Console#show ethernet cfm linktrace-cache
Hops MA          IP / Alias          Ingress MAC          Ing. Action Relay
          Egress MAC          Egr. Action
-----
  2 rd          192.168.0.6        00-12-CF-12-12-2D ingOk          Hit
          Not Forwarded
Console#
```

**Table 176: show ethernet cfm linktrace-cache - display description**

Field	Description
Hops	The number hops taken to reach the target MEP.
MA	Name of the MA to which this device belongs.
IP/Alias	IP address or alias of the target device's CPU.
Forwarded	Shows whether or not this link trace message was forwarded. A message is not forwarded if received by the target MEP.
Ingress MAC	MAC address of the ingress port on the target device.
Egress MAC	MAC address of the egress port on the target device.

Table 176: show ethernet cfm linktrace-cache - display description (Continued)

Field	Description
Ing. Action	<p>Action taken on the ingress port:</p> <p>IngOk – The target data frame passed through to the MAC Relay Entity.</p> <p>IngDown – The bridge port’s MAC_Operational parameter is false. This value could be returned, for example, by an operationally Down MEP that has another Down MEP at a higher MD level on the same bridge port that is causing the bridge port’s MAC_Operational parameter to be false.</p> <p>IngBlocked – The ingress port can be identified, but the target data frame was not forwarded when received on this port due to active topology management, i.e., the bridge port is not in the forwarding state.</p> <p>IngVid – The ingress port is not in the member set of the LTM’s VIDs, and ingress filtering is enabled, so the target data frame was filtered by ingress filtering.</p>
Egr. Action	<p>Action taken on the egress port:</p> <p>EgrOk – The targeted data frame was forwarded.</p> <p>EgrDown – The Egress Port can be identified, but that bridge port’s MAC_Operational parameter is false.</p> <p>EgrBlocked – The egress port can be identified, but the data frame was not passed through the egress port due to active topology management, i.e., the bridge port is not in the forwarding state.</p> <p>EgrVid – The Egress Port can be identified, but the bridge port is not in the LTM’s VID member set, and was therefore filtered by egress filtering.</p>
Relay	<p>Relay action:</p> <p>FDB – Target address found in forwarding database.</p> <p>MPDB – Target address found in the maintenance point database.</p> <p>HIT – Target located on this device.</p>

## Loopback Operations

**ethernet cfm loopback** This command sends CFM loopback messages to a MAC address for a MEP or MIP.

### Syntax

```
ethernet cfm loopback {dest-mep destination-mpid | src-mep source-mpid
{dest-mep destination-mpid | mac-address} | mac-address} md domain-name
ma ma-name [count transmit-count] [pattern padding-value]
[priority priority-value] [size packet-size]
```

*destination-mpid* – The identifier of a MEP that is the target of the loopback message. (Range: 1-8191)

*source-mpid* – The identifier of a source MEP that will send the loopback message. (Range: 1-8191)

*mac-address* – MAC address of the remote maintenance point that is the target of the loopback message. This address can be entered in either of the following formats: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

*transmit-count* – The number of times the loopback message is sent. (Range: 1-1024)

*padding-value* – Padding characters used to fill the data TLV in a loopback message. (Range: Any hexadecimal characters; Default: 0x0)

*priority-value* – Priority assigned to the loopback message (Range:0-7; Default: 7)

*packet-size* – The size of the loopback message. (Range: 64-1518 bytes)

### Default Setting

Loop back count: One loopback message is sent.

Loop back size: 64 bytes

### Command Mode

Privileged Exec

### Command Usage

- ◆ Use this command to test the connectivity between maintenance points. If the continuity check database does not have an entry for the specified maintenance point, an error message will be displayed.
- ◆ The point from which the loopback message is transmitted (i.e., the DSAP) and the target maintenance point specified in this command must be within the same MA.
- ◆ Loop back messages can be used for fault verification and isolation after automatic detection of a fault or receipt of some other error report. Loopback messages can also be used to confirm the successful restoration or initiation of connectivity. The receiving maintenance point should respond to the loop back message with a loopback reply.
- ◆ When using the command line or web interface, the source MEP used by to send a loopback message is chosen by the CFM protocol. However, when using SNMP, the source MEP can be specified by the user.

### Example

This example sends a loopback message to the specified remote MEP.

```

Console#ethernet cfm loopback dest-mep 2 md rd2 ma rd2
Type ESC to abort.
Source MA Name      : rd2
Destination Address : 00-00-09-98-00-00
Transmitted LBM    : 5
Received LBR In Time : 5
Console#

```

## Fault Generator Operations

**mep fault-notify alarm-time** This command sets the time a defect must exist before a fault alarm is issued. Use the **no** form to restore the default setting.

### Syntax

**mep fault-notify alarm-time** *alarm-time*

**no fault-notify alarm-time**

*alarm-time* – The time that one or more defects must be present before a fault alarm is generated. (Range: 3-10 seconds)

### Default Setting

3 seconds

### Command Mode

CFM Domain Configuration

### Command Usage

A fault alarm is issued when the MEP fault notification generator state machine detects that a time period configured by this command has passed with one or more defects indicated, and fault alarms are enabled at or above the priority level set by the **mep fault-notify lowest-priority** command.

### Example

This example set the delay time before generating a fault alarm.

```
Console(config)#ethernet cfm domain index 1 name voip level 3
Console(config-ether-cfm)#mep fault-notify alarm-time 10
Console(config-ether-cfm)#
```

**mep fault-notify lowest-priority** This command sets the lowest priority defect that is allowed to generate a fault alarm. Use the **no** form to restore the default setting.

### Syntax

**mep fault-notify lowest-priority** *priority*

**no fault-notify lowest-priority**

*priority* – Lowest priority default allowed to generate a fault alarm. (Range: 1-6)

### Default Setting

Priority level 2

### Command Mode

CFM Domain Configuration

### Command Usage

- ◆ A fault alarm can generate an SNMP notification. It is issued when the MEP fault notification generator state machine detects that a configured time period (see the [mep fault-notify alarm-time](#) command) has passed with one or more defects indicated, and fault alarms are enabled at or above the priority level set by this command. The state machine transmits no further fault alarms until it is reset by the passage of a configured time period (see the [mep fault-notify reset-time](#) command) without a defect indication. The normal procedure upon receiving a fault alarm is to inspect the reporting MEP's managed objects using an appropriate SNMP software tool, diagnose the fault, correct it, re-examine the MEP's managed objects to see whether the MEP fault notification generator state machine has been reset, and repeat those steps until the fault is resolved.
- ◆ Only the highest priority defect currently detected is reported in the fault alarm.
- ◆ Priority defects include the following items:

**Table 177: Remote MEP Priority Levels**

Priority Level	Level Name	Description
1	allDef	All defects.
2	macRemErrXcon	DefMACstatus, DefRemoteCCM, DefErrorCCM, or DefXconCCM.
3	remErrXcon	DefErrorCCM, DefXconCCM or DefRemoteCCM.
4	errXcon	DefErrorCCM or DefXconCCM.
5	xcon	DefXconCCM
6	noXcon	No defects DefXconCCM or lower are to be reported.

**Table 178: MEP Defect Descriptions**

Field	Description
DefMACstatus	Either some remote MEP is reporting its Interface Status TLV as not isUp, or all remote MEPs are reporting a Port Status TLV that contains some value other than psUp.
DefRemoteCCM	The MEP is not receiving valid CCMs from at least one of the remote MEPs.
DefErrorCCM	The MEP has received at least one invalid CCM whose CCM Interval has not yet timed out.
DefXconCCM	The MEP has received at least one CCM from either another MAID or a lower MD Level whose CCM Interval has not yet timed out.

**Example**

This example sets the lowest priority defect that will generate a fault alarm.

```
Console(config)#ethernet cfm domain index 1 name voip level 3
Console(config-ether-cfm)#mep fault-notify lowest-priority 1
Console(config-ether-cfm)#
```

**mep fault-notify  
reset-time**

This command configures the time after a fault alarm has been issued, and no defect exists, before another fault alarm can be issued. Use the **no** form to restore the default setting.

**Syntax**

**mep fault-notify reset-time** *reset-time*

**no fault-notify reset-time**

*reset-time* – The time that must pass without any further defects indicated before another fault alarm can be generated. (Range: 3-10 seconds)

**Default Setting**

10 seconds

**Command Mode**

CFM Domain Configuration

**Example**

This example sets the reset time after which another fault alarm can be generated.

```
Console(config)#ethernet cfm domain index 1 name voip level 3
Console(config-ether-cfm)#mep fault-notify reset-time 7
Console(config-ether-cfm)#
```

**show ethernet cfm  
fault-notify-generator**

This command displays configuration settings for the fault notification generator.

**Syntax**

**show ethernet cfm fault-notify-generator mep** *mpid*

*mpid* – Maintenance end point identifier. (Range: 1-8191)

**Default Setting**

None

**Command Mode**

Privileged Exec

**Example**

This example shows the fault notification settings configured for one MEP.

```

Console#show ethernet cfm fault-notify-generator mep 1
MD Name      MA Name      Highest Defect Lowest Alarm  Alarm Time Reset Time
-----
voip         rd           none          macRemErrXcon  3sec.    10sec.
Console#

```

**Table 179: show fault-notify-generator - display description**

Field	Description
MD Name	The maintenance domain for this entry.
MA Name	The maintenance association for this entry.
Hihest Defect	The highest defect that will generate a fault alarm. (This is disabled by default.)
Lowest Alarm	The lowest defect that will generate a fault alarm (see the <a href="#">mep fault-notify lowest-priority</a> command).
Alarm Time	The time a defect must exist before a fault alarm is issued (see the <a href="#">mep fault-notify alarm-time</a> , command).
Reset Time	The time after a fault alarm has been issued, and no defect exists, before another fault alarm can be issued (see the <a href="#">mep fault-notify reset-time</a> command).

## Delay Measure Operations

**ethernet cfm delay-measure two-way** This command sends periodic delay-measure requests to a specified MEP within a maintenance association.

### Syntax

```

ethernet cfm delay-measure two-way [src-mep source-mpid] {dest-mep
destination-mpid | mac-address} md domain-name ma ma-name
[count transmit-count] [interval interval] [size packet-size] [timeout timeout]

```

*source-mpid* – The identifier of a source MEP that will send the delay-measure message. (Range: 1-8191)

*destination-mpid* – The identifier of a remote MEP that is the target of the delay-measure message. (Range: 1-8191)

*mac-address* – MAC address of a remote MEP that is the target of the delay-measure message. This address can be entered in either of the following formats: xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx

*domain-name* – Domain name. (Range: 1-43 alphanumeric characters)

*ma-name* – Maintenance association name. (Range: 1-43 alphanumeric characters)

*count* – The number of times to retry sending the message if no response is received before the specified timeout. (Range: 1-5)

*interval* – The transmission delay between delay-measure messages. (Range: 1-5 seconds)

*packet-size* – The size of the delay-measure message. (Range: 64-1518 bytes)

*timeout* – The timeout to wait for a response. (Range: 1-5 seconds)

### Default Setting

Count: 5

Interval: 1 second

Size: 64 bytes

Timeout: 5 seconds

### Command Mode

Privileged Exec

### Command Usage

- ◆ Delay measurement can be used to measure frame delay and frame delay variation between MEPs.
- ◆ A local MEP must be configured for the same MA before you can use this command.
- ◆ If a MEP is enabled to generate frames with delay measurement (DM) information, it periodically sends DM frames to its peer MEP in the same MA., and expects to receive DM frames back from it.
- ◆ Frame delay measurement can be made only for two-way measurements, where the MEP transmits a frame with DM request information with the TxTimeStampf (Timestamp at the time of sending a frame with DM request information), and the receiving MEP responds with a frame with DM reply information with TxTimeStampf copied from the DM request information, RxTimeStampf (Timestamp at the time of receiving a frame with DM request information), and TxTimeStamptb (Timestamp at the time of transmitting a frame with DM reply information):
 
$$\text{Frame Delay} = (\text{RxTimeStampb} - \text{TxTimeStampf}) - (\text{TxTimeStamptb} - \text{RxTimeStampf})$$
- ◆ The MEP can also make two-way frame delay variation measurements based on its ability to calculate the difference between two subsequent two-way frame delay measurements.

### Example

This example sends periodic delay-measure requests to a remote MEP.

```

Console#ethernet cfm delay-measure two-way dest-mep 1 md voip ma rd
Type ESC to abort.
Sending 5 Ethernet CFM delay measurement message, timeout is 5 sec.
Sequence  Delay Time (ms.)  Delay Variation (ms.)
-----  -
1                < 10                0
  
```

```
2          < 10          0
3          < 10          0
4          40           40
5          < 10          40
```

Success rate is 100% (5/5), delay time min/avg/max=0/8/40 ms.

Average frame delay variation is 16 ms.

Console#

---

## OAM Commands

The switch provides OAM (Operation, Administration, and Maintenance) remote management tools required to monitor and maintain the links to subscriber CPEs (Customer Premise Equipment). This section describes functions including enabling OAM for selected ports, loop back testing, and displaying device information.

**Table 180: OAM Commands**

Command	Function	Mode
<code>efm oam</code>	Enables OAM services	IC
<code>efm oam critical-link-event</code>	Enables reporting of critical event or dying gasp	IC
<code>efm oam link-monitor frame</code>	Enables reporting of errored frame link events	IC
<code>efm oam link-monitor frame threshold</code>	Sets the threshold for errored frame link events	IC
<code>efm oam link-monitor frame window</code>	Sets the monitor period for errored frame link events	IC
<code>efm oam mode</code>	Sets the OAM operational mode to active or passive	IC
<code>clear efm oam counters</code>	Clears statistical counters for various OAMPDU message types	PE
<code>clear efm oam event-log</code>	Clears all entries from the OAM event log for the specified port	PE
<code>efm oam remote-loopback</code>	Initiates or terminates remote loopback test	PE
<code>efm oam remote-loopback test</code>	Performs remote loopback test, sending a specified number of packets	PE
<code>show efm oam counters interface</code>	Displays counters for various OAM PDU message types	PE
<code>show efm oam event-log interface</code>	Displays OAM event log	PE
<code>show efm oam remote-loopback interface</code>	Displays results of OAM remote loopback test	PE
<code>show efm oam status interface</code>	Displays OAM configuration settings and event counters	PE
<code>show efm oam status remote interface</code>	Displays information about attached OAM-enabled devices	PE

**efm oam** This command enables OAM functions on the specified port. Use the **no** form to disable this function.

### Syntax

**[no] efm oam**

### Default Setting

Disabled

### Command Mode

Interface Configuration

### Command Usage

- ◆ If the remote device also supports OAM, both exchange Information OAMPDUs to establish an OAM link.
- ◆ Not all CPEs support OAM functions, and OAM is therefore disabled by default. If the CPE attached to a port supports OAM, then this functionality must first be enabled by the **efm oam** command to gain access to other remote configuration functions.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#efm oam
Console(config-if)#
```

**efm oam critical-link-event** This command enables reporting of critical event or dying gasp. Use the **no** form to disable this function.

### Syntax

**[no] efm oam critical-link-event {critical-event | dying-gasp}**

**critical-event** - If a critical event occurs, the local OAM entity (this switch) indicates this to its peer by setting the appropriate flag in the next OAMPDU to be sent and stores this information in its OAM event log.

**dying-gasp** - If an unrecoverable condition occurs, the local OAM entity indicates this by immediately sending a trap message.

### Default Setting

Enabled

### Command Mode

Interface Configuration

### Command Usage

- ◆ Critical events are vendor-specific and may include various failures, such as abnormal voltage fluctuations, out-of-range temperature detected, fan failure, CRC error in flash memory, insufficient memory, or other hardware faults.
- ◆ Dying gasp events are caused by an unrecoverable failure, such as a power failure or device reset.



**Note:** When system power fails, the switch will always send a dying gasp trap message prior to power down.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#efm oam critical-link-event dying-gasp
Console(config-if)#
```

### efm oam link-monitor frame

This command enables reporting of errored frame link events. Use the **no** form to disable this function.

### Syntax

**[no] efm oam link-monitor frame**

### Default Setting

Enabled

### Command Mode

Interface Configuration

### Command Usage

- ◆ An errored frame is a frame in which one or more bits are errored.
- ◆ If this feature is enabled and an errored frame link event occurs, the local OAM entity (this switch) sends an Event Notification OAMPDU.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#efm oam link-monitor frame
Console(config-if)#
```

**efm oam link-monitor frame threshold** This command sets the threshold for errored frame link events. Use the **no** form to restore the default setting.

#### Syntax

**efm oam link-monitor frame threshold** *count*

**no efm oam link-monitor frame threshold**

*count* - The threshold for errored frame link events. (Range: 1-65535)

#### Default Setting

1

#### Command Mode

Interface Configuration

#### Command Usage

If this feature is enabled, an event notification message is sent if the threshold is reached or exceeded within the period specified by the [efm oam link-monitor frame window](#) command. The Errored Frame Event TLV includes the number of errored frames detected during the specified period.

#### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#efm oam link-monitor frame threshold 5
Console(config-if)#
```

**efm oam link-monitor frame window** This command sets the monitor period for errored frame link events. Use the **no** form to restore the default setting.

#### Syntax

**efm oam link-monitor frame window** *size*

**no efm oam link-monitor frame window**

*size* - The period of time in which to check the reporting threshold for errored frame link events. (Range: 10-65535 units of 100 milliseconds)

#### Default Setting

10 (units of 100 milliseconds) = 1 second

#### Command Mode

Interface Configuration

#### Command Usage

If this feature is enabled, an event notification message is sent if the threshold specified by the [efm oam link-monitor frame threshold](#) command is reached or

exceeded within the period specified by this command. The Errored Frame Event TLV includes the number of errored frames detected during the specified period.

### Example

This example set the window size to 5 seconds.

```
Console(config)#interface ethernet 1/1
Console(config-if)#efm oam link-monitor frame window 50
Console(config-if)#
```

**efm oam mode** This command sets the OAM mode on the specified port. Use the **no** form to restore the default setting.

### Syntax

**efm oam mode** {**active** | **passive**}

**no efm oam mode**

**active** - All OAM functions are enabled.

**passive** - All OAM functions are enabled, except for OAM discovery, and sending loopback control OAMPDUs.

### Default Setting

Active

### Command Mode

Interface Configuration

### Command Usage

When set to active mode, the selected interface will initiate the OAM discovery process. When in passive mode, it can only respond to discovery messages.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#efm oam mode active
Console(config-if)#
```

**clear efm oam counters** This command clears statistical counters for various OAMPDU message types.

#### Syntax

**clear efm oam counters** [*interface-list*]

*interface-list* - *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Example

```
Console#clear efm oam counters
Console#
```

#### Related Commands

[show efm oam counters interface \(887\)](#)

**clear efm oam event-log** This command clears all entries from the OAM event log for the specified port.

#### Syntax

**clear efm oam event-log** [*interface-list*]

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Example

```
Console#clear efm oam event-log
Console#
```

**efm oam remote-loopback** This command starts or stops OAM loopback test mode to the attached CPE.

#### Syntax

**efm oam remote-loopback** {**start** | **stop**} *interface*

**start** - Starts remote loopback test mode.

**stop** - Stops remote loopback test mode.

*interface* - *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

#### Default Setting

None

#### Command Mode

Privileged Exec

#### Command Usage

- ◆ OAM remote loop back can be used for fault localization and link performance testing. Statistics from both the local and remote DTE can be queried and compared at any time during loop back testing.
- ◆ Use the **efm oam remote-loopback start** command to start OAM remote loop back test mode on the specified port. Afterwards, use the **efm oam remote-loopback test** command to start sending test packets. Then use the **efm oam remote loopback stop** command to terminate testing (if test packets are still being sent) and to terminate loop back test mode.
- ◆ The port that you specify to run this test must be connected to a peer OAM device capable of entering into OAM remote loopback mode.
- ◆ During a remote loopback test, the remote OAM entity loops back every frame except for OAMPDUs and pause frames.
- ◆ During loopback testing, both the switch and remote device are permitted to send OAMPDUs to the peer device and to process any OAMPDUs received from the peer.

#### Example

```
Console#efm oam remote-loopback start 1/1
Loopback operation is processing, please wait.
Enter loopback mode succeeded.
Console#
```

**efm oam remote-loopback test** This command performs a remote loopback test, sending a specified number of packets.

### Syntax

**efm oam remote-loopback test** *interface* [*number-of-packets* [*packet-size*]]

*interface* - unit/port

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

*number-of-packets* - Number of packets to send. (Range: 1-99999999)

*packet-size* - Size of packets to send. (Range: 64-1518 bytes)

### Default Setting

Number of packets: 10,000

Packet size: 64 bytes

### Command Mode

Privileged Exec

### Command Usage

- ◆ You can use this command to perform an OAM remote loopback test on the specified port. The port that you specify to run this test must be connected to a peer OAM device capable of entering into OAM remote loopback mode.
- ◆ During a remote loopback test, the remote OAM entity loops back every frame except for OAMPDUs and pause frames.
- ◆ OAM remote loopback can be used for fault localization and link performance testing. Statistics from both the local and remote DTE can be queried and compared at any time during loopback testing.
- ◆ A summary of the test is displayed after it is finished.

### Example

```

Console#efm oam remote-loopback test 1/2
Loopback test is processing, press ESC to suspend.
....
Port OAM loopback Tx OAM loopback Rx Loss Rate
-----
1/2          1990          1016    48.94 %
Console#

```

**show efm oam counters interface** This command displays counters for various OAM PDU message types.

#### Syntax

**show efm oam counters interface** [*interface-list*]

*interface-list* - *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Example

```

Console#show efm oam counters interface 1/1
Port OAMPDU Type          TX          RX
-----
1/1  Information           1121         1444
1/1  Event Notification     0             0
1/1  Loopback Control       1             0
1/1  Organization Specific  76            0
Console#

```

**show efm oam event-log interface** This command displays the OAM event log for the specified port(s) or for all ports that have logs.

**show efm oam event-log interface** [*interface-list*]

*interface-list* - *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

#### Command Mode

Privileged Exec

#### Command Usage

- ◆ When a link event occurs, no matter whether the location is local or remote, this information is entered in the OAM event log.
- ◆ When the log system becomes full, older events are automatically deleted to make room for new entries.

**Example**

```

Console#show efm oam event-log interface 1/1
OAM event log of Eth 1/1:
 00:24:07 2001/01/01
  "Unit 1, Port 1: Dying Gasp at Remote"
Console#

```

This command can show OAM link status changes for link partner as shown in this example.

```

Console#show efm oam event-log interface 1/1
OAM event log of Eth 1/1:
 10:22:55 2013/09/13
  "Unit 1, Port 1: Connection to remote device is up at Local"
 10:22:44 2013/09/13
  "Unit 1, Port 1: Connection to remote device is down at Local"
  <--- When the link is down,this event will be written to OAM event-log
 10:20:02 2013/09/13
  "Unit 1, Port 1: Connection to remote device is up at Local"
  <--- When the link is up,this event will be written to OAM event-log,
Console#clear efm oam event-log
  <--- Use he "clear efm oam event-log" command to clear the event-log.
Console#show efm oam event-log interface 1/1
Console#

```

This command can show OAM dying gasp changes for link partner as shown in this example.

```

Console#show efm oam event-log interface 1/1
  <--- When dying gasp happens and the switch get these packets, it will log
  this event in OAM event-log.
OAM event log of Eth 1/1:
 10:27:21 2013/09/13
  "Unit 1, Port 1: Connection to remote device is down at Local"
 10:27:20 2013/09/13
  "Unit 1, Port 1: Dying Gasp occurred at Remote"
Console#show efm oam event-log interface 1/1
OAM event log of Eth 1/1:
 10:28:31 2013/09/13
  "Unit 1, Port 1: Connection to remote device is up at Local"
 10:28:28 2013/09/13
  "Unit 1, Port 1: Dying Gasp clear occurred at Remote"
  <--- When the remote device comes up, the switch will get OAM packets
  without the dying gasp bit and display "dying gasp event clear".
Console#

```

**show efm oam remote-loopback interface** This command displays the results of an OAM remote loopback test.  
Syntax

**show efm oam remote-loopback interface** [*interface-list*]

*interface-list* - unit/port

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Example

```
Console#show efm oam remote-loopback interface 1/1
Port OAM loopback Tx OAM loopback Rx Loss Rate
-----
1/1          2300          2250    0.01 %
Console#
```

**show efm oam status interface** This command displays OAM configuration settings and event counters.

### Syntax

**show efm oam status interface** [*interface-list*] [**brief**]

*interface* - unit/port

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

**brief** - Displays a brief list of OAM configuration states.

### Command Mode

Privileged Exec

### Example

```
Console#show efm oam status interface 1/1
OAM information of Eth 1/1:
Basic Information:
Admin State           : Enabled
Operation State      : Operational
Mode                  : Active
Remote Loopback       : Disabled
Remote Loopback Status : No loopback
Dying Gasp            : Enabled
Critical Event        : Enabled
```

```

Link Monitor (Errored Frame) : Enabled
Link Monitor:
  Errored Frame Window (100msec) : 10
  Errored Frame Threshold : 1
Console#show efm oam status interface 1/1 brief
$ = local OAM in loopback
* = remote OAM in loopback

Port Admin   Mode      Remote   Dying   Critical Errored
  State      Loopback Gasp     Event   Frame
-----
1/1 Enabled Active Disabled Enabled Enabled Enabled
Console#

```

**show efm oam status remote interface** This command displays information about attached OAM-enabled devices.

### Syntax

**show efm oam status remote interface** [*interface-list*]

*interface-list* - unit/port

*unit* - Unit identifier. (Range: 1)

*port* - Port number or list of ports. To enter a list, separate nonconsecutive port identifiers with a comma and no spaces; use a hyphen to designate a range of ports. (Range: 1-28/54)

### Command Mode

Privileged Exec

### Example

```

Console#show efm oam status remote interface 1/1
Port MAC Address      OUI      Remote   Unidirectional Link   MIB Variable
  Loopback            Retrieval
-----
1/1 00-12-CF-6A-07-F6 000084 Enabled Disabled Enabled Disabled
Console#

```

# Domain Name Service Commands

These commands are used to configure Domain Naming System (DNS) services. Entries can be manually configured in the DNS domain name to IP address mapping table, default domain names configured, or one or more name servers specified to use for domain name to address translation.

Note that domain name services will not be enabled until at least one name server is specified with the `ip name-server` command and domain lookup is enabled with the `ip domain-lookup` command.

The switch performs both as a DNS client and a DNS server/proxy in the following manner:

PC (DNS Client) <-----> Switch (DNS client<sup>1</sup>, server/proxy<sup>2</sup>) <-----> Server (another server/proxy)

- <sup>1</sup> For the case that the switch performs as a DNS client and an incomplete host name is received, it will work through the domain list, appending each domain name in the list to the host name, and checking with the specified name servers for a match.
- <sup>2</sup> Otherwise, the switch acts as a DNS server/proxy when an outside host (namely, a DNS client) intends to get an IP address for a host name through the switch. In this case, it will not add the domain suffix to query name servers). That means that the DNS client is responsible for adding the domain suffix.

**Table 181: Address Table Commands**

Command	Function	Mode
<i>DNS</i>		
<code>ip domain-list</code>	Defines a list of default domain names for incomplete host names	GC
<code>ip domain-lookup</code>	Enables DNS-based host name-to-address translation	GC
<code>ip domain-name</code>	Defines a default domain name for incomplete host names	GC
<code>ip host</code>	Creates a static IPv4 host name-to-address mapping	GC
<code>ip name-server</code>	Specifies the address of one or more name servers to use for host name-to-address translation	GC
<code>ipv6 host</code>	Creates a static IPv6 host name-to-address mapping	GC
<code>clear dns cache</code>	Clears all entries from the DNS cache	PE
<code>show dns</code>	Displays the configuration for DNS services	PE
<code>show dns cache</code>	Displays entries in the DNS cache	PE
<code>show hosts</code>	Displays the static host name-to-address mapping table	PE

Table 181: Address Table Commands

Command	Function	Mode
<i>mDNS</i>		
<code>ip mdns</code>	Enables multicast DNS	GC
<code>show ip mdns</code>	Shows configuration state for multicast DNS	GC

## DNS Commands

**ip domain-list** This command defines a list of domain names that can be appended to incomplete host names (i.e., host names passed from a client that are not formatted with dotted notation). Use the **no** form to remove a name from this list.

### Syntax

**[no] ip domain-list** *name*

*name* - Name of the host. Do not include the initial dot that separates the host name from the domain name. (Range: 1-127 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Domain names are added to the end of the list one at a time.
- ◆ When an incomplete host name is received by the DNS service on this switch, it will work through the domain list, appending each domain name in the list to the host name, and checking with the specified name servers for a match.
- ◆ If there is no domain list, the domain name specified with the `ip domain-name` command is used. If there is a domain list, the default domain name is not used.

### Example

This example adds two domain names to the current list and then displays the list.

```
Console(config)#ip domain-list sample.com.jp
Console(config)#ip domain-list sample.com.uk
Console(config)#end
Console#show dns
Domain Lookup Status:
    DNS Disabled
Default Domain Name:
    sample.com
```

```
Domain Name List:
  sample.com.jp
  sample.com.uk
Name Server List:
Console#
```

## Related Commands

[ip domain-name \(894\)](#)

**ip domain-lookup** This command enables DNS host name-to-address translation. Use the **no** form to disable DNS.

## Syntax

**[no] ip domain-lookup**

## Default Setting

Disabled

## Command Mode

Global Configuration

## Command Usage

- ◆ At least one name server must be specified before DNS can be enabled.
- ◆ If one or more name servers are configured, but DNS is not yet enabled and the switch receives a DHCP packet containing a DNS field with a list of DNS servers, then the switch will automatically enable DNS host name-to-address translation.
- ◆ If all name servers are deleted, DNS will automatically be disabled.

## Example

This example enables DNS and then displays the configuration.

```
Console(config)#ip domain-lookup
Console(config)#end
Console#show dns
Domain Lookup Status:
  DNS Enabled
Default Domain Name:
  sample.com
Domain Name List:
  sample.com.jp
  sample.com.uk
Name Server List:
  192.168.1.55
  10.1.0.55
Console#
```

### Related Commands

[ip domain-name \(894\)](#)

[ip name-server \(895\)](#)

**ip domain-name** This command defines the default domain name appended to incomplete host names (i.e., host names passed from a client that are not formatted with dotted notation). Use the **no** form to remove the current domain name.

### Syntax

**ip domain-name** *name*

**no ip domain-name**

*name* - Name of the host. Do not include the initial dot that separates the host name from the domain name. (Range: 1-127 characters)

### Default Setting

None

### Command Mode

Global Configuration

### Example

```
Console(config)#ip domain-name sample.com
Console(config)#end
Console#show dns
Domain Lookup Status:
  DNS Disabled
Default Domain Name:
  sample.com
Domain Name List:
Name Server List:
Console#
```

### Related Commands

[ip domain-list \(892\)](#)

[ip name-server \(895\)](#)

[ip domain-lookup \(893\)](#)

**ip host** This command creates a static entry in the DNS table that maps a host name to an IPv4 address. Use the **no** form to remove an entry.

### Syntax

**[no] ip host** *name address*

*name* - Name of an IPv4 host. (Range: 1-127 characters)

*address* - Corresponding IPv4 address.

**Default Setting**

No static entries

**Command Mode**

Global Configuration

**Command Usage**Use the **no ip host** command to clear static entries.**Example**

This example maps an IPv4 address to a host name.

```

Console(config)#ip host rd5 192.168.1.55
Console(config)#end
Console#show hosts
No.  Flag Type      IP Address          TTL  Host
-----
  0   2 Address 192.168.1.55          rd5
Console#

```

**ip name-server** This command specifies the address of one or more domain name servers to use for name-to-address resolution. Use the **no** form to remove a name server from this list.

**Syntax**

```
[no] ip name-server server-address1 [server-address2 ...
server-address6]
```

*server-address1* - IPv4 or IPv6 address of domain-name server.

*server-address2 ... server-address6* - IPv4 or IPv6 address of additional domain-name servers.

**Default Setting**

None

**Command Mode**

Global Configuration

**Command Usage**

The listed name servers are queried in the specified sequence until a response is received, or the end of the list is reached with no response.

**Example**

This example adds two domain-name servers to the list and then displays the list.

```

Console(config)#ip name-server 192.168.1.55 10.1.0.55
Console(config)#end
Console#show dns

```

```
Domain Lookup Status:
  DNS disabled
Default Domain Name:
  sample.com
Domain Name List:
  sample.com.jp
  sample.com.uk
Name Server List:
  192.168.1.55
  10.1.0.55
Console#
```

### Related Commands

[ip domain-name \(894\)](#)

[ip domain-lookup \(893\)](#)

**ipv6 host** This command creates a static entry in the DNS table that maps a host name to an IPv6 address. Use the **no** form to remove an entry.

### Syntax

**[no] ipv6 host** *name ipv6-address*

*name* - Name of an IPv6 host. (Range: 1-127 characters)

*ipv6-address* - Corresponding IPv6 address. This address must be entered according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

### Default Setting

No static entries

### Command Mode

Global Configuration

### Example

This example maps an IPv6 address to a host name.

```
Console(config)#ipv6 host rd6 2001:0db8:1::12
Console(config)#end
Console#show hosts
No.  Flag Type      IP Address          TTL  Domain
-----
  0   2 Address 192.168.1.55          rd5
  1   2 Address 2001:DB8:1::12      rd6
Console#
```

**clear dns cache** This command clears all entries in the DNS cache.

**Command Mode**  
Privileged Exec

**Example**

```

Console#clear dns cache
Console#show dns cache
No.      Flag   Type   IP Address      TTL      Host
-----
Console#
    
```

**show dns** This command displays the configuration of the DNS service.

**Command Mode**  
Privileged Exec

**Example**

```

Console#show dns
Domain Lookup Status:
  DNS enabled
Default Domain Name:
  sample.com
Domain Name List:
  sample.com.jp
  sample.com.uk
Name Server List:
  192.168.1.55
  10.1.0.55
Console#
    
```

**show dns cache** This command displays entries in the DNS cache.

**Command Mode**  
Privileged Exec

**Example**

```

Console#show dns cache
No.      Flag   Type   IP Address      TTL      Host
-----
      0     4 Host   52.196.118.60   3501    www.accton.com
      1     4 Host   166.62.56.229   21540   www.edge-core.com
      2     4 Host   35.201.87.174   1787    ignitenet.com
      3     4 CNAME  POINTER TO:2    1787    www.ignitenet.com
Console#
    
```

**Table 182: show dns cache - display description**

Field	Description
No.	The entry number for each resource record.
Flag	The flag is always "4" indicating a cache entry and therefore unreliable.
Type	This field includes "Host" which specifies the primary name for the owner, and "CNAME" which specifies multiple domain names (or aliases) which are mapped to the same IP address as an existing entry.
IP Address	The IP address associated with this record.
TTL	The time to live reported by the name server.
Host	The host name associated with this record.

**show hosts** This command displays the static host name-to-address mapping table.

### Command Mode

Privileged Exec

### Example

Note that a host name will be displayed as an alias if it is mapped to the same address(es) as a previously configured entry.

```

Console#show hosts
No.  Flag Type      IP Address          TTL  Host
-----
  0   2  Address 192.168.2.1          rdrouter
  1   4  Address 52.196.118.60       3341 www.accton.com
  2   4  Address 166.62.56.229     21381 www.edge-core.com
  3   4  Address 35.201.87.174  1627 ignitenet.com
  4   4  CNAME  POINTER TO:3       1628 www.ignitenet.com
Console#

```

**Table 183: show hosts - display description**

Field	Description
No.	The entry number for each resource record.
Flag	The field displays "2" for a static entry, or "4" for a dynamic entry stored in the cache.
Type	This field includes "Address" which specifies the primary name for the owner, and "CNAME" which specifies multiple domain names (or aliases) which are mapped to the same IP address as an existing entry.
IP Address	The IP address associated with this record.
TTL	The time to live reported by the name server. This field is always blank for static entries.
Host	The host name associated with this record.

---

## Multicast DNS Commands

**ip mdns** This command enables multicast DNS. Use the **no** form to disable this feature.

### Syntax

**[no] ip mdns**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

Use this command to enable multicast DNS host name-to-address mapping on the local network without the need for a dedicated DNS server. For more information on this command refer to the *Web Management Guide*.

### Example

```
Console(config)#ip mdns
Console(config)#
```

**show ip mdns** This command displays the configuration state multicast DNS service.

### Command Mode

Privileged Exec

### Example

```
Console#show ip mdns
Multicast DNS Status : Enabled
Console#
```



# DHCP Commands

These commands are used to configure Dynamic Host Configuration Protocol (DHCP) client, relay, and server functions. Any VLAN interface can be configured to automatically obtain an IPv4 address through DHCP. This switch can also be configured to relay DHCP client configuration requests to a DHCP server on another network.

**Table 184: DHCP Commands**

Command Group	Function
DHCP Client	Allows interfaces to dynamically acquire IP address information
DHCP Relay	Relays DHCP requests from local hosts to a remote DHCP server
DHCP Server	Configures DHCP service using address pools or static bindings

## DHCP Client

Use the commands in this section to allow the switch's VLAN interfaces to dynamically acquire IP address information.

**Table 185: DHCP Client Commands**

Command	Function	Mode
<i>DHCP for IPv4</i>		
<code>ip dhcp dynamic-provision</code>	Enables dynamic provision via DHCP	GC
<code>ip dhcp client class-id</code>	Specifies the DHCP client identifier for an interface	IC
<code>ip dhcp inform</code>	Enables DHCP Inform on a VLAN interface	IC
<code>ip dhcp restart client</code>	Submits a BOOTP or DHCP client request	PE
<code>show ip dhcp dynamic-provision</code>	Shows the status of dynamic provision via DHCP	PE
<i>DHCP for IPv6</i>		
<code>ipv6 dhcp client rapid-commit vlan</code>	Specifies the Rapid Commit option for DHCPv6 message exchange	GC
<code>ipv6 dhcp restart client vlan</code>	Submits a DHCPv6 client request	PE
<code>ipv6 dhcp dynamic-provision</code>	Enables dynamic provision via DHCPv6	GC
<code>show ipv6 dhcp duid</code>	Shows the DHCP Unique Identifier for this switch	PE

Table 185: DHCP Client Commands

Command	Function	Mode
<code>show ipv6 dhcp vlan</code>	Shows DHCPv6 information for specified interface	PE
<code>show ipv6 dhcp dynamic-provision</code>	Shows the status of dynamic provision via DHCPv6	PE

## DHCP for IPv4

**ip dhcp dynamic-provision** This command enables dynamic provisioning via DHCP. Use the **no** form to disable this feature.

### Syntax

**[no] ip dhcp dynamic-provision**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

DHCPD is the daemon used by Linux to dynamically configure TCP/IP information for client systems. To support DHCP option 66/67, you have to add corresponding statements to the configuration file of DHCPD. Information on how to complete this process are described in [“Downloading a Configuration File and Other Parameters from a DHCP Server” on page 76](#).

The following are some alternative commands which can be added to the DHCPD to complete the dynamic provisioning process.

By default, the parameters for DHCP option 66/67 are not carried by the reply sent from the DHCP server. To ask for a DHCP reply with option 66/67, the client can inform the server that it is interested in option 66/67 by sending a DHCP request that includes a 'parameter request list' option. Besides this, the client can also send a DHCP request that includes a 'vendor class identifier' option to the server so that the DHCP server can identify the device, and determine what information should be given to requesting device.

The following are two additional sample configurations of the dhcpd.conf file for the server version dhcp-3.0.4rc1, you can choose either one of them.

#### 1. Define the conditions in subnet section:

```
shared-network Sample1 {
    subnet 192.168.1.0 netmask 255.255.255.0 {
# option 55
        option dhcp-parameter-request-list 1,66,67;
# option 66
        option tftp-server-name "192.168.1.1";
    }
}
```

```
# option 67
  option bootfile-name "dhcp_config.cfg";
}
}
```

## 2. Define the conditions in class section:

```
class "OPT66_67" { # for option 66/67
  # option 124
  match if option vendor-class-identifier = "Edgecore";
  # option 55
  option dhcp-parameter-request-list 1,66,67;
  # option 66
  option tftp-server-name "192.168.1.1";
  # option 67
  option bootfile-name "dhcp_config.cfg";
}

shared-network Sample2 {
  subnet 192.168.1.0 netmask 255.255.255.0 {
  }
  pool {
    allow members of "OPT66_67";
    range 192.168.1.10 192.168.1.20;
  }
}
```

### Example

In the following example enables dhcp dynamic provisioning.

```
Console(config)#ip dhcp dynamic-provision
Console(config)#
```

**ip dhcp client class-id** This command specifies the DHCP client vendor class identifier for the current interface. Use the **no** form to remove the class identifier from the DHCP packet.

### Syntax

**ip dhcp client class-id** [*text text* | *hex hex*]

**no ip dhcp client class-id**

*text* - A text string. (Range: 1-32 characters)

*hex* - A hexadecimal value. (Range: 1-64 characters)

### Default Setting

Class identifier option enabled, using the model number as the string

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Use this command without any keyword to restore the default setting.
- ◆ This command is used to identify the vendor class and configuration of the switch to the DHCP server, which then uses this information to decide on how to service the client or the type of information to return.
- ◆ The general framework for this DHCP option is set out in RFC 2132 (Option 60). This information is used to convey configuration settings or other identification information about a client, but the specific string to use should be supplied by your service provider or network administrator. Options 60, 66 and 67 statements can be added to the server daemon's configuration file.

**Table 186: Options 60, 66 and 67 Statements**

Option	Statement	
	Keyword	Parameter
60	vendor-class-identifier	a string indicating the vendor class identifier
66	tftp-server-name	a string indicating the tftp server name
67	bootfile-name	a string indicating the bootfile name

- ◆ By default, DHCP option 66/67 parameters are not carried in a DHCP server reply. To ask for a DHCP reply with option 66/67 information, the DHCP client request sent by this switch includes a "parameter request list" asking for this information. Besides, the client request also includes a "vendor class identifier" set by the **ip dhcp client class-id** command that allows the DHCP server to identify the device, and select the appropriate configuration file for download. This information is included in Option 55 and 124.

**Table 187: Options 55 and 124 Statements**

Option	Statement	
	Keyword	Parameter
55	dhcp-parameter-request-list	a list of parameters, separated by "
124	vendor-class-identifier	a string indicating the vendor class identifier

- ◆ The server should reply with Option 66 attributes, including the TFTP server name and boot file name.
- ◆ Note that the vendor class identifier can be formatted in either text or hexadecimal using the **ip dhcp client class-id** command, but the format used by both the client and server must be the same.

### Example

```
Console(config)#interface vlan 2
Console(config-if)#ip dhcp client class-id hex 0000e8666572
Console(config-if)#
```

### Related Commands

[ip dhcp restart client \(906\)](#)

**ip dhcp inform** This command enables DHCP client information to be received on a VLAN interface that has a user-configured IP address. Use the **no** form to disable the feature.

### Syntax

**[no] ip dhcp inform**

### Default Setting

Disabled

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ A DHCP Inform message enables a client to obtain information from a DHCP server without requesting an IP address. When a client enables DHCP Inform, it must have a static IP address configured on the specified VLAN interface. Additional parameters are requested by sending a DHCP Inform packet with a parameter request list option. Once the DHCP server receives this DHCP Inform packet, it replies with a DHCP “ack” packet with the supported option parameters.
- ◆ Only Option 3 (router) and Option 6 (domain name server) is supported for client configuration via DHCP Inform.
- ◆ If DHCP Inform is enabled when an interface’s address mode is not user configured or no IP address is configured, a warning message is displayed.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip dhcp inform
Console(config-if)#
```

**ip dhcp restart client** This command submits a DHCP client request.

#### Default Setting

None

#### Command Mode

Privileged Exec

#### Command Usage

- ◆ This command issues a DHCP client request for any IP interface that has been set to DHCP mode through the [ip address](#) command.
- ◆ DHCP requires the server to reassign the client's last address if available.
- ◆ If the DHCP server has been moved to a different domain, the network portion of the address provided to the client will be based on this new domain.

#### Example

In the following example, the device is reassigned the same address.

```
Console(config)#interface vlan 1
Console(config-if)#ip address dhcp
Console(config-if)#exit
Console#ip dhcp restart client
Console#show ip interface
VLAN 1 is Administrative Up - Link Up
  Address is 00-E0-00-00-00-01
  Index: 1001, MTU: 1500
  Address Mode is DHCP
  IP Address: 192.168.0.2 Mask: 255.255.255.0
  Proxy ARP is disabled
  DHCP Client Vendor Class ID (text): ECS4650-54P
  DHCP Inform is disabled
  DHCP Relay Server:
Console#
```

#### Related Commands

[ip address \(934\)](#)

**show ip dhcp dynamic-provision** This command shows the status of dynamic provision via DHCP.

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip dhcp dynamic-provision
Dynamic Provision via DHCP Status: Disabled
Console#
```

## DHCP for IPv6

**ipv6 dhcp client rapid-commit vlan** This command specifies the Rapid Commit option for DHCPv6 message exchange for all DHCPv6 client requests submitted from the specified interface. Use the **no** form to disable this option.

### Syntax

**[no] ipv6 dhcp client rapid-commit vlan** *vlan-list*

*vlan-list* - VLAN ID, specified as a single number, a range of consecutive numbers separated by a hyphen, or multiple numbers separated by commas. (Range: 1-4094; Maximum command length: 300 characters)

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ DHCPv6 clients can obtain configuration parameters from a server through a normal four-message exchange (solicit, advertise, request, reply), or through a rapid two-message exchange (solicit, reply). The rapid-commit option must be enabled on both client and server for the two-message exchange to be used.
- ◆ This command allows two-message exchange method for prefix delegation. When enabled, DHCPv6 client requests submitted from the specified interface will include the rapid commit option in all solicit messages.
- ◆ If the rapid commit option has been enabled on the switch with this command, and on the DHCPv6 server, message exchange can be reduced from the normal four step process to a two-step exchange of only solicit and reply messages.

### Example

```
Console(config)#ipv6 dhcp client rapid-commit vlan 2
Console(config)#
```

**ipv6 dhcp restart client vlan** This command submits a DHCPv6 client request.

### Syntax

**ipv6 dhcp restart client vlan** *vlan-id*

*vlan-id* - VLAN ID, specified as a single number, a range of consecutive numbers separated by a hyphen, or multiple numbers separated by commas. (Range: 1-4094; Maximum command length: 300 characters)

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ This command starts the DHCPv6 client process if it is not yet running by submitting requests for configuration information through the specified interface(s). When DHCPv6 is restarted, the switch may attempt to acquire an IP address prefix through stateful address auto-configuration. If the router advertisements have the “other stateful configuration” flag set, the switch may also attempt to acquire other non-address configuration information (such as a default gateway or DNS server) when DHCPv6 is restarted.

Prior to submitting a client request to a DHCPv6 server, the switch should be configured with a link-local address using the [ipv6 address autoconfig](#) command. The state of the Managed Address Configuration flag (M flag) and Other Stateful Configuration flag (O flag) received in Router Advertisement messages will determine the information this switch should attempt to acquire from the DHCPv6 server as described below.

- Both M and O flags are set to 1:  
DHCPv6 is used for both address and other configuration settings.  
This combination is known as DHCPv6 stateful, in which a DHCPv6 server assigns stateful addresses to IPv6 hosts.
- The M flag is set to 0, and the O flag is set to 1:  
DHCPv6 is used only for other configuration settings.  
Neighboring routers are configured to advertise non-link-local address prefixes from which IPv6 hosts derive stateless addresses.  
This combination is known as DHCPv6 stateless, in which a DHCPv6 server does not assign stateful addresses to IPv6 hosts, but does assign stateless configuration settings.
- ◆ DHCPv6 clients build a list of servers by sending a solicit message and collecting advertised message replies. These servers are then ranked based on their advertised preference value. If the client needs to acquire prefixes from servers, only servers that have advertised prefixes are considered.
- ◆ If the rapid commit option has been enabled on the switch using the [ipv6 dhcp client rapid-commit vlan](#) command, and on the DHCPv6 server, message exchange can be reduced from the normal four step process to a two-step exchange of only solicit and reply messages.

### Example

The following command submits a client request on VLAN 1.

```
Console#ipv6 dhcp restart client vlan 1
Console#
```

### Related Commands

[ipv6 address autoconfig \(953\)](#)

**ipv6 dhcp dynamic-provision** This command enables dynamic provisioning via DHCPv6. Use the **no** form to disable this feature.

### Syntax

**[no] ipv6 dhcp dynamic-provision**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ DHCPD is the daemon used by Linux to dynamically configure TCP/IP information for client systems. To support DHCPv6 options 59 and 60, you have to add corresponding statements to the configuration file of DHCPD. Information on how to complete this process are described in [“Downloading a Configuration File and Other Parameters from a DHCP Server” on page 76](#).
- ◆ The DHCPv6 options (59/60) for dynamic provision are described in RFC5970.

### Example

In the following example enables DHCPv6 dynamic provisioning.

```
Console(config)#ipv6 dhcp dynamic-provision
Console(config)#
```

**show ipv6 dhcp duid** This command shows the DHCP Unique Identifier for this switch.

### Command Mode

Privileged Exec

### Command Usage

DHCPv6 clients and servers are identified by a DHCP Unique Identifier (DUID) included in the client identifier and server identifier options. Static or dynamic address prefixes may be assigned by a DHCPv6 server based on the client's DUID.

### Example

```
Console#show ipv6 dhcp duid
DHCPv6 Unique Identifier (DUID): 0001-0001-4A8158B4-00E00C0000FD
Console#
```

**show ipv6 dhcp vlan** This command shows DHCPv6 information for the specified interface(s).

### Syntax

**show ipv6 dhcp vlan** *vlan-list*

*vlan-list* - VLAN ID, specified as a single number, a range of consecutive numbers separated by a hyphen, or multiple numbers separated by commas. (Range: 1-4094; Maximum command length: 300 characters)

### Command Mode

Privileged Exec

### Command Usage

Each allocation in the DHCPv6 server is identified by a DUID and an IAID. IAID means Interface Association Identifier, and is a binding between the interface and one or more IP addresses.

### Example

```
Console#show ipv6 dhcp vlan 1
VLAN 1 is in DHCP client mode, Rapid-Commit
IAID:                                C0000F0
List of known servers:
Server address : FE80::250:FCFF:FEF9:A494
DUID           : 0001-0001-48CFB0D5-F48F2A006801

Server address : FE80::250:FCFF:FEF9:A405
DUID           : 0001-0001-38CF5AB0-F48F2A003917
Console#
```

### Related Commands

[ipv6 address \(952\)](#)

**show ipv6 dhcp dynamic-provision** This command shows the status of dynamic provision via DHCPv6.

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 dhcp dynamic-provision
Dynamic Provision via DHCPv6 Status: Disabled
Console#
```

## DHCP Relay

This section describes commands used to configure the switch to relay DHCP requests from local hosts to a remote DHCP server.

**Table 188: DHCP Relay Commands**

Command	Function	Mode
<i>Global DHCP Relay Settings</i>		
<code>ip dhcp relay server</code>	Specifies DHCP server or relay server addresses	IC
<code>ip dhcp restart relay</code>	Enables DHCP relay agent	PE
<code>show ip dhcp relay</code>	Show the switch's global DHCP Relay setting - L2 or L3	PE
<i>L3 DHCP Relay Option Settings</i>		
<code>ip dhcp relay information option</code>	Enables information 82 option to be inserted into the client requests when utilizing L3 DHCP relay.	GC
<code>ip dhcp relay information option encode no-subtype</code>	Disables the sub-type and sub-length sub-options of the information 82 option.	GC
<code>ip dhcp relay information option remote-id</code>	Sets the Remote ID sub-option	GC
<code>ip dhcp relay information policy</code>	Sets the information 82 forwarding policy for DHCP Relay.	GC
<i>DHCP Relay for IPv6</i>		
<code>ipv6 dhcp relay destination</code>	Specifies a DHCPv6 server or VLAN to which client requests are forwarded and enables DHCPv6 relay service	IC
<code>show ipv6 dhcp relay destination</code>	Displays a DHCPv6 server or VLAN to which client requests are forwarded	PE

### Global DHCP Relay settings

**ip dhcp relay server** This command specifies the DHCP server or relay server addresses to use. Use the **no** form to clear all addresses.

#### Syntax

**ip dhcp relay server** *address1* [*address2* [*address3* [*address4* [*address5*]]]]

**no ip dhcp relay server**

*address* - IP address of DHCP server. (Range: 1-5 addresses)

### Default Setting

None

### Command Mode

Interface Configuration (VLAN)

### Usage Guidelines

- ◆ DHCP relay service applies to DHCP client requests received on any configured VLAN, both the management VLAN and non-management VLANs.
- ◆ This command is used to configure DHCP relay for host devices attached to the switch. If DHCP relay service is enabled (using the [ip dhcp relay information option](#) command), and this switch sees a DHCP client request, it inserts its own IP address into the request so that the DHCP server will know the subnet where the client is located. Then, the switch forwards the packet to a DHCP server on another network. When the server receives the DHCP request, it allocates a free IP address for the DHCP client from its defined scope for the DHCP client's subnet, and sends a DHCP response back to the DHCP relay agent (i.e., this switch). This switch then passes the DHCP response received from the server to the client.
- ◆ You must specify the IP address for at least one active DHCP server. Otherwise, the switch's DHCP relay agent will not be able to forward client requests to a DHCP server. Up to five DHCP servers can be specified in order of preference.  
  
If any of the specified DHCP server addresses are not located in the same network segment with this switch, use the [ip default-gateway](#) or [ipv6 default-gateway](#) command to specify the default router through which this switch can reach other IP subnetworks.
- ◆ To start the DHCP relay service, enter the [ip dhcp restart relay](#) command.

### Example

```
Console(config-if)#ip dhcp relay server 192.168.10.19  
Console(config-if)#
```

**ip dhcp restart relay** This command enables DHCP relay for the switch. Use the **no** form to disable it.

### Syntax

**ip dhcp restart relay**

### Default Setting

Disabled

### Command Mode

Privileged Exec

### Command Usage

This command is used to configure DHCP relay functions for host devices attached to the switch. If DHCP relay service is enabled, and this switch sees a DHCP request broadcast, it inserts its own IP address into the request so the DHCP server will know the subnet where the client is located. Then, the switch forwards the packet to the DHCP server on another network. When the server receives the DHCP request, it allocates a free IP address for the DHCP client from its defined scope for the DHCP client's subnet, and sends a DHCP response back to the DHCP relay agent (i.e., this switch). This switch then broadcasts the DHCP response received from the server to the client.

### Example

In the following example, the device is reassigned the same address.

```
Console#ip dhcp restart relay
Console#show ip interface
VLAN 1 is Administrative Up - Link Up
  Address is CC-37-AB-BC-4F-FA
  Index: 1001, MTU: 1500
  Address Mode is User specified
  IP Address: 192.168.2.98 Mask: 255.255.255.0
  Proxy ARP is disabled
  DHCP Client Vendor Class ID (text): ECS4650-54P
  DHCP Inform is disabled
  DHCP Relay Server: 192.168.2.1
Console#
```

### Related Commands

[ip dhcp relay server \(911\)](#)

**show ip dhcp relay** This command displays the operational mode and parameters of the DHCP relay server.

### Syntax

**show ip dhcp relay**

### Command Mode

Privileged Exec

### Example

```
Console#show ip dhcp relay
Status of DHCP relay information:
Insertion of relay information: disabled.
DHCP option policy: drop.
DHCP sub-option format: extra subtype included
DHCP remote id sub-option: mac address (hex encoded)
Console#
```

## L3 DHCP Relay Option Settings

**ip dhcp relay information option** Enables the option 82 information to be relayed when the switch is set as an L3 DHCP Relay agent. Use the **no** form of the command to disable relaying option 82 information (RFC3046).

### Syntax

**ip dhcp relay information option**  
**no ip dhcp relay information option**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Usage Guidelines

This command enables the insertion of relay Option 82 information in DHCP request packets.

### Example

```
Console(config)#ip dhcp relay information option
Console(config)#
```

**ip dhcp relay information option encode no-subtype** Use this command to disable the Option 82 packets including sub-type and sub-length in both CID and RID. Use the **no** form of the command to enable including the sub-type and sub-length in both CID and RID.

### Syntax

**ip dhcp relay information option encode no-subtype**  
**no ip dhcp relay information option encode no-subtype**

### Default Setting

Sub-type and sub-length information is included.

### Command Mode

Global Configuration

### Usage Guidelines

Use this command when the Type and Length fields do not need to be relayed as part of the CID and RID in the option 82 packets.

### Example

```
Console(config)#ip dhcp relay information option encode no-subtype
Console(config)#
```

#### ip dhcp relay information option remote-id

This command sets the remote ID to the switch's IP address, MAC address, arbitrary or string. Use the **no** form to restore the default setting.

#### Syntax

```
ip dhcp relay information option remote-id
  {ip-address [encode {ascii | hex}] |
  mac-address [encode {ascii | hex}] |
  string string }
```

```
no ip dhcp relay information option remote-id
  [ip-address encode] | [mac-address encode]
```

**ip-address** - Inserts an IP address in the remote ID sub-option for the DHCP relay (that is, the IP address of the management interface).

**mac-address** - Inserts a MAC address in the remote ID sub-option for the DHCP relay (that is, the MAC address of the switch's CPU).

**encode** - Indicates encoding in ASCII or hexadecimal.

*string* - An arbitrary string inserted into the remote identifier field. (Range: 1-32 characters)

#### Default Setting

MAC address: hexadecimal

#### Command Mode

Global Configuration

### Example

This example sets the remote ID to the switch's IP address.

```
Console(config)#ip dhcp relay information option remote-id ip-address
Console(config)#
```

#### ip dhcp relay information policy

This command sets the Option 82 Information forwarding policy of the switch's DHCP Relay service. Use the **no** form of the command to set the policy to the default setting.

#### Syntax

```
ip dhcp relay information policy {drop | keep | replace}
no ip dhcp relay information policy
```

**drop** - Do not relay the DHCP request packet.

**keep** - Retain the original CID and RID in the Option 82 information of the DHCP request.

**replace** - Replace the CID and RID of the Option 82 information with the relay agent switch address information.

### Default Setting

drop

### Command Mode

Global Configuration

### Usage Guidelines

- ◆ If set to **drop**, the original DHCP request packet flooded to the receiving VLAN is received but not relayed to the DHCP server.
- ◆ When the **replace** policy is set, the DHCP request packet's Option 82 content (RID and CID sub-option) is replaced with the relay agent switch's address information. The agent then unicasts the modified DHCP Request packet to the DHCP server.
- ◆ When set to the **keep** option the DHCP request packet's Option 82 content is unmodified. However the switch address information of the relay agent is additionally added into the DHCP request packet. The agent finally unicasts the modified DHCP Request packet including the original RID and CID to the DHCP server.

### Example

```
Console(config)#ip dhcp relay information policy keep
Console(config)#
```

## DHCP Relay for IPv6

**ipv6 dhcp relay destination** This command specifies a DHCPv6 server or the VLAN to which client requests are forwarded, and also enables DHCPv6 relay service on this interface. Use the **no** form to disable this service.

### Syntax

**ipv6 dhcp relay destination** {*ipv6-address* | **multicast** {**all** | **vlan** *vlan-id*}}

**no ipv6 dhcp relay destination** [*ipv6-address* | **multicast** {**all** | **vlan** *vlan-id*}]

*ipv6-address* - A full IPv6 address including the network prefix and host address bits. This address may designate another relay server or a DHCPv6 server.

**multicast** - All DHCP server multicast address (FF:05::1:3).

**all** - Specifies all local VLAN interfaces.

*vlan-id* - ID of configured VLAN. (Range: 1-4094)

### Default Setting

None

### Command Mode

Interface Configuration (VLAN)

### Usage Guidelines

- ◆ You must specify the IPv6 address for at least one DHCPv6 server or another relay agent, or the VLAN to which to multicast a relay message. Otherwise, the switch's DHCPv6 relay agent will not forward client requests. This command enables DHCPv6 relay service for the VLAN from which the command is entered.
- ◆ Up to five destination addresses may be defined using consecutive commands.
- ◆ This command is used to configure DHCPv6 relay functions for host devices attached to the switch. If DHCPv6 relay service is enabled (by entering this command), and this switch sees a DHCPv6 request broadcast, it inserts its own IP address into the request so the DHCPv6 server will know the subnet where the client is located. Then, the switch forwards the packet to the next relay agent or DHCPv6 server on another network. When the server receives the DHCPv6 request, it allocates a free IP address for the DHCPv6 client from its defined scope for the DHCPv6 client's subnet, and sends a DHCPv6 response back to the DHCPv6 relay agent (i.e., this switch). This switch then broadcasts the DHCPv6 response received from the server to the client.
- ◆ When the multicast option is used, the switch multicasts the modified client request to all configured VLANs or to a specified VLAN, and enables DHCPv6 relay service for those VLANs.
- ◆ Up to five relay destinations may be configured by repeating this command.
- ◆ When issuing the **no ipv6 dhcp relay destination** command without any arguments, the switch will delete all configured destination addresses and disable DHCP for IPv6 relay for all VLANs.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 dhcp relay destination 2001:0DB8:3000:3000::42
Console(config-if)#
```

**show ipv6 dhcp relay destination** This command shows the destination addresses or VLAN to which client messages are forwarded for DHCP relay service.

### Syntax

**show ipv6 dhcp relay destination interface [vlan *vlan-id*]**

*vlan-id* - VLAN ID (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 dhcp relay destination interface vlan 1
DHCP relay destination :
VLAN 1 :
  Unicast   : 2001:DB8:3000:3000::42
Console#
```

## DHCP Server

This section describes commands used to configure client address pools for the DHCP service.

**Table 189: DHCP Server Commands**

Command	Function	Mode
<a href="#">ip dhcp excluded-address</a>	Specifies IP addresses that a DHCP server should not assign to DHCP clients	GC
<a href="#">ip dhcp pool</a>	Configures a DHCP address pool on a DHCP Server	GC
<a href="#">service dhcp</a>	Enables the DHCP server feature on this switch	GC
<a href="#">bootfile</a>	Specifies a default boot image for a DHCP client	DC
<a href="#">client-identifier*</a>	Specifies a client identifier for a DHCP client	DC
<a href="#">default-router</a>	Specifies the default router list for a DHCP client	DC
<a href="#">dns-server</a>	Specifies the Domain Name Server (DNS) servers available to a DHCP client	DC
<a href="#">domain-name</a>	Specifies the domain name for a DHCP client	DC
<a href="#">hardware-address*</a>	Specifies the hardware address of a DHCP client	DC
<a href="#">host*</a>	Specifies the IP address and network mask to manually bind to a DHCP client	DC
<a href="#">lease</a>	Sets the duration an IP address is assigned to a DHCP client	DC
<a href="#">netbios-name-server</a>	Configures NetBIOS Windows Internet Naming Service (WINS) name servers available to Microsoft DHCP clients	DC
<a href="#">netbios-node-type</a>	Configures NetBIOS node type for Microsoft DHCP clients	DC
<a href="#">network</a>	Configures the subnet number and mask for a DHCP address pool	DC

Table 189: DHCP Server Commands (Continued)

Command	Function	Mode
<code>next-server</code>	Configures the next server in the boot process of a DHCP client	DC
<code>option</code>	Sets DHCP option details	DC
<code>clear ip dhcp binding</code>	Deletes an automatic address binding from the DHCP server database	PE
<code>show ip dhcp binding</code>	Displays address bindings on the DHCP server	PE, NE
<code>show ip dhcp</code>	Displays DHCP address pools	PE
<code>show ip dhcp pool</code>	Displays detailed information of DHCP address pools	PE

\* These commands are used for manually binding an address to a client.

**ip dhcp excluded-address** This command specifies IP addresses that the DHCP server should not assign to DHCP clients. Use the **no** form to remove the excluded IP addresses.

#### Syntax

**[no] ip dhcp excluded-address** *low-address* [*high-address*]

*low-address* - An excluded IP address, or the first IP address in an excluded address range.

*high-address* - The last IP address in an excluded address range.

#### Default Setting

All IP pool addresses may be assigned.

#### Command Mode

Global Configuration

#### Example

```
Console(config)#ip dhcp excluded-address 10.1.0.19
Console(config)#
```

**ip dhcp pool** This command configures a DHCP address pool and enter DHCP Pool Configuration mode. Use the **no** form to remove the address pool.

#### Syntax

**[no] ip dhcp pool** *name*

*name* - A string or integer. (Range: 1-32 characters)

#### Default Setting

DHCP address pools are not configured.

### Command Mode

Global Configuration

### Usage Guidelines

- ◆ After executing this command, the switch changes to DHCP Pool Configuration mode, identified by the (config-dhcp)# prompt.
- ◆ From this mode, first configure address pools for the network interfaces (using the [network](#) command). You can also manually bind an address to a specific client (with the [host](#) command) if required. You can configure up to 8 network address pools, and up to 32 manually bound host address pools (i.e., listing one host address per pool). However, note that any address specified in a [host](#) command must fall within the range of a configured network address pool.

### Example

```
Console(config)#ip dhcp pool R&D
Console(config-dhcp)#
```

### Related Commands

[network \(928\)](#)

[host \(924\)](#)

**service dhcp** This command enables the DHCP server on this switch. Use the **no** form to disable the DHCP server.

### Syntax

```
[no] service dhcp
```

### Default Setting

Enabled

### Command Mode

Global Configuration

### Command Usage

If the DHCP server is running, you must restart it to implement any configuration changes.

### Example

```
Console(config)#service dhcp
Console(config)#
```

**bootfile** This command specifies the name of the default boot image for a DHCP client. This file should be placed on the Trivial File Transfer Protocol (TFTP) server specified with the [next-server](#) command. Use the **no** form to delete the boot image name.

#### Syntax

**bootfile** *filename*

**no bootfile**

*filename* - Name of the file that is used as a default boot image. (Range: 1 to 128 characters)

#### Default Setting

None

#### Command Mode

DHCP Pool Configuration

#### Example

```
Console(config-dhcp)#bootfile wme.bat  
Console(config-dhcp)#
```

#### Related Commands

[next-server \(929\)](#)

**client-identifier** This command specifies the client identifier of a DHCP client. Use the **no** form to remove the client identifier.

#### Syntax

**client-identifier** {**text** *text* | **hex** *hex*}

**no client-identifier**

*text* - A text string. (Range: 1-32 characters)

*hex* - The hexadecimal value.

#### Default Setting

None

#### Command Mode

DHCP Pool Configuration

#### Command Usage

- ◆ This command identifies a DHCP client to bind to an address specified in the [host](#) command. If both a client identifier and hardware address are configured for a host address, the client identifier takes precedence over the hardware address in the search procedure.

- ◆ BOOTP clients cannot transmit a client identifier. To bind an address to a BOOTP client, you must associate a hardware address with the host entry.

### Example

```
Console(config-dhcp)#client-identifier text steve
Console(config-dhcp)#
```

### Related Commands

[host \(924\)](#)

**default-router** This command specifies default routers for a DHCP pool. Use the **no** form to remove the default routers.

### Syntax

**default-router** { *address1* [*address2*] | **bootfile** *filename*}

**no default-router**

*address1* - Specifies the IP address of the primary router.

*address2* - Specifies the IP address of an alternate router.

**bootfile** *filename* - specifies the boot file name. (Range: 1-128 characters)

### Default Setting

None

### Command Mode

DHCP Pool Configuration

### Usage Guidelines

The IP address of the router should be on the same subnet as the client. You can specify up to two routers. Routers are listed in order of preference (starting with *address1* as the most preferred router).

### Example

```
Console(config-dhcp)#default-router 10.1.0.54 10.1.0.64
Console(config-dhcp)#
```

**dns-server** This command specifies the Domain Name System (DNS) IP servers available to a DHCP client. Use the **no** form to remove the DNS server list.

### Syntax

**dns-server** *address1* [*address2*]

**no dns-server**

*address1* - Specifies the IP address of the primary DNS server.

*address2* - Specifies the IP address of the alternate DNS server.

### Default Setting

None

### Command Mode

DHCP Pool Configuration

### Usage Guidelines

- ◆ If DNS IP servers are not configured for a DHCP client, the client cannot correlate host names to IP addresses.
- ◆ Servers are listed in order of preference (starting with *address1* as the most preferred server).

### Example

```
Console(config-dhcp)#dns-server 10.1.1.253 192.168.3.19
Console(config-dhcp)#
```

**domain-name** This command specifies the domain name for a DHCP client. Use the **no** form to remove the domain name.

### Syntax

**domain-name** *domain*

**no domain-name**

*domain* - Specifies the domain name of the client.  
(Range: 1-128 characters)

### Default Setting

None

### Command Mode

DHCP Pool Configuration

### Example

```
Console(config-dhcp)#domain-name sample.com  
Console(config-dhcp)#
```

**hardware-address** This command specifies the hardware address of a DHCP client. This command is valid for manual bindings only. Use the **no** form to remove the hardware address.

### Syntax

**hardware-address** *hardware-address type*

**no hardware-address**

*hardware-address* - Specifies the MAC address of the client device.

*type* - Indicates the following protocol used on the client device:

- ethernet
- ieee802

### Default Setting

If no type is specified, the default protocol is Ethernet.

### Command Mode

DHCP Pool Configuration

### Command Usage

This command identifies a DHCP or BOOTP client to bind to an address specified in the **host** command. BOOTP clients cannot transmit a client identifier. To bind an address to a BOOTP client, you must associate a hardware address with the host entry.

### Example

```
Console(config-dhcp)#hardware-address 00-e0-29-94-34-28 ethernet  
Console(config-dhcp)#
```

### Related Commands

[host \(924\)](#)

**host** Use this command to specify the IP address and network mask to manually bind to a DHCP client. Use the **no** form to remove the IP address for the client.

### Syntax

**host** *address [mask]*

**no host**

*address* - Specifies the IP address of a client.

*mask* - Specifies the network mask of the client.

### Default Setting

None

### Command Mode

DHCP Pool Configuration

### Usage Guidelines

- ◆ Host addresses must fall within the range specified for an existing network pool.
- ◆ When a client request is received, the switch first checks for a network address pool matching the gateway where the request originated (i.e., if the request was forwarded by a relay server). If there is no gateway in the client request (i.e., the request was not forwarded by a relay server), the switch searches for a network pool matching the interface through which the client request was received. It then searches for a manually configured host address that falls within the matching network pool.
- ◆ When searching for a manual binding, the switch compares the client identifier for DHCP clients, and then compares the hardware address for DHCP or BOOTP clients.
- ◆ If no manual binding has been specified for a host entry with the [client-identifier](#) or [hardware-address](#) commands, then the switch will assign an address from the matching network pool.
- ◆ If the mask is unspecified, DHCP examines its address pools. If no mask is found in the pool database, the Class A, B, or C natural mask is used (see [page 928](#)). This command is valid for manual bindings only.
- ◆ The **no host** command only clears the address from the DHCP server database. It does not cancel the IP address currently in use by the host.

### Example

```
Console(config-dhcp)#host 10.1.0.21 255.255.255.0
Console(config-dhcp)#
```

### Related Commands

[client-identifier \(921\)](#)

[hardware-address \(924\)](#)

**lease** This command configures the duration that an IP address is assigned to a DHCP client. Use the **no** form to restore the default value.

### Syntax

**lease** {*days* [*hours*] [*minutes*] | **infinite**}

#### **no lease**

*days* - Specifies the duration of the lease in numbers of days. (Range: 0-365)

*hours* - Specifies the number of hours in the lease. A *days* value must be supplied before you can configure *hours*. (Range: 0-23)

*minutes* - Specifies the number of minutes in the lease. A *days* and *hours* value must be supplied before you can configure *minutes*. (Range: 0-59)

**infinite** - Specifies that the lease time is unlimited. This option is normally used for addresses manually bound to a BOOTP client via the **host** command.

### Default Setting

One day

### Command Modes

DHCP Pool Configuration

### Example

The following example leases an address to clients using this pool for 7 days.

```
Console(config-dhcp)#lease 7
Console(config-dhcp)#
```

**netbios-name-server** This command configures NetBIOS Windows Internet Naming Service (WINS) name servers that are available to Microsoft DHCP clients. Use the **no** form to remove the NetBIOS name server list.

### Syntax

**netbios-name-server** *address1* [*address2*]

#### **no netbios-name-server**

*address1* - Specifies IP address of primary NetBIOS WINS name server.

*address2* - Specifies IP address of alternate NetBIOS WINS name server.

### Default Setting

None

### Command Mode

DHCP Pool Configuration

### Usage Guidelines

Servers are listed in order of preference (starting with *address1* as the most preferred server).

### Example

```
Console(config-dhcp)#netbios-name-server 10.1.0.33 10.1.0.34
Console(config-dhcp)#
```

### Related Commands

[netbios-node-type \(927\)](#)

**netbios-node-type** This command configures the NetBIOS node type for Microsoft DHCP clients. Use the **no** form to remove the NetBIOS node type.

### Syntax

**netbios-node-type** *type*

**no netbios-node-type**

*type* - Specifies the NetBIOS node type:

**broadcast**

**hybrid** (recommended)

**mixed**

**peer-to-peer**

### Default Setting

None

### Command Mode

DHCP Pool Configuration

### Example

```
Console(config-dhcp)#netbios-node-type hybrid
Console(config-dhcp)#
```

### Related Commands

[netbios-name-server \(926\)](#)

**network** This command configures the subnet number and mask for a DHCP address pool. Use the **no** form to remove the subnet number and mask.

### Syntax

**network** *network-number* [*mask*]

**no network**

*network-number* - The IP address of the DHCP address pool.

*mask* - The bit combination that identifies the network (or subnet) and the host portion of the DHCP address pool.

### Command Mode

DHCP Pool Configuration

### Usage Guidelines

- ◆ When a client request is received, the switch first checks for a network address pool matching the gateway where the request originated (i.e., if the request was forwarded by a relay server). If there is no gateway in the client request (i.e., the request was not forwarded by a relay server), the switch searches for a network pool matching the interface through which the client request was received. It then searches for a manually configured host address that falls within the matching network pool. If no manually configured host address is found, it assigns an address from the matching network address pool. However, if no matching address pool is found the request is ignored.
- ◆ This command is valid for DHCP network address pools only. If the mask is not specified, the class A, B, or C natural mask is used. Subnet addresses are interpreted as class A, B or C, based on the first field in the specified address. In other words, if a subnet address *nnn.xxx.xxx.xxx* is entered, the first field (*nnn*) determines the class:
  - 0 - 127 is class A, only uses the first field in the network address.
  - 128 - 191 is class B, uses the first two fields in the network address.
  - 192 - 223 is class C, uses the first three fields in the network address.
- ◆ The DHCP server assumes that all host addresses are available. You can exclude subsets of the address space by using the `ip dhcp excluded-address` command.

### Example

```
Console(config-dhcp)#network 10.1.0.0 255.255.255.0  
Console(config-dhcp)#
```

**next-server** This command configures the next server in the boot process of a DHCP client. Use the **no** form to remove the boot server list.

### Syntax

**[no] next-server** *address*

*address* - Specifies the IP address of the next server in the boot process, which is typically a Trivial File Transfer Protocol (TFTP) server.

### Default Setting

None

### Command Mode

DHCP Pool Configuration

### Example

```
Console(config-dhcp)#next-server 10.1.0.21
Console(config-dhcp)#
```

### Related Commands

[bootfile \(921\)](#)

**option** Use this command to enable DHCP options. Use the **no** form of the command to disable DHCP options.

### Syntax

**option** *code* {**ascii** *word* | **hex** *hex-value* | **ip-address** *address1*[*address2* [*address3*[ *address 4*]]]}

*code* - A DHCP option code (Range: 0-254).

**ascii** *word* - ASCII character string representing a network device (Range: 1-48 ASCII characters).

**hex** *hex-value* - A concatenated hex number string of up to 4 IPv4 addresses in hex format each representing a network device.

**ip-address** *address* - up to 4 IPv4 addresses can be entered sequentially with blank spaces between. Each address represents a device in the network.

### Default:

Disabled

### Command Mode:

DHCP Pool Configuration

### Command Usage:

To convert IPv4 address to a hex number string, each octet of the address is individually converted to hex and then all four hex values obtained concatenated. Take for example the address 192.168.2.1, 192= $c0_{16}$ , 168= $a8_{16}$ , 2= $02_{16}$ , and 1= $01_{16}$  resulting in  $c0a80201_{16}$  as the hex value for the IPv4 address.

### Example

In this example network devices 192.168.2.1 and 192.168.3.1 are entered in hex format using the **option** command.

```
Console(config-dhcp)#option 43 hex c0a802021c0a80301
Console(config-dhcp)#
```

**clear ip dhcp binding** This command deletes an automatic address binding from the DHCP server database.

### Syntax

**clear ip dhcp binding** [*address*]

*address* - The address of the binding to clear.

### Default Setting

None

### Command Mode

Privileged Exec

### Usage Guidelines

- ◆ An *address* specifies the client's IP address. If no ip address is specified, the DHCP server clears all automatic bindings.
- ◆ Use the **no host** command to delete a manual binding.
- ◆ This command is normally used after modifying the address pool, or after moving DHCP service to another device.

### Example.

```
Console#clear ip dhcp binding
Console
```

### Related Commands

**show ip dhcp binding (931)**

**show ip dhcp binding** This command displays address bindings on the DHCP server.

### Syntax

**show ip dhcp binding** [*address*]

*address* - Specifies the IP address of the DHCP client for which bindings will be displayed.

### Default Setting

None

### Command Mode

Normal Exec, Privileged Exec

### Example

```

Console#show ip dhcp binding

      IP                MAC                Lease Time          Start
      -----
      192.1.1.3.21  00-00-e8-98-73-21          86400  Dec 25 08:01:57 2002

Total entries : 1
Console#

```

**show ip dhcp** This command displays DHCP address pools configured on the switch.

### Command Mode

Privileged Exec

### Example

```

Console#show ip dhcp

      Name   Type   IP Address          Mask                Active Pool
      -----
      tps    Net   192.168.1.0         255.255.255.0       192.168.1.1 - 192.168.1.254

Total entry : 1
Console#

```

**show ip dhcp pool** This command displays the detailed configuration information of DHCP address pools on the switch.

### Command Mode

Privileged Exec

### Example

```
Console#show ip dhcp pool
Pool name : officea
Pool type : Network
  Network address      : 192.168.3.1

  Subnet mask         : 255.255.255.0

  Boot file           :
  Client identifier mode : Hex
  Client identifier   :
  Default router      : 10.2.3.4
                     : 0.0.0.0
  DNS server          : 192.168.4.4
                     : 0.0.0.0
  Domain name         : officeA
  Hardware type       : None
  Hardware address    : 00-00-00-00-00-00
  Lease time          : 1 d/ 0 h/ 0 m
  Netbios name server : 0.0.0.0
                     : 0.0.0.0
  Netbios node type   : Hybrid
  Next server         : 192.168.5.1
```

```
Console#
```

# IP Interface Commands

An IP Version 4 and Version 6 address may be used for management access to the switch over the network. Both IPv4 or IPv6 addresses can be used simultaneously to access the switch. You can manually configure a specific IPv4 or IPv6 address or direct the switch to obtain an IPv4 address from a BOOTP or DHCP server when it is powered on. An IPv6 address can either be manually configured or dynamically generated.

The IPv4 address for VLAN 1 on this switch is set to 192.168.2.10 by default. You may also need to establish an IPv4 or IPv6 default gateway between this device and management stations that exist on another network segment.

**Table 190: IP Interface Commands**

Command Group	Function
<a href="#">IPv4 Interface</a>	Configures an IPv4 address for the switch
<a href="#">IPv6 Interface</a>	Configures an IPv6 address for the switch
<a href="#">ND Snooping</a>	Maintains IPv6 prefix table and user address binding table which can be used for stateless address auto-configuration or for address filtering by IPv6 Source Guard

## IPv4 Interface

An initial IPv4 address of 192.168.2.10 is assigned to VLAN 1 on this switch by default. If this address is not suitable, you can manually configure a new address to manage the switch over your network or to connect the switch to existing IP subnets. You may also need to establish a default gateway between this device and management stations or other devices that exist on another network segment (if routing is not enabled).

This section includes commands for configuring IP interfaces, the Address Resolution Protocol (ARP) and Proxy ARP, and UDP Helper.

**Table 191: IPv4 Interface Commands**

Command Group	Function
<a href="#">Basic IPv4 Configuration</a>	Configures the IP address for interfaces and the gateway router
<a href="#">ARP Configuration</a>	Configures static, dynamic and proxy ARP service
<a href="#">UDP Helper Configuration</a>	Forwards UDP broadcast packets to a specified server

**Basic IPv4 Configuration** This section describes commands used to configure IP addresses for VLAN interfaces on the switch.

**Table 192: Basic IP Configuration Commands**

Command	Function	Mode
<a href="#">ip address</a>	Sets the IP address for the current interface	IC
<a href="#">ip default-gateway</a>	Defines the default gateway through which this switch can reach other subnetworks	GC
<a href="#">interface loopback</a>	Configures a loopback interface and enters interface loopback configuration mode	GC
<a href="#">ip address (loopback)</a>	Sets an IP address for the loopback interface	IC
<a href="#">show ip interface</a>	Displays the IP settings for this device	PE
<a href="#">show ip route</a>	Displays specified entries in the routing table	PE
<a href="#">show ip traffic</a>	Displays statistics for IP, ICMP, UDP, TCP and ARP protocols	PE
<a href="#">traceroute</a>	Shows the route packets take to the specified host	PE
<a href="#">ping</a>	Sends ICMP echo request packets to another node on the network	NE, PE

**ip address** This command sets the IPv4 address for the currently selected VLAN interface. Use the **no** form to remove an IP address.

### Syntax

**ip address** *{ip-address netmask [secondary]*  
*[default-gateway ip-address] | bootp | dhcp}*

**no ip address** *[ip-address netmask [secondary] | dhcp]*

*ip-address* - IP address

*netmask* - Network mask for the associated IP subnet. This mask identifies the host address bits used for routing to specific subnets. The network mask can use either the traditional format xxx.xxx.xxx.xxx or classless format with the range /5 to /32. For example the subnet 255.255.224.0 would be /19.

**secondary** - Specifies a secondary IP address.

**default-gateway** - The default gateway. (Refer to the [ip default-gateway](#) command which provides the same function.)

**bootp** - Obtains IP address from BOOTP.

**dhcp** - Obtains IP address from DHCP.

### Default Setting

192.168.2.10/24

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Before any network interfaces are configured on the router, first create a VLAN for each unique user group, or for each network application and its associated users. Then assign the ports associated with each of these VLANs.
- ◆ An IP address must be assigned to this device to gain management access over the network or to connect the router to existing IP subnets. A specific IP address can be manually configured, or the router can be directed to obtain an address from a BOOTP or DHCP server. Valid IP addresses consist of four numbers, 0 to 255, separated by periods. Anything other than this format will not be accepted by the configuration program.
- ◆ An interface can have only one primary IP address, but can have many secondary IP addresses. In other words, secondary addresses need to be specified if more than one IP subnet can be accessed through this interface. Note that a secondary address cannot be configured prior to setting the primary IP address, and the primary address cannot be removed if a secondary address is still present. Also, if any router/switch in a network segment uses a secondary address, all other routers/switches in that segment must also use a secondary address from the same network or subnet address space.
- ◆ If **bootp** or **dhcp** options are selected, the system will immediately start broadcasting service requests for all VLANs configured to obtain address assignments through BOOTP or DHCP. IP is enabled but will not function until a BOOTP or DHCP reply has been received. Requests are broadcast periodically by the router in an effort to learn its IP address. (BOOTP and DHCP values can include the IP address, default gateway, and subnet mask). If the DHCP/BOOTP server is slow to respond, you may need to use the `ip dhcp restart client` command to re-start broadcasting service requests, or reboot the switch.



**Note:** Each VLAN group can be assigned its own IP interface address. You can manage the switch via any of these IP addresses.

### Example

In the following example, the device is assigned an address in VLAN 1.

```
Console(config)#interface vlan 1
Console(config-if)#ip address 192.168.1.5 255.255.255.0
Console(config-if)#
```

This example assigns an IP address to VLAN 2 using a classless network mask.

```
Console(config)#interface vlan 2
Console(config-if)#ip address 10.2.2.1/24
Console(config-if)#
```

### Related Commands

[ip dhcp restart client \(906\)](#)  
[ip default-gateway \(936\)](#)  
[ipv6 address \(952\)](#)

**ip default-gateway** This command specifies the default gateway for destinations not found in local routing tables. Use the **no** form to remove a default gateway.

### Syntax

**ip default-gateway** *gateway*

**no ip default-gateway**

*gateway* - IP address of the default gateway

### Default Setting

No default gateway is established.

### Command Mode

Global Configuration

### Command Usage

- ◆ The default gateway can also be defined using the following Global configuration command: **ip route 0.0.0.0 0.0.0.0** *gateway-address*.
- ◆ Static routes can also be defined using the [ip route](#) command to ensure that traffic to the designated address or subnet passes through a preferred gateway.
- ◆ A default gateway can only be successfully set when a network interface that directly connects to the gateway has been configured on the router.
- ◆ The same link-local address may be used by different interfaces/nodes in different zones (RFC 4007). Therefore, when specifying a link-local address for a default gateway, include zone-id information indicating the VLAN identifier after the % delimiter. For example, FE80::7272%1 identifies VLAN 1 as the interface.

### Example

The following example defines a default gateway for this device:

```
Console(config)#ip default-gateway 192.168.2.1
Console(config)#end
Console#show ip route
Codes: C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default

S*    0.0.0.0/0 [1/0] via 192.168.2.1, VLAN1
```

```
C          192.168.2.0/24 is directly connected, VLAN1  
Console(config)#
```

### Related Commands

[ip address \(934\)](#)

[ip route \(1006\)](#)

[ipv6 default-gateway \(951\)](#)

**interface loopback** This command configures a loopback interface and enters interface loopback configuration mode. Use the **no** form to remove a loopback interface.

### Syntax

**[no] interface loopback** *interface-number*

*interface-number* - The interface number (always 0).

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

Configure a loopback interface to create an interface that is always up.

### Example

```
Console#interface loopback 0  
Console(config-if)#
```

**ip address (loopback)** This command sets the IPv4 address for the loopback interface. Use the **no** form to remove the IP address.

### Syntax

**[no] ip address** {*ip-address netmask* | *ip-address/prefix-length*}

*ip-address* - IP address

*netmask* - Network mask for the associated IP subnet. This mask identifies the host address bits used for routing to specific subnets.

*prefix-length* - The network mask specified in classless format with the range /5 to /32.

### Default Setting

None

## Command Mode

### Interface Configuration (Loopback)

### Example

```
Console#interface loopback 0
Console(config-if)#ip address 192.168.1.1 255.255.255.0
Console(config-if)#
```

**show ip interface** This command displays the settings of an IPv4 interface.

### Syntax

**show ip interface** [vlan *vlan-id*]

*vlan-id* - VLAN ID (Range: 1-4094)

## Command Mode

### Privileged Exec

### Example

```
Console#show ip interface
VLAN 1 is Administrative Up - Link Up
Address is E4-9D-73-1B-5E-00
Index: 1001, MTU: 1500
Address Mode is User specified
IP Address: 192.168.1.1 Mask: 255.255.255.0
Proxy ARP is disabled
DHCP Client Vendor Class ID (text): ECS4650-54P
DHCP Inform is disabled
DHCP Relay Server:
Console#
```

## Related Commands

[ip address \(934\)](#)

[show ipv6 interface \(961\)](#)

**show ip traffic** This command displays statistics for IP, ICMP, UDP, TCP and ARP protocols.

## Command Mode

### Privileged Exec

### Example

```
Console#show ip traffic
IP Statistics:
IP received
    7845 total received
    header errors
    unknown protocols
    address errors
```

```

discards
7845 delivers
reassembly request datagrams
reassembly succeeded
reassembly failed

IP sent
forwards datagrams
9903 requests
discards
no routes
generated fragments
fragment succeeded
fragment failed

ICMP Statistics:
ICMP received
input
errors
destination unreachable messages
time exceeded messages
parameter problem message
echo request messages
echo reply messages
redirect messages
timestamp request messages
timestamp reply messages
source quench messages
address mask request messages
address mask reply messages

ICMP sent
output
errors
destination unreachable messages
time exceeded messages
parameter problem message
echo request messages
echo reply messages
redirect messages
timestamp request messages
timestamp reply messages
source quench messages
address mask request messages
address mask reply messages

UDP Statistics:
input
no port errors
other errors
output

TCP Statistics:
7841 input
input errors
9897 output

Console#

```

**traceroute** This command shows the route packets take to the specified destination.

### Syntax

**traceroute** *host*

*host* - IP address or alias of the host.

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ Use the **traceroute** command to determine the path taken to reach a specified destination.
- ◆ A trace terminates when the destination responds, when the maximum timeout (TTL) is exceeded, or the maximum number of hops is exceeded.
- ◆ The traceroute command first sends probe datagrams with the TTL value set at one. This causes the first router to discard the datagram and return an error message. The trace function then sends several probe messages at each subsequent TTL level and displays the round-trip time for each message. Not all devices respond correctly to probes by returning an "ICMP port unreachable" message. If the timer goes off before a response is returned, the trace function prints a series of asterisks and the "Request Timed Out" message. A long sequence of these messages, terminating only when the maximum timeout has been reached, may indicate this problem with the target device.
- ◆ If the target device does not respond or other errors are detected, the switch will indicate this by one of the following messages:
  - \* - No Response
  - H - Host Unreachable
  - N - Network Unreachable
  - P - Protocol Unreachable
  - O -Other

### Example

```
Console#traceroute 192.168.0.99
Press "ESC" to abort.
Traceroute to 192.168.0.99, 30 hops max, timeout is 3 seconds
Hop  Packet 1  Packet 2  Packet 3  IP Address
-----
 1      20 ms   <10 ms   <10 ms   192.168.0.99

Trace completed.
Console#
```

**ping** This command sends (IPv4) ICMP echo request packets to another node on the network.

## Syntax

**ping** *host* [**count** *count*] [**size** *size*]

*host* - IP address or alias of the host.

*count* - Number of packets to send. (Range: 1-16)

*size* - Number of bytes in a packet. (Range: 32-512)

The actual packet size will be eight bytes larger than the size specified because the switch adds header information.

## Default Setting

count: 5

size: 32 bytes

## Command Mode

Normal Exec, Privileged Exec

## Command Usage

- ◆ Use the ping command to see if another site on the network can be reached.
- ◆ The following are some results of the **ping** command:
  - *Normal response* - The normal response occurs in one to ten seconds, depending on network traffic.
  - *Destination does not respond* - If the host does not respond, a “timeout” appears in ten seconds.
  - *Destination unreachable* - The gateway for this destination indicates that the destination is unreachable.
  - *Network or host unreachable* - The gateway found no corresponding entry in the route table.
- ◆ When pinging a host name, be sure the DNS server has been defined ([page 895](#)) and host name-to-address translation enabled ([page 893](#)). If necessary, local devices can also be specified in the DNS static host table ([page 894](#)).

## Example

```
Console#ping 10.1.0.9
Press ESC to abort.
PING to 10.1.0.9, by 5 32-byte payload ICMP packets, timeout is 5 seconds
response time: 10 ms
response time: 10 ms
response time: 10 ms
response time: 10 ms
response time: 0 ms
Ping statistics for 10.1.0.9:
 5 packets transmitted, 5 packets received (100%), 0 packets lost (0%)
Approximate round trip times:
```

```
Minimum = 0 ms, Maximum = 10 ms, Average = 8 ms  
Console#
```

## Related Commands

[interface \(423\)](#)

**ARP Configuration** This section describes commands used to configure the Address Resolution Protocol (ARP) on the switch.

**Table 193: Address Resolution Protocol Commands**

Command	Function	Mode
<a href="#">arp</a>	Adds a static entry in the ARP cache	GC
<a href="#">arp timeout</a>	Sets the time a dynamic entry remains in the ARP cache	GC
<a href="#">ip proxy-arp</a>	Enables proxy ARP service	IC
<a href="#">clear arp-cache</a>	Deletes all dynamic entries from the ARP cache	PE
<a href="#">show arp</a>	Displays entries in the ARP cache	PE

**arp** This command adds a static entry in the Address Resolution Protocol (ARP) cache. Use the **no** form to remove an entry from the cache.

### Syntax

**arp** *ip-address hardware-address*

**no arp** *ip-address*

*ip-address* - IP address to map to a specified hardware address.

*hardware-address* - Hardware address to map to a specified IP address. (The format for this address is xx-xx-xx-xx-xx-xx or xxxxxxxxxxxx.)

### Default Setting

No default entries

### Command Mode

Global Configuration

### Command Usage

- ◆ The ARP cache is used to map 32-bit IP addresses into 48-bit hardware (i.e., Media Access Control) addresses. This cache includes entries for hosts and other routers on local network interfaces defined on this router.
- ◆ The maximum number of static entries allowed in the ARP cache is 128.
- ◆ You may need to put a static entry in the cache if there is no response to an ARP broadcast message. For example, some applications may not respond to ARP

requests or the response arrives too late, causing network operations to time out.

- ◆ Static entries will not be aged out nor deleted when power is reset. A static entry can only be removed through the configuration interface.

### Example

```
Console(config)#arp 10.1.0.19 01-02-03-04-05-06
Console(config)#
```

### Related Commands

[clear arp-cache \(944\)](#)

[show arp \(945\)](#)

**arp timeout** This command sets the aging time for dynamic entries in the Address Resolution Protocol (ARP) cache. Use the **no** form to restore the default timeout.

### Syntax

**arp timeout** *seconds*

**no arp timeout**

*seconds* - The time a dynamic entry remains in the ARP cache.  
(Range: 300-86400; 86400 seconds is one day)

### Default Setting

1200 seconds (20 minutes)

### Command Mode

Global Configuration

### Command Usage

- ◆ When a ARP entry expires, it is deleted from the cache and an ARP request packet is sent to re-establish the MAC address.
- ◆ The aging time determines how long dynamic entries remain in the cache. If the timeout is too short, the router may tie up resources by repeating ARP requests for addresses recently flushed from the table.

### Example

This example sets the ARP cache timeout for 15 minutes (i.e., 900 seconds).

```
Console(config)#arp timeout 900
Console(config)#
```

**ip proxy-arp** This command enables proxy Address Resolution Protocol (ARP). Use the **no** form to disable proxy ARP.

### Syntax

**[no] ip proxy-arp**

### Default Setting

Disabled

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Proxy ARP allows a non-routing device to determine the MAC address of a host on another subnet or network.
- ◆ End stations that require Proxy ARP must view the entire network as a single network. These nodes must therefore use a smaller subnet mask than that used by the router or other relevant network devices.
- ◆ Extensive use of Proxy ARP can degrade router performance because it may lead to increased ARP traffic and increased search time for larger ARP address tables.

### Example

```
Console(config)#interface vlan 3
Console(config-if)#ip proxy-arp
Console(config-if)#
```

**clear arp-cache** This command deletes all dynamic entries from the Address Resolution Protocol (ARP) cache.

### Command Mode

Privileged Exec

### Example

This example clears all dynamic entries in the ARP cache.

```
Console#clear arp-cache
This operation will delete all the dynamic entries in ARP Cache.
Do you want to continue this operation (y/n)?
Console#
```

**show arp** This command displays entries in the Address Resolution Protocol (ARP) cache.

### Command Mode

Privileged Exec

### Command Usage

- ◆ This command displays information about the ARP cache. The first line shows the cache timeout. It also shows each cache entry, including the IP address, MAC address, type (static, dynamic, other), and VLAN interface. Note that entry type “other” indicates local addresses for this router.
- ◆ Static entries are only displayed for VLANs that are up. In other words, static entries are only displayed when configured for the IP subnet of a existing VLAN, and that VLAN is linked up.

### Example

This example displays all entries in the ARP cache.

```
Console#show arp
ARP Cache Timeout: 1200 (seconds)

IP Address      MAC Address      Type      Interface
-----
10.1.0.0        FF-FF-FF-FF-FF-FF  other     VLAN1
10.1.0.254      00-00-AB-CD-00-00  other     VLAN1
10.1.0.255      FF-FF-FF-FF-FF-FF  other     VLAN1
145.30.20.23    09-50-40-30-20-10  dynamic   VLAN3

Total entry : 4
Console#
```

**UDP Helper Configuration** User Datagram Protocol (UDP) Helper allows host applications to forward UDP broadcast packets from this switch to another part of the network. This section describes the commands used to configure UDP Helper.

**Table 194: UDP Helper Commands**

Command	Function	Mode
<code>ip forward-protocol udp</code>	Specifies the UDP destination ports for which broadcast traffic will be forwarded	GC
<code>ip helper</code>	Enables UDP helper globally on the switch	GC
<code>ip helper-address</code>	Specifies the servers to which designated UDP protocol packets are forwarded	IC
<code>show ip helper</code>	Displays configuration settings for UDP helper	PE

**ip forward-protocol udp** This command specifies the UDP destination ports for which broadcast traffic will be forwarded when the UDP helper is enabled. Use the **no** form to remove a UDP port from the forwarding list.

#### Syntax

**[no] ip forward-protocol udp** *destination-port*

*destination-port* - UDP application port for which UDP service requests are forwarded. (Range: 1-65535)

#### Default Setting

The following UDP ports are included in the forwarding list when UDP helper is enabled with the `ip helper` command and a remote server address is configured with the `ip helper-address` command:

BOOTP client	port 67
BOOTP server	port 68
Domain Name Service	port 53
IEN-116 Name Service	port 42
NetBIOS Datagram Server	port 138
NetBIOS Name Server	port 137
NTP	port 37
TACACS service	port 49
TFTP	port 69

#### Command Mode

Global Configuration

#### Command Usage

Up to 100 UDP ports can be specified with this command for forwarding to one or more remote servers.

### Example

This example enables forwarding for DHCPv6 UDP packets.

```
Console(config)#ip forward-protocol udp 547
Console(config)#
```

**ip helper** This command enables UDP helper globally on the switch. Use the **no** form to disable this feature.

### Syntax

**[no] ip helper**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Network hosts occasionally use UDP broadcasts to determine information such as address configuration, and domain name mapping. These broadcasts are confined to the local subnet, either as an all hosts broadcast (all ones broadcast - 255.255.255.255), or a directed subnet broadcast (such as 10.10.10.255). To reduce the number of application servers deployed in a multi-segment network, UDP helper can be used to forward broadcast packets for specified UDP application ports to remote servers located in another network segment.
- ◆ To configure UDP helper, it must be enabled globally with the **ip helper** command. The UDP destination ports for which broadcast traffic will be forwarded must be specified with the **ip forward-protocol udp** command. And the remote servers which are configured to service UDP clients on another network segment specified with the **ip helper-address** command.

### Example

This example enables UDP helper globally on the switch.

```
Console(config)#ip helper
Console(config)#
```

**ip helper-address** This command specifies the application server or subnet (indicated by a directed broadcast address) to which designated UDP broadcast packets are forwarded. Use the **no** form to remove a UDP helper address.

### Syntax

**[no] ip helper-address** *ip-address*

*ip-address* - Host address or directed broadcast address to which UDP broadcast packets are forwarded. (Range: 1-65535)

### Default Setting

None

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Up to 20 helper addresses can be specified with this command.
- ◆ To forward UDP packets with the UDP helper, the clients must be connected to the selected interface, and the interface configured with an IP address.
- ◆ The UDP packets to be forwarded must be specified by the [ip forward-protocol udp](#) command, and the packets meet the following criteria:
  - The MAC address of the received frame must be all-ones broadcast address (ffff.ffff.ffff).
  - The IP destination address must be one of the following:
    - all-ones broadcast (255.255.255.255)
    - subnet broadcast for the receiving interface
  - The IP time-to-live (TTL) value must be at least 2.
  - The IP protocol must be UDP (17).
  - The UDP destination port must be TFTP, Domain Name System (DNS), Time, NetBIOS, BOOTP or DHCP packet, or a UDP port specified by the [ip forward-protocol udp](#) command.
- ◆ If a helper address is specified with this command, but no UDP ports have been specified with the [ip forward-protocol udp](#) command, broadcast traffic for several UDP protocol types will be forwarded by default as described under the [ip forward-protocol udp](#) command.

### Example

This example indicates that designated UDP broadcast packets are to be forwarded to the directed broadcast address of 192.168.2.255.

```
Console(config)#interface vlan 1
Console(config-if)#ip helper-address 192.168.2.255
Console(config-if)#
```

**show ip helper** This command displays configuration settings for UDP helper.

### Command Mode

Privileged Exec

### Command Usage

This command displays all configuration settings for UDP helper, including its functional status, the UDP ports for which broadcast traffic will be forwarded, and the remote servers or subnets to which the traffic will be forwarded.

### Example

```
Console#show ip helper
Helper mechanism is enabled
Forward port list(maximum count: 100)
 547
Total port number now is: 1
Helper address list(maximum count: 1024)
Interface VLAN 1:
 192.168.2.255
Total helper number now is: 1
Console#
```

```
 192.168.2.255
Total helper number now is: 1
Console#
```

## IPv6 Interface

This switch supports the following IPv6 interface commands.

**Table 195: IPv6 Configuration Commands**

Command	Function	Mode
<i>Interface Address Configuration and Utilities</i>		
<a href="#">ipv6 default-gateway</a>	Sets an IPv6 default gateway for traffic with no known next hop	GC
<a href="#">ipv6 address</a>	Configures an IPv6 global unicast address, and enables IPv6 on an interface	IC

**Table 195: IPv6 Configuration Commands (Continued)**

Command	Function	Mode
<code>ipv6 address autoconfig</code>	Enables automatic configuration of IPv6 addresses on an interface and enables IPv6 on the interface	IC
<code>ipv6 address dhcp</code>	Enables IPv6 DHCP client functionality on an interface	IC
<code>ipv6 address eui-64</code>	Configures an IPv6 global unicast address for an interface using an EUI-64 interface ID in the low order 64 bits, and enables IPv6 on the interface	IC
<code>ipv6 address link-local</code>	Configures an IPv6 link-local address for an interface and enables IPv6 on the interface	IC
<code>ipv6 enable</code>	Enables IPv6 on an interface that has not been configured with an explicit IPv6 address	IC
<code>ipv6 mtu</code>	Sets the size of the maximum transmission unit (MTU) for IPv6 packets sent on an interface	IC
<code>show ipv6 interface</code>	Displays the usability and configured settings for IPv6 interfaces	PE
<code>show ipv6 mtu</code>	Displays maximum transmission unit (MTU) information for IPv6 interfaces	PE
<code>show ipv6 traffic</code>	Displays statistics about IPv6 traffic	PE
<code>clear ipv6 traffic</code>	Resets IPv6 traffic counters	PE
<code>ping6</code>	Sends IPv6 ICMP echo request packets to another node on the network	NE, PE
<code>tracert6</code>	Shows the route packets take to the specified host	PE
<i>Neighbor Discovery</i>		
<code>ipv6 hop-limit</code>	Configures the maximum number of hops used in router advertisements that are originated by this router	GC
<code>ipv6 neighbor</code>	Configures a static entry in the IPv6 neighbor discovery cache	GC
<code>ipv6 nd dad attempts</code>	Configures the number of consecutive neighbor solicitation messages sent on an interface during duplicate address detection	IC
<code>ipv6 nd managed-config-flag</code>	Configures router advertisements to indicate that attached hosts can use stateful autoconfiguration to obtain addresses	IC
<code>ipv6 nd other-config-flag</code>	Configures router advertisements to indicate that attached hosts can obtain autoconfiguration information other than addresses	IC
<code>ipv6 nd ns-interval</code>	Configures the interval between IPv6 neighbor solicitation retransmissions on an interface	IC
<code>ipv6 nd rguard</code>	Blocks incoming Router Advertisement and Router Redirect packets	IC
<code>ipv6 nd reachable-time</code>	Configures the amount of time that a remote IPv6 node is considered reachable after some reachability confirmation event has occurred	IC
<code>ipv6 nd prefix</code>	Configures the IPv6 prefixes to include in router advertisements	IC

Table 195: IPv6 Configuration Commands (Continued)

Command	Function	Mode
<code>ipv6 nd ra interval minimum-interval [maximum-interval]</code>	Configures the interval between the transmission of router advertisements on an interface	IC
<code>ipv6 nd ra lifetime</code>	Configures the router lifetime value used in router advertisements sent from an interface	IC
<code>ipv6 nd ra router-preference</code>	Configures the default router preference for the router on an interface	IC
<code>ipv6 nd ra suppress</code>	Suppresses router advertisement transmissions on an interface	IC
<code>show ipv6 nd raguard</code>	Displays the configuration setting for RA Guard	PE
<code>clear ipv6 neighbors</code>	Deletes all dynamic entries in the IPv6 neighbor discovery cache	PE
<code>show ipv6 neighbors</code>	Displays information in the IPv6 neighbor discovery cache	PE
<code>show ipv6 nd prefix</code>	Displays IPv6 neighbor discovery prefixes for a VLAN	PE

## Interface Address Configuration and Utilities

**ipv6 default-gateway** This command sets an IPv6 default gateway to use for destinations with no known next hop. Use the **no** form to remove a previously configured default gateway.

### Syntax

**ipv6 default-gateway** *ipv6-address*

**no ipv6 default-gateway**

*ipv6-address* - The IPv6 address of the default next hop router to use for destinations with no known next hop.

### Default Setting

No default gateway is defined

### Command Mode

Global Configuration

### Command Usage

- ◆ All IPv6 addresses must be according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.
- ◆ The same link-local address may be used by different interfaces/nodes in different zones (RFC 4007). Therefore, when specifying a link-local address, include zone-id information indicating the VLAN identifier after the % delimiter. For example, FE80::7272%1 identifies VLAN 1 as the interface from which the ping is sent.

- ◆ An IPv6 default gateway should be defined if the destination has been assigned an IPv6 address that is located in a different IP segment.
- ◆ An IPv6 default gateway can only be successfully set when a network interface that directly connects to the gateway has been configured on the switch.

### Example

The following example defines a default gateway for this device:

```
Console(config)#ipv6 default-gateway FE80::269:3EF9:FE19:6780%1
Console(config)#
```

### Related Commands

[ip default-gateway \(936\)](#)

**ipv6 address** This command configures an IPv6 global unicast address and enables IPv6 on an interface. Use the **no** form without any arguments to remove all IPv6 addresses from the interface, or use the **no** form with a specific IPv6 address to remove that address from the interface.

### Syntax

**[no] ipv6 address** *ipv6-address*[/*prefix-length*]

*ipv6-address* - A full IPv6 address including the network prefix and host address bits.

*prefix-length* - A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix (i.e., the network portion of the address).

### Default Setting

No IPv6 addresses are defined

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ All IPv6 addresses must be according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.
- ◆ To connect to a larger network with multiple subnets, you must configure a global unicast address. This address can be manually configured with this command, or it can be automatically configured using the [ipv6 address autoconfig](#) command.

- ◆ If a link-local address has not yet been assigned to this interface, this command will assign the specified static global unicast address and also dynamically generate a link-local unicast address for the interface. (The link-local address is made with an address prefix of FE80 and a host portion based the switch's MAC address in modified EUI-64 format.)
- ◆ If a duplicate address is detected, a warning message is sent to the console.

### Example

This example specifies a full IPv6 address and prefix length.

```

Console(config)#interface vlan 1
Console(config-if)#ipv6 address 2001:DB8:2222:7272::72/96
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled
Link-local address:
  fe80::7272:cfff:fe83:3466%1/64
Global unicast address(es):
  2001:db8:2222:7272::72/96, subnet is 2001:db8:2222:7272::/96
Joined group address(es):
  ff02::1:ff00:72
  ff02::1:ff83:3466
  ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#

```

### Related Commands

[ipv6 address eui-64 \(956\)](#)  
[ipv6 address autoconfig \(953\)](#)  
[show ipv6 interface \(961\)](#)  
[ip address \(934\)](#)

**ipv6 address autoconfig** This command enables stateless autoconfiguration of IPv6 addresses on an interface and enables IPv6 on the interface. The network portion of the address is based on prefixes received in IPv6 router advertisement messages; the host portion is based on the modified EUI-64 form of the interface identifier (i.e., the switch's MAC address). Use the **no** form to remove the address generated by this command.

### Syntax

**[no] ipv6 address autoconfig**

### Default Setting

No IPv6 addresses are defined

## Command Mode

Interface Configuration (VLAN)

## Command Usage

- ◆ If a link local address has not yet been assigned to this interface, this command will dynamically generate a global unicast address (if a global prefix is included in received router advertisements) and a link local address for the interface. (The link-local address is made with an address prefix of FE80 and a host portion based the switch's MAC address in modified EUI-64 format.)
- ◆ If a duplicate address is detected, a warning message is sent to the console.
- ◆ When DHCPv6 is restarted, the switch may attempt to acquire an IP address prefix through stateful address autoconfiguration. If the router advertisements have the "other stateful configuration" flag set, the switch may also attempt to acquire other non-address configuration information (such as a default gateway) from a DHCPv6 server when DHCPv6 is restarted.

## Example

This example assigns a dynamic global unicast address of to the switch.

```
Console(config-if)#ipv6 address autoconfig
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is stale
Link-local address:
    fe80::7272:cfff:fe83:3466%1/64
Global unicast address(es):
(None)
Joined group address(es):
ff02::1:ffbc:4ffa
ff02::1:2
ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#
```

## Related Commands

[ipv6 address \(952\)](#)

[show ipv6 interface \(961\)](#)

**ipv6 address dhcp** This command enables IPv6 DHCP client functionality on an interface so that it can acquire a stateful IPv6 address. Use the **no** form of the command to disabled the IPv6 DHCP client.

#### Syntax

**ipv6 address dhcp**  
**no ipv6 address dhcp**

#### Default Setting

Disabled

#### Command Mode

Interface Configuration (VLAN)

#### Command Usage

- ◆ Once enabled on any interface, the interface will have the ability to have a stateful IPv6 address assigned to it dynamically using the DHCPv6 protocol.
- ◆ If IPv6 router advertisements are enabled and this command is configured, the IPv6 dhcp client will fail to be enabled on the interface.

#### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 address dhcp
Console(config-if)#
```

#### Related Commands

[ipv6 address eui-64 \(956\)](#)  
[ipv6 address link-local \(958\)](#)  
[show ipv6 interface \(961\)](#)

**ipv6 address eui-64** This command configures an IPv6 address for an interface using an EUI-64 interface ID in the low order 64 bits and enables IPv6 on the interface. Use the **no** form without any arguments to remove all manually configured IPv6 addresses from the interface. Use the **no** form with a specific address to remove it from the interface.

### Syntax

**ipv6 address** *ipv6-prefix/prefix-length eui-64*

**no ipv6 address** [*ipv6-prefix/prefix-length eui-64*]

*ipv6-prefix* - The IPv6 network portion of the address assigned to the interface.

*prefix-length* - A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix (i.e., the network portion of the address).

### Default Setting

No IPv6 addresses are defined

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ The prefix must be formatted according to RFC 2373 “IPv6 Addressing Architecture,” using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.
- ◆ If a link local address has not yet been assigned to this interface, this command will dynamically generate a global unicast address and a link-local address for this interface. (The link-local address is made with an address prefix of FE80 and a host portion based the switch’s MAC address in modified EUI-64 format.)
- ◆ Note that the value specified in the *ipv6-prefix* may include some of the high-order host bits if the specified prefix length is less than 64 bits. If the specified prefix length exceeds 64 bits, then the network portion of the address will take precedence over the interface identifier.
- ◆ If a duplicate address is detected, a warning message is sent to the console.
- ◆ IPv6 addresses are 16 bytes long, of which the bottom 8 bytes typically form a unique host identifier based on the device’s MAC address. The EUI-64 specification is designed for devices that use an extended 8-byte MAC address. For devices that still use a 6-byte MAC address (also known as EUI-48 format), it must be converted into EUI-64 format by inverting the universal/local bit in the address and inserting the hexadecimal number FFFE between the upper and lower three bytes of the MAC address.
- ◆ For example, if a device had an EUI-48 address of 28-9F-18-1C-82-35, the global/local bit must first be inverted to meet EUI-64 requirements (i.e., 1 for

globally defined addresses and 0 for locally defined addresses), changing 28 to 2A. Then the two bytes FFFE are inserted between the OUI (i.e., company id) and the rest of the address, resulting in a modified EUI-64 interface identifier of 2A-9F-18-FF-FE-1C-82-35.

- ◆ This host addressing method allows the same interface identifier to be used on multiple IP interfaces of a single device, as long as those interfaces are attached to different subnets.

### Example

This example uses the network prefix of 2001:0DB8:0:1::/64, and specifies that the EUI-64 interface identifier be used in the lower 64 bits of the address.

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 address 2001:0DB8:0:1::/64 eui-64
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled
Link-local address:
    fe80::7272:cfff:fe83:3466%1/64
Global unicast address(es):
    2001:db8:0:1:7272:cfff:fe83:3466/64, subnet is 2001:db8:0:1::/64[EUI]
    2001:db8:2222:7272::72/96, subnet is 2001:db8:2222:7272::/96
Joined group address(es):
    ff02::1:ff00:72
    ff02::1:ff83:3466
    ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#
```

### Related Commands

[ipv6 address autoconfig \(953\)](#)

[show ipv6 interface \(961\)](#)

**ipv6 address link-local** This command configures an IPv6 link-local address for an interface and enables IPv6 on the interface. Use the **no** form without any arguments to remove all manually configured IPv6 addresses from the interface. Use the **no** form with a specific address to remove it from the interface.

### Syntax

**ipv6 address** *ipv6-address* **link-local**  
**no ipv6 address** [*ipv6-address* **link-local**]

*ipv6-address* - The IPv6 address assigned to the interface.

### Default Setting

No IPv6 addresses are defined

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ The specified address must be formatted according to RFC 2373 “IPv6 Addressing Architecture,” using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields. And the address prefix must be in the range of FE80~FEBF.
- ◆ The address specified with this command replaces a link-local address that was automatically generated for the interface.
- ◆ You can configure multiple IPv6 global unicast addresses per interface, but only one link-local address per interface.
- ◆ If a duplicate address is detected, a warning message is sent to the console.

### Example

This example assigns a link-local address of FE80::269:3EF9:FE19:6779 to VLAN 1. Note that a prefix in the range of FE80~FEBF is required for link-local addresses, and the first 16-bit group in the host address is padded with a zero in the form 0269.

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 address FE80::269:3EF9:FE19:6779 link-local
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled
Link-local address:
  fe80::269:3ef9:fe19:6779%1/64
Global unicast address(es):
  2001:db8:0:1:7272:cfff:fe83:3466/64, subnet is 2001:db8:0:1::/64[EUI]
  2001:db8:2222:7272::72/96, subnet is 2001:db8:2222:7272::/96
Joined group address(es):
ff02::1:ff19:6779
ff02::1:ff00:72
ff02::1:ff83:3466
```

```
ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#
```

## Related Commands

[ipv6 enable \(959\)](#)

[show ipv6 interface \(961\)](#)

**ipv6 enable** This command enables IPv6 on an interface that has not been configured with an explicit IPv6 address. Use the **no** form to disable IPv6 on an interface that has not been configured with an explicit IPv6 address.

## Syntax

**[no] ipv6 enable**

## Default Setting

IPv6 is disabled

## Command Mode

Interface Configuration (VLAN)

## Command Usage

- ◆ This command enables IPv6 on the current VLAN interface and automatically generates a link-local unicast address. The address prefix uses FE80, and the host portion of the address is generated by converting the switch's MAC address to modified EUI-64 format (see [page 956](#)). This address type makes the switch accessible over IPv6 for all devices attached to the same local subnet.
- ◆ If a duplicate address is detected on the local segment, this interface will be disabled and a warning message displayed on the console.
- ◆ The **no ipv6 enable** command does not disable IPv6 for an interface that has been explicitly configured with an IPv6 address.

## Example

In this example, IPv6 is enabled on VLAN 1, and the link-local address FE80::2E0:CFF:FE00:FD/64 is automatically generated by the switch.

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 enable
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
```

```

IPv6 is enabled
Link-local address:
  fe80::269:3ef9:fe19:6779%1/64
Global unicast address(es):
  2001:db8:0:1:7272:cfff:fe83:3466/64, subnet is 2001:db8:0:1::/64[EUI]
  2001:db8:2222:7272::72/96, subnet is 2001:db8:2222:7272::/96
Joined group address(es):
  ff02::1:ff19:6779
  ff02::1:ff00:72
  ff02::1:ff83:3466
  ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 3.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#

```

### Related Commands

[ipv6 address link-local \(958\)](#)

[show ipv6 interface \(961\)](#)

**ipv6 mtu** This command sets the size of the maximum transmission unit (MTU) for IPv6 packets sent on an interface. Use the **no** form to restore the default setting.

### Syntax

**ipv6 mtu** *size*

**no ipv6 mtu**

*size* - Specifies the MTU size. (Range: 1280-65535 bytes)

### Default Setting

1500 bytes

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ If a non-default value is configured, an MTU option is included in the router advertisements sent from this device.
- ◆ The maximum value set by this command cannot exceed the MTU of the physical interface, which is currently fixed at 1500 bytes.
- ◆ IPv6 routers do not fragment IPv6 packets forwarded from other routers. However, traffic originating from an end-station connected to an IPv6 router may be fragmented.

- ◆ All devices on the same physical medium must use the same MTU in order to operate correctly.
- ◆ IPv6 must be enabled on an interface before the MTU can be set.

### Example

The following example sets the MTU for VLAN 1 to 1280 bytes:

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 mtu 1280
Console(config-if)#
```

### Related Commands

[show ipv6 mtu \(963\)](#)

[jumbo frame \(133\)](#)

**show ipv6 interface** This command displays the usability and configured settings for IPv6 interfaces.

### Syntax

**show ipv6 interface** [**brief** [**vlan** *vlan-id* [*ipv6-prefix/prefix-length*]]]

**brief** - Displays a brief summary of IPv6 operational status and the addresses configured for each interface.

*vlan-id* - VLAN ID (Range: 1-4094)

*ipv6-prefix* - The IPv6 network portion of the address assigned to the interface. The prefix must be formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

*prefix-length* - A decimal value indicating how many of the contiguous bits (from the left) of the address comprise the prefix (i.e., the network portion of the address).

### Command Mode

Privileged Exec

### Example

This example displays all the IPv6 addresses configured for the switch.

```
Console#show ipv6 interface
VLAN 2 is down.
IPv6 is stale.
Link-local address:
  FE80::260:3EFF:FE11:6770/64[TEN]
Global unicast address(es):
  3FFE::1, subnet is 3FFE:0:0:0::/64[TEN]
  3FFE::212:CFFF:FE32:2120, subnet is 3FFE:0:0:0::/64[TEN]
Joined group address(es):
```

```

FF01::1/16
FF02::1/16
FF02::1:FF00:1/104
FF02::1:FF11:6770/104
FF02::1:FF32:2120/104

IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 1.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND managed-config-flag: disabled
ND other-config-flag : disabled
ND ra suppress: disabled
Console#

```

**Table 196: show ipv6 interface - display description**

Field	Description
VLAN	A VLAN is marked “up” if the switch can send and receive packets on this interface, “down” if a line signal is not present, or “administratively down” if the interface has been disabled by the administrator.
IPv6	IPv6 is marked “enable” if the switch can send and receive IP traffic on this interface, “disable” if the switch cannot send and receive IP traffic on this interface, or “stalled” if a duplicate link-local address is detected on the interface.
Link-local address	Shows the link-local address assigned to this interface
Global unicast address(es)	Shows the global unicast address(es) assigned to this interface
Joined group address(es)	In addition to the unicast addresses assigned to an interface, a node is required to join the all-nodes multicast addresses FF01::1 and FF02::1 for all IPv6 nodes within scope 1 (interface-local) and scope 2 (link-local), respectively.  FF01::1/16 is the transient interface-local multicast address for all attached IPv6 nodes, and FF02::1/16 is the link-local multicast address for all attached IPv6 nodes. The interface-local multicast address is only used for loopback transmission of multicast traffic. Link-local multicast addresses cover the same types as used by link-local unicast addresses, including all nodes (FF02::1), all routers (FF02::2), and solicited nodes (FF02::1:FFXX:XXXX) as described below.  A node is also required to compute and join the associated solicited-node multicast addresses for every unicast and anycast address it is assigned. IPv6 addresses that differ only in the high-order bits, e.g. due to multiple high-order prefixes associated with different aggregations, will map to the same solicited-node address, thereby reducing the number of multicast addresses a node must join. In this example, FF02::1:FF90:0/104 is the solicited-node multicast address which is formed by taking the low-order 24 bits of the address and appending those bits to the prefix.
IPv6 Link MTU	Maximum transmission unit for this interface (bytes).
ND DAD	Indicates whether (neighbor discovery) duplicate address detection is enabled.
ND retransmit interval	The interval between IPv6 neighbor solicitation retransmissions sent on an interface during duplicate address detection.
ND advertised retransmit interval	The retransmit interval is included in all router advertisements sent out of an interface so that nodes on the same link use the same time value.
ND reachable time	The amount of time a remote IPv6 node is considered reachable after a reachability confirmation event has occurred

**Table 196: show ipv6 interface - display description** (Continued)

Field	Description
ND advertised reachable time	The reachable time is included in all router advertisements sent out of an interface so that nodes on the same link use the same time value.
ND advertised router lifetime	The length of time during which the prefix is valid for on-link determination.
ND managed-config-flag	Shows if router advertisements indicate that attached hosts can use stateful autoconfiguration to obtain addresses
ND other-config-flag	Shows if router advertisements indicate that attached hosts can obtain autoconfiguration information other than addresses
ND ra suppress	Shows if periodic unsolicited router advertisements on an interface have been suppressed.

This example displays a brief summary of IPv6 addresses configured on the switch.

```

Console#show ipv6 interface brief
Interface      Status      IPv6      IPv6 Address
-----
VLAN 1         Up          Up        FE80::768E:F8FF:FE68:870
VLAN 1         Up          Up        2001:1DB8:1111:2F3B:12AA:11FF:FE28:9C5A
VLAN 2         Up          Down      Unassigned
Craft          Up          Up        FE80::768E:F8FF:FE68:870

Console#

```

### Related Commands

[show ip interface \(938\)](#)

**show ipv6 mtu** This command displays the maximum transmission unit (MTU) cache for destinations that have returned an ICMP packet-too-big message along with an acceptable MTU to this switch.

### Command Mode

Normal Exec, Privileged Exec

### Example

The following example shows the MTU cache for this device:

```

Console#show ipv6 mtu
MTU      Since      Destination Address
1400     00:04:21  5000:1::3
1280     00:04:50  FE80::203:A0FF:FED6:141D

Console#

```

**Table 197: show ipv6 mtu - display description\***

Field	Description
MTU	Adjusted MTU contained in the ICMP packet-too-big message returned from this destination, and now used for all traffic sent along this path.
Since	Time since an ICMP packet-too-big message was received from this destination.
Destination Address	Address which sent an ICMP packet-too-big message.

\* No information is displayed if an IPv6 address has not been assigned to the switch.

**show ipv6 traffic** This command displays statistics about IPv6 traffic passing through this switch.

### Command Mode

Privileged Exec

### Example

The following example shows statistics for all IPv6 unicast and multicast traffic, as well as ICMP, UDP and TCP statistics:

```

Console#show ipv6 traffic
IPv6 Statistics:
IPv6 received
    3 total received
    header errors
    too big errors
    no routes
    address errors
    unknown protocols
    truncated packets
    discards
    delivers
    reassembly request datagrams
    reassembly succeeded
    reassembly failed
IPv6 sent
    forwards datagrams
    6 requests
    discards
    no routes
    generated fragments
    fragment succeeded
    fragment failed
ICMPv6 Statistics:
ICMPv6 received
    input
    errors
    destination unreachable messages
    packet too big messages
    time exceeded messages
    parameter problem message
    echo request messages
    echo reply messages
    router solicit messages
    router advertisement messages
    neighbor solicit messages

```

```

neighbor advertisement messages
redirect messages
group membership query messages
group membership response messages
group membership reduction messages

ICMPv6 sent
6 output
destination unreachable messages
packet too big messages
time exceeded messages
parameter problem message
echo request messages
echo reply messages
3 router solicit messages
router advertisement messages
3 neighbor solicit messages
neighbor advertisement messages
redirect messages
group membership query messages
group membership response messages
group membership reduction messages

UDP Statistics:
input
no port errors
other errors
output

Console#

```

**Table 198: show ipv6 traffic - display description**

Field	Description
<i>IPv6 Statistics</i>	
<i>IPv6 received</i>	
total received	The total number of input datagrams received by the interface, including those received in error.
header errors	The number of input datagrams discarded due to errors in their IPv6 headers, including version number mismatch, other format errors, hop count exceeded, IPv6 options, etc.
too big errors	The number of input datagrams that could not be forwarded because their size exceeded the link MTU of outgoing interface.
no routes	The number of input datagrams discarded because no route could be found to transmit them to their destination.
address errors	The number of input datagrams discarded because the IPv6 address in their IPv6 header's destination field was not a valid address to be received at this entity. This count includes invalid addresses (e.g., ::0) and unsupported addresses (e.g., addresses with unallocated prefixes). For entities which are not IPv6 routers and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.
unknown protocols	The number of locally-addressed datagrams received successfully but discarded because of an unknown or unsupported protocol. This counter is incremented at the interface to which these datagrams were addressed which might not be necessarily the input interface for some of the datagrams.
truncated packets	The number of input datagrams discarded because datagram frame didn't carry enough data.

**Table 198: show ipv6 traffic - display description (Continued)**

Field	Description
discards	The number of input IPv6 datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (e.g., for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.
delivers	The total number of datagrams successfully delivered to IPv6 user-protocols (including ICMP). This counter is incremented at the interface to which these datagrams were addressed which might not be necessarily the input interface for some of the datagrams.
reassembly request datagrams	The number of IPv6 fragments received which needed to be reassembled at this interface. Note that this counter is incremented at the interface to which these fragments were addressed which might not be necessarily the input interface for some of the fragments.
reassembly succeeded	The number of IPv6 datagrams successfully reassembled. Note that this counter is incremented at the interface to which these datagrams were addressed which might not be necessarily the input interface for some of the fragments.
reassembly failed	The number of failures detected by the IPv6 re-assembly algorithm (for whatever reason: timed out, errors, etc.). Note that this is not necessarily a count of discarded IPv6 fragments since some algorithms (notably the algorithm in RFC 815) can lose track of the number of fragments by combining them as they are received. This counter is incremented at the interface to which these fragments were addressed which might not be necessarily the input interface for some of the fragments.
<i>IPv6 sent</i>	
forwards datagrams	The number of output datagrams which this entity received and forwarded to their final destinations. In entities which do not act as IPv6 routers, this counter will include only those packets which were Source-Routed via this entity, and the Source-Route processing was successful. Note that for a successfully forwarded datagram the counter of the outgoing interface is incremented.
requests	The total number of IPv6 datagrams which local IPv6 user-protocols (including ICMP) supplied to IPv6 in requests for transmission. Note that this counter does not include any datagrams counted in <code>ipv6IfStatsOutForwDatagrams</code> .
discards	The number of output IPv6 datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded (e.g., for lack of buffer space). Note that this counter would include datagrams counted in <code>ipv6IfStatsOutForwDatagrams</code> if any such packets met this (discretionary) discard criterion.
no routes	The number of input datagrams discarded because no route could be found to transmit them to their destination.
generated fragments	The number of output datagram fragments that have been generated as a result of fragmentation at this output interface.
fragment succeeded	The number of IPv6 datagrams that have been successfully fragmented at this output interface.
fragment failed	The number of IPv6 datagrams that have been discarded because they needed to be fragmented at this output interface but could not be.

**Table 198: show ipv6 traffic - display description** (Continued)

Field	Description
<i>ICMPv6 Statistics</i>	
<i>ICMPv6 received</i>	
input	The total number of ICMP messages received by the interface which includes all those counted by <code>ipv6IfIcmpInErrors</code> . Note that this interface is the interface to which the ICMP messages were addressed which may not be necessarily the input interface for the messages.
errors	The number of ICMP messages which the interface received but determined as having ICMP-specific errors (bad ICMP checksums, bad length, etc.).
destination unreachable messages	The number of ICMP Destination Unreachable messages received by the interface.
packet too big messages	The number of ICMP Packet Too Big messages received by the interface.
time exceeded messages	The number of ICMP Time Exceeded messages received by the interface.
parameter problem message	The number of ICMP Parameter Problem messages received by the interface.
echo request messages	The number of ICMP Echo (request) messages received by the interface.
echo reply messages	The number of ICMP Echo Reply messages received by the interface.
router solicit messages	The number of ICMP Router Solicit messages received by the interface.
router advertisement messages	The number of ICMP Router Advertisement messages received by the interface.
neighbor solicit messages	The number of ICMP Neighbor Solicit messages received by the interface.
neighbor advertisement messages	The number of ICMP Neighbor Advertisement messages received by the interface.
redirect messages	The number of Redirect messages received by the interface.
group membership query messages	The number of ICMPv6 Group Membership Query messages received by the interface.
group membership response messages	The number of ICMPv6 Group Membership Response messages received by the interface.
group membership reduction messages	The number of ICMPv6 Group Membership Reduction messages received by the interface.
<i>ICMPv6 sent</i>	
output	The total number of ICMP messages which this interface attempted to send. Note that this counter includes all those counted by <code>icmpOutErrors</code> .
destination unreachable messages	The number of ICMP Destination Unreachable messages sent by the interface.
packet too big messages	The number of ICMP Packet Too Big messages sent by the interface.
time exceeded messages	The number of ICMP Time Exceeded messages sent by the interface.
parameter problem message	The number of ICMP Parameter Problem messages sent by the interface.
echo request messages	The number of ICMP Echo (request) messages sent by the interface.

**Table 198: show ipv6 traffic - display description** (Continued)

Field	Description
echo reply messages	The number of ICMP Echo Reply messages sent by the interface.
router solicit messages	The number of ICMP Router Solicitation messages sent by the interface.
router advertisement messages	The number of ICMP Router Advertisement messages sent by the interface.
neighbor solicit messages	The number of ICMP Neighbor Solicit messages sent by the interface.
neighbor advertisement messages	The number of ICMP Router Advertisement messages sent by the interface.
redirect messages	The number of Redirect messages sent. For a host, this object will always be zero, since hosts do not send redirects.
group membership query messages	The number of ICMPv6 Group Membership Query messages sent by the interface.
group membership response messages	The number of ICMPv6 Group Membership Response messages sent.
group membership reduction messages	The number of ICMPv6 Group Membership Reduction messages sent.
<i>UDP Statistics</i>	
input	The total number of UDP datagrams delivered to UDP users.
no port errors	The total number of received UDP datagrams for which there was no application at the destination port.
other errors	The number of received UDP datagrams that could not be delivered for reasons other than the lack of an application at the destination port.
output	The total number of UDP datagrams sent from this entity.

**clear ipv6 traffic** This command resets IPv6 traffic counters.

#### Command Mode

Privileged Exec

#### Command Usage

This command resets all of the counters displayed by the [show ipv6 traffic](#) command.

#### Example

```
Console#clear ipv6 traffic
Console#
```

**ping6** This command sends (IPv6) ICMP echo request packets to another node on the network.

### Syntax

**ping6** {*ipv6-address* | *host-name*} [**count** *count*] [**size** *size*]

*ipv6-address* - The IPv6 address of a neighbor device. You can specify either a link-local or global unicast address formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

*host-name* - A host name string which can be resolved into an IPv6 address through a domain name server.

*count* - Number of packets to send. (Range: 1-16)

*size* - Number of bytes in a packet. (Range: 0-1500 bytes)

The actual packet size will be eight bytes larger than the size specified because the router adds header information.

### Default Setting

count: 5

size: 32 bytes

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

- ◆ Use the **ping6** command to see if another site on the network can be reached, or to evaluate delays over the path.
- ◆ The same link-local address may be used by different interfaces/nodes in different zones (RFC 4007). Therefore, when specifying a link-local address, include zone-id information indicating the VLAN identifier after the % delimiter. For example, FE80::7272%1 identifies VLAN 1 as the interface from which the ping is sent.
- ◆ When pinging a host name, be sure the DNS server has been enabled (see [page 893](#)). If necessary, local devices can also be specified in the DNS static host table (see [page 894](#)).
- ◆ When using ping6 with a host name, the switch first attempts to resolve the alias into an IPv6 address before trying to resolve it into an IPv4 address.

### Example

```
Console#ping6 FE80::2E0:CFF:FE00:FC%1
Press ESC to abort.
PING to FE80::2E0:CFF:FE00:FC%1/64, by 5 32-byte payload ICMP packets,
  timeout is 3 seconds
response time: 20 ms      [FE80::2E0:CFF:FE00:FC] seq_no: 1
response time: 0 ms      [FE80::2E0:CFF:FE00:FC] seq_no: 2
```

```
response time: 0 ms      [FE80::2E0:CFF:FE00:FC] seq_no: 3
response time: 0 ms      [FE80::2E0:CFF:FE00:FC] seq_no: 4
response time: 0 ms      [FE80::2E0:CFF:FE00:FC] seq_no: 5
Ping statistics for FE80::2E0:CFF:FE00:FC%1/64:
 5 packets transmitted, 5 packets received (100%), 0 packets lost (0%)
Approximate round trip times:
  Minimum = 0 ms, Maximum = 20 ms, Average = 4 ms
Console#
```

**traceroute6** This command shows the route packets take to the specified destination.

### Syntax

**traceroute6** {*ipv6-address* | *host-name*} [**max-failures** *failure-count*]

*ipv6-address* - The IPv6 address of a neighbor device. You can specify either a link-local or global unicast address formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

*host-name* - A host name string which can be resolved into an IPv6 address through a domain name server.

*failure-count* - The maximum number of failures before which the trace route is terminated. (Range: 1-255)

### Default Setting

Maximum failures: 5

### Command Mode

Privileged Exec

### Command Usage

- ◆ Use the **traceroute6** command to determine the path taken to reach a specified destination.
- ◆ The same link-local address may be used by different interfaces/nodes in different zones (RFC 4007). Therefore, when specifying a link-local address, include zone-id information indicating the VLAN identifier after the % delimiter. For example, FE80::7272%1 identifies VLAN 1 as the interface from which the ping is sent.
- ◆ A trace terminates when the destination responds, when the maximum timeout (TTL) is exceeded, or the maximum number of hops is exceeded.
- ◆ The traceroute command first sends probe datagrams with the TTL value set at one. This causes the first router to discard the datagram and return an error message. The trace function then sends several probe messages at each subsequent TTL level and displays the round-trip time for each message. Not all devices respond correctly to probes by returning an "ICMP port unreachable" message. If the timer goes off before a response is returned, the trace function

prints a series of asterisks and the "Request Timed Out" message. A long sequence of these messages, terminating only when the maximum timeout has been reached, may indicate this problem with the target device.

### Example

```
Console#traceroute6 FE80::2E0:CFF:FE9C:CA10%1
Press "ESC" to abort.

Traceroute to FE80::2E0:CFF:FE9C:CA10%1/64, 30 hops max, timeout is 3
seconds, 5 max failure(s) before termination.

Hop Packet 1 Packet 2 Packet 3 IPv6 Address
-----
  1   <10 ms   <10 ms   <10 ms FE80::2E0:CFF:FE9C:CA10%1/64

Trace completed.
Console#
```

## Neighbor Discovery

**ipv6 hop-limit** This command configures the maximum number of hops used in router advertisements that are originated by this router. Use the **no** form to restore the default setting.

### Syntax

**ipv6 hop-limit** *hops*

**no ipv6 hop-limit**

*hops* - The maximum number of hops in router advertisements and all IPv6 packets. (Range: 1-255)

### Default Setting

1

### Command Mode

Global Configuration

### Example

The following sets the hop limit for router advertisements to 64:

```
Console(config)#ipv6 hop-limit 64
Console(config)#
```

**ipv6 neighbor** This command configures a static entry in the IPv6 neighbor discovery cache. Use the **no** form to remove a static entry from the cache.

### Syntax

**ipv6 neighbor** *ipv6-address* **vlan** *vlan-id* *hardware-address*

**no ipv6 neighbor** *ipv6-address* **vlan** *vlan-id*

*ipv6-address* - The IPv6 address of a neighbor device that can be reached through one of the network interfaces configured on this switch. You can specify either a link-local or global unicast address formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

*vlan-id* - VLAN ID (Range: 1-4094)

*hardware-address* - The 48-bit MAC layer address for the neighbor device. This address must be formatted as six hexadecimal pairs separated by hyphens.

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ Address Resolution Protocol (ARP) has been replaced in IPv6 with the Neighbor Discovery Protocol (NDP). The **ipv6 neighbor** command is similar to the [mac-address-table static](#) command that is implemented using ARP.
- ◆ Static entries can only be configured on an IPv6-enabled interface.
- ◆ The switch does not determine whether a static entry is reachable before placing it in the IPv6 neighbor discovery cache.
- ◆ If the specified entry was dynamically learned through the IPv6 neighbor discovery process, and already exists in the neighbor discovery cache, it is converted to a static entry. Static entries in the IPv6 neighbor discovery cache are not modified if subsequently detected by the neighbor discovery process.
- ◆ Disabling IPv6 on an interface with the [no ipv6 enable](#) command (see [page 959](#)) deletes all dynamically learned entries in the IPv6 neighbor discovery cache for that interface, but does not delete static entries.

### Example

The following maps a static entry for global unicast address to a MAC address:

```

Console(config)#ipv6 neighbor 2009:DB9:2229::81 vlan 1 30-65-14-01-11-86
Console(config)#end
Console#show ipv6 neighbors
State: I1 - Incomplete, I2 - Invalid, R - Reachable, S - Stale, D - Delay,
      P1 - Probe, P2 - Permanent, U - Unknown
IPv6 Address          Age          Link-layer Addr   State   VLAN
2009:DB9:2229::80    956          12-34-11-11-43-21 R        1
2009:DB9:2229::81    Permanent    30-65-14-01-11-86 R        1
FE80::1034:11FF:FE11:4321 961          12-34-11-11-43-21 R        1
Console#

```

### Related Commands

[show ipv6 neighbors \(984\)](#)

**ipv6 nd dad attempts** This command configures the number of consecutive neighbor solicitation messages sent on an interface during duplicate address detection. Use the **no** form to restore the default setting.

### Syntax

**ipv6 nd dad attempts** *count*

**no ipv6 nd dad attempts**

*count* - The number of neighbor solicitation messages sent to determine whether or not a duplicate address exists on this interface. (Range: 0-255)

### Default Setting

1

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Configuring a value of 0 disables duplicate address detection.
- ◆ Duplicate address detection determines if a new unicast IPv6 address already exists on the network before it is assigned to an interface.
- ◆ Duplicate address detection is stopped on any interface that has been suspended (see the [vlan](#) command). While an interface is suspended, all unicast IPv6 addresses assigned to that interface are placed in a “pending” state. Duplicate address detection is automatically restarted when the interface is administratively re-activated.
- ◆ An interface that is re-activated restarts duplicate address detection for all unicast IPv6 addresses on the interface. While duplicate address detection is performed on the interface’s link-local address, the other IPv6 addresses remain

in a “tentative” state. If no duplicate link-local address is found, duplicate address detection is started for the remaining IPv6 addresses.

- ◆ If a duplicate address is detected, it is set to “duplicate” state, and a warning message is sent to the console. If a duplicate link-local address is detected, IPv6 processes are disabled on the interface. If a duplicate global unicast address is detected, it is not used. All configuration commands associated with a duplicate address remain configured while the address is in “duplicate” state.

If the link-local address for an interface is changed, duplicate address detection is performed on the new link-local address, but not for any of the IPv6 global unicast addresses already associated with the interface.

### Example

The following configures five neighbor solicitation attempts for addresses configured on VLAN 1. The `show ipv6 interface` command indicates that the duplicate address detection process is still on-going.

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 nd dad attempts 5
Console(config-if)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled.
Link-local address:
  fe80::269:3ef9:fe19:6779%1/64
Global unicast address(es):
  2001:db8:0:1:2e0:cff:fe02:fd/64, subnet is 2001:db8:0:1::/64[EUI]
  2001:db8:2222:7272::72/96, subnet is 2001:db8:2222:7272::/96
Joined group address(es):
ff02::2
ff02::1:ff19:6779
ff02::1:ff00:0
ff02::1:ff00:72
ff02::1:ff02:fd
ff02::1:2
ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 5.
ND retransmit interval is 1000 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#
```

### Related Commands

[ipv6 nd ns-interval \(976\)](#)

[show ipv6 neighbors \(984\)](#)

**ipv6 nd managed-config-flag** This command configures IPv6 router advertisements to indicate to attached hosts that they can use stateful autoconfiguration to obtain addresses. Use the **no** form to clear this flag from router advertisements.

### Syntax

**[no] ipv6 nd managed-config-flag**

### Default Setting

Disabled

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ The “managed-address configuration” flag tells hosts that they should use stateful autoconfiguration to obtain addresses from a DHCPv6 server.
- ◆ The **ipv6 nd other-config-flag** command is used to tell hosts that they should use stateless address autoconfiguration to get IPv6 address (based on the IPv6 prefixes found in router advertisements) and stateful autoconfiguration to get other non-address parameters (such as DNS server addresses) from DHCPv6 servers.
- ◆ The absence of the “managed-address configuration” flag tells hosts to use only stateless address autoconfiguration (based on IPv6 prefixes found in router advertisements).
- ◆ The “managed address configuration” flag is only a suggestion to attached hosts. They may still use stateful and/or stateless address autoconfiguration. If hosts must be forced to use DHCPv6 for security reasons, ensure that no route prefixes are sent in router advertisements.

### Example

The following tells hosts to use stateful autoconfiguration to obtain addresses:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd managed-config-flag
Console(config)#
```

**ipv6 nd other-config-flag** This command configures IPv6 router advertisements to indicate to attached hosts that they can obtain stateful autoconfiguration information other than addresses. Use the **no** form to clear this flag from router advertisements.

### Syntax

**[no] ipv6 nd other-config-flag**

### Default Setting

Disabled

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ The “other-stateful-configuration” flag tells hosts that they should use stateful autoconfiguration to obtain information other than addresses from a DHCPv6 server.
- ◆ Some hosts interpret the “other stateful configuration” flag to indicate that they should use stateless address autoconfiguration to get IPv6 address (based on the IPv6 prefixes found in router advertisements) and stateful autoconfiguration to get other non-address parameters from DHCPv6 servers. In this case, the absence of both the “managed address configuration” flag and the “other stateful configuration” flag is interpreted to mean that they should use only stateless autoconfiguration to obtain addresses.

### Example

The following tells hosts to use stateful autoconfiguration to obtain other non-address information from a DHCPv6 server:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd other-config-flag
Console(config)#
```

**ipv6 nd ns-interval** This command configures the interval between transmitting IPv6 neighbor solicitation messages on an interface. Use the **no** form to restore the default value.

### Syntax

**ipv6 nd ns-interval** *milliseconds*

**no ipv6 nd ns-interval**

*milliseconds* - The interval between transmitting IPv6 neighbor solicitation messages. (Range: 1000-3600000)

### Default Setting

1000 milliseconds is used for neighbor discovery operations  
0 milliseconds is advertised in router advertisements

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ When a non-default value is configured, the specified interval is used both for router advertisements and by the router itself.

- ◆ This command specifies the interval between transmitting neighbor solicitation messages when resolving an address, or when probing the reachability of a neighbor. Therefore, avoid using very short intervals for normal IPv6 operations.
- ◆ Setting the neighbor solicitation interval to 0 means that the configured time is unspecified by this router. Setting the neighbor solicitation interval to 0 means that the configured time is unspecified by this router.

### Example

The following sets the interval between sending neighbor solicitation messages to 30000 milliseconds:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd ns-interval 30000
Console(config)#end
Console#show ipv6 interface
VLAN 1 is up
IPv6 is enabled.
Link-local address:
  fe80::269:3ef9:fe19:6779%1/64
Global unicast address(es):
  2001:db8:0:1:2e0:cff:fe02:fd/64, subnet is 2001:db8:0:1::/64[EUI][EUI]
  2001:db8:2222:7272::72/96, subnet is 2001:db8:2222:7272::/96
Joined group address(es):
  ff02::2
  ff02::1:ff19:6779
  ff02::1:ff00:0
  ff02::1:ff00:72
  ff02::1:ff02:fd
  ff02::1:2
  ff02::1
IPv6 link MTU is 1500 bytes
ND DAD is enabled, number of DAD attempts: 5.
ND retransmit interval is 30000 milliseconds
ND advertised retransmit interval is 30000 milliseconds
ND reachable time is 30000 milliseconds
ND advertised reachable time is 0 milliseconds
ND advertised router lifetime is 1800 seconds

Console#
```

### Related Commands

[show running-config \(126\)](#)

**ipv6 nd rguard** This command blocks incoming Router Advertisement and Router Redirect packets. Use the no form to disable this feature.

### Syntax

**[no] ipv6 nd rguard**

### Default Setting

Disabled

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ IPv6 Router Advertisements (RA) convey information that enables nodes to auto-configure on the network. This information may include the default router address taken from the observed source address of the RA message, as well as on-link prefix information. However, unintended mis-configurations, or possibly malicious attacks on the network, may lead to bogus RAs being sent, which in turn can cause operational problems for hosts on the network.
- ◆ This command can be used to block RAs and Router Redirect (RR) messages on the specified interface. Determine which interfaces are connected to known routers, and enable RA Guard on all other untrusted interfaces.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ipv6 nd raguard
Console(config-if)#
```

**show ipv6 nd raguard** This command displays the configuration setting for RA Guard.

### Syntax

**show ipv6 nd raguard** [*interface*]

*interface*

**ethernet** *unit/port*

*unit* - Unit identifier. (Range: 1)

*port* - Port number. (Range: 1-28/54)

**port-channel** *channel-id* (Range: 1-28)

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 nd raguard interface ethernet 1/1
Interface RA Guard
-----
Eth 1/ 1  Yes
Console#
```

**ipv6 nd reachable-time** This command configures the amount of time that a remote IPv6 node is considered reachable after some reachability confirmation event has occurred. Use the **no** form to restore the default setting.

### Syntax

**ipv6 nd reachable-time** *milliseconds*

**no ipv6 nd reachable-time**

*milliseconds* - The time that a node can be considered reachable after receiving confirmation of reachability. (Range: 0-3600000)

### Default Setting

30000 milliseconds is used for neighbor discovery operations  
0 milliseconds is advertised in router advertisements

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ The time limit configured by this parameter allows the router to detect unavailable neighbors. During the neighbor discover process, an IPv6 node will multicast neighbor solicitation messages to search for neighbor nodes. For a neighbor node to be considered reachable, it must respond to the neighbor soliciting node with a neighbor advertisement message to become a confirmed neighbor, after which the reachable timer will be considered in effect for subsequent unicast IPv6 layer communications.
- ◆ This time limit is included in all router advertisements sent out through an interface, ensuring that nodes on the same link use the same time value.
- ◆ Setting the time limit to 0 means that the configured time is unspecified by this router.

### Example

The following sets the reachable time for a remote node to 1000 milliseconds:

```
Console(config)#interface vlan 1
Console(config-if)ipv6 nd reachable-time 1000
Console(config-if)#
```

**ipv6 nd prefix** This command configures the IPv6 prefixes to include in router advertisements. Use the **no** form to remove a prefix.

### Syntax

**ipv6 nd prefix** *ipv6-address/prefix-length* {**default** |  
[*valid-lifetime preferred-lifetime* [**no-autoconfig** | **off-link**]]}

### **no ipv6 nd prefix** *ipv6-address/prefix-length*

*ipv6-address* - An IPv6 address including the network prefix and host address bits.

*prefix-length* - A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix (i.e., the network portion of the address).

**default** - Uses default values for remaining parameters.

*valid-lifetime* - The amount of time that the specified IPv6 prefix is advertised as being valid. (Range: 0-4294967295 seconds)

*preferred-lifetime* - The amount of time that the specified IPv6 prefix is advertised as being preferred. The preferred lifetime is counted down in real time. (Range: 0-4294967295 seconds)

**no-autoconfig** - Indicates to hosts on the local link that the specified prefix cannot be used for IPv6 autoconfiguration.

**off-link** - Indicates that the specified prefix is assigned to the link. Nodes sending traffic to addresses that contain the prefix consider the destination to be locally reachable on the link.

#### Default Setting

<i>valid-lifetime</i>	2592000 seconds
<i>preferred-lifetime</i>	2592000 seconds
no-autoconfig	Disabled
off-link	Disabled

#### Command Mode

Interface Configuration (VLAN)

#### Command Usage

- ◆ Prefixes configured as addresses on an interface using the [ipv6 address](#) command are advertised in router advertisements. If prefixes are configured for advertisement using the **ipv6 nd prefix** command, then only these prefixes are advertised.
- ◆ The preferred lifetime and valid lifetime are counted down in real time. After the preferred lifetime expires, no new connections are made using this prefix. When the valid lifetime expires, this prefix will no longer be advertised.
- ◆ All prefixes are inserted in the routing table as Connected (i.e., on-line), unless specified with the off-link option. If the off-link option is specified, and the prefix is already present in the routing table as a Connected prefix, it will be removed.
- ◆ Do not include the link-local prefix in the list of advertised prefixes.

### Example

The following configures a network prefix with a valid lifetime of 1000 seconds, and a preferred lifetime of 900 seconds:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd prefix 2011:0DBF::/35 1000 900
Console(config)#
```

**ipv6 nd ra interval** This command configures the interval between the transmission of IPv6 router advertisements on an interface. Use the **no** form to restore the default interval.

### Syntax

**ipv6 nd ra interval** *minimum-interval* [*maximum-interval*]

**no ipv6 nd ra interval**

*minimum-interval* - The maximum interval between IPv6 router advertisements. (Range: 4-1800 seconds)

*maximum-interval* - The minimum interval between IPv6 router advertisements. (Range: 3-1350 seconds)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

maximum interval: 600 seconds

minimum interval: 198 seconds

### Command Usage

- ◆ The interval between transmissions should be less than or equal to the IPv6 router advertisement lifetime if you configure a route as a default router by using the **ipv6 nd ra lifetime** command.
- ◆ To prevent synchronization with other IPv6 nodes, the actual interval used is randomly selected from a value between the minimum value set by the system (33% of the maximum RA interval) and the maximum value set by the **ipv6 nd ra interval** command.

### Example

The following sets the maximum RA interval to 1800 seconds:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd ra interval 1800
Console(config)#
```

**ipv6 nd ra lifetime** This command configures the router lifetime value used in IPv6 router advertisements sent from an interface. Use the **no** form to restore the default setting.

#### Syntax

**ipv6 nd ra lifetime** *lifetime*

**no ipv6 nd ra lifetime**

*lifetime* - Router lifetime. (Range: 0-9000 seconds)

#### Command Mode

Interface Configuration (VLAN)

#### Default Setting

1800 seconds

#### Command Usage

- ◆ This command can be used to indicate the usefulness of this router as a default router on this interface.
- ◆ Set the router lifetime to 0 to indicate that this router should not be considered a default router. Set the lifetime to a non-zero value to indicate that it should be considered a default router. When a non-zero value is used, the lifetime should not be less than the router advertisement interval.

#### Example

The following sets the router lifetime to 8000 seconds:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd ra lifetime 8000
Console(config)#
```

**ipv6 nd ra router-preference** This command configures the default router preference for the router on an interface. Use the **no** form to restore the default setting.

#### Syntax

**ipv6 nd ra router-preference** {**high** | **medium** | **low**}

**no ipv6 nd ra router-preference**

**high** - Preference for the router is high.

**medium** - Preference for the router is medium.

**low** - Preference for the router is low.

#### Command Mode

Interface Configuration (VLAN)

### Default Setting

medium

### Command Usage

Default router preference may be used to prioritize routers which provide equivalent, but not equal-cost, routing, and policy dictates that hosts should prefer one of the routers.

### Example

The following sets the default router preference to high:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd ra router-preference high
Console(config)#
```

**ipv6 nd ra suppress** This command suppresses router advertisement transmissions on an interface. Use the **no** form to re-enable router advertisements.

### Syntax

**[no] ipv6 nd ra suppress**

### Command Mode

Interface Configuration (VLAN, IPv6/v4 Tunnel)

### Default Setting

Not suppressed

### Command Usage

This command suppresses periodic unsolicited router advertisements. It does not suppress advertisements sent in response to a router solicitation.

### Example

The following suppresses router advertisements on the current interface:

```
Console(config)#interface vlan 1
Console(config)#ipv6 nd ra suppress
Console(config)#
```

**clear ipv6 neighbors** This command deletes all dynamic entries in the IPv6 neighbor discovery cache.

#### Command Mode

Privileged Exec

#### Example

The following deletes all dynamic entries in the IPv6 neighbor cache:

```
Console#clear ipv6 neighbors
Console#
```

**show ipv6 neighbors** This command displays information in the IPv6 neighbor discovery cache.

#### Syntax

**show ipv6 neighbors** [**vlan** *vlan-id* | *ipv6-address*]

*vlan-id* - VLAN ID (Range: 1-4094)

*ipv6-address* - The IPv6 address of a neighbor device. You can specify either a link-local or global unicast address formatted according to RFC 2373 "IPv6 Addressing Architecture," using 8 colon-separated 16-bit hexadecimal values. One double colon may be used in the address to indicate the appropriate number of zeros required to fill the undefined fields.

#### Default Setting

All IPv6 neighbor discovery cache entries are displayed.

#### Command Mode

Privileged Exec

#### Example

The following shows all known IPv6 neighbors for this switch:

```
Console#show ipv6 neighbors
State: I1 - Incomplete, I2 - Invalid, R - Reachable, S - Stale, D - Delay,
      P1 - Probe, P2 - Permanent, U - Unknown
IPv6 Address                               Age  Link-layer Addr  State Interface
-----
FE80::2E0:CFF:FE9C:CA10                    4    00-E0-0C-9C-CA-10 R      1
Console#
```

**Table 199: show ipv6 neighbors - display description**

Field	Description
IPv6 Address	IPv6 address of neighbor
Age	The time since the address was verified as reachable (in seconds). A static entry is indicated by the value "Permanent."

**Table 199: show ipv6 neighbors - display description** (Continued)

Field	Description
Link-layer Addr	Physical layer MAC address.
State	<p>The following states are used for dynamic entries:</p> <p>I1 (Incomplete) - Address resolution is being carried out on the entry. A neighbor solicitation message has been sent to the multicast address of the target, but it has not yet returned a neighbor advertisement message.</p> <p>I2 (Invalid) - An invalidated mapping. Setting the state to invalid dis-associates the interface identified with this entry from the indicated mapping (RFC 4293).</p> <p>R (Reachable) - Positive confirmation was received within the last ReachableTime interval that the forward path to the neighbor was functioning. While in REACH state, the device takes no special action when sending packets.</p> <p>S (Stale) - More than the ReachableTime interval has elapsed since the last positive confirmation was received that the forward path was functioning. While in STALE state, the device takes no action until a packet is sent.</p> <p>D (Delay) - More than the ReachableTime interval has elapsed since the last positive confirmation was received that the forward path was functioning. A packet was sent within the last DELAY_FIRST_PROBE_TIME interval. If no reachability confirmation is received within this interval after entering the DELAY state, the switch will send a neighbor solicitation message and change the state to PROBE.</p> <p>P1 (Probe) - A reachability confirmation is actively sought by resending neighbor solicitation messages every RetransTimer interval until confirmation of reachability is received.</p> <p>U (Unknown) - Unknown state.</p> <p>The following states are used for static entries:</p> <p>I1 (Incomplete)-The interface for this entry is down.</p> <p>R (Reachable) - The interface for this entry is up. Reachability detection is not applied to static entries in the IPv6 neighbor discovery cache.</p> <p>P2 (Permanent) - Indicates a static entry.</p>
VLAN	VLAN interface from which the address was reached.

### Related Commands

[show mac-address-table \(526\)](#)

**show ipv6 nd prefix** This command displays IPv6 prefixes in neighbor discovery router advertisements.

### Syntax

**show ipv6 nd prefix vlan** *vlan-id*

*vlan-id* - VLAN ID (Range: 1-4094)

### Default Setting

All IPv6 prefixes for the specified VLAN are displayed.

### Command Mode

Privileged Exec

### Example

The following shows all neighbor discovery IPv6 prefixes for VLAN 1:

```
Console#show ipv6 nd prefix vlan 1
Ipv6 Neighbor Discovery Prefix Information.

VLAN Name           : DefaultVlan

  IPv6 Prefix        : 2011:dbf::/35
  Valid Lifetime     : 2592000
  Preferred Lifetime : 604800
  On-link Flag       : On
  Autonomous Flag    : On

Console#
```

## ND Snooping

Neighbor Discover (ND) Snooping maintains an IPv6 prefix table and user address binding table. These tables can be used for stateless address auto-configuration or for address filtering by IPv6 Source Guard.

ND snooping maintains a binding table in the process of neighbor discovery. When it receives an Neighbor Solicitation (NS) packet from a host, it creates a new binding. If it subsequently receives a Neighbor Advertisement (NA) packet, this means that the address is already being used by another host, and the binding is therefore deleted. If it does not receive an NA packet after a timeout period, the binding will be bound to the original host. ND snooping can also maintain a prefix table used for stateless address auto-configuration by monitoring Router Advertisement (RA) packets sent from neighboring routers.

ND snooping can also detect if an IPv6 address binding is no longer valid. When a binding has been timed out, it checks to see if the host still exists by sending an NS packet to the target host. If it receives an NA packet in response, it knows that the target still exists and updates the lifetime of the binding; otherwise, it deletes the binding.

This section describes commands used to configure ND Snooping.

**Table 200: ND Snooping Commands**

Command	Function	Mode
<a href="#">ipv6 nd snooping</a>	Enables ND snooping globally or on a specified VLAN or range of VLANs	GC
<a href="#">ipv6 nd snooping auto-detect</a>	Enables automatic validation of binding table entries by periodically sending NS messages and awaiting NA replies	GC
<a href="#">ipv6 nd snooping auto-detect retransmit count</a>	Sets the number of times to send an NS message to determine if a binding is still valid	GC

Table 200: ND Snooping Commands (Continued)

Command	Function	Mode
<code>ipv6 nd snooping auto-detect retransmit interval</code>	Sets the interval between sending NS messages to determine if a binding is still valid	GC
<code>ipv6 nd snooping prefix timeout</code>	Sets the time to wait for an RA message before deleting an entry in the prefix table	GC
<code>ipv6 nd snooping max-binding</code>	Sets the maximum number of address entries which can be bound to a port	IC
<code>ipv6 nd snooping trust</code>	Configures a port as a trusted interface from which prefix information in RA messages can be added to the prefix table, or NS messages can be forwarded without validation	IC
<code>clear ipv6 nd snooping binding</code>	Clears all entries in the address binding table	PE
<code>clear ipv6 nd snooping prefix</code>	Clears all entries in the prefix table	PE
<code>show ipv6 nd snooping</code>	Shows configuration settings for ND snooping	PE
<code>show ipv6 nd snooping binding</code>	Shows entries in the binding table	PE
<code>show ipv6 nd snooping prefix</code>	Show entries in the prefix table	PE

**ipv6 nd snooping** This command enables ND snooping globally or on a specified VLAN or range of VLANs. Use the **no** form to disable this feature.

### Syntax

**[no] ipv6 nd snooping [vlan {vlan-id | vlan-range}]**

*vlan-id* - VLAN ID. (Range: 1-4094)

*vlan-range* - A consecutive range of VLANs indicated by the use a hyphen, or a random group of VLANs with each entry separated by a comma.

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

- ◆ Use this command without any keywords to enable ND snooping globally on the switch. Use the VLAN keyword to enable ND snooping on a specific VLAN or a range of VLANs.
- ◆ Once ND snooping is enabled both globally and on the required VLANs, the switch will start monitoring RA messages to build an address prefix table as described below:
  - If an RA message is received on an untrusted interface, it is dropped. If received on a trusted interface, the switch adds an entry in the prefix table

according to the Prefix Information option in the RA message. The prefix table records prefix, prefix length, valid lifetime, as well as the VLAN and port interface which received the message.

- If an RA message is not received updating a table entry with the same prefix for a specified timeout period, the entry is deleted.
- ◆ Once ND snooping is enabled both globally and on the required VLANs, the switch will start monitoring NS messages to build a dynamic user binding table for use in Duplicate Address Detection (DAD) or for use by other security filtering protocols (e.g., IPv6 Source Guard) as described below:
  - If an NS message is received on an trusted interface, it is forwarded without further processing.
  - If an NS message is received on an untrusted interface, and the address prefix does not match any entry in the prefix table, it drops the packet.
  - If the message does match an entry in the prefix table, it adds an entry to the dynamic user binding table after a fixed delay, and forwards the packet. Each entry in the dynamic binding table includes the link-layer address, IPv6 address, lifetime, as well as the VLAN and port interface which received the message.
  - If an RA message is received in response to the original NS message (indicating a duplicate address) before the dynamic binding timeout period expires, the entry is deleted. Otherwise, when the timeout expires, the entry is dropped if the auto-detection process is not enabled.
  - If the auto-detection process is enabled, the switch periodically sends an NS message to determine is the client still exists. If it does not receive an RA message in response after the configured timeout, the entry is dropped. If the switch receives an RA message before the timeout expires, it resets the lifetime for the dynamic binding, and the auto-detection process resumes.

### Example

This example enables ND snooping globally and on VLAN 1.

```
Console(config)#ipv6 nd snooping
Console(config)#ipv6 nd snooping vlan 1
Console(config)#
```

### ipv6 nd snooping auto-detect

This command enables automatic validation of dynamic user binding table entries by periodically sending NS messages and awaiting NA replies. Use the **no** form to disable this feature.

### Syntax

**[no] ipv6 nd snooping auto-detect**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

If auto-detection is enabled, the switch periodically sends an NS message to determine if a client listed in the dynamic binding table still exists. If it does not receive an RA message in response after the configured timeout, the entry is dropped. If the switch receives an RA message before the timeout expires, it resets the lifetime for the dynamic binding, and the auto-detection process resumes.

### Example

```
Console(config)#ipv6 nd snooping auto-detect
Console(config)#
```

### ipv6 nd snooping auto-detect retransmit count

This command sets the number of times the auto-detection process sends an NS message to determine if a dynamic user binding is still valid. Use the **no** form to restore the default setting.

### Syntax

**ipv6 nd snooping auto-detect retransmit count** *retransmit-times*

**no ipv6 nd snooping auto-detect retransmit count**

*retransmit-times* – The number of times to send an NS message to determine if a client still exists. (Range: 1-5)

### Default Setting

3

### Command Mode

Global Configuration

### Command Usage

The timeout after which the switch will delete a dynamic user binding if no RA message is received is set to the retransmit count x the retransmit interval (see the [ipv6 nd snooping auto-detect retransmit interval](#) command). Based on the default settings, this is 3 seconds.

### Example

```
Console(config)#ipv6 nd snooping auto-detect retransmit count 5
Console(config)#
```

**ipv6 nd snooping auto-detect retransmit interval** This command sets the interval between which the auto-detection process sends NS messages to determine if a dynamic user binding is still valid. Use the **no** form to restore the default setting.

#### Syntax

**ipv6 nd snooping auto-detect retransmit interval** *retransmit-interval*

**no ipv6 nd snooping auto-detect retransmit interval**

*retransmit-interval* – The interval between which the switch sends an NS message to determine if a client still exists. (Range: 1-10 seconds)

#### Default Setting

1 second

#### Command Mode

Global Configuration

#### Command Usage

The timeout after which the switch will delete a dynamic user binding if no RA message is received is set to the retransmit count (see the [ipv6 nd snooping auto-detect retransmit count](#) command) x the retransmit interval. Based on the default settings, this is 3 seconds.

#### Example

```
Console(config)#ipv6 nd snooping auto-detect retransmit interval 5
Console(config)#
```

**ipv6 nd snooping prefix timeout** This command sets the time to wait for an RA message before deleting an entry in the prefix table. Use the **no** form to restore the default setting.

#### Syntax

**ipv6 nd snooping prefix timeout** *timeout*

**no ipv6 nd snooping prefix timeout**

*timeout* – The time to wait for an RA message to confirm that a prefix entry is still valid. (Range: 3-1800 seconds)

#### Default Setting

None set

#### Command Mode

Global Configuration

#### Command Usage

If ND snooping is enabled and an RA message is received on a trusted interface, the switch will add an entry in the prefix table based upon the Prefix Information

contained in the message. If an RA message is not received for a table entry with the same prefix for the specified timeout period, the entry is deleted.

### Example

```
Console(config)#ipv6 nd snooping prefix timeout 200
Console(config)#
```

**ipv6 nd snooping max-binding** This command sets the maximum number of address entries in the dynamic user binding table which can be bound to a port. Use the **no** form to restore the default setting.

### Syntax

**ipv6 nd snooping max-binding** *max-bindings*

**no ipv6 nd snooping max-binding**

*max-bindings* – The maximum number of address entries in the dynamic user binding table which can be bound to a port. (Range: 1-5)

### Default Setting

5

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Example

```
Console(config)#interface ethernet 1/12
Console(config-if)#ipv6 nd snooping max-binding 5
Console(config-if)#
```

**ipv6 nd snooping trust** This command configures a port as a trusted interface from which prefix information in RA messages can be added to the prefix table, or NS messages can be forwarded without validation. Use the **no** form to restore the default setting.

### Syntax

**[no] ipv6 nd snooping trust**

### Default Setting

Not trusted

### Command Mode

Interface Configuration (Ethernet, Port Channel)

### Command Usage

- ◆ In general, interfaces facing toward to the network core, or toward routers supporting the Network Discovery protocol, are configured as trusted interfaces.
- ◆ RA messages received from a trusted interface are added to the prefix table and forwarded toward their destination.
- ◆ NS messages received from a trusted interface are forwarded toward their destination. Nothing is added to the dynamic user binding table.

### Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#ipv6 nd snooping trust
Console(config-if)#
```

**clear ipv6 nd snooping binding** This command clears all entries in the dynamic user address binding table.

### Syntax

**clear ipv6 nd snooping binding**

### Command Mode

Privileged Exec

### Example

```
Console#clear ipv6 nd snooping binding
Console#show ipv6 nd snooping binding
MAC Address      IPv6 Address      Lifetime  VLAN Interface
-----
Console#
```

**clear ipv6 nd snooping prefix** This command clears all entries in the address prefix table.

### Syntax

**clear ipv6 nd snooping prefix [interface vlan *vlan-id*]**

*vlan-id* - VLAN ID. (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#clear ipv6 nd snooping prefix
Console#show ipv6 nd snooping prefix
Prefix entry timeout: (seconds)
Prefix          Len Valid-Time Expire  VLAN Interface
```

```
-----  
Console#
```

**show ipv6 nd snooping** This command shows the configuration settings for ND snooping.

### Syntax

**show ipv6 nd snooping**

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 nd snooping  
Global ND Snooping status: enabled  
ND Snooping auto-detection: disabled  
ND Snooping auto-detection retransmit count: 3  
ND Snooping auto-detection retransmit interval: 1 (second)  
ND Snooping is configured on the following VLANs:  
VLAN 1,  
Interface          Trusted          Max-binding  
-----  
Eth 1/1            Yes             1  
Eth 1/2            No              5  
Eth 1/3            No              5  
Eth 1/4            No              5  
Eth 1/5            No              5  
⋮
```

**show ipv6 nd snooping binding** This command shows all entries in the dynamic user binding table.

### Syntax

**show ipv6 nd snooping binding**

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 nd snooping binding  
MAC Address      IPv6 Address          Lifetime  VLAN Interface  
-----  
0013-49aa-3926  2001:b001::211:95ff:fe84:cb9e  100      1 Eth 1/1  
0012-cf01-0203  2001::1                  3400     2 Eth 1/2  
Console#
```

**show ipv6 nd snooping prefix** This command shows all entries in the address prefix table.

#### Syntax

**show ipv6 nd snooping prefix** [**interface vlan** *vlan-id*]

*vlan-id* - VLAN ID. (Range: 1-4094)

#### Command Mode

Privileged Exec

#### Example

```
Console#show ipv6 nd snooping prefix
Prefix entry timeout: 100 (second)
Prefix                               Len Valid-Time Expire      VLAN Interface
-----
2001:b000::                           64   2592000    100    1 Eth 1/1
2001::                                  64     600      34     2 Eth 1/2
Console#
```

## VRRP Commands

Virtual Router Redundancy Protocol (VRRP) use a virtual IP address to support a primary router and multiple backup routers. The backup routers can be configured to take over the workload if the master router fails, or can also be configured to share the traffic load. The primary goal of router redundancy is to allow a host device which has been configured with a fixed gateway to maintain network connectivity in case the primary gateway goes down.

To configure VRRP, select an interface on each router in the group that will participate in the protocol as the master router or a backup router. To select a specific device as the master router, set the address of this interface as the virtual router address for the group. Now set the same virtual address and a priority on the backup routers, and configure an authentication string. You can also enable the preempt feature which allows a router to take over as the master router when it comes on line if it has a higher priority than the currently active master router.

**Table 201: VRRP Commands**

Command	Function	Mode
<code>vrrp authentication</code>	Configures a key used to authenticate VRRP packets received from other routers	IC
<code>vrrp ip</code>	Enables VRRP and sets the IP address of the virtual router	IC
<code>vrrp preempt</code>	Configures the router to take over as master virtual router for a VRRP group if it has a higher priority than the current master virtual router	IC
<code>vrrp priority</code>	Sets the priority of this router in the VRRP group	IC
<code>vrrp timers advertise</code>	Sets the interval between successive advertisements by the master virtual router	IC
<code>show vrrp</code>	Displays VRRP status information	PE
<code>show vrrp interface</code>	Displays VRRP status information for the specified interface	PE
<code>show vrrp interface counters</code>	Displays VRRP statistics for the specified interface	PE
<code>show vrrp router counters</code>	Displays VRRP statistics	PE

**vrrp authentication** This command specifies the key used to authenticate VRRP packets received from other routers. Use the **no** form to prevent authentication.

### Syntax

**vrrp group authentication key**

**no vrrp group authentication**

*group* - Identifies the virtual router group. (Range: 1-255)  
The maximum number of groups which can be defined is 64.

*key* - Authentication string. (Range: 1-8 alphanumeric characters)

### Default Setting

No key is defined.

### Command Mode

Interface (VLAN)

### Command Usage

- ◆ All routers in the same VRRP group must be configured with the same authentication key.
- ◆ When a VRRP packet is received from another router in the group, its authentication key is compared to the string configured on this router. If the keys match, the message is accepted. Otherwise, the packet is discarded.
- ◆ Plain text authentication does not provide any real security. It is supported only to prevent a misconfigured router from participating in VRRP.

### Example

```
Console(config-if)#vrrp 1 authentication bluebird
Console(config-if)#
```

**vrrp ip** This command enables the Virtual Router Redundancy Protocol (VRRP) on an interface and specifies the IP address of the virtual router. Use the **no** form to disable VRRP on an interface and remove the IP address from the virtual router.

### Syntax

**[no] vrrp group ip ip-address**

*group* - Identifies the virtual router group. (Range: 1-255)  
The maximum number of groups which can be defined is 64.

*ip-address* - The IP address of the virtual router. This is the IP address that end-hosts set as their default gateway.

### Default Setting

No virtual router groups are configured.

### Command Mode

Interface (VLAN)

### Command Usage

- ◆ The interfaces of all routers participating in a virtual router group must be within the same IP subnet.
- ◆ If the IP address assigned to the virtual router with this command is already configured as the primary address on this interface, this router is considered the Owner, and will assume the role of the Master virtual router in the group.
- ◆ This interface is used for two purposes - to send/receive advertisement messages and to forward on behalf of the virtual router when operating as the Master VRRP router.
- ◆ VRRP is enabled as soon as this command is entered. If you need to customize any of the other parameters for VRRP such as authentication, priority, or advertisement interval, then first configure these parameters before enabling VRRP.

### Example

This example creates VRRP group 1 using the primary interface for VLAN 1 as the VRRP group Owner.

```

Console(config)#interface vlan 1
Console(config-if)#vrrp 1 ip 192.168.1.6
Console(config-if)#

```

**vrrp preempt** This command configures the router to take over as the master virtual router for a VRRP group if it has a higher priority than the current acting master router. Use the **no** form to disable preemption.

### Syntax

**vrrp group preempt [delay seconds]**

**no vrrp group preempt**

*group* - Identifies the VRRP group. (Range: 1-255)

The maximum number of groups which can be defined is 64.

*seconds* - The time to wait before issuing a claim to become the master. (Range: 0-120 seconds)

### Default Setting

Preempt: Enabled

Delay: 0 seconds

### Command Mode

Interface (VLAN)

**Command Usage**

- ◆ If preempt is enabled, and this backup router has a priority higher than the current acting master, it will take over as the new master. However, note that if the original master (i.e., the owner of the VRRP IP address) comes back on line, it will always resume control as the master.
- ◆ The delay can give additional time to receive an advertisement message from the current master before taking control. If the router attempting to become the master has just come on line, this delay also gives it time to gather information for its routing table before actually preempting the currently active router.

**Example**

```
Console(config-if)#vrrp 1 preempt delay 10
Console(config-if)#
```

**Related Commands**

[vrrp priority \(998\)](#)

**vrrp priority** This command sets the priority of this router in a VRRP group. Use the **no** form to restore the default setting.

**Syntax**

**vrrp** *group* **priority** *level*

**no vrrp** *group* **priority**

*group* - Identifies the VRRP group. (Range: 1-255)  
The maximum number of groups which can be defined is 64.

*level* - Priority of this router in the VRRP group. (Range: 1-255)

**Default Setting**

Master: 255

Backup: 100

**Command Mode**

Interface (VLAN)

**Command Usage**

- ◆ A router that has a physical interface with the same IP address as that used for the virtual router (that is, the owner of the VRRP IP address) will become the master virtual router. The backup router with the highest priority will become the master router if the current master fails. When the original master router recovers, it will take over as the active master router again.

- ◆ If two or more routers are configured with the same VRRP priority, the router with the highest IP address is elected as the new master router if the current master fails.
- ◆ If the backup preempt function is enabled with the `vrrp preempt` command, and a backup router with a priority higher than the current acting master comes on line, this backup router will take over as the new acting master. However, note that if the original master (i.e., the owner of the VRRP IP address) comes back on line, it will always resume control as the master.
- ◆ If the virtual IP address for the VRRP group is the same as that of the configured device, the priority will automatically be set to 255 prior to using this command.

### Example

```
Console(config-if)#vrrp 1 priority 1
Console(config-if)#
```

### Related Commands

[vrrp preempt \(997\)](#)

**vrrp timers advertise** This command sets the interval at which the master virtual router sends advertisements communicating its state as the master. Use the **no** form to restore the default interval.

### Syntax

**vrrp** *group* **timers advertise** *interval*

**no vrrp** *group* **timers advertise**

*group* - Identifies the VRRP group. (Range: 1-255)  
The maximum number of groups which can be defined is 64.

*interval* - Advertisement interval for the master virtual router.  
(Range: 1-255 seconds)

### Default Setting

1 second

### Command Mode

Interface (VLAN)

### Command Usage

- ◆ VRRP advertisements from the current master virtual router include information about its priority and current state as the master.

- ◆ VRRP advertisements are sent to the multicast address 224.0.0.18. Using a multicast address reduces the amount of traffic that has to be processed by network devices that are not part of the designated VRRP group.
- ◆ If the master router stops sending advertisements, backup routers will bid to become the master router based on priority. The dead interval before attempting to take over as the master is three times the hello interval plus half a second

### Example

```
Console(config-if)#vrrp 1 timers advertise 5
Console(config-if)#
```

**show vrrp** This command displays status information for VRRP.

### Syntax

**show vrrp** [**brief** | *group*]

**brief** - Displays summary information for all VRRP groups on this router.

*group* - Identifies a VRRP group. (Range: 1-255)

### Defaults

None

### Command Mode

Privileged Exec

### Command Usage

- ◆ Use this command without any keywords to display the full listing of status information for all VRRP groups configured on this router.
- ◆ Use this command with the **brief** keyword to display a summary of status information for all VRRP groups configured on this router.
- ◆ Specify a group number to display status information for a specific group

### Example

This example displays the full listing of status information for all groups.

```
Console#show vrrp
VLAN 1 - Group 1,
State                               Master
Virtual IP Address                  192.168.1.6
Virtual MAC Address                  00-00-5E-00-01-01
Advertisement Interval                5 sec
Preemption                           Enabled
Min Delay                             10 sec
Priority                               255
```

```

Authentication                SimpleText
Authentication Key            bluebird
Master Router                  192.168.1.6
Master Priority                 255
Master Advertisement Interval  5 sec
Master Down Interval           15
Console#

```

**Table 202: show vrrp - display description**

Field	Description
State	VRRP role of this interface (master or backup)
Virtual IP address	Virtual address that identifies this VRRP group
Virtual MAC address	Virtual MAC address derived from the owner of the virtual IP address
Advertisement interval	Interval at which the master virtual router advertises its role as the master
Preemption	Shows whether or not a higher priority router can preempt the current acting master
MinDelay	Delay before a router with a higher priority can preempt the current acting master
Priority	Priority of this router
Authentication	Authentication mode used to verify VRRP packets
Authentication Key	Key used to authenticate VRRP packets received from other routers
Master Router	IP address of the router currently acting as the VRRP group master
Master Priority	The priority of the router currently acting as the VRRP group master
Master Advertisement Interval	The advertisement interval configured on the VRRP master.
Master down Interval	The down interval configured on the VRRP master (This interval is used by all the routers in the group regardless of their local settings)

This example displays the brief listing of status information for all groups.

```

Console#show vrrp brief
Interface  Grp   State   Virtual Addr   Interval  Preempt  Priority
-----
VLAN 1    1    Master   192.168.0.3    1        E        255
Console#

```

**Table 203: show vrrp brief - display description**

Field	Description
Interface	VLAN interface
Grp	VRRP group
State	VRRP role of this interface (master or backup)

**Table 203: show vrrp brief - display description** (Continued)

Field	Description
Virtual Addr	Virtual address that identifies this VRRP group
Interval	Interval at which the master virtual router advertises its role as the master
Preempt	Shows whether or not a higher priority router can preempt the current acting master
Priority	Priority of this router

**show vrrp interface** This command displays status information for the specified VRRP interface.

### Syntax

**show vrrp interface vlan** *vlan-id* [**brief**]

*vlan-id* - Identifier of configured VLAN interface. (Range: 1-4094)

**brief** - Displays summary information for all VRRP groups on this router.

### Defaults

None

### Command Mode

Privileged Exec

### Example

This example displays the full listing of status information for VLAN 1.

```

Console#show vrrp interface vlan 1
Vlan 1 - Group 1,
State                               Master
Virtual IP Address                   192.168.1.6
Virtual MAC Address                   00-00-5E-00-01-01
Advertisement Interval                5 sec
Preemption                           Enabled
Min Delay                             10 sec
Priority                               1
Authentication                       SimpleText
Authentication Key                    bluebird
Master Router                         192.168.1.6
Master Priority                        1
Master Advertisement Interval         5 sec
Master Down Interval                  15
Console#

```

\* Refer to the [show vrrp](#) command for a description of the display items.

**show vrrp interface counters** This command displays counters for VRRP protocol events and errors that have occurred for the specified group and interface.

**show vrrp group interface vlan interface counters**

*group* - Identifies a VRRP group. (Range: 1-255)

*interface* - Identifier of configured VLAN interface. (Range: 1-4094)

**Defaults**

None

**Command Mode**

Privileged Exec

**Example**

```

Console#show vrrp 1 interface vlan 1 counters
Total Number of Times Transitioned to MASTER           : 6
Total Number of Received Advertisements Packets       : 0
Total Number of Received Error Advertisement Interval Packets : 0
Total Number of Received Authentication Failures Packets : 0
Total Number of Received Error IP TTL VRRP Packets    : 0
Total Number of Received Priority 0 VRRP Packets      : 0
Total Number of Sent Priority 0 VRRP Packets          : 5
Total Number of Received Invalid Type VRRP Packets    : 0
Total Number of Received Error Address List VRRP Packets : 0
Total Number of Received Invalid Authentication Type VRRP Packets : 0
Total Number of Received Mismatch Authentication Type VRRP Packets : 0
Total Number of Received Error Packet Length VRRP Packets : 0
Console#

```

**Table 204: show vrrp interface counters - display description**

Parameter	Description
Times Transitioned to Master	Number of times this router has transitioned to master.
Received Advertisement Packets	Number of VRRP advertisements received by this router.
Received Error Advertisement Interval Packets	Number of VRRP advertisements received for which the advertisement interval is different from the one configured for the local virtual router.
Received Authentication Failure Packets	Number of VRRP packets received that do not pass the authentication check.
Received Error IP TTL VRRP Packets	Number of VRRP packets received by the virtual router with IP TTL (Time-To-Live) not equal to 255.
Received Priority 0 VRRP Packets	Number of VRRP packets received by the virtual router with priority set to 0.
Sent Priority 0 VRRP Packets	Number of VRRP packets sent by the virtual router with priority set to 0. A priority value of zero indicates that the group master has stopped participating in VRRP, and is used to quickly transition a backup unit to master mode without having to wait for the master to time out.
Received Invalid Type VRRP Packets	Number of VRRP packets received by the virtual router with an invalid value in the "type" field.

**Table 204: show vrrp interface counters - display description**

Parameter	Description
Received Error Address List VRRP Packets	Number of packets received for which the address list does not match the locally configured list for the virtual router.
Received Invalid Authentication Type VRRP Packets	Number of packets received with an unknown authentication type.
Received Mismatch Authentication Type VRRP Packets	Number of packets received with "Auth Type" not equal to the locally configured authentication method.
Received Error Packets Length VRRP Packets	Number of packets received with a packet length less than the length of the VRRP header.

**show vrrp router counters** This command displays counters for errors found in VRRP protocol packets.

#### Command Mode

Privileged Exec

#### Example

Note that unknown errors indicate VRRP packets received with an unknown or unsupported version number.

```

Console#show vrrp router counters
  Total Number of VRRP Packets with Invalid Checksum : 0
  Total Number of VRRP Packets with Unknown Error   : 0
  Total Number of VRRP Packets with Invalid VRID    : 0
Console#

```

# IP Routing Commands

After network interfaces are configured for the switch, the paths used to send traffic between different interfaces must be set. To forward traffic to devices on other subnetworks, either configure fixed paths with static routing commands, or enable a dynamic routing protocol that exchanges information with other routers on the network to automatically determine the best path to any subnetwork.

This section includes commands for static routing. These commands are used to connect between different local subnetworks or to connect the router to the enterprise network.

**Table 188: IP Routing Commands**

Command Group	Function
<a href="#">Global Routing Configuration</a>	Configures global parameters for static routing, displays the routing table

## Global Routing Configuration

**Table 189: Global Routing Configuration Commands**

Command	Function	Mode
<i>IPv4 Commands</i>		
<a href="#">ip route</a>	Configures static routes	GC
<a href="#">maximum-paths</a>	Sets the maximum number of paths allowed	GC
<a href="#">show ip route</a>	Displays entries in the routing table	PE
<a href="#">show ip host-route</a>	Displays the interface associated with known routes	PE
<a href="#">show ip route database</a>	Displays static or dynamically learned entries in the routing table	PE
<a href="#">show ip route summary</a>	Displays summary information for the routing table	PE
<a href="#">show ip traffic</a>	Displays statistics for IP, ICMP, UDP, TCP and ARP protocols	PE
<i>IPv6 Commands</i>		
<a href="#">ipv6 route</a>	Configures static routes	GC
<a href="#">show ipv6 route</a>	Displays specified entries in the routing table	PE

## IPv4 Commands

**ip route** This command configures static routes. Use the **no** form to remove static routes.

### Syntax

**ip route** *destination-ip netmask* {*next-hop* [*distance*] | **null0**}

**no ip route** {*destination-ip netmask* [*next-hop* | **null0**] | \*}

*destination-ip* – IP address of the destination network, subnetwork, or host.

*netmask* – Network mask for the associated IP subnet. This mask identifies the host address bits used for routing to specific subnets.

*next-hop* – IP address of the next hop router used for this route.

*distance* – An administrative distance indicating that this route can be overridden by dynamic routing information if the distance of the dynamic route is less than that configured for the static route. Note that the default administrative distances used by the dynamic unicast routing protocols is 120 for RIP, 20 for eBGP, and 200 for iBGP. (Range: 1-255, Default: 1)

**null0** – Keyword for specifying a null interface.

\* – Removes all static routing table entries.

### Default Setting

No static routes are configured.

### Command Mode

Global Configuration

### Command Usage

- ◆ Up to 1024 static routes can be configured.
- ◆ If an administrative distance is defined for a static route, and the same destination can be reached through a dynamic route at a lower administration distance, then the dynamic route will be used.
- ◆ A null interface never forwards or receives traffic. Packets routed to a null interface are dropped.
- ◆ Up to eight equal-cost multipaths (ECMP) can be configured for static routing using the [maximum-paths](#) command.

### Example

This example forwards all traffic for subnet 192.168.1.0 to the gateway router 192.168.5.254, using the default metric of 1.

```
Console(config)#ip route 192.168.1.0 255.255.255.0 192.168.5.254
Console(config)#
```

**maximum-paths** This command sets the maximum number of paths allowed. Use the **no** form to restore the default settings.

### Syntax

**maximum-paths** *path-count*

**no maximum-paths**

*path-count* - The maximum number of equal-cost paths to the same destination that can be installed in the routing table. (Range: 1-8)

### Default Setting

Enabled, 4 paths

### Command Mode

Global Configuration

### Command Usage

- ◆ Up to eight equal-cost multipaths (ECMP) can be configured for routing using this command.
- ◆ Using ECMP in a network will distribute traffic equally across paths with the same cost. In cases where a different traffic balance is required, you can modify the OSPF cost of links using the [ip ospf cost](#) command, or adjust the BGP weight using the [neighbor weight](#) command.

### Example

```
Console(config)#maximum-paths 8
Console(config)#
```

**show ip route** This command displays information in the Forwarding Information Base (FIB).

### Syntax

**show ip route** [**connected** | **database** | **rip** | **static** | **summary**]

**connected** – Displays all currently connected entries.

**database** – All known routes, including inactive routes. See [show ip route database](#).

**rip** – Displays all entries learned through the Routing Information Protocol (RIP).

**static** – Displays all static entries.

**summary** – Displays a brief list of summary information about entries in the routing table, including the maximum number of entries supported, the number of connected routes, the total number of routes currently stored in the routing table, and the number of entries in the FIB. See [show ip route summary](#).

## Command Mode

Privileged Exec

## Command Usage

- ◆ The FIB contains information required to forward IP traffic. It contains the interface identifier and next hop information for each reachable destination network prefix based on the IP routing table. When routing or topology changes occur in the network, the routing table is updated, and those changes are immediately reflected in the FIB.

The FIB is distinct from the routing table (or, Routing Information Base), which holds all routing information received from routing peers. The forwarding information base contains unique paths only. It does not contain any secondary paths. A FIB entry consists of the minimum amount of information necessary to make a forwarding decision on a particular packet. The typical components within a forwarding information base entry are a network prefix, a router port identifier, and next hop information.

- ◆ This command only displays routes which are currently accessible for forwarding. The router must be able to directly reach the next hop, so the VLAN interface associated with any dynamic or static route entry must be up. Note that routes currently not accessible for forwarding, may still be displayed by using the [show ip route database](#) command.

## Example

```
Console#show ip route
Codes: K - kernel route, C - connected, S - static, R - RIP,
       B - BGP, T - Table, v - VNC, V - VNC-Direct,
       > - selected route, * - FIB route, q - queued, r - rejected, b - backup
       t - trapped, o - offload failure

C>* 10.10.10.0/24 is directly connected, VLAN1, 02:22:54
C>* 192.168.10.0/24 is directly connected, VLAN10, 02:24:02
Console#
```

The RIB contains all available routes learned through directly attached networks, and any additionally configured routes such as static routes. The RIB contains the set of all available routes from which optimal entries are selected for use by the Forwarding Information Base (see Command Usage under the [show ip route](#) command).

```
Console#show ip route database
Codes: C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       > - selected route, * - FIB route, p - stale info

S    *> 0.0.0.0/0 [1/0] via 192.168.2.1, VLAN1
C    *> 192.168.2.0/24 is directly connected, VLAN1
Console#
```

In the following example, the numeric identifier following the routing table name (0) indicates the Forwarding Information Base identifier.

```

Console#show ip route summary
IP routing table name is Default-IP-Routing-Table(0)
IP routing table maximum-paths is 1
Connected          1
Static             1
Total              2
Console#
    
```

**show ip host-route** This command displays the interface associated with known routes.

### Syntax

**show ip host-route**

### Command Mode

Privileged Exec

### Example

```

Console#show ip host-route
IP Address      MAC Address      VLAN Port
-----
192.168.0.99    00-E0-29-94-34-64  1 1/1
192.168.1.250  00-00-30-01-01-01  3 1/ 1
10.2.48.2      00-00-30-01-01-02  1 1/ 1
10.2.5.6       00-00-30-01-01-03  1 1/ 2
10.3.9.1       00-00-30-01-01-04  2 1/ 3
Console#
    
```

**Table 190: show ip host-route - display description**

Field	Description
IP Address	IP address of the destination network, subnetwork, or host.
MAC Address	The physical layer address associated with the IP address.
VLAN	The VLAN that connects to this IP address.
Port	The port that connects to this IP address.

**show ip route database** This command displays entries in the Routing Information Base (RIB).

**Command Mode**  
Privileged Exec

#### Command Usage

The RIB contains all available routes learned through dynamic routing protocols, directly attached networks, and any additionally configured routes such as static routes. The RIB contains the set of all available routes from which optimal entries are selected for use by the Forwarding Information Base (see Command Usage under the [show ip route](#) command).

#### Example

```
Console#show ip route database
Codes: C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       > - selected route, * - FIB route, p - stale info

C    *> 127.0.0.0/8 is directly connected, lo0
C    *> 192.168.1.0/24 is directly connected, VLAN1

Console#
```

**show ip route summary** This command displays summary information for the routing table.

**Command Mode**  
Privileged Exec

#### Example

In the following example, the numeric identifier following the routing table name (0) indicates the Forwarding Information Base (FIB) identifier.

```
Console#show ip route summary
Route Source      Routes      FIB (vrf default)
connected         2           2
-----
Totals            2           2

Console#
```

**show ip traffic** This command displays statistics for IP, ICMP, UDP, TCP and ARP protocols.

**Command Mode**  
Privileged Exec

## Example

```
Console#show ip traffic
IP Statistics:
IP received
    4877 total received
        header errors
        unknown protocols
        address errors
        discards
    4763 delivers
        reassembly request datagrams
        reassembled succeeded
        reassembled failed

IP sent
    forwards datagrams
    5927 requests
        discards
        no routes
        generated fragments
        fragment succeeded
        fragment failed

ICMP Statistics:
ICMP received
    input
    errors
    destination unreachable messages
    time exceeded messages
    parameter problem message
    echo request messages
    echo reply messages
    redirect messages
    timestamp request messages
    timestamp reply messages
    source quench messages
    address mask request messages
    address mask reply messages

ICMP sent
    output
    errors
    destination unreachable messages
    time exceeded messages
    parameter problem message
    echo request messages
    echo reply messages
    redirect messages
    timestamp request messages
    timestamp reply messages
    source quench messages
    address mask request messages
    address mask reply messages

UDP Statistics:
    2 input
        no port errors
        other errors
    output

TCP Statistics:
    4698 input
        input errors
    5867 output

Console#
```

## IPv6 Commands

**ipv6 route** This command configures static IPv6 routes. Use the **no** form to remove static routes.

### Syntax

```
[no] ipv6 route destination-ipv6-address/prefix-length  
{gateway-address [distance] |  
link-local-address%zone-id [distance]}
```

*destination-ipv6-address* – The IPv6 address of a destination network, subnetwork, or host. This must be a full IPv6 address including the network prefix and host address bits.

*prefix-length* – A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix (i.e., the network portion of the address).

*gateway-address* – IP address of the next hop router used for this route.

*link-local-address%zone-id* – a link-local address, including a zone-id indicating the VLAN identifier after the % delimiter.

*distance* – An administrative distance indicating that this route can be overridden by dynamic routing information if the distance of the dynamic route is less than that configured for the static route. Note that the default administrative distances used by the dynamic unicast routing protocols is 110 for OSPF, 120 for RIP, 20 for eBGP, and 200 for iBGP. (Range: 1-255, Default: 1)

### Default Setting

No static routes are configured.

### Command Mode

Global Configuration

### Command Usage

- ◆ Up to 1024 static routes can be configured.
- ◆ If an administrative distance is defined for a static route, and the same destination can be reached through a dynamic route at a lower administration distance, then the dynamic route will be used.
- ◆ The default distance of 1 will take precedence over any other type of route, except for local routes.
- ◆ If both static and dynamic paths have the same lowest cost, the first route stored in the routing table, either statically configured or dynamically learned via a routing protocol, will be used.

### Example

This example forwards all traffic for subnet 2001::/64 to the next hop router 2001:DB8:2222:7272::254, using the default metric of 1.

```
Console(config)#ipv6 route 2001::/64 2001:DB8:2222:7272::254
Console(config)#
```

### Related Commands

[show ip route summary \(1010\)](#)

**show ipv6 route** This command displays information in the Forwarding Information Base (FIB).

### Syntax

**show ipv6 route** [*ipv6-address*[/*prefix-length*] | **database** | **interface** [*vlan vlan-id*] | **local** | **static**]

*ipv6-address* - A full IPv6 address including the network prefix and host address bits.

*prefix-length* - A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix (i.e., the network portion of the address).

**database** – All known routes, including inactive routes.

**interface** – Displays all routes that be accessed through this interface.

**local** – Displays all entries for destinations attached directly to this router.

**static** – Displays all static entries.

*vlan-id* - VLAN ID. (Range: 1-4093)

### Command Mode

Privileged Exec

### Command Usage

- ◆ The FIB contains information required to forward IP traffic. It contains the interface identifier and next hop information for each reachable destination network prefix based on the IP routing table. When routing or topology changes occur in the network, the routing table is updated, and those changes are immediately reflected in the FIB.

The FIB is distinct from the routing table (or, Routing Information Base), which holds all routing information received from routing peers. The forwarding information base contains unique paths only. It does not contain any secondary paths. A FIB entry consists of the minimum amount of information necessary to make a forwarding decision on a particular packet. The typical components within a forwarding information base entry are a network prefix, a router port identifier, and next hop information.

- ◆ This command only displays routes which are currently accessible for forwarding. The router must be able to directly reach the next hop, so the VLAN interface associated with any dynamic or static route entry must be up.

### Example

In the following example, note that the last entry displays both the distance and metric for this route.

```
Console#show ipv6 route
Codes: K - kernel route, C - connected, S - static, B - BGP,
       T - Table, v - VNC, V - VNC-Direct,
       > - selected route, * - FIB route, q - queued, r - rejected, b - backup
       t - trapped, o - offload failure

C * fe80::/64 is directly connected, VLAN1, 02:17:31
C>* fe80::/64 is directly connected, VLAN10, 02:18:47
K>* ff00::/8 [0/256] is directly connected, VLAN1, 02:17:33

Console#
```

# RIP Commands

This section includes commands for Routing Information Protocol (RIP) dynamic routing. These commands are used to connect between different local subnetworks.

The RIP protocol is the most widely used routing protocol. The RIP protocol uses a distance-vector-based approach to routing. Routes are determined on the basis of minimizing the distance vector, or hop count, which serves as a rough estimate of transmission cost. Each router broadcasts its advertisement every 30 seconds, together with any updates to its routing table. This allows all routers on the network to learn consistent tables of next hop links which lead to relevant subnets.

**Table 191: Routing Information Protocol Commands**

Command	Function	Mode
<code>router rip</code>	Enables the RIP routing protocol	GC
<code>default-information originate</code>	Generates a default external route into an autonomous system	RC
<code>default-metric</code>	Sets the default metric assigned to external routes imported from other protocols	RC
<code>distance</code>	Defines an administrative distance for external routes learned from other routing protocols	RC
<code>maximum-prefix</code>	Sets the maximum number of RIP routes allowed	RC
<code>neighbor</code>	Defines a neighboring router with which to exchange information	RC
<code>network</code>	Specifies the network interfaces that are to use RIP routing	RC
<code>passive-interface</code>	Stops RIP from sending routing updates on the specified interface	RC
<code>redistribute</code>	Redistribute routes from one routing domain to another	RC
<code>timers basic</code>	Sets basic timers, including update, timeout, garbage collection	RC
<code>version</code>	Specifies the RIP version to use on all network interfaces (if not already specified with a receive version or send version command)	RC
<code>ip rip authentication mode</code>	Specifies the type of authentication used for RIP2 packets	IC
<code>ip rip authentication string</code>	Enables authentication for RIP2 packets and specifies keys	IC
<code>ip rip receive version</code>	Sets the RIP receive version to use on a network interface	IC
<code>ip rip receive-packet</code>	Configures the interface to receive of RIP packets	IC
<code>ip rip send version</code>	Sets the RIP send version to use on a network interface	IC

Table 191: Routing Information Protocol Commands (Continued)

Command	Function	Mode
<code>ip rip send-packet</code>	Configures the interface to send RIP packets	IC
<code>ip rip split-horizon</code>	Enables split-horizon or poison-reverse loop prevention	IC
<code>clear ip rip route</code>	Clears specified data from the RIP routing table	PE
<code>show ip protocols rip</code>	Displays RIP process parameters	PE
<code>show ip rip</code>	Displays information about RIP routes and configuration settings	PE

**router rip** This command enables Routing Information Protocol (RIP) routing for all IP interfaces on the router. Use the **no** form to disable it.

### Syntax

**[no] router rip**

### Command Mode

Global Configuration

### Default Setting

Disabled

### Command Usage

- ◆ RIP is used to specify how routers exchange routing table information.
- ◆ This command is also used to enter router configuration mode.

### Example

```
Console(config)#router rip
Console(config-router)#
```

### Related Commands

[network \(1020\)](#)

**default-information originate** This command generates a default external route into the local RIP autonomous system. Use the **no** form to disable this feature.

### Syntax

**[no] default-information originate**

### Default Setting

Disabled

### Command Mode

Router Configuration

### Command Usage

This command sets a default route for every Layer 3 interface where RIP is enabled. The response packet to external queries marks each active RIP interface as a default router with the IP address 0.0.0.0.

### Example

```

Console(config-router)#default-information originate
Console(config-router)#

```

### Related Commands

[ip route \(1006\)](#)

[redistribute \(1022\)](#)

**default-metric** This command sets the default metric assigned to external routes imported from other protocols. Use the **no** form to restore the default value.

### Syntax

**default-metric** *metric-value*

**no default-metric**

*metric-value* – Metric assigned to external routes. (Range: 1-15)

### Default Setting

1

### Command Mode

Router Configuration

### Command Usage

- ◆ This command does not override the metric value set by the [redistribute](#) command. When a metric value has not been configured by the [redistribute](#) command, the **default-metric** command sets the metric value to be used for all imported external routes.
- ◆ The default metric must be used to resolve the problem of redistributing external routes with incompatible metrics.
- ◆ It is advisable to use a low metric when redistributing routes from another protocol into RIP. Using a high metric limits the usefulness of external routes redistributed into RIP. For example, if a metric of 10 is defined for redistributed routes, these routes can only be advertised to routers up to 5 hops away, at which point the metric exceeds the maximum hop count of 15. By defining a low metric of 1, traffic can follow a imported route the maximum number of hops allowed within a RIP domain. However, note that using a low metric can

increase the possibility of routing loops. For example, this can occur if there are multiple redistribution points and the router learns about the same external network with a better metric from a redistribution point other than that derived from the original source.

### Example

This example sets the default metric to 5.

```
Console(config-router)#default-metric 5
Console(config-router)#
```

### Related Commands

[redistribute \(1022\)](#)

**distance** This command defines an administrative distance for external routes learned from other routing protocols. Use the **no** form to restore the default setting.

### Syntax

**[no] distance** *distance network-address netmask*

*distance* - Administrative distance for external routes. External routes are routes for which the best path is learned from a neighbor external to the local RIP autonomous system. Routes with a distance of 255 are not installed in the routing table. (Range: 1-255)

*network-address* - IP address of a route entry.

*netmask* - Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

### Default Setting

None

### Command Mode

Router Configuration

### Command Usage

- ◆ Administrative distance is used by the routers to select the preferred path when there are two or more different routes to the same destination from two different routing protocols. A smaller administrative distance indicates a more reliable protocol.
- ◆ The administrative distance is applied to all routes learned for the specified network.

### Example

```
Console(config-router)#distance 2 192.168.3.0 255.255.255.0
Console(config-router)#
```

**maximum-prefix** This command sets the maximum number of RIP routes allowed by the system. Use the **no** form to restore the default setting.

### Syntax

**maximum-prefix** *maximum-routes*

**no maximum-prefix**

*maximum-routes* - The maximum number of RIP routes which can be installed in the routing table. (Range: 1-11766)

### Default Setting

11766

### Command Mode

Router Configuration

### Command Usage

All the learned RIP routes may not be copied to the hardware tables in ASIC for fast data forwarding because of hardware resource limitations.

### Example

```
Console(config-router)#maximum-prefix 1024
Console(config-router)#
```

**neighbor** This command defines a neighboring router with which this router will exchange routing information. Use the **no** form to remove an entry.

### Syntax

**[no] neighbor** *ip-address*

*ip-address* - IP address of a neighboring router.

### Default Setting

No neighbors are defined.

### Command Mode

Router Configuration

### Command Usage

- ◆ This command can be used to configure a static neighbor (specifically for point-to-point links) with which this router will exchange routing information, rather than relying on broadcast or multicast messages generated by the RIP protocol.
- ◆ Use this command in conjunction with the [passive-interface](#) command to control the routing updates sent to specific neighbors.

### Example

```
Console(config-router)#neighbor 10.2.0.254
Console(config-router)#
```

### Related Commands

[passive-interface \(1021\)](#)

**network** This command specifies the network interfaces that will be included in the RIP routing process. Use the **no** form to remove an entry.

### Syntax

**[no] network** {*ip-address netmask* | **vlan** *vlan-id*}

*ip-address* – IP address of a network directly connected to this router.

*netmask* - Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

*vlan-id* - VLAN ID. (Range: 1-4094)

### Default Setting

No networks are specified.

### Command Mode

Router Configuration

### Command Usage

- ◆ RIP only sends and receives updates on interfaces specified by this command. If a network is not specified, the interfaces in that network will not be advertised in any RIP updates.
- ◆ Subnet addresses are interpreted as class A, B or C, based on the first field in the specified address. In other words, if a subnet address *nnn.xxx.xxx.xxx* is entered, the first field (*nnn*) determines the class:
  - 0 - 127 is class A, and only the first field in the network address is used.
  - 128 - 191 is class B, and the first two fields in the network address are used.
  - 192 - 223 is class C, and the first three fields in the network address are used.

### Example

This example includes network interface 10.1.0.0 in the RIP routing process.

```
Console(config-router)#network 10.1.0.0
Console(config-router)#
```

### Related Commands

[router rip \(1016\)](#)

**passive-interface** This command stops RIP from sending routing updates on the specified interface. Use the **no** form to disable this feature.

### Syntax

```
[no] passive-interface vlan vlan-id
      vlan-id - VLAN ID. (Range: 1-4094)
```

### Default Setting

Disabled

### Command Mode

Router Configuration

### Command Usage

- ◆ If this command is used to stop sending routing updates on an interface, the attached subnet will still continue to be advertised to other interfaces, and updates from other routers on that interface will continue to be received and processed.
- ◆ Use this command in conjunction with the [neighbor](#) command to control the routing updates sent to specific neighbors.

### Example

```
Console(config-router)#passive-interface vlan1
Console(config-router)#
```

### Related Commands

[neighbor \(1019\)](#)

**redistribute** This command imports external routing information from other routing domains (that is, directly connected routes, protocols, or static routes) into the autonomous system. Use the **no** form to disable this feature.

### Syntax

**[no] redistribute (bgp | connected | ospf | static) [metric *metric-value*]**

**bgp** - External routes will be imported from the Border Gateway Protocol (BGP) into this routing domain.

**connected** - Imports routes that are established automatically just by enabling IP on an interface.

**ospf** - External routes will be imported from the Open Shortest Path First (OSPF) protocol into this routing domain.

**static** - Static routes will be imported into this routing domain.

*metric-value* - Metric value assigned to all external routes for the specified protocol. (Range: 1-16)

### Default Setting

redistribution - none

metric-value - set by the [default-metric](#) command

### Command Mode

Router Configuration

### Command Usage

- ◆ When a metric value has not been configured by the **redistribute** command, the [default-metric](#) command sets the metric value to be used for all imported external routes.
- ◆ A route metric must be used to resolve the problem of redistributing external routes with incompatible metrics.
- ◆ It is advisable to use a low metric when redistributing routes from another protocol into RIP. Using a high metric limits the usefulness of external routes redistributed into RIP. For example, if a metric of 10 is defined for redistributed routes, these routes can only be advertised to routers up to 5 hops away, at which point the metric exceeds the maximum hop count of 15. By defining a low metric of 1, traffic can follow a imported route the maximum number of hops allowed within a RIP domain. However, using a low metric can increase the possibility of routing loops For example, this can occur if there are multiple redistribution points and the router learns about the same external network with a better metric from a redistribution point other than that derived from the original source.

### Example

This example redistributes routes learned from OSPF and sets the metric for all external routes imported from OSPF to a value of 3.

```
Console(config-router)#redistribute ospf metric 3
Console(config-router)#
```

This example redistributes static routes and sets the metric for all of these routes to a value of 3.

```
Console(config-router)#redistribute static metric 3
Console(config-router)#
```

### Related Commands

[default-metric \(1017\)](#)

**timers basic** This command configures the RIP update timer, timeout timer, and garbage-collection timer. Use the **no** form to restore the defaults.

### Syntax

**timers basic** *update timeout garbage*

**no timers basic**

*update* – Sets the update timer to the specified value.  
(Range: 5-2147483647 seconds)

*timeout* – Sets the timeout timer to the specified value. (Range: 90-360 seconds)

*garbage* – Sets the garbage collection timer to the specified value.  
(Range: 60-240 seconds)

### Default Setting

Update: 30 seconds

Timeout: 180 seconds

Garbage collection: 120 seconds

### Command Mode

Router Configuration

### Command Usage

- ◆ The *update* timer sets the rate at which updates are sent. This is the fundamental timer used to control all basic RIP processes.
- ◆ The *timeout* timer is the time after which there have been no update messages that a route is declared dead. The route is marked inaccessible (i.e., the metric

set to infinite) and advertised as unreachable. However, packets are still forwarded on this route.

- ◆ After the *timeout* interval expires, the router waits for an interval specified by the *garbage-collection* timer before removing this entry from the routing table. This timer allows neighbors to become aware of an invalid route prior to it being purged by this device.
- ◆ Setting the update timer to a short interval can cause the router to spend an excessive amount of time processing updates.
- ◆ These timers must be set to the same values for all routers in the network.

### Example

This example sets the update timer to 40 seconds. The timeout timer is subsequently set to 240 seconds, and the garbage-collection timer to 160 seconds.

```
Console(config-router)#timers basic 15
Console(config-router)#
```

**version** This command specifies a RIP version used globally by the router. Use the **no** form to restore the default value.

### Syntax

**version** {1 | 2}

**no version**

**1** - RIP Version 1

**2** - RIP Version 2

### Default Setting

Receive: Accepts RIPv1 or RIPv2 packets

Send: Route information is broadcast to other routers with RIPv2.

### Command Mode

Router Configuration

### Command Usage

- ◆ When this command is used to specify a global RIP version, any VLAN interface not previously set by the [ip rip receive version](#) or [ip rip send version](#) command will use the global RIP version setting.
- ◆ When the **no** form of this command is used to restore the default value, any VLAN interface not previously set by the [ip rip receive version](#) or [ip rip send version](#) command will be set to the default send or receive version.

- ◆ Any configured interface settings take precedence over the global settings.

### Example

This example sets the global version for RIP to send and receive version 2 packets.

```
Console(config-router)#version 2
Console(config-router)#
```

### Related Commands

[ip rip receive version \(1027\)](#)

[ip rip send version \(1028\)](#)

**ip rip authentication mode** This command specifies the type of authentication that can be used for RIPv2 packets. Use the **no** form to restore the default value.

### Syntax

**ip rip authentication mode {md5 | text}**

**no ip rip authentication mode**

**md5** - Message Digest 5 (MD5) authentication

**text** - Indicates that a simple password will be used.

### Default Setting

Text authentication

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ The password to be used for authentication is specified in the [ip rip authentication string](#) command.
- ◆ This command requires the interface to exchange routing information with other routers based on an authorized password. (Note that this command only applies to RIPv2.)
- ◆ For authentication to function properly, both the sending and receiving interface must be configured with the same password or authentication key.
- ◆ MD5 is a one-way hash algorithm that takes the authentication key and produces a 128 bit message digest or “fingerprint.” This makes it computationally infeasible to produce two messages having the same message digest, or to produce any message having a given pre-specified target message digest.

**Example**

This example sets the authentication mode to plain text.

```
Console(config)#interface vlan 1
Console(config-if)#ip rip authentication mode text
Console(config-if)#
```

**Related Commands**

[ip rip authentication string \(1026\)](#)

**ip rip authentication string** This command specifies an authentication key for RIPv2 packets. Use the **no** form to delete the authentication key.

**Syntax**

**ip rip authentication string** *key-string*

**no ip rip authentication string**

*key-string* - A password used for authentication.  
(Range: 1-16 characters, case sensitive)

**Default Setting**

No authentication key

**Command Mode**

Interface Configuration (VLAN)

**Command Usage**

- ◆ This command can be used to restrict the interfaces that can exchange RIPv2 routing information. (Note that this command does not apply to RIPv1.)
- ◆ For authentication to function properly, both the sending and receiving interface must be configured with the same password, and authentication enabled by the [ip rip authentication mode](#) command.

**Example**

This example sets an authentication password of “small” to verify incoming routing messages and to tag outgoing routing messages.

```
Console(config)#interface vlan 1
Console(config-if)#ip rip authentication string small
Console(config-if)#
```

**Related Commands**

[ip rip authentication mode \(1025\)](#)

**ip rip receive version** This command specifies a RIP version to receive on an interface. Use the **no** form to restore the default value.

### Syntax

**ip rip receive version {1 | 2}**

**no ip rip receive version**

- 1 - Accepts only RIPv1 packets.
- 2 - Accepts only RIPv2 packets.

### Default Setting

RIPv1 and RIPv2 packets

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ Use this command to override the global setting specified by the RIP [version](#) command.
- ◆ You can specify the receive version based on these options:
  - Use version 1 or version 2 if all routers in the local network are based on RIPv1 or RIPv2, respectively.
  - Use the default of version 1 or 2 if some routers in the local network are using RIPv2, but there are still some older routers using RIPv1.

### Example

This example sets the interface version for VLAN 1 to receive RIPv1 packets.

```
Console(config)#interface vlan 1
Console(config-if)#ip rip receive version 1
Console(config-if)#
```

### Related Commands

[version \(1024\)](#)

**ip rip receive-packet** This command configures the interface to receive RIP packets. Use the **no** form to disable this feature.

### Syntax

**[no] ip rip receive-packet**

### Default Setting

Enabled

**Command Mode**

Interface Configuration (VLAN)

**Default Setting**

Enabled

**Command Usage**

Use the **no** form of this command if it is not required to add any dynamic entries to the routing table for an interface. For example, when only static routes are to be allowed for a specific interface.

**Example**

```
Console(config)#interface vlan 1
Console(config-if)#ip rip receive-packet
Console(config-if)#
```

**Related Commands**[ip rip send-packet \(1029\)](#)

**ip rip send version** This command specifies a RIP version to send on an interface. Use the **no** form to restore the default value.

**Syntax****ip rip send version {1 | 2 | 1-compatible}****no ip rip send version****1** - Sends only RIPv1 packets.**2** - Sends only RIPv2 packets.**1-compatible** - Route information is broadcast to other routers with RIPv2.**Default Setting**

1-compatible (Route information is broadcast to other routers with RIPv2)

**Command Mode**

Interface Configuration (VLAN)

**Command Usage**

- ◆ Use this command to override the global setting specified by the RIP [version](#) command.
- ◆ You can specify the send version based on these options:
  - Use version 1 or version 2 if all routers in the local network are based on RIPv1 or RIPv2, respectively.
  - Use “1-compatible” to propagate route information by broadcasting to other routers on the network using RIPv2, instead of multicasting as

normally required by RIPv2. (Using this mode allows older RIPv2 routers which only receive RIP broadcast messages to receive all of the information provided by RIPv2, including subnet mask, next hop and authentication information.)

### Example

This example sets the interface version for VLAN 1 to send RIPv1 packets.

```
Console(config)#interface vlan 1
Console(config-if)#ip rip send version 1
Console(config-if)#
```

### Related Commands

[version \(1024\)](#)

**ip rip send-packet** This command configures the interface to send RIP packets. Use the **no** form to disable this feature.

**[no] ip rip send-packet**

#### Default Setting

Enabled

#### Command Mode

Interface Configuration (VLAN)

#### Default Setting

Enabled

#### Command Usage

The **no** form of this command allows the router to passively monitor route information advertised by other routers attached to the network, without transmitting any RIP updates.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip rip send-packet
Console(config-if)#
```

### Related Commands

[ip rip receive-packet \(1027\)](#)

**ip rip split-horizon** This command enables split-horizon or poison-reverse (a variation) on an interface. Use the **no** form to disable this function.

#### Syntax

**ip rip split-horizon [poisoned]**

**no rip ip split-horizon**

**poisoned** - Enables poison-reverse on the current interface.

#### Command Mode

Interface Configuration (VLAN)

#### Default Setting

split-horizon poisoned

#### Command Usage

- ◆ Split horizon never propagates routes back to an interface from which they have been acquired.
- ◆ Poison reverse propagates routes back to an interface port from which they have been acquired, but sets the distance-vector metrics to infinity. (This provides faster convergence.)
- ◆ If split-horizon is disabled with the **no rip ip split-horizon** command, and a loop occurs, the hop count for a route may be gradually incremented to infinity (that is, 16) before the route is deemed unreachable.

#### Example

This example propagates routes back to the source using poison-reverse.

```
Console(config)#interface vlan 1
Console(config-if)#ip split-horizon poison-reverse
Console(config-if)#
```

**clear ip rip route** This command clears specified data from the RIP routing table.

#### Syntax

**clear ip rip route {ip-address netmask | all | connected | ospf | rip | static}**

*ip-address* - IP address of a route entry.

*netmask* - Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

**all** - Deletes all entries from the routing table.

**connected** - Deletes all currently connected entries.

**ospf** - Deletes all entries learned through the Open Shortest Path First routing protocol.

**rip** - Deletes all entries learned through the Routing Information Protocol.

**static** - Deletes all static entries.

### Default Setting

None

### Command Mode

Privileged Exec

### Command Usage

Using this command with the “all” parameter clears the RIP table of all routes. To avoid deleting the entire RIP network, use the [redistribute connected](#) command to make the RIP network a connected route. To delete the RIP routes learned from neighbors and also keep the RIP network intact, use the “rip” parameter with this command (**clear ip rip route rip**).

### Example

This example clears one specific route.

```
Console#clear ip rip route 192.168.1.0 255.255.255.0
Console#
```

**show ip protocols rip** This command displays RIP process parameters.

### Command Mode

Privileged Exec

### Example

```
Console#show ip protocols rip
Routing Protocol is "rip"
  Sending updates every 30 seconds with +/-5 seconds
  Timeout after 180 seconds, garbage collect after 120 seconds
  Outgoing update filter list for all interface is not set
  Incoming update filter list for all interface is not set
  Default redistribution metric is 1
  Redistributing:
  Default version control: send version by interface set, receive version by
  interface set
    Interface Send      Recv
    VLAN1     1-compatible 1 2
  Routing for Networks:
    10.0.0.0/24
  Routing Information Sources:
    Gateway         Distance  Last Update  Bad Packets  Bad Routes
    10.0.0.2         120      00:00:13    0             0
  The maximum number of RIP routes allowed: 11766
```

```
Distance: Default is 120
Console#
```

**show ip rip** This command displays information about RIP routes and configuration settings. Use this command without any keywords to display all RIP routes.

### Syntax

```
show ip rip [interface [vlan vlan-id]]
```

**interface** - Shows RIP configuration settings for all interfaces or for a specified interface.

*vlan-id* - VLAN ID. (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#show ip rip

Codes: R - RIP, Rc - RIP connected, Rs - RIP static,
       C - Connected, S - Static, O - OSPF

   Network          Next Hop          Metric From          Interface Time
Rc 192.168.0.0/24
Console#show ip rip interface vlan 1
Interface: vlan1
Routing Protocol: RIP
  Receive RIPv1 and RIPv2 packets
  Send RIPv1 Compatible
  Passive interface: Disabled
  Authentication mode: (None)
  Authentication string: (None)
  Split horizon: Enabled with Poisoned Reverse
  IP interface address: 192.168.0.2/24
Console#
```

# OSPF Commands

This section includes commands for Open Shortest Path First (OSPF) dynamic routing. These commands are used to connect between different local subnetworks.

OSPF is more suited for large area networks which experience frequent changes in the links. It also handles subnets much better than RIP. OSPF protocol actively tests the status of each link to its neighbors to generate a shortest path tree, and builds a routing table based on this information. OSPF then utilizes IP multicast to propagate routing information. A separate routing area scheme is also used to further reduce the amount of routing traffic.

Note: The OSPF protocol implemented in this device is based on RFC 2328 (Version 2). It also supports RFC 1583 (early Version 2) compatibility mode to ensure that the same method is used to calculate summary route costs throughout the network when older OSPF routers exist; as well as the not-so-stubby area option (RFC 3101).

**Table 188: Open Shortest Path First Commands**

Command Group	Function
Open Shortest Path First (OSPFv2)	Configures global and interface specific parameters for OSPFv2
Open Shortest Path First (OSPFv3)	Configures global and interface specific parameters for OSPFv3

## Open Shortest Path First (OSPFv2)

**Table 189: OSPFv2 Commands**

Command	Function	Mode
<i>General Configuration</i>		
<code>router ospf</code>	Enables or disables OSPFv2	GC
<code>area authentication</code>	Enables authentication for an OSPF area	RC
<code>area default-cost</code>	Sets the cost for a default summary route sent into a stub or NSSA	RC
<code>area nssa</code>	Defines a not-so-stubby that can import external routes	RC
<code>area range</code>	Summarizes routes advertised by an ABR	RC
<code>area stub</code>	Defines a stubby area that cannot send or receive LSAs	RC

**Table 189: OSPFv2 Commands** (Continued)

Command	Function	Mode
<code>auto-cost reference-bandwidth</code>	Calculates default metrics for an interface based on bandwidth	RC
<code>compatible rfc1583</code>	Calculates summary route costs using RFC 1583 (early OSPFv2)	RC
<code>default-information originate</code>	Generates a default external route into an autonomous system	RC
<code>default-metric</code>	Sets the default metric for external routes imported from other protocols	RC
<code>passive-interface</code>	Suppresses OSPF routing traffic on the specified interface	RC
<code>redistribute</code>	Redistribute routes from one routing domain to another	RC
<code>router-id</code>	Sets the router ID for this device	RC
<code>summary-address</code>	Summarizes routes advertised by an ASBR	RC
<code>timers spf</code>	Configures the delay after a topology change and the hold time between consecutive SPF calculations	RC
<code>ip ospf area</code>	Assigns a process ID and area ID to an interface	IC
<code>ip ospf authentication</code>	Specifies the authentication type for an interface	IC
<code>ip ospf authentication-key</code>	Assigns a simple password to be used by neighboring routers	IC
<code>ip ospf cost</code>	Specifies the cost of sending a packet on an interface	IC
<code>ip ospf dead-interval</code>	Sets the interval at which hello packets are not seen before neighbors declare the router down	IC
<code>ip ospf hello-interval</code>	Specifies the interval between sending hello packets	IC
<code>ip ospf message-digest-key</code>	Enables MD5 authentication and sets the key for an interface	IC
<code>ip ospf network</code>	Sets the network type connected to the interface	IC
<code>ip ospf priority</code>	Sets the router priority used to determine the designated router	IC
<code>ip ospf retransmit-interval</code>	Specifies the time between resending a link-state advertisement	IC
<code>ip ospf transmit-delay</code>	Estimates time to send a link-state update packet over an interface	IC
<code>clear ip ospf process</code>	Clears and restarts the OSPF routing process	PE
<code>show ip ospf</code>	Displays general information about the routing processes	PE
<code>show ip ospf border-routers</code>	Displays routing table entries for Area Border Routers (ABR) and Autonomous System Boundary Routers (ASBR)	PE
<code>show ip ospf database</code>	Shows information about different LSAs in the database	PE
<code>show ip ospf database asbr-summary</code>	Shows information about ASBR summary LSAs	PE
<code>show ip ospf database external</code>	Shows information about external LSAs	PE
<code>show ip ospf database network</code>	Shows information about network LSAs in the database	PE

**Table 189: OSPFv2 Commands** (Continued)

Command	Function	Mode
<code>show ip ospf database nssa-external</code>	Shows information about NSSA external LSAs in the database	PE
<code>show ip ospf database router</code>	Shows information about LSAs in the router's database	PE
<code>show ip ospf database self-originate</code>	Shows information originated by this router	PE
<code>show ip ospf database summary</code>	Shows information about summary LSAs in the router's database	PE
<code>show ip ospf interface</code>	Displays interface information	PE
<code>show ip ospf neighbor</code>	Displays neighbor information	PE
<code>show ip ospf route</code>	Displays the OSPF routing table	PE

**router ospf** This command enables Open Shortest Path First (OSPFv2) routing for all IP interfaces on the router and enters router configuration mode. Use the **no** form to disable OSPF for all processes or for a specified process.

#### Syntax

**[no] router ospf** [*process-id*]

*process-id* - Process ID must be entered when configuring multiple routing instances. (Range: 1-65535; Default: 1)

#### Command Mode

Global Configuration

#### Default Setting

No routing process is defined.

#### Command Usage

- ◆ OSPF is used to specify how routers exchange routing table information.
- ◆ This command is also used to enter router configuration mode.
- ◆ If the process ID is not defined, the default is instance 1.

#### Example

```
Console(config)#router ospf
Console(config-router)#
```

**area authentication** This command enables authentication for an OSPF area. Use the **no** form to remove authentication for an area.

### Syntax

**[no] area *area-id* authentication [message-digest]**

*area-id* - Identifies an area for which authentication is to be configured. The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.

**message-digest** - Specifies message-digest (MD5) authentication.

### Command Mode

Router Configuration

### Default Setting

No authentication

### Command Usage

- ◆ Use authentication to prevent routers from inadvertently joining an unauthorized area. Configure routers in the same area with the same password or key. All neighboring routers on the same network with the same password will exchange routing data.
- ◆ To enable or disable authentication, first use this command to configure it at the router configuration level, and then configure it at the VLAN interface level using the [ip ospf authentication](#) command.
- ◆ Specifying authentication for an area without the **message-digest** keyword sets authentication to Type 1 (simple password). Before specifying plain-text password authentication for an area, configure a password with the [ip ospf authentication-key](#) interface command. This password is inserted into the OSPF header when routing protocol packets are originated by this device. Assign a separate password to each area for different interfaces.
- ◆ When using simple password authentication, a password is included in the packet. If it does not match the password configured on the receiving router, the packet is discarded. This method provides very little security as it is possible to learn the authentication key by snooping on routing protocol packets.
- ◆ When using Message-Digest 5 (MD5) authentication, the router uses the MD5 algorithm to verify data integrity by creating a 128-bit message digest from the authentication key. Without the proper key and key-id, it is nearly impossible to produce any message that matches the pre-specified target message digest.
- ◆ Before specifying MD5 authentication for an area, configure the message-digest key-id and key with the [ip ospf message-digest-key](#) interface command.
- ◆ The plain-text authentication-key, or the MD5 *key-id* and *key*, must be used consistently throughout the autonomous system.

### Example

This example first enables authentication for a specified area and interface, and then disables it.

```
Console(config)#router ospf
Console(config-router)#area 0 authentication
Console(config-router)#exit
Console(config)#interface vlan 1
Console(config-if)#ip ospf 1 area 0
Console(config-if)#ip ospf authentication
Console(config-if)#ip ospf authentication-key 12345678
Console(config-if)#
Console(config-if)#ip ospf authentication null
Console(config-if)#no ip ospf authentication
Console(config-if)#exit
Console(config)#router ospf 1
Console(config-router)#no area 0 authentication
Console(config-router)#end
Console#clear ip ospf process
Console#
```

### Related Commands

[ip ospf authentication \(1051\)](#)

[ip ospf authentication-key \(1052\)](#)

[ip ospf message-digest-key \(1055\)](#)

**area default-cost** This command specifies a cost for the default summary route sent into a stub or NSSA from an Area Border Router (ABR). Use the **no** form to remove the assigned default cost.

### Syntax

**area** *area-id* **default-cost** *cost*

**no area** *area-id* **default-cost**

*area-id* - Identifies the stub or NSSA. (The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.)

*cost* - Cost for the default summary route sent to a stub or NSSA. (Range: 0-16777215)

### Command Mode

Router Configuration

### Default Setting

Default cost: 1

### Command Usage

- ◆ If the default cost is set to "0," the router will not advertise a default route into the attached stub or NSSA.

## Example

```
Console(config-router)#area 10.3.9.0 default-cost 10  
Console(config-router)#
```

## Related Commands

[area stub \(1040\)](#)

[area nssa \(1038\)](#)

**area nssa** This command defines a not-so-stubby area (NSSA). To remove an NSSA, use the **no** form without any optional keywords. To remove an optional attribute, use the **no** form without the relevant keyword.

## Syntax

```
[no] area area-id nssa  
[translator-role [candidate | never | always]] |  
[no-redistribution] | [no-summary] | [default-information-originate]  
[metric metric-value | metric-type type-value]
```

**area-id** - Identifies the NSSA. The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.

**translator-role** - Indicates NSSA-ABR translator role for Type 5 external LSAs.

**candidate** - Router translates NSSA LSAs to Type-5 external LSAs if elected.

**never** - Router never translates NSSA LSAs to Type-5 external LSAs.

**always** - Router always translates NSSA LSAs to Type-5 external LSAs.

**no-redistribution** - Use this keyword when the router is an NSSA Area Border Router (ABR) and you want the [redistribute](#) command to import routes only into normal areas, and not into the NSSA. In other words, this keyword prevents the NSSA ABR from advertising external routing information (learned via routers in other areas) into the NSSA.

**no-summary** - Allows an area to retain standard NSSA features, but does not inject inter-area routes into this area.

**default-information-originate** - When the router is an NSSA Area Border Router (ABR) or an NSSA Autonomous System Boundary Router (ASBR), this parameter causes it to generate Type-7 default LSA into the NSSA. This default provides a route to other areas within the AS for an NSSA ABR, or to areas outside the AS for an NSSA ASBR.

**metric-value** - Metric assigned to Type-7 default LSAs.  
(Range: 1-16777214; Default: 1)

*type-value*

1 - Type 1 external route

2 - Type 2 external route (default) - Routers do not add internal cost to the external route metric.

### Command Mode

Router Configuration

### Default Setting

No NSSA is configured.

### Command Usage

- ◆ All routers in a NSSA must be configured with the same area ID.
- ◆ An NSSA is similar to a stub, because when the router is an ABR, it can send a default route for other areas in the AS into the NSSA using the **default-information-originate** keyword. However, an NSSA is different from a stub, because when the router is an ASBR, it can import a default external AS route (for routing protocol domains adjacent to the NSSA but not within the OSPF AS) into the NSSA using the **default-information-originate** keyword.
- ◆ External routes advertised into an NSSA can include network destinations outside the AS learned via OSPF, the default route, static routes, routes imported from other routing protocols such as BGP or RIP, and networks directly connected to the router that are not running OSPF.
- ◆ NSSA external LSAs (Type 7) are converted by any ABR adjacent to the NSSA into external LSAs (Type-5), and propagated into other areas within the AS.
- ◆ Also, note that unlike stub areas, all Type-3 summary LSAs are always imported into NSSAs to ensure that internal routes are always chosen over Type-7 NSSA external routes.
- ◆ This router supports up to 16 total areas (either normal transit areas, stubs, or NSSAs).

### Example

This example creates a stub area 10.3.0.0, and assigns all interfaces with class B addresses 10.3.x.x to the NSSA. It also instructs the router to generate external LSAs into the NSSA when it is an NSSA ABR or NSSA ASBR.

```
Console(config-router)#area 10.3.0.0 nssa default-information-originate
Console(config-router)#network 10.3.0.0 255.255.0.0 area 10.2.0.0
Console(config-router)#
```

**area range** This command summarizes the routes advertised by an Area Border Router (ABR). Use the **no** form to disable this function.

### Syntax

```
[no] area area-id range ip-address netmask [advertise | not-advertise]
```

*area-id* - Identifies an area for which the routes are summarized. The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.

*ip-address* - Base address for the routes to summarize.

*netmask* - Network mask for the summary route.

**advertise** - Advertises the specified address range.

**not-advertise** - The summary is not sent, and the routes remain hidden from the rest of the network.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ This command can be used to summarize intra-area routes and advertise this information to other areas through Area Border Routers (ABRs).
- ◆ If the network addresses within an area are assigned in a contiguous manner, the ABRs can advertise a summary route that covers all of the individual networks within the area that fall into the specified range using a single **area range** command.
- ◆ If routes are set to be advertised by this command, the router will issue a Type 3 summary LSA for each address range specified by this command.
- ◆ This router supports up to 64 summary routes for area ranges.

### Example

This example creates a summary address for all area routes in the range of 10.2.x.x.

```
Console(config-router)#area 10.2.0.0 range 10.2.0.0 255.255.0.0 advertise  
Console(config-router)#
```

**area stub** This command defines a stub area. To remove a stub, use the **no** form without the optional keyword. To remove the summary attribute, use the **no** form with the summary keyword.

## Syntax

**[no] area *area-id* stub [no-summary]**

*area-id* - Identifies the stub area. The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.

**no-summary** - Stops an Area Border Router (ABR) from sending summary link advertisements into the stub area.

## Command Mode

Router Configuration

## Default Setting

No stub is configured.

Summary advertisement are sent into the stub.

## Command Usage

- ◆ All routers in a stub must be configured with the same area ID.
- ◆ Routing table space is saved in a stub by blocking Type-4 AS summary LSAs and Type 5 external LSAs. The default setting for this command completely isolates the stub by blocking Type-3 summary LSAs that advertise the default route for destinations external to the local area or the autonomous system.
- ◆ Use the **no-summary** parameter of this command on the ABR attached to the stub to define a totally stubby area. Define an area as a totally stubby area only if routers in the area do not require summary LSAs from other areas.
- ◆ Use the [area default-cost](#) command to specify the cost of a default summary route sent into a stub by an ABR attached to the stub area.

## Example

This example creates a stub area 10.2.0.0, and assigns all interfaces with class B addresses 10.2.x.x to the stub.

```
Console(config-router)#area 10.2.0.0 stub
Console(config-router)#network 10.2.0.0 0.255.255.255 area 10.2.0.0
Console(config-router)#
```

## Related Commands

[area default-cost \(1037\)](#)

**auto-cost reference-bandwidth** Use this command to calculate the default metrics for an interface based on bandwidth. Use the **no** form to automatically assign costs based on interface type.

### Syntax

**auto-cost reference-bandwidth** *reference-value*

**no auto-cost reference-bandwidth**

*reference-value* - Bandwidth of interface. (Range: 1-4294967 Mbps)

### Command Mode

Router Configuration

### Default Setting

1 Mbps

### Command Usage

- ◆ The system calculates the cost for an interface by dividing the reference bandwidth by the interface bandwidth. By default, the cost is 1 Mbps for all port types (including 100 Mbps ports, 1 Gigabit ports, and 10 Gigabit ports).
- ◆ A higher reference bandwidth can be used for aggregate links to indicate preferred use as a lower cost interface.
- ◆ The **ip ospf cost** command overrides the cost calculated by the **auto-cost reference-bandwidth** command.

### Example

This example sets the reference value to 10000, which generates a cost of 100 for 100 Mbps ports, 10 for 1 Gbps ports and 1 for 10 Gbps ports.

```
Console(config-router)#auto-cost reference-bandwidth 10000
Console(config-router)#
```

### Related Commands

[ip ospf cost \(1053\)](#)

**compatible rfc1583** This command calculates summary route costs using RFC 1583 (early OSPFv2). Use the **no** form to calculate costs using RFC 2328 (OSPFv2).

### Syntax

**[no] compatible rfc1583**

### Command Mode

Router Configuration

### Default Setting

RFC 1583 compatible

### Command Usage

- ◆ When RFC 1583 compatibility is enabled, only cost is used when choosing among multiple AS-external LSAs advertising the same destination. When disabled, preference is based on type of path (where type 1 external paths are preferred over type 2 external paths, using cost only to break ties (RFC 2328).
- ◆ All routers in an OSPF routing domain should use the same RFC for calculating summary routes.
- ◆ If there are any OSPF routers in an area exchanging summary information (specifically, ABRs) which have not been upgraded to OSPFv2, this command should be used on the newly upgraded OSPFv2 routers to ensure compatibility with routers still running older OSPFv2 code. Once all systems have been upgraded to newer OSPFv2 code, use the `no` form of this command to restore compatibility for all systems with RFC 2328.

### Example

```
Console(config-router)#compatible rfc1583  
Console(config-router)#
```

**default-information originate** This command generates a default external route into an autonomous system. Use the **no** form to disable this feature.

### Syntax

**default-information originate** [**always**] [**metric** *interface-metric*]  
[**metric-type** *metric-type*]

**no default-information originate** [**always** | **metric** | **metric-type**]

**always** - Always advertise itself as a default external route for the local AS regardless of whether the router has a default route. (See [“ip route” on page 1006.](#))

*interface-metric* - Metric assigned to the default route. (Range: 0-16777214)

*metric-type* - External link type used to advertise the default route.  
(Options: Type 1, Type 2)

### Command Mode

Router Configuration

### Default Setting

Disabled

Metric: 20

Metric Type: 2

### Command Usage

- ◆ If the **always** parameter is not selected, the router can only advertise a default external route into the AS if it has been configured to import external routes through other routing protocols or static routing, and such a route is known. (See the [redistribute](#) command.)
- ◆ The metric for the default external route is used to calculate the path cost for traffic passed from other routers within the AS out through the ASBR.
- ◆ When you use this command to redistribute routes into a routing domain (i.e., an Autonomous System, this router automatically becomes an Autonomous System Boundary Router (ASBR). However, an ASBR does not, by default, generate a default route into the routing domain.
  - If you use the **always** keyword, the router will advertise itself as a default external route into the AS, even if a default external route does not actually exist. To define a default route, use the [ip route](#) command.
  - If you do *not* use the **always** keyword, the router can only advertise a default external route into the AS if the [redistribute](#) command is used to import external routes via RIP or static routing, and such a route is known.
- ◆ Type 1 route advertisements add the internal cost to the external route metric. Type 2 routes do not add the internal cost metric. When comparing Type 2 routes, the internal cost is only used as a tie-breaker if several Type 2 routes have the same cost.
- ◆ This command should not be used to generate a default route for a stub or NSSA. To generate a default route for these area types, use the [area stub](#) or [area nssa](#) commands.

### Example

This example assigns a metric of 20 to the default external route advertised into an autonomous system, sending it as a Type 2 external metric.

```
Console(config-router)#default-information originate metric 20 metric-type 2
Console(config-router)#
```

### Related Commands

[ip route \(1006\)](#)

[redistribute \(1078\)](#)

**default-metric** This command sets the default metric for external routes imported from other protocols. Use the **no** form to remove the default metric for the supported protocol types.

#### Syntax

**default-metric** *metric-value*

**no default-metric**

*metric-value* – Metric assigned to all external routes imported from other protocols. (Range: 0-16777214)

#### Command Mode

Router Configuration

#### Default Setting

20

#### Command Usage

- ◆ The default metric must be used to resolve the problem of redistributing external routes from other protocols that use incompatible metrics.
- ◆ This command does not override the metric value set by the [redistribute](#) command. When a metric value has not been configured by the [redistribute](#) command, the **default-metric** command sets the metric value to be used for all imported external routes.

#### Example

```
Console(config-router)#default-metric 100  
Console(config-router)#
```

#### Related Commands

[redistribute \(1046\)](#)

**passive-interface** This command suppresses OSPF routing traffic on the specified interface. Use the **no** form to allow routing traffic to be sent and received on the specified interface.

#### Syntax

**[no] passive-interface vlan** *vlan-id* [*ip-address*]

*vlan-id* - VLAN ID. (Range: 1-4094)

*ip-address* - An IPv4 address configured on this interface.

#### Command Mode

Router Configuration

### Default Setting

None

### Command Usage

You can configure an OSPF interface as passive to prevent OSPF routing traffic from exiting or entering that interface. No OSPF adjacency can be formed if one of the interfaces involved is set to passive mode. The specified interface will appear as a stub in the OSPF domain. Also, if you configure an OSPF interface as passive where an adjacency already exists, the adjacency will drop almost immediately.

### Example

```
Console(config-router)#passive-interface vlan 1  
Console(config-router)#
```

**redistribute** This command redistributes external routing information from other routing protocols and static routes into an autonomous system. Use the **no** form to disable this feature or to restore the default settings.

### Syntax

```
redistribute {bgp | connected | rip | static} [metric metric-value]  
[metric-type type-value] [tag tag-value]
```

```
no redistribute {bgp | connected | rip | static} [metric] [metric-type] [tag]
```

**bgp** – Displays external routes imported from the Border Gateway Protocol (BGP) into this routing domain.

**connected** - Imports all currently connected entries.

**rip** – Imports external routes learned through Routing Information Protocol (RIP) into this routing domain.

**static** - Static routes will be imported into this Autonomous System.

*metric-value* - Metric assigned to all external routes for the specified protocol. (Range: 0-16777214; Default: 10)

*type-value*

**1** - Type 1 external route

**2** - Type 2 external route (default) - Routers do not add internal route metric to external route metric.

**tag** *tag-value* - A tag placed in the AS-external LSA to identify a specific external routing domain, or to pass additional information between routers. (Range: 0-4294967295)

**Note:** The **tag** option is currently not supported.

### Command Mode

Router Configuration

### Default Setting

redistribution - none  
metric-value - 10  
type-metric - 2

### Command Usage

- ◆ This command is used to import routes learned from other routing protocols into the OSPF domain, and to generate AS-external-LSAs.
- ◆ When you redistribute external routes into an OSPF autonomous system (AS), the router automatically becomes an autonomous system boundary router (ASBR). If the **redistribute** command is used in conjunction with the **default-information originate** command to generate a “default” external route into the AS, the metric value specified in this command supersedes the metric specified in the **default-information originate** command.
- ◆ Metric type specifies the way to advertise routes to destinations outside the AS through External LSAs. When a Type 1 LSA is received by a router, it adds the internal cost to the external route metric. In other words, the cost of the route from any router within the AS is equal to the cost associated with reaching the advertising ASBR, plus the cost of the external route. When a Type 2 LSA is received by a router, it only uses the external route metric to determine route cost.
- ◆ A tag can be used to distinguish between routes learned from different external autonomous systems (other routing protocols). For example, if there are two ASBRs in a routing domain: A and B. ASBR A can be configured to redistribute routes learned from RIP domain 1 (identified by tag 1) and ASBR B can redistribute routes learned from RIP domain 2 (identified by tag 2).

### Example

This example redistributes routes learned from RIP as Type 1 external routes.

```
Console(config-router)#redistribute rip metric-type 1  
Console(config-router)#
```

### Related Commands

[default-information originate \(1043\)](#)

**router-id** This command assigns a unique router ID for this device within the autonomous system for the current OSPF process. Use the **no** form to use the default router identification method (i.e., the highest interface address).

#### Syntax

**router-id** *ip-address*

**no router-id**

*ip-address* - Router ID formatted as an IPv4 address.

#### Command Mode

Router Configuration

#### Default Setting

Highest interface address

#### Command Usage

- ◆ This command sets the router ID for the OSPF process specified in the [router ospf](#) command.
- ◆ The router ID must be unique for every router in the autonomous system. Using the default setting based on the highest interface address ensures that each router ID is unique. (Note that the router ID cannot be set to 0.0.0.0.)
- ◆ If this router already has registered neighbors, the new router ID will be used when the router is rebooted, or manually restarted by entering the **no router ospf** followed by the **router ospf** command.
- ◆ If the priority values of the routers bidding to be the designated router or backup designated router for an area are equal, the router with the highest ID is elected.

#### Example

```
Console(config-router)#router-id 10.1.1.1  
Console(config-router)#
```

#### Related Commands

[router ospf \(1035\)](#)

**summary-address** This command aggregates routes learned from other protocols. Use the **no** form to remove a summary address.

#### Syntax

**[no] summary-address** *summary-address netmask*

*summary-address* - Summary address covering a range of addresses.

*netmask* - Network mask for the summary route.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

Redistributing routes from other protocols into OSPF normally requires the router to advertise each route individually in an external LSA. An Autonomous System Boundary Router (ASBR) can be configured to redistribute routes learned from other protocols by advertising an aggregate route into all attached autonomous systems. This helps both to decrease the number of external LSAs and the size of the OSPF link state database.

### Example

This example creates a summary address for all routes contained in 192.168.x.x.

```
Console(config-router)#summary-address 192.168.0.0 255.255.0.0
Console(config-router)#
```

### Related Commands

[area range \(1074\)](#)

[redistribute \(1078\)](#)

**timers spf** This command configures the delay after receiving a topology change and starting the shortest path first (SPF) calculation, and the hold time between making two consecutive SPF calculations. Use the **no** form to restore the default values.

### Syntax

**timers spf** *spf-delay* *spf-holdtime* *spf-maxtime*

**no timers spf**

*spf-delay* - The delay after receiving a topology change notification and starting the SPF calculation. (Range: 0-600000 milliseconds)

*spf-holdtime* - Minimum hold time between two consecutive SPF calculations. (Range: 0-600000 milliseconds)

*spf-maxtime* - Minimum time between two consecutive SPF calculations. (Range: 0-600000 milliseconds)

### Command Mode

Router Configuration

### Default Setting

Automatically calculated

### Command Usage

- ◆ Setting the SPF holdtime to 0 means that there is no delay between consecutive calculations.
- ◆ Using a low value allows the router to switch to a new path faster, but uses more CPU processing time.

### Example

```
Console(config-router)#timers spf 20  
Console(config-router)#
```

**ip ospf area** This command assigns a process ID and area ID to an interface. Use the **no** form to disable OSPF on an interface.

### Syntax

**[no] ip ospf** [*ospf-proc-id*] **area** [*ospf-area-id* | *ip-address*]

*ospf-proc-id* - Assigns an OSPF process ID to an interface. (Range: 1-65535)

*ospf-area-id* - Assigns an area ID to an interface. (Range: 0-4294967295)

*ip-address* - Specifies an OSPF area ID in IPv4 address format.

### Command Mode

Interface Configuration (VLAN)

### Default Setting

OSPF disabled

### Example

```
Console(config)#interface vlan 1  
Console(config-if)# ip ospf 1 area 0  
  
Console(config-if)#
```

**ip ospf authentication** This command specifies the authentication type used for an interface. Enter this command without any optional parameters to specify plain text (or simple password) authentication. Use the **no** form to restore the default of no authentication.

### Syntax

**ip ospf authentication [message-digest | null]**

**no ip ospf authentication**

**message-digest** - Specifies message-digest (MD5) authentication.

**null** - Indicates that no authentication is used.

### Command Mode

Interface Configuration (VLAN)

### Default Setting

No authentication

### Command Usage

- ◆ Use authentication to prevent routers from inadvertently joining an unauthorized area. Configure routers in the same area with the same password or key. All neighboring routers on the same network with the same password will exchange routing data.
- ◆ To enable or disable authentication on a VLAN interface, you must first configure authentication at the router configuration level using the [area authentication](#) command.
- ◆ This command creates a password (key) that is inserted into the OSPF header when routing protocol packets are originated by this device. Assign a separate password to each network for different interfaces.
- ◆ When using simple password authentication, a password is included in the packet. If it does not match the password configured on the receiving router, the packet is discarded. This method provides very little security as it is possible to learn the authentication key by snooping on routing protocol packets.
- ◆ When using Message-Digest 5 (MD5) authentication, the router uses the MD5 algorithm to verify data integrity by creating a 128-bit message digest from the authentication key. Without the proper key and key-id, it is nearly impossible to produce any message that matches the pre-specified target message digest.
- ◆ Before specifying plain-text password authentication for an interface, configure a password with the [ip ospf authentication-key](#) command. Before specifying MD5 authentication for an interface, configure the message-digest key-id and key with the [ip ospf message-digest-key](#) command.
- ◆ The plain-text authentication-key, or the MD5 *key-id* and *key*, must be used consistently throughout the autonomous system.

### Example

This example enables authentication for the specified interface.

```
Console(config)#router ospf
Console(config-router)#area 0 authentication
Console(config-router)#exit
Console(config)#interface vlan 1
Console(config-if)#ip ospf 1 area 0
Console(config-if)#ip ospf authentication
Console(config-if)#ip ospf authentication-key 12345678
Console(config-if)#
```

### Related Commands

[area authentication \(1036\)](#)

[ip ospf authentication-key \(1052\)](#)

[ip ospf message-digest-key \(1055\)](#)

**ip ospf authentication-key** This command assigns a simple password to be used by neighboring routers to verify the authenticity of routing protocol messages. Use the **no** form to remove the password.

### Syntax

**ip ospf authentication-key** *key*

**no ip ospf authentication-key**

*key* - Sets a plain text password. (Range: 1-8 characters)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

No password

### Command Usage

- ◆ Before specifying plain-text password authentication for an interface with the [ip ospf authentication](#) command, configure a password with this command.
- ◆ This command creates a password (*key*) that is inserted into the OSPF header when routing protocol packets are originated by this device. Assign a separate password to each network for different interfaces. All neighboring routers on the same network with the same password will exchange routing data.
- ◆ A different password can be assigned to each network interface, but the password must be used consistently on all neighboring routers throughout a network (i.e., autonomous system).

### Example

This example sets a password for the specified interface.

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf authentication-key badboy
Console(config-if)#
```

### Related Commands

[ip ospf authentication \(1051\)](#)

**ip ospf cost** This command explicitly sets the cost of sending a protocol packet on an interface, where higher values indicate slower ports. Use the **no** form to restore the default value.

### Syntax

**ip ospf cost** *cost*

**no ip ospf cost**

*cost* - Link metric for this interface. Use higher values to indicate slower ports. (Range: 1-65535)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

1

### Command Usage

- ◆ The interface cost indicates the overhead required to send packets across a certain interface. This is advertised as the link cost in router link state advertisements.
- ◆ Routes are assigned a metric equal to the sum of all metrics for each interface link in the route.
- ◆ This router uses a default cost of 1 for all port types. Therefore, if any VLAN contains 10 Gbps ports, you may want to reset the cost for other VLANs which do not contain 10 Gbps ports to a value greater than 1.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf cost 10
Console(config-if)#
```

**ip ospf dead-interval** This command sets the interval at which hello packets are not seen before neighbors declare the router down. Use the **no** form to restore the default value.

#### Syntax

**ip ospf dead-interval** *seconds*

**no ip ospf dead-interval**

*seconds* - The maximum time that neighbor routers can wait for a hello packet before declaring the transmitting router down. This interval must be set to the same value for all routers on the network. (Range: 1-65535)

#### Command Mode

Interface Configuration (VLAN)

#### Default Setting

40, or four times the interval specified by the [ip ospf hello-interval](#) command.

#### Command Usage

The dead-interval is advertised in the router's hello packets. It must be a multiple of the hello-interval and be the same for all routers on a specific network.

#### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf dead-interval 50
Console(config-if)#
```

#### Related Commands

[ip ospf hello-interval \(1054\)](#)

**ip ospf hello-interval** This command specifies the interval between sending hello packets on an interface. Use the **no** form to restore the default value.

#### Syntax

**ip ospf hello-interval** *seconds*

**no ip ospf hello-interval**

*seconds* - Interval at which hello packets are sent from an interface. This interval must be set to the same value for all routers on the network. (Range: 1-65535)

#### Command Mode

Interface Configuration (VLAN)

#### Default Setting

10 seconds

### Command Usage

Hello packets are used to inform other routers that the sending router is still active. Setting the hello interval to a smaller value can reduce the delay in detecting topological changes, but will increase routing traffic.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf hello-interval 5
Console(config-if)#
```

**ip ospf message-digest-key** This command enables message-digest (MD5) authentication on the specified interface and assigns a key-id and key to be used by neighboring routers. Use the **no** form to remove an existing key.

### Syntax

**ip ospf message-digest-key** *key-id* **md5** *key*

**no ip ospf message-digest-key** *key-id*

*key-id* - Index number of an MD5 key. (Range: 1-255)

*key* - Alphanumeric password used to generate a 128 bit message digest or "fingerprint." (Range: 1-16 characters)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

MD5 authentication is disabled.

### Command Usage

- ◆ Before specifying MD5 authentication for an interface with the **ip ospf authentication** command, configure the message-digest key-id and key with this command.
- ◆ Normally, only one key is used per interface to generate authentication information for outbound packets and to authenticate incoming packets. Neighbor routers must use the same key identifier and key value.
- ◆ When changing to a new key, the router will send multiple copies of all protocol messages, one with the old key and another with the new key. Once all the neighboring routers start sending protocol messages back to this router with the new key, the router will stop using the old key. This rollover process gives the network administrator time to update all the routers on the network without affecting the network connectivity. Once all the network routers have been updated with the new key, the old key should be removed for security reasons.

### Example

This example sets a message-digest key identifier and password.

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf message-digest-key 1 md5 aiebel
Console(config-if)#
```

### Related Commands

[ip ospf authentication \(1051\)](#)

**ip ospf network** This command configures the OSPF network type. Use the **no** form to restore the default value.

### Syntax

**ip ospf network {broadcast | point-to-point}**

**no ip ospf network**

**broadcast** - Specifies a broadcast type network connecting more than two devices.

**point-to-point** - Specifies a point-to-point network connecting two routers.

### Command Mode

Interface Configuration (VLAN)

### Default Setting

Broadcast

### Command Usage

- ◆ Broadcast networks, or broadcast multi-access networks, are capable of connecting more than two devices, and all attached devices can receive a single transmitted broadcast packet. OSPF routers on broadcast networks will elect a DR and a BDR. Hello packets are multicast with the AllSPFRouters destination address 224.0.0.5, as are all OSPF packets originated by the DR and BDR. All other routers will multicast link-state update and link-state acknowledgment packets to the reserved class D address 224.0.0.6, known as AllDRouters.
- ◆ Point-to-point networks connect a single pair of routers. Valid neighbors on point-to-point networks will always become adjacent. The destination address of OSPF packets on these networks will always be the reserved class D address 224.0.0.5, known as AllSPFRouters. The exception to this rule is retransmitted LSAs, which are always unicast on all network types.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf network point-to-point
Console(config-if)#
```

**ip ospf priority** This command sets the router priority used when determining the designated router (DR) and backup designated router (BDR) for an area. Use the **no** form to restore the default value.

### Syntax

**ip ospf priority** *priority*

**no ip ospf priority**

*priority* - Sets the interface priority for this router. (Range: 0-255)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

1

### Command Usage

- ◆ A designated router (DR) and backup designated router (BDR) are elected for each OSPF network segment based on Router Priority. The DR forms an active adjacency to all other routers in the network segment to exchange routing topology information. If for any reason the DR fails, the BDR takes over this role.
- ◆ Set the priority to zero to prevent a router from being elected as a DR or BDR. If set to any value other than zero, the router with the highest priority will become the DR and the router with the next highest priority becomes the BDR. If two or more routers are tied with the same highest priority, the router with the higher ID will be elected.
- ◆ If a DR already exists for a network segment when this interface comes up, the new router will accept the current DR regardless of its own priority. The DR will not change until the next time the election process is initiated.
- ◆ Configure router priority for multi-access networks only and not for point-to-point networks.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf priority 5
Console(config-if)#
```

**ip ospf retransmit-interval** This command specifies the time between resending link-state advertisements (LSAs). Use the **no** form to restore the default value.

#### Syntax

**ip ospf retransmit-interval** *seconds*

**no ip ospf retransmit-interval**

*seconds* - Sets the interval at which LSAs are retransmitted from this interface. (Range: 1-65535)

#### Command Mode

Interface Configuration (VLAN)

#### Default Setting

5 seconds

#### Command Usage

- ◆ A router will resend an LSA to a neighbor if it receives no acknowledgment after the specified retransmit interval. The retransmit interval should be set to a conservative value that provides an adequate flow of routing information, but does not produce unnecessary protocol traffic. Note that this value should be larger for virtual links.
- ◆ Set this interval to a value that is greater than the round-trip delay between any two routers on the attached network to avoid unnecessary retransmissions.

#### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf retransmit-interval 7
Console(config-if)#
```

**ip ospf transmit-delay** This command sets the estimated time to send a link-state update packet over an interface. Use the **no** form to restore the default value.

#### Syntax

**ip ospf transmit-delay** *seconds*

**no ip ospf transmit-delay**

*seconds* - Sets the estimated time required to send a link-state update. (Range: 1-3600)

#### Command Mode

Interface Configuration (VLAN)

#### Default Setting

1 second

### Command Usage

- ◆ LSAs have their age incremented by this delay before transmission. When estimating the transmit delay, consider both the transmission and propagation delays for an interface. Set the transmit delay according to link speed, using larger values for lower-speed links.
- ◆ If this delay is not added, the time required to transmit an LSA over the link is not taken into consideration by the routing process. On slow links, the router may send packets more quickly than devices can receive them. To avoid this problem, use the transmit delay to force the router to wait a specified interval between transmissions.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ip ospf transmit-delay 6
Console(config-if)#
```

**clear ip ospf process** This command clears and restarts the OSPF routing process. Specify the process ID to clear a particular OSPF process. When no process ID is specified, this command clears all running OSPF processes.

### Syntax

**clear ip ospf** [*process-id*] **process**

*process-id* - Specifies the routing process ID. (Range: 1-65535)

### Default Setting

Clears all routing processes.

### Command Mode

Privileged Exec

### Example

```
Console#clear ip ospf process
Console#
```

**show ip ospf** This command shows basic information about the routing configuration.

### Syntax

**show ip ospf** [*process-id*]

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

## Command Mode Privileged Exec

### Example

```
Console#show ip ospf

OSPF Instance: 1

OSPF Routing Process, Router ID: 192.168.1.1
Supports only single TOS (TOS0) routes
This implementation conforms to RFC2328
RFC1583Compatibility flag is disabled
OpaqueCapability flag is disabled
Initial SPF scheduling delay 0 millise(c)s
Minimum hold time between consecutive SPF(s) 50 millise(c)s
Maximum hold time between consecutive SPF(s) 5000 millise(c)s
Hold time multiplier is currently 1
SPF algorithm last executed 30.435s ago
Last SPF duration 64 usecs
SPF timer is inactive
LSA minimum interval 5000 msec(s)
LSA minimum arrival 1000 msec(s)
Write Multiplier set to 20
Refresh timer 10 sec(s)
Maximum multiple paths(ECMP) supported 8
Administrative distance 110
This router is an ASBR (injecting external routing information)
Number of external LSA 0. Checksum Sum 0x00000000
Number of opaque AS LSA 0. Checksum Sum 0x00000000
Number of areas attached to this router: 1
Area ID: 0.0.0.1 (NSSA)
Shortcutting mode: Default, S-bit consensus: ok
Number of interfaces in this area: Total: 0, Active: 0
It is an NSSA configuration.
Elected NSSA/ABR performs type-7/type-5 LSA translation.
It is not ABR, therefore not Translator.
Number of fully adjacent neighbors in this area: 0
Area has no authentication
Number of full virtual adjacencies going through this area: 0
SPF algorithm executed 1 times
Number of LSA 1
Number of router LSA 1. Checksum Sum 0x00004b39
Number of network LSA 0. Checksum Sum 0x00000000
Number of summary LSA 0. Checksum Sum 0x00000000
Number of ASBR summary LSA 0. Checksum Sum 0x00000000
Number of NSSA LSA 0. Checksum Sum 0x00000000
Number of opaque link LSA 0. Checksum Sum 0x00000000
Number of opaque area LSA 0. Checksum Sum 0x00000000

Console#
```

**show ip ospf border-routers** This command shows entries in the routing table that lead to an Area Border Router (ABR) or Autonomous System Boundary Router (ASBR).

## Syntax

**show ip ospf [process-id] border-routers**

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

## Command Mode

Privileged Exec

## Example

```

Console#show ip ospf border-routers

OSPF Instance: 123

===== OSPF router routing table =====

OSPF Instance: 22

===== OSPF router routing table =====
R   10.214.6.5           [110] area: 0.0.8.98, ABR
                        via 10.214.6.18, VLAN1
R   10.214.7.3           [110] area: 0.0.8.98, ABR, ASBR
                        via 10.214.6.18, VLAN1

Console#

```

**show ip ospf database** This command shows a database summary of OSPF information.

## Syntax

**show ip ospf [process-id] database [self-originate]**

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

**self-originate** - Shows LSAs originated by this router.

## Command Mode

Privileged Exec

## Examples

The following shows output for the **show ip ospf database** command.

```

Console#show ip ospf database

OSPF Instance: 123

OSPF Router with ID (192.168.2.10)

Router Link States (Area 0.0.8.98)

```

```
Link ID      ADV Router  Age  Seq#      CkSum  Link count
192.168.2.10 192.168.2.10 13  0x80000001 0xfc7b 0
```

```
OSPF Instance: 22
```

```
OSPF Router with ID (192.168.1.10)
```

```
Router Link States (Area 0.0.8.98)
```

```
Link ID      ADV Router  Age  Seq#      CkSum  Link count
10.214.6.5   10.214.6.5   974  0x8000003a 0x7d87 1
10.214.6.18  10.214.6.18   5   0x80000065 0x19e4 3
10.214.6.22  10.214.6.22  663  0x80000037 0x0227 1
10.214.7.3   10.214.7.3   914  0x8000003c 0x2cc9 1
192.168.1.10 192.168.1.10 4    0x8000000a 0xd789 1
192.168.2.10 192.168.2.10 673  0x80000043 0x53d2 1
```

```
Net Link States (Area 0.0.8.98)
```

```
Link ID      ADV Router  Age  Seq#      CkSum
10.214.6.6   10.214.6.18 915  0x80000005 0xc5cc
10.214.6.12  10.214.7.3  904  0x80000034 0x3b31
10.214.6.19  192.168.1.10 3600 0x80000003 0x5e22
10.214.6.22  10.214.6.22 14   0x80000019 0x9fb9
```

```
Summary Link States (Area 0.0.8.98)
```

```
Link ID      ADV Router  Age  Seq#      CkSum  Route
10.212.1.0   10.214.6.5 894  0x80000033 0xfd98 10.212.1.0/24
10.212.2.0   10.214.6.5 984  0x80000032 0x09f1 10.212.2.0/24
10.212.3.0   10.214.6.5 904  0x80000032 0xfdfb 10.212.3.0/24
10.212.4.0   10.214.6.5 914  0x80000032 0xc837 10.212.4.0/29
10.213.0.0   10.214.6.5 944  0x80000032 0xe81a 10.213.0.0/29
10.214.7.0   10.214.7.3 904  0x80000033 0x9268 10.214.7.0/29
```

```
Console#
```

**show ip ospf database asbr-summary** This command shows information about Autonomous System Boundary Router summary LSAs.

### Syntax

```
show ip ospf [process-id] database asbr-summary [link-state-id | self-originate | adv-router ip-address]
```

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

*link-state-id* - The network portion described by an LSA. The *link-state-id* entered should be:

- An IP network number for Type 3 Summary and External LSAs
- A Router ID for Router, Network, and Type 4 AS Summary LSAs

Also, note that when an Type 5 ASBR External LSA is describing a default route, its *link-state-id* is set to the default destination (0.0.0.0).

**self-originate** - Shows LSAs originated by this router.

**adv-router** - IP address of the advertising router. If not entered, information about all advertising routers is displayed.

*ip-address* - IP address of the specified router. If no address is entered, information about the local router is displayed.

## Command Mode

Privileged Exec

## Examples

The following shows output for the **show ip ospf database** command.

```

Console#show ip ospf database asbr-summary

                OSPF Router with ID (0.0.0.0) (Process ID 1)

                ASBR-Summary Link States (Area 0.0.0.1)

LS Age: 0
Options: 0x2 (*|---|---|E|)
LS Type: ASBR-summary-LSA
Link State ID: 2.1.0.0 (AS Boundary Router address)
Advertising Router: 192.168.2.1
LS Seq Number: 80000001
Checksum: 0x21ca
Length: 28
Network Mask: /0
                TOS: 0 Metric: 1

Console#

```

**show ip ospf database external** This command shows information about external Link State Advertisements (LSAs) stored in this router's database.

## Syntax

**show ip ospf** [*process-id*] **database external**  
[**adv-router** *ip-address* | *link-state-id* | **self-originate**]

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

*link-state-id* - The network portion described by an LSA. The *link-state-id* entered should be:

- An IP network number for Type 3 Summary and External LSAs
- A Router ID for Router, Network, and Type 4 AS Summary LSAs

Also, note that when an Type 5 ASBR External LSA is describing a default route, its *link-state-id* is set to the default destination (0.0.0.0).

**self-originate** - Shows LSAs originated by this router.

**adv-router** - IP address of the advertising router. If not entered, information about all advertising routers is displayed.

*ip-address* - IP address of the specified router. If no address is entered, information about the local router is displayed.

## Command Mode

Privileged Exec

## Examples

The following shows output for the **show ip ospf database** command.

```
Console#show ip ospf database external

          OSPF Router with ID (0.0.0.0) (Process ID 1)

          AS External Link States

LS Age: 2
Options: 0x0 (*|-|-|-|-|-|-)
LS Type: AS-external-LSA
Link State ID: 192.168.10.0 (External Network Number)
Advertising Router: 2.1.1.0.0
LS Seq Number: 80000006
Checksum: 0x39a0
Length: 36
Network Mask: /24
    Metric Type: 1
    TOS: 0
    Metric: 0
    Forward Address: 0.0.0.0
    External Route Tag: 0

Console#
```

**show ip ospf database network** This command shows information about network Link State Advertisements (LSAs) stored in the router's database.

## Syntax

```
show ip ospf [process-id] database network [link-state-id | self-originate | adv-router ip-address]
```

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

*link-state-id* - The network portion described by an LSA. The *link-state-id* entered should be:

- An IP network number for Type 3 Summary and External LSAs

- A Router ID for Router, Network, and Type 4 AS Summary LSAs

Also, note that when an Type 5 ASBR External LSA is describing a default route, its *link-state-id* is set to the default destination (0.0.0.0).

**self-originate** - Shows LSAs originated by this router.

**adv-router** - IP address of the advertising router. If not entered, information about all advertising routers is displayed.

*ip-address* - IP address of the specified router. If no address is entered, information about the local router is displayed.

## Command Mode

Privileged Exec

## Examples

The following shows output for the **show ip ospf database network** command.

```

Console#show ip ospf database network

          OSPF Router with ID (0.0.0.0) (Process ID 1)

          Net Link States (Area 0.0.0.1)

LS Age: 0
Options: 0x2 (*|---|---|E|-)
LS Type: network-LSA
Link State ID: 192.168.1.1 (address of Designated Router)
Advertising Router: 192.168.1.1
LS Seq Number: 80000003
Checksum: 0x5db5
Length: 32
Network Mask: /24
          Attached Router: 192.168.1.1
          Attached Router: 2.1.0.0

Console#

```

**show ip ospf database nssa-external** This command shows information about NSSA external Link State Advertisements (LSAs) stored in this router's database.

## Syntax

**show ip ospf** [*process-id*] **database nssa-external** [*link-state-id*] **self-originate** | **adv-router** *ip-address*]

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

*link-state-id* - The network portion described by an LSA. The *link-state-id* entered should be:

- An IP network number for Type 3 Summary and External LSAs
- A Router ID for Router, Network, and Type 4 AS Summary LSAs

Also, note that when an Type 5 ASBR External LSA is describing a default route, its *link-state-id* is set to the default destination (0.0.0.0).

**self-originate** - Shows LSAs originated by this router.

**adv-router** - IP address of the advertising router. If not entered, information about all advertising routers is displayed.

*ip-address* - IP address of the specified router. If no address is entered, information about the local router is displayed.

### Command Mode

Privileged Exec

### Examples

The following shows output for the **show ip ospf database nssa-external** command.

```
Console#show ip ospf database nssa-external
OSPF Instance: 22

      OSPF Router with ID (192.168.1.10)

          NSSA-external Link States (Area 0.0.8.98)

OSPF Instance: 24

      OSPF Router with ID (192.168.1.10)

Console#
```

**show ip ospf database router** This command shows information about the router's OSPF Link State Advertisements (LSAs) stored in its database.

### Syntax

**show ip ospf** [*process-id*] **database router** [*link-state-id* | **self-originate** | **adv-router** *ip-address*]

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

*link-state-id* - The network portion described by an LSA. The *link-state-id* entered should be:

- An IP network number for Type 3 Summary and External LSAs
- A Router ID for Router, Network, and Type 4 AS Summary LSAs

Also, note that when an Type 5 ASBR External LSA is describing a default route, its *link-state-id* is set to the default destination (0.0.0.0).

**self-originate** - Shows LSAs originated by this router.

**adv-router** - IP address of the advertising router. If not entered, information about all advertising routers is displayed.

*ip-address* - IP address of the specified router. If no address is entered, information about the local router is displayed.

## Command Mode

Privileged Exec

## Examples

The following shows output for the **show ip ospf database router** command.

```
Console#show ip ospf database router

OSPF Instance: 22

      OSPF Router with ID (192.168.1.10)

                Router Link States (Area 0.0.8.98)

LS age: 85
Options: 0x2  : *|---|---|E|
LS Flags: 0x3
Flags: 0x0
LS Type: router-LSA
Link State ID: 192.168.1.10
Advertising Router: 192.168.1.10
LS Seq Number: 80000004
Checksum: 0x7af2
Length: 36

Number of Links: 1

Link connected to: Stub Network
(Link ID) Net: 10.214.6.16
(Link Data) Network Mask: 255.255.255.248
Number of TOS metrics: 0
TOS 0 Metric: 10
Console#
```

**show ip ospf database self-originate** This command shows information originated by this router.

## Syntax

**show ip ospf [process-id] database self-originate**

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

## Command Mode Privileged Exec

### Examples

The following shows output for the **show ip ospf database self-originate** command.

```
Console#show ip ospf database self-originate

OSPF Instance: 123

      OSPF Router with ID (192.168.2.10)

          Router Link States (Area 0.0.8.98)

Link ID        ADV Router    Age  Seq#           CkSum  Link count
192.168.2.10  192.168.2.10  850  0x80000001  0xfc7b  0

OSPF Instance: 22

      OSPF Router with ID (192.168.1.10)

          Router Link States (Area 0.0.8.98)

Link ID        ADV Router    Age  Seq#           CkSum  Link count
192.168.1.10  192.168.1.10  836  0x8000001d  0xb19c  1

Console#
```

**show ip ospf database summary** This command shows information about OSPF summary Link State Advertisements (LSAs) stored in this router's database.

### Syntax

**show ip ospf** [*process-id*] **database summary** [*link-state-id* | **self-originate** | **adv-router** *ip-address*]

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

*link-state-id* - The network portion described by an LSA. The *link-state-id* entered should be:

- An IP network number for Type 3 Summary and External LSAs
- A Router ID for Router, Network, and Type 4 AS Summary LSAs

Also, note that when an Type 5 ASBR External LSA is describing a default route, its *link-state-id* is set to the default destination (0.0.0.0).

**self-originate** - Shows LSAs originated by this router.

**adv-router** - IP address of the advertising router. If not entered, information about all advertising routers is displayed.

*ip-address* - IP address of the specified router. If no address is entered, information about the local router is displayed.

## Command Mode

Privileged Exec

## Examples

The following shows output for the **show ip ospf database summary** command.

```

Console#show ip ospf database summary

OSPF Instance: 123

      OSPF Router with ID (192.168.2.10)

          Summary Link States (Area 0.0.8.98)

OSPF Instance: 22

      OSPF Router with ID (192.168.1.10)

          Summary Link States (Area 0.0.8.98)

LS age: 1616
Options: 0x2 : *| - | - | - | - | E | -
LS Flags: 0x6
LS Type: summary-LSA
Link State ID: 10.212.1.0 (summary Network Number)
Advertising Router: 10.214.6.5
LS Seq Number: 80000033
Checksum: 0xfd98
Length: 28

Network Mask: /24
      TOS: 0 Metric: 200

LS age: 1706
Options: 0x2 : *| - | - | - | - | E | -
LS Flags: 0x6
LS Type: summary-LSA
Link State ID: 10.212.2.0 (summary Network Number)
Advertising Router: 10.214.6.5
LS Seq Number: 80000032
Checksum: 0x09f1
Length: 28

Network Mask: /24
      TOS: 0 Metric: 100

LS age: 1626
Options: 0x2 : *| - | - | - | - | E | -
LS Flags: 0x6
LS Type: summary-LSA

```

```
Link State ID: 10.212.3.0 (summary Network Number)
Advertising Router: 10.214.6.5
LS Seq Number: 80000032
Checksum: 0xfdfb
Length: 28

Network Mask: /24
      TOS: 0 Metric: 100

LS age: 1636
Options: 0x2 : *| - | - | - | - | E | -
LS Flags: 0x6
LS Type: summary-LSA
Link State ID: 10.212.4.0 (summary Network Number)
Advertising Router: 10.214.6.5
LS Seq Number: 80000032
Checksum: 0xc837
Length: 28
```

Console#

**show ip ospf interface** This command displays summary information for OSPF interfaces.

### Syntax

**show ip ospf interface** [**vlan** *vlan-id*]

*vlan-id* - VLAN ID (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```
Console#show ip ospf interface
```

```
OSPF Instance: 123
```

```
OSPF Instance: 22
```

```
VLAN1 is up
```

```
  ifindex 1001, MTU 1500 bytes, BW 0 Mbit <UP,BROADCAST,RUNNING,MULTICAST>
```

```
  Internet Address 10.214.6.19/29, Broadcast 10.214.6.23, Area 0.0.8.98
```

```
  MTU mismatch detection: enabled
```

```
  Router ID 192.168.1.10, Network Type BROADCAST, Cost: 10
```

```
  Transmit Delay is 1 sec, State DROther, Priority 1
```

```
  Designated Router (ID) 10.214.6.22 Interface Address 10.214.6.22/29
```

```
  Backup Designated Router (ID) 10.214.6.18, Interface Address 10.214.6.18
```

```
  Saved Network-LSA sequence number 0x80000003
```

```
  Multicast group memberships: OSPFAllRouters
```

```
  Timer intervals configured, Hello 10s, Dead 40s, Wait 40s, Retransmit 5
```

```
    Hello due in 5.820s
```

```
  Neighbor Count is 2, Adjacent neighbor count is 2
```

```
Console#
```

**show ip ospf neighbor** This command displays information about neighboring routers on each interface within an OSPF area.

### Syntax

**show ip ospf [process-id] neighbor**

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

### Command Mode

Privileged Exec

### Example

```

Console#show ip ospf neighbor

OSPF Instance: 123

Neighbor ID      Pri State          Up Time          Dead Time Address
Interface

OSPF Instance: 22

Neighbor ID      Pri State          Up Time          Dead Time Address
Interface
10.214.6.18      1 Full/Backup      9m43s           36.174s 10.214.6.18
VLAN1:10.214.6.19 0 0 0
10.214.6.22     128 Full/DR         9m43s           39.001s 10.214.6.22
VLAN1:10.214.6.19 0 0 0

Console#

```

**show ip ospf route** This command displays the OSPF routing table.

### Syntax

**show ip ospf [process-id] route**

*process-id* - The ID of the router process for which information will be displayed. (Range: 1-65535)

### Command Mode

Privileged Exec

### Example

```

Console#show ip ospf route
Codes: C - connected, D - Discard, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
C 192.168.1.0/24 [1] is directly connected, VLAN1, Area 0.0.0.1
IA 192.168.20.0/24 [1] via 192.168.1.100, VLAN1, Area 0.0.0.1

```

Console#

## Open Shortest Path First (OSPFv3)

**Table 190: OSPFv3 Commands**

Command	Function	Mode
<code>router ipv6 ospf</code>	Enables or disables OSPFv3 routing process	GC
<code>area range</code>	Summarizes routes advertised by an ABR	RC
<code>area stub</code>	Defines a stubby area that cannot send or receive LSAs	RC
<code>default-metric</code>	Sets the default metric for external routes imported from other protocols	RC
<code>passive-interface</code>	Suppresses OSPF routing traffic on the specified interface	RC
<code>redistribute</code>	Redistribute routes from one routing domain to another	RC
<code>router-id</code>	Sets the router ID for this device	RC
<code>timers spf</code>	Configures the delay after a topology change and the hold time between consecutive SPF calculations	RC
<code>ipv6 ospf area</code>	Binds an area to the selected interface	IC
<code>ipv6 ospf cost</code>	Specifies the cost of sending a packet on an interface	IC
<code>ipv6 ospf dead-interval</code>	Sets the interval at which hello packets are not seen before neighbors declare the router down	IC
<code>ipv6 ospf hello-interval</code>	Specifies the interval between sending hello packets	IC
<code>ipv6 ospf priority</code>	Sets the router priority used to determine the designated router	IC
<code>ipv6 ospf retransmit-interval</code>	Specifies the time between resending a link-state advertisement	IC
<code>ipv6 ospf transmit-delay</code>	Estimates time to send a link-state update packet over an interface	IC
<code>show ipv6 ospf</code>	Displays general information about the routing processes	PE
<code>show ipv6 ospf database</code>	Shows information about different LSAs in the database	PE
<code>show ipv6 ospf database external</code>	Shows the routing information stored in the external OSPFv3 database	PE
<code>show ipv6 ospf database inter-area-prefix</code>	Shows the OSPFv3 inter-area prefix information stored the database	PE
<code>show ipv6 ospf database inter-area-router</code>	Shows the OSPFv3 inter-area router information stored the database	PE
<code>show ipv6 ospf database intra-area-router</code>	Shows the OSPFv3 intra-area router information stored the database	PE
<code>show ipv6 ospf database link</code>	Shows the OSPFv3 link state information stored in this router's database	PE
<code>show ipv6 ospf database network</code>	Shows the OSPFv3 network link information stored in this router's database	PE

**Table 190: OSPFv3 Commands** (Continued)

Command	Function	Mode
<code>show ipv6 ospf database router</code>	Shows the LSAs that have been exchanged between this router and its neighbors	PE
<code>show ipv6 ospf database self-originate</code>	Shows information about LSAs that have been generated by this router itself	PE
<code>show ipv6 ospf interface</code>	Displays interface information	PE
<code>show ipv6 ospf neighbor</code>	Displays neighbor information	PE
<code>show ipv6 ospf route</code>	Displays the OSPF routing table	PE

### General Guidelines

Follow these basic steps to configure OSPFv3:

1. Assign an IPv6 link-local address to each VLAN interface that will participate in an OSPF routing process. You can automatically generate a link-local address using the `ipv6 enable` command, or manually assign an address to an interface using the `ipv6 address link-local` command.
2. Use the `router ipv6 ospf` command to create a local OSPF router process and enter router configuration mode.
3. Use the `router-id` command to assign a unique identifier to the router. Note that the default router ID of "0.0.0.0" cannot be used with the current software version.
4. Use the `ipv6 ospf area` command to assign an area to each interface that will participate in the specified OSPF process.

**router ipv6 ospf** This command creates an Open Shortest Path First (OSPFv3) routing process and enters router configuration mode. Use the **no** form to disable OSPF for all processes or for a specified process.

### Syntax

**router ipv6 ospf**

**no router ipv6 ospf** [*process-id*]

*process-id* - The OSPFv3 process ID. (Range: 1-10)

### Command Mode

Global Configuration

### Default Setting

Disabled

## Command Usage

This command is used to enable an OSPFv3 routing process, and to enter router configuration mode.

## Example

```
Console(config)#router ipv6 ospf
Console(config-router)#end
Console#show ipv6 ospf
  OSPFv3 Routing Process (0) with Router-ID 0.0.0.0
  Running 00:18:50
  LSA minimum arrival 1000 msec
  Maximum-paths 8
  Administrative distance 110
  Initial SPF scheduling delay 0 millisecond(s)
  Minimum hold time between consecutive SPF's 50 millisecond(s)
  Maximum hold time between consecutive SPF's 5000 millisecond(s)
  Hold time multiplier is currently 1
  SPF algorithm has not been run
  SPF timer is inactive
  Number of AS scoped LSAs is 0
  Number of areas in this router is 0
  Authentication Sequence number info
    Higher sequence no 0, Lower sequence no 0

Console#
```

## Related Commands

[ipv6 ospf area \(1080\)](#)

**area range** This command summarizes the routes advertised by an Area Border Router (ABR). Use the **no** form to disable this function.

## Syntax

**[no] area *area-id* range *ipv6-prefix/prefix-length* {**advertise** | **not-advertise**}**

*area-id* - Identifies an area for which the routes are summarized. The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.

*ipv6-prefix* - A full IPv6 address including the network prefix and host address bits.

*prefix-length* - A decimal value indicating how many contiguous bits (from the left) of the address comprise the prefix (i.e., the portion of the address to summarize).

**advertise** - Advertises the specified address range.

**not-advertise** - The summary is not sent, and the routes remain hidden from the rest of the network.

## Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ This command can be used to summarize intra-area routes and advertise this information to other areas through Area Border Routers (ABRs).
- ◆ If the network addresses within an area are assigned in a contiguous manner, the ABRs can advertise a summary route that covers all of the individual networks within the area that fall into the specified range using a single **area range** command.
- ◆ If routes are set to be advertised by this command, the router will issue a Type 3 summary LSA for each address range specified by this command.
- ◆ This router supports up to 64 summary routes for area ranges.

### Example

This example creates a summary address for all area routes in the range of 73::/8, or all IPv6 addresses that start with the first byte 73 (hexadecimal).

```
Console(config-router)#area 1 range 73::/8 advertise
Console(config-router)#
```

**area stub** This command defines a stub area. To remove a stub, use the **no** form without the optional keyword. To remove the summary attribute, use the **no** form with the summary keyword.

### Syntax

**[no] area *area-id* stub [no-summary]**

*area-id* - Identifies the stub area. The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.

**no-summary** - Stops an Area Border Router (ABR) from sending summary link advertisements into the stub area.

### Command Mode

Router Configuration

### Default Setting

No stub is configured.

Summary advertisements are sent into the stub.

### Command Usage

- ◆ All routers in a stub must be configured with the same area ID.

- ◆ Routing table space is saved by stopping an ABR from flooding Type-4 Inter-Area Router and Type 5 AS-External LSAs into the stub. Since no information on external routes is known inside the stub, an ABR will advertise the default route 0::0/0 using a Type 3 Inter-Area Prefix LSA.
- ◆ The default setting for this command blocks Type-4 Inter-Area Router and Type 5 AS-External LSAs. Therefore, any destinations that cannot be matched to an inter-area or intra-area route will have to use the default route.
- ◆ Use the **no-summary** parameter of this command on an ABR attached to the stub to define a totally stubby area, blocking all Type 3 network summary LSAs. Define an area as a totally stubby area only if routers in the area do not require summary LSAs from other areas.
- ◆ Use the [area default-cost](#) command to specify the cost of a default summary route sent into a stub by an ABR attached to the stub area.

### Example

This example creates a stub area 2, and makes it totally stubby by blocking all Type 3 summary LSAs.

```
Console(config-router)#area 2 stub no-summary  
Console(config-router)#
```

### Related Commands

[area default-cost \(1037\)](#)

**default-metric** This command sets the default metric for external routes imported from other protocols. Use the **no** form to remove the default metric for the supported protocol types.

### Syntax

**default-metric** *metric-value*

**no default-metric**

*metric-value* – Metric assigned to all external routes imported from other protocols. (Range: 0-16777214)

### Command Mode

Router Configuration

### Default Setting

20

### Command Usage

- ◆ The default metric must be used to resolve the problem of redistributing external routes from other protocols that use incompatible metrics.

- ◆ This command does not override the metric value set by the [redistribute](#) command. When a metric value has not been configured by the [redistribute](#) command, the **default-metric** command sets the metric value to be used for all imported external routes.

### Example

```
Console(config-router)#default-metric 100  
Console(config-router)#
```

### Related Commands

[redistribute \(1078\)](#)

**passive-interface** This command suppresses OSPF routing traffic on the specified interface. Use the **no** form to allow routing traffic to be sent and received on the specified interface.

### Syntax

```
[no] passive-interface vlan vlan-id  
vlan-id - VLAN ID. (Range: 1-4094)
```

### Command Mode

Router Configuration

### Default Setting

None

### Command Usage

You can configure an OSPF interface as passive to prevent OSPF routing traffic from exiting or entering that interface. No OSPF adjacency can be formed if one of the interfaces involved is set to passive mode. The specified interface will appear as a stub in the OSPF domain. Also, if you configure an OSPF interface as passive where an adjacency already exists, the adjacency will drop almost immediately.

### Example

```
Console(config-router)#passive-interface vlan 1  
Console(config-router)#
```

**redistribute** This command redistributes external routing information from other routing protocols and static routes into an autonomous system. Use the **no** form to disable this feature or to restore the default settings.

### Syntax

```
redistribute {connected | static} [metric metric-value]  
[metric-type type-value]
```

```
no redistribute {connected | static} [metric] [metric-type]
```

**connected** - Imports all currently connected entries.

**static** - IPv6 static routes will be imported into this Autonomous System.

*metric-value* - Metric assigned to all external routes for the specified protocol. (Range: 0-16777214; Default: 20)

*type-value*

**1** - Type 1 external route

**2** - Type 2 external route (default) - Routers do not add internal route metric to external route metric.

### Command Mode

Router Configuration

### Default Setting

redistribution - none

metric-value - 20

type-metric - 2

### Command Usage

- ◆ This command is used to import routes learned from other routing protocols into the OSPF domain, and to generate AS-external-LSAs.
- ◆ When you redistribute external routes into an OSPF autonomous system (AS), the router automatically becomes an autonomous system boundary router (ASBR).
- ◆ Metric type specifies the way to advertise routes to destinations outside the AS through External LSAs. When a Type 1 LSA is received by a router, it adds the internal cost to the external route metric. In other words, the cost of the route from any router within the AS is equal to the cost associated with reaching the advertising ASBR, plus the cost of the external route. When a Type 2 LSA is received by a router, it only uses the external route metric to determine route cost.

### Example

This example redistributes automatically connected routes as Type 1 external routes.

```
Console(config-router)#redistribute connected metric-type 1
Console(config-router)#
```

**router-id** This command assigns a unique router ID for this device within the autonomous system for the current OSPFv3 process. Use the **no** form to restore the default setting.

### Syntax

**router-id** *ip-address*

**no router-id**

*ip-address* - Router ID formatted as an IPv4 address.

### Command Mode

Router Configuration

### Default Setting

None

### Command Usage

- ◆ This command sets the router ID for the OSPF process specified in the [router ipv6 ospf](#) command.
- ◆ The router ID must be unique for every router in the autonomous system. (Note that the router ID can also be set to 0.0.0.0 or 255.255.255.255).
- ◆ If this router already has registered neighbors, the new router ID will be used when the router is rebooted, or manually restarted by entering the **no router ipv6 ospf** followed by the [router ipv6 ospf](#) command.
- ◆ If the priority values of the routers bidding to be the designated router or backup designated router for an area are equal, the router with the highest ID is elected.
- ◆ The current routing process will not be enabled until a Router ID is configured with this command.

### Example

```
Console(config-router)#router-id 10.1.1.1
Console(config-router)#
```

### Related Commands

[router ipv6 ospf \(1073\)](#)

**timers spf** This command configures the delay after receiving a topology change and starting the shortest path first (SPF) calculation, and the hold time between making two consecutive SPF calculations. Use the **no** form to restore the default values.

### Syntax

**timers spf** *spf-delay spf-holdtime spf-maxtime*

**no timers spf**

*spf-delay* - The delay after receiving a topology change notification and starting the SPF calculation. (Range: 0-600000 milliseconds)

*spf-holdtime* - Minimum hold time between two consecutive SPF calculations. (Range: 0-600000 milliseconds)

*spf-maxtime* - Minimum time between two consecutive SPF calculations. (Range: 0-600000 milliseconds)

### Command Mode

Router Configuration

### Default Setting

SPF delay: 0 milliseconds

SPF holdtime: 50 milliseconds

SPF maxtime: 5000 milliseconds

### Command Usage

- ◆ Setting the SPF holdtime to 0 means that there is no delay between consecutive calculations.
- ◆ Using a low value for the holdtime allows the router to switch to a new path faster, but uses more CPU processing time.

### Example

```
Console(config-router)#timers spf 20
Console(config-router)#
```

**ipv6 ospf area** This command binds an OSPF area to the selected interface. Use the **no** form to remove an OSPF area or disable an OSPF process on an interface.

### Syntax

**[no] ipv6 ospf area** *area-id*

*area-id* - Area to bind to the current Layer 3 interface. An OSPF area identifies a group of routers that share common routing information. The area ID can be in the form of an IPv4 address or as a four octet unsigned integer ranging from 0-4294967295.

### Command Mode

Interface Configuration (VLAN)

### Default Setting

None

### Command Usage

- ◆ An area ID uniquely defines an OSPF broadcast area. The area ID 0.0.0.0 indicates the OSPF backbone for an autonomous system. Each router must be connected to the backbone via a direct connection or a virtual link.
- ◆ Set the area ID to the same value for all routers on a network segment.
- ◆ The backbone (area 0.0.0.0) must be created before any other area.

### Example

This example creates the backbone 0.0.0.0.

```
Console(config)#router ipv6 ospf
Console(config-router)#router-id 192.168.0.2
Console(config-router)#exit
Console(config)#interface vlan 1
Console(config-if)#ipv6 ospf area 0
Console(config-if)#
```

### Related Commands

[router ipv6 ospf \(1073\)](#)

[router-id \(1079\)](#)

**ipv6 ospf cost** This command explicitly sets the cost of sending a protocol packet on an interface, where higher values indicate slower ports. Use the **no** form to restore the default value.

### Syntax

**ipv6 ospf cost** *cost*

**no ipv6 ospf cost**

*cost* - Link metric for this interface. Use higher values to indicate slower ports. (Range: 1-65535)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

1

### Command Usage

- ◆ The interface cost indicates the overhead required to send packets across a certain interface. This is advertised as the link cost in router link state advertisements.
- ◆ Routes are assigned a metric equal to the sum of all metrics for each interface link in the route.
- ◆ This router uses a default cost of 1 for all interfaces. Therefore, if you install a 10 Gigabit module, you may need to reset the cost for all other VLAN interfaces with only 1 Gbps ports to a value greater than 1 to reflect the actual interface bandwidth.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 ospf cost 10
Console(config-if)#
```

**ipv6 ospf dead-interval** This command sets the interval at which hello packets are not seen before neighbors declare the router down. Use the **no** form to restore the default value.

### Syntax

**ipv6 ospf dead-interval** *seconds*

**no ipv6 ospf dead-interval**

*seconds* - The maximum time that neighbor routers can wait for a hello packet before declaring the transmitting router down. This interval must be set to the same value for all routers on the network. (Range: 1-65535)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

40 seconds, or four times the interval specified by the [ipv6 ospf hello-interval](#) command.

### Command Usage

The dead-interval is advertised in the router's hello packets. It must be a multiple of the hello-interval and be the same for all routers on a specific network.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 ospf dead-interval 50
Console(config-if)#
```

### Related Commands

[ipv6 ospf hello-interval \(1083\)](#)

**ipv6 ospf hello-interval** This command specifies the interval between sending hello packets on an interface. Use the **no** form to restore the default value.

### Syntax

**ipv6 ospf hello-interval** *seconds*

**no ipv6 ospf hello-interval**

*seconds* - Interval at which hello packets are sent from an interface. This interval must be set to the same value for all routers on the network.  
(Range: 1-65535)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

10 seconds

### Command Usage

Hello packets are used to inform other routers that the sending router is still active. Setting the hello interval to a smaller value can reduce the delay in detecting topological changes, but will increase routing traffic.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 ospf hello-interval 5
Console(config-if)#
```

### Related Commands

[ipv6 ospf dead-interval \(1082\)](#)

**ipv6 ospf priority** This command sets the router priority used when determining the designated router (DR) and backup designated router (BDR) for an area. Use the **no** form to restore the default value.

### Syntax

**ipv6 ospf priority** *priority* [**instance** *instance-id*]

**no ipv6 ospf priority**

*priority* - Sets the interface priority for this router. (Range: 0-255)

*instance-id* - Identifies a specific OSPFv3 routing process on the link-local network segment attached to this interface. (Range: 0-10)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

1

### Command Usage

- ◆ A designated router (DR) and backup designated router (BDR) are elected for each OSPF area based on Router Priority. The DR forms an active adjacency to all other routers in the area to exchange routing topology information. If for any reason the DR fails, the BDR takes over this role.
- ◆ Set the priority to zero to prevent a router from being elected as a DR or BDR. If set to any value other than zero, the router with the highest priority will become the DR and the router with the next highest priority becomes the BDR. If two or more routers are tied with the same highest priority, the router with the higher ID will be elected.
- ◆ If a DR already exists for a network segment when this interface comes up, the new router will accept the current DR regardless of its own priority. The DR will not change until the next time the election process is initiated.
- ◆ Configure router priority for multi-access networks only and not for point-to-point networks.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 ospf priority 5
Console(config-if)#
```

**ipv6 ospf retransmit-interval** This command specifies the time between resending link-state advertisements (LSAs). Use the **no** form to restore the default value.

### Syntax

**ipv6 ospf retransmit-interval** *seconds*

**no ipv6 ospf retransmit-interval**

*seconds* - Sets the interval at which LSAs are retransmitted from this interface. (Range: 1-65535)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

5 seconds

### Command Usage

- ◆ A router will resend an LSA to a neighbor if it receives no acknowledgment after the specified retransmit interval. The retransmit interval should be set to a conservative value that provides an adequate flow of routing information, but does not produce unnecessary protocol traffic. Note that this value should be larger for virtual links.
- ◆ Set this interval to a value that is greater than the round-trip delay between any two routers on the attached network to avoid unnecessary retransmissions.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 ospf retransmit-interval 7
Console(config-if)#
```

**ipv6 ospf transmit-delay** This command sets the estimated time to send a link-state update packet over an interface. Use the **no** form to restore the default value.

### Syntax

**ipv6 ospf transmit-delay** *seconds*

**no ipv6 ospf transmit-delay**

*seconds* - Sets the estimated time required to send a link-state update.  
(Range: 1-65535)

### Command Mode

Interface Configuration (VLAN)

### Default Setting

1 second

### Command Usage

- ◆ LSAs have their age incremented by this delay before transmission. When estimating the transmit delay, consider both the transmission and propagation delays for an interface. Set the transmit delay according to link speed, using larger values for lower-speed links.
- ◆ If this delay is not added, the time required to transmit an LSA over the link is not taken into consideration by the routing process. On slow links, the router may send packets more quickly than devices can receive them. To avoid this problem, use the transmit delay to force the router to wait a specified interval between transmissions.

### Example

```
Console(config)#interface vlan 1
Console(config-if)#ipv6 ospf transmit-delay 6
Console(config-if)#
```

**show ipv6 ospf** This command shows basic information about the routing configuration.

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 ospf
OSPFv3 Routing Process (0) with Router-ID 0.0.0.0
Running 01:09:25
LSA minimum arrival 1000 msec
Maximum-paths 8
Administrative distance 110
Initial SPF scheduling delay 0 millisecond(s)
Minimum hold time between consecutive SPF's 50 millisecond(s)
Maximum hold time between consecutive SPF's 5000 millisecond(s)
Hold time multiplier is currently 1
SPF algorithm has not been run
SPF timer is inactive
Number of AS scoped LSAs is 0
Number of areas in this router is 0
Authentication Sequence number info
Higher sequence no 0, Lower sequence no 0

Console#
```

**show ipv6 ospf database** This command shows information about different OSPF Link State Advertisements (LSAs) stored in this router's database.

### Syntax

**show ipv6 ospf database**

### Command Mode

Privileged Exec

### Examples

The following shows output for the **show ip ospf database** command.

```
Console#show ipv6 ospf database

Area Scoped Link State Database (Area 0)

Type LSId          AdvRouter          Age   SeqNum          Payload

Area Scoped Link State Database (Area 2)
```

```

Type LSId          AdvRouter      Age   SeqNum          Payload
Rtr  0.0.0.0       1.0.0.1        372  80000002       0.0.0.0/0.0.0.3

      I/F Scoped Link State Database (I/F eth3 in Area 0)

Type LSId          AdvRouter      Age   SeqNum          Payload
Lnk  0.0.0.5       1.0.0.1        447  80000001       fe80::ed9:2bff:feea:3

      I/F Scoped Link State Database (I/F eth2 in Area 2)

Type LSId          AdvRouter      Age   SeqNum          Payload
Lnk  0.0.0.4       1.0.0.1        385  80000001       fe80::ed9:2bff:feea:2
Lnk  0.0.0.4       1.0.0.1        385  80000001       1001::

      AS Scoped Link State Database

Type LSId          AdvRouter      Age   SeqNum          Payload
Console#

```

**show ipv6 ospf database external** This command shows the routing information stored in the external OSPFv3 database.

### Syntax

**show ipv6 ospf database external**

### Command Mode

Privileged Exec

### Examples

```

Console#show ipv6 ospf database external

      AS Scoped Link State Database

Type          LSId          AdvRouter      Age   SeqNum          Payload
AS-External   0.0.0.1       1.0.0.1        385  80000001       [Payload
data for AS-External LSA]
AS-External   0.0.0.2       1.0.0.2        386  80000002       [Payload
data for AS-External LSA]
AS-External   0.0.0.3       1.0.0.3        387  80000003       [Payload
data for AS-External LSA]

Console#

```

**show ipv6 ospf database inter-area-prefix** This command shows the OSPFv3 inter-area prefix information stored in this router's database.

**Syntax**

**show ipv6 ospf database inter-area-prefix**

**Command Mode**

Privileged Exec

**Examples**

```
Console#show ipv6 ospf database inter-area-prefix

Area Scoped Link State Database (Area 1)

Type LSId          AdvRouter      Age  SeqNum          Payload
Inter-Area Prefix Link State Database
Type              LSId           AdvRouter      Age  SeqNum          Payload
AS-External       0.0.0.1        1.0.0.1        385  80000001        [Payload
data for inter-area-prefix]
AS-External       0.0.0.2        1.0.0.2        386  80000002        [Payload
data for inter-area-prefix]
AS-External       0.0.0.3        1.0.0.3        387  80000003        [Payload
data for inter-area-prefix]

Console#
```

**show ipv6 ospf database inter-area-router** This command shows the OSPFv3 inter-area router information stored in this router's database.

**Syntax**

**show ipv6 ospf database inter-area-router**

**Command Mode**

Privileged Exec

**Examples**

```
Console#show ipv6 ospf database inter-area-router

Area Scoped Link State Database (Area 1)

Type LSId          AdvRouter      Age  SeqNum          Payload
Inter-Area-Router 0.0.0.1        1.0.0.1        385  80000001        [Payload
data for Inter-Area-Router LSA 1]
Inter-Area-Router 0.0.0.2        1.0.0.2        386  80000002        [Payload
data for Inter-Area-Router LSA 2]
Inter-Area-Router 0.0.0.3        1.0.0.3        387  80000003        [Payload
data for Inter-Area-Router LSA 3]

Console#
```

**show ipv6 ospf database intra-area-router** This command shows the OSPFv3 intra-area router information stored in this router's database.

### Syntax

**show ipv6 ospf database intra-area-router**

### Command Mode

Privileged Exec

### Examples

```

Console#show ipv6 ospf database intra-area-router

          Area Scoped Link State Database (Area 1)

Type LSId          AdvRouter      Age  SeqNum          Payload
Intra-Area-Prefix 0.0.0.1        1.0.0.1  385  80000001        [Payload data for Intra-Area-Prefix LSA 1]
Intra-Area-Prefix 0.0.0.2        1.0.0.2  386  80000002        [Payload data for Intra-Area-Prefix LSA 2]
Intra-Area-Prefix 0.0.0.3        1.0.0.3  387  80000003        [Payload data for Intra-Area-Prefix LSA 3]

Console#

```

**show ipv6 ospf database link** This command shows the OSPFv3 link state information stored in this router's database.

### Syntax

**show ipv6 ospf database link**

### Command Mode

Privileged Exec

### Examples

```

Console#show ipv6 ospf database link

          I/F Scoped Link State Database (I/F eth3 in Area 0)

Type LSId          AdvRouter      Age  SeqNum          Payload
Lnk  0.0.0.5        1.0.0.1        423  80000002        fe80::ed9:2bff:feea:3
Lnk  0.0.0.3        1.0.0.3       1033  80000001        fe80::e66:a4ff:fe2f:1
Lnk  0.0.0.3        1.0.0.3       1033  80000001        3001::

          I/F Scoped Link State Database (I/F eth2 in Area 2)

Type LSId          AdvRouter      Age  SeqNum          Payload
Lnk  0.0.0.4        1.0.0.1        361  80000002        fe80::ed9:2bff:feea:2
Lnk  0.0.0.4        1.0.0.1        361  80000002        1001::

Console#

```

**show ipv6 ospf database network** This command shows the OSPFv3 network link information stored in this router's database.

### Syntax

**show ipv6 ospf database network**

### Command Mode

Privileged Exec

### Examples

```
Console#show ipv6 ospf database network

      Area Scoped Link State Database (Area 0)

Type LSId          AdvRouter    Age   SeqNum          Payload
Net  0.0.0.5       1.0.0.1     1059 80000003       1.0.0.1
Net  0.0.0.5       1.0.0.1     1059 80000003       1.0.0.3

      Area Scoped Link State Database (Area 2)

Type LSId          AdvRouter    Age   SeqNum          Payload
Console#
```

**show ipv6 ospf database router** This command shows the LSAs that have been exchanged between this router and its neighbors.

### Syntax

**show ipv6 ospf database router**

### Command Mode

Privileged Exec

### Examples

```
Console#show ipv6 ospf database router

      Area Scoped Link State Database (Area 0)

Type LSId          AdvRouter    Age   SeqNum          Payload
Rtr  0.0.0.0       1.0.0.1     1139 80000003       1.0.0.1/0.0.0.5
Rtr  0.0.0.0       1.0.0.3     1120 80000002       1.0.0.1/0.0.0.5

      Area Scoped Link State Database (Area 2)

Type LSId          AdvRouter    Age   SeqNum          Payload
Rtr  0.0.0.0       1.0.0.1     444  80000003       0.0.0.0/0.0.0.3
Console#
```

**show ipv6 ospf database self-originate** This command shows information about LSAs that have been generated by this router itself.

### Syntax

**show ipv6 ospf database self-originate**

### Command Mode

Privileged Exec

### Examples

```

Console#show ipv6 ospf database self-originate

Area Scoped Link State Database (Area 1)

Type          LSId          AdvRouter      Age   SeqNum      Payload
----          -
Self-Originate 0.0.0.1       1.0.0.1        385   80000001    [Payload
  data for Self-Originate LSA 1]
Self-Originate 0.0.0.2       1.0.0.2        386   80000002    [Payload
  data for Self-Originate LSA 2]
Self-Originate 0.0.0.3       1.0.0.3        387   80000003    [Payload
  data for Self-Originate LSA 3]

AS Scoped Link State Database

Type          LSId          AdvRouter      Age   SeqNum      Payload
----          -
Console#
  
```

**show ipv6 ospf interface** This command displays summary information for OSPF interfaces.

### Syntax

**show ipv6 ospf interface [vlan *vlan-id*]**

*vlan-id* - VLAN ID (Range: 1-4094)

### Command Mode

Privileged Exec

### Example

```

Console#show ipv6 ospf interface vlan 1
VLAN 1 is up, line protocol is up
Link local Address FE80::200:E8FF:FE93:82A0/64, Area 0.0.0.0
Tag 1, Router ID 192.168.0.2, Network Type BROADCAST, Cost: 1
Transmit Delay is 1 sec, State DR, Priority 1
Designated Router (ID) 192.168.0.2, Interface Address
FE80::200:E8FF:FE93:82A0
No backup designated router on this network
Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
Neighbor Count is 0, Adjacent neighbor count is 0
Hello received 0 sent 92, DD received 0 sent 0
LS-Req received 0 sent 0, LS-Upd received 0 sent 0
  
```

```
LS-Ack received 0 sent 0, Discarded 0  
Console#
```

**show ipv6 ospf neighbor** This command displays information about neighboring routers on each interface within an OSPF area.

### Syntax

**show ipv6 ospf neighbor**

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 ospf neighbor
```

ID	Pri	State	Interface ID	Interface
192.168.0.2	1	FULL/DR	1001	vlan1

```
Console#
```

**show ipv6 ospf route** This command displays the OSPF routing table.

### Syntax

**show ipv6 ospf route**

### Command Mode

Privileged Exec

### Example

```
Console#show ipv6 ospf route  
Codes: C - connected, S - static, R - RIP, B - BGP  
O - OSPF, IA - OSPF inter area  
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2  
E1 - OSPF external type 1, E2 - OSPF external type 2  
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area  
C    ::1/128, lo0  
O    2001:DB8:2222:7272::/64, VLAN1  
C    2001:DB8:2222:7272::/64, VLAN1  
?    FE80::/64, VLAN1 inactive  
C    FE80::/64, VLAN1  
?    FF00::/8, VLAN1 inactive  
  
Console#
```

# BGPv4 Commands

This section includes commands for Border Gateway Protocol (BGPv4) dynamic routing and policy-based routing maps for BGP.

**Table 191: BGP Routing Commands**

Command Group	Function
Border Gateway Protocol (BGPv4)	Configures general and neighbor specific parameters for BGPv4
Policy-based Routing for BGP	Configures policy-based routing maps for BGP

## Border Gateway Protocol (BGPv4)

An autonomous system (AS) functions as a separate routing domain under one administrative authority, which implements its own routing policies. An AS exchanges routing information within its boundaries using Interior Gateway Protocols (IGPs) such as RIP or OSPF, and connects to external organizations or to the Internet using an Exterior Gateway Protocol (EGP). BGP version 4 is the primary EGP deployed on the Internet today.

When connecting to the Internet, external BGP (eBGP) is used. Although BGP is widely used as an exterior gateway protocol (EGP), it is also used in many organizations with complex internal networks. Internal networks can be simplified by exchanging routing information among BGP peers within the same organization through internal BGP (iBGP) peering sessions.

**Table 192: Border Gateway Protocol Commands – Version 4**

Command	Function	Mode
<code>router bgp</code>	Enables BGPv4 routing process and enters router configuration mode	GC
<code>bgp as-path access-list</code>	Configures an autonomous system path access list	GC
<code>bgp community-list</code>	Configures a community list	GC
<code>bgp extcommunity-list</code>	Configures an extended community list	GC
<code>ip prefix-list</code>	Configures an address prefix list	GC
<code>aggregate-address</code>	Configures an aggregate address in the routing table	RC
<code>bgp always-compare-med</code>	Allows comparison of the Multi Exit Discriminator (MED) for paths advertised from neighbors in different autonomous systems	RC

**Table 192: Border Gateway Protocol Commands – Version 4** (Continued)

Command	Function	Mode
<code>bgp bestpath as-path ignore</code>	Ignores AS path length in the selection of a path	RC
<code>bgp bestpath as-path confed</code>	Compare confederation AS path length in addition to external AS path length in the selection of a path	RC
<code>bgp bestpath compare-routerid</code>	Compare similar routes from external peers, and give preference to a route with the lowest router identifier	RC
<code>bgp bestpath med</code>	Enables comparison of MED attribute for paths learned from confederation peers, and the treatment of a route when the MED is missing	RC
<code>bgp client-to-client reflection</code>	Configures route reflection between clients via route reflector	RC
<code>bgp cluster-id</code>	Configures cluster identifier for multiple route reflectors in the same cluster	RC
<code>bgp confederation identifier</code>	Configures the identifier for a confederation containing smaller multiple internal autonomous systems	RC
<code>bgp confederation peers</code>	Adds an internal peer autonomous system to a confederation	RC
<code>bgp dampening</code>	Configures route dampening to reduce the propagation of unstable routes	RC
<code>bgp default local-preference</code>	Sets the default local preference used for best path selection among local iBGP peers	RC
<code>bgp deterministic-med</code>	Enforces deterministic comparison of the MED attribute between all paths received from the same AS, ensuring that selection of the best path will always be the same, regardless of the order in which the paths are received by the local router	RC
<code>bgp fast-external-failover</code>	Resets sessions for any directly connected external peers if the link goes down	RC
<code>bgp log-neighbor-changes</code>	Enables logging of neighbor resets (that is, up or down status changes)	RC
<code>bgp network import-check</code>	Checks the existence of the next-hop and its accessibility to IGP	RC
<code>bgp router-id</code>	Sets the router ID for this device	RC
<code>bgp conditional-advertisement timer</code>	Sets the interval at which to validate next hop information for BGP routes	RC
<code>clear ip bgp</code>	Clears connections using hard or soft re-configuration	PE
<code>clear ip bgp ipv4</code>	Clears IPv4 connections using hard or soft re-configuration	PE
<code>clear ip bgp dampening</code>	Clears route dampening information and unsuppresses any suppressed routes	PE
<code>distance</code>	Sets the administrative distance for a specified external BGP (eBGP) route	RC
<code>distance bgp</code>	Sets the administrative distance for BGP external, internal, and local routes	RC
<code>neighbor activate</code>	Enables exchange of routing information with a neighboring router or peer group	RC

**Table 192: Border Gateway Protocol Commands – Version 4 (Continued)**

Command	Function	Mode
<code>neighbor advertisement-interval</code>	Configures the interval between sending update messages to a neighbor	RC
<code>neighbor allowas-in</code>	Configures the number of times the AS path for a received route can contain the same AS number	RC
<code>neighbor attribute-unchanged</code>	Configures certain attributes to be kept unchanged for transparent transmission to the specified neighbor	RC
<code>neighbor capability dynamic</code>	Configures dynamic negotiation of capabilities between neighboring routers	RC
<code>neighbor capability orf prefix-list</code>	Configures negotiation of outbound route filter capabilities with neighboring router	RC
<code>neighbor default-originate</code>	Allows the local router to send a default route to a neighbor	RC
<code>neighbor description</code>	Configures the description of a neighbor or peer group	RC
<code>neighbor distribute-list</code>	Filters route updates to/from a neighbor or peer group	RC
<code>neighbor dont-capability-negotiate</code>	Disables capability negotiation when creating connections	RC
<code>neighbor ebgp-multihop</code>	Allows eBGP neighbors to exist in different segments, and configures the maximum hop count (TTL)	RC
<code>neighbor enforce-first-as</code>	Denies an update received from an external peer that does not list its own autonomous system number at the beginning of the AS path attribute	RC
<code>neighbor enforce-multihop</code>	Enforces the requirement for all neighbors to form multi-hop connections	RC
<code>neighbor filter-list</code>	Filters route updates sent to or received from a neighbor based on an AS path access-list	RC
<code>neighbor interface</code>	Specifies the interface to a neighbor	RC
<code>neighbor maximum-prefix</code>	Sets the maximum number or route prefixes that can be received from a neighbor	RC
<code>neighbor next-hop-self</code>	Configures the local router as the next hop for a neighbor	RC
<code>neighbor override-capability</code>	Overrides the result of capability negotiations, allowing a session to be formed with a peer that does not support capability negotiation	RC
<code>neighbor passive</code>	Passively forms a connection with the specified neighbor, not sending a TCP connection request, but waiting a request from the specified neighbor	RC
<code>neighbor password</code>	Enables MD5 authentication and sets the key for a neighboring router	RC
<code>neighbor peer-group (Creating)</code>	Configures a router peer group which can be easily configured with the same attributes	RC
<code>neighbor peer-group (Group Members)</code>	Assigns routers to a peer group	RC
<code>neighbor port</code>	Specifies the TCP port number of the partner through which communications are carried	RC
<code>neighbor prefix-list</code>	Configures prefix restrictions applied in inbound/outbound route updates to/from specified neighbors	RC

**Table 192: Border Gateway Protocol Commands – Version 4** (Continued)

Command	Function	Mode
<code>neighbor remote-as</code>	Configures a neighbor and its AS number, identifying the neighbor as a local AS member	RC
<code>neighbor remove-private-as</code>	Removes private autonomous system numbers from outbound routing updates to an external neighbor	RC
<code>neighbor route-map</code>	Specifies the route mapping policy for inbound/outbound routing updates for specified neighbors	RC
<code>neighbor route-reflector-client</code>	Configures this router as a route reflector and the specified neighbor as its client	RC
<code>neighbor route-server-client</code>	Configures this router as a route server and the specified neighbor as its client	RC
<code>neighbor send-community</code>	Configures the router to send community attributes to a neighbor in peering messages	RC
<code>neighbor shutdown</code>	Closes a neighbor connection without canceling the neighbor configuration	RC
<code>neighbor soft-reconfiguration inbound</code>	Configures the switch to store updates in the inbound message buffer, and perform soft re-configuration from this buffer for specified neighbors when required	RC
<code>neighbor strict-capability-match</code>	Forces strict capability matching when establishing connections	RC
<code>neighbor timers</code>	Sets the Keep Alive time and Hold time used for specified neighbors	RC
<code>neighbor timers connect</code>	Sets the time to wait before attempting to reconnect to a neighbor whose TCP connection has failed	RC
<code>neighbor unsuppress-map</code>	Allows specified suppressed routes to be advertised	RC
<code>neighbor update-source</code>	Specifies the interface to use for a connection, instead of using the nearest interface	RC
<code>neighbor weight</code>	Assigns a weight to a neighbor connection	RC
<code>network</code>	Specifies a network to advertise	RC
<code>redistribute</code>	Redistribute routes from one routing domain to another	RC
<code>timers bgp</code>	Sets the Keep Alive time used for maintaining connectivity, and the Hold time to wait for Keep Alive messages before declaring a neighbor down	RC
<code>show ip bgp</code>	Shows entries in the routing table	PE
<code>show ip bgp attribute-info</code>	Shows internal attribute information	PE
<code>show ip bgp community</code>	Shows routes that belong to specified BGP communities	PE
<code>show ip bgp community-info</code>	Shows permitted community messages	PE
<code>show ip bgp community-list</code>	Shows the routes matching a community-list	PE
<code>show ip bgp dampening</code>	Shows dampened routes	PE
<code>show ip bgp filter-list</code>	Shows routes matching the specified filter list	PE
<code>show ip bgp neighbors</code>	Shows connection information for neighbor sessions	PE
<code>show ip bgp paths</code>	Shows all paths in the database	PE

**Table 192: Border Gateway Protocol Commands – Version 4** (Continued)

Command	Function	Mode
<a href="#">show ip bgp prefix-list</a>	Shows routes matching the specified prefix-list	PE
<a href="#">show ip bgp regexp</a>	Shows routes matching the AS path regular expression	PE
<a href="#">show ip bgp route-map</a>	Shows routes matching the specified route map	PE
<a href="#">show ip bgp nexthop</a>	Shows BGP scan status	PE
<a href="#">show ip bgp summary</a>	Shows summary information for all connections	PE
<a href="#">show ip community-list</a>	Shows routes permitted by a community list	PE
<a href="#">show ip extcommunity-list</a>	Shows routes permitted by an extended community list	PE
<a href="#">show ip prefix-list</a>	Shows the specified prefix list	PE
<a href="#">show ip prefix-list detail</a>	Shows detailed information for the specified prefix list	PE
<a href="#">show ip prefix-list summary</a>	Shows summary information for the specified prefix list	PE

**router bgp** This command enables the Border Gateway Protocol (BGPv4) routing process and enters router configuration mode. Use the **no** form to disable it.

### Syntax

**[no] router bgp** *as-number*

*as-number* – Autonomous system number which identifies this router as a member of the specified domain, and tags routing messages passed to other BGP routers with this number. (Range: 1-4294967295)

### Command Mode

Global Configuration

### Default Setting

No routing process is defined.

### Command Usage

- ◆ To enable BGP routing, you must use this command to establish a BGP routing process. After entering this command, the switch enters router configuration mode.
- ◆ AS numbers in the range 64512-65535 are normally used for private routing domains, and can be removed from the AS path attribute in outbound routing messages using the [neighbor remove-private-as](#) command. Note that AS number 23456 is reserved for the AS-Transitive attribute which is required when setting up a new BGP speaker.
- ◆ Use this command to specify all of the routers within an autonomous system used to exchange interior or exterior BGP routing messages. Repeat this process for any other autonomous system under your administrative control to

create a distributed routing core for the exchange of routing information between autonomous systems.

### Example

```
Console(config)#router bgp 100
Console(config-router)#
```

### Related Commands

[network \(1149\)](#)

**bgp as-path access-list** This command configures an autonomous system path access list. Use the **no** form with only the access list name to disable its use, or with all parameters to remove a path attribute from the access list.

### Syntax

**bgp as-path access-list** *access-list-name* {**deny** | **permit**} *regular-expression*

**no bgp as-path access-list** *access-list-name* [{**deny** | **permit**} *regular-expression*]

*access-list-name* – Name of the access list. (Maximum length: 16 characters, no spaces or other special characters)

**deny** – Permits access for messages with matching path attribute.

**permit** – Denies access to messages with matching path attribute.

*regular-expression* – Autonomous system in the access list expressed as a regular expression<sup>17</sup>.

### Command Mode

Global Configuration

### Default Setting

No AS path access lists are defined.

### Command Usage

- ◆ If the regular expression in an AS path list is matched, then the deny/permit condition is applied to the routing message.
- ◆ Use this command in conjunction with the [neighbor filter-list](#) command to filter route updates sent to or received from a neighbor, or with the [match as-path](#) route map command to implement a more comprehensive filter for policy-based routing.

17. Syntax complies with the IEEE POSIX Basic Regular Expressions (BRE) standard.

### Example

The regular expression in this example uses symbols which instruct the filter to match the character or null string at the beginning and end of an input string.

```
Console(config-router)#bgp as-path access-list RD deny ^100$
Console(config-router)#
```

### Related Commands

[neighbor filter-list \(1131\)](#)

[match as-path \(1168\)](#)

**bgp community-list** This command configures a community access list. Use the **no** form with only the access list name to disable its use, or with all parameters to remove a community attribute from the access list.

### Syntax

#### [no] bgp community-list

```
{1-99 | standard community-list-name {deny | permit}
[AA:NN] [internet] [local-as] [no-advertise] [no-export]} | {100-500 |
expanded community-list-name {deny | permit} regular-expression}
```

1-99 – Standard community list number that identifies one or more groups of communities.

**standard** *community-list-name* – Name of standard access list. A maximum of 16 communities can be configured in a standard community list (Maximum length: 32 characters, no spaces or other special characters)

**deny** – Denies access to messages with matching community attribute.

**permit** – Permits access for messages with matching community attribute.

AA:NN – Standard community-number to deny or permit. The 4-byte community number is composed of a 2-byte autonomous system number and a 2-byte network number, separated by one colon. Each 2-byte number can range from 0 to 65535. One or more communities can be entered, separated by a space. Up to 16 community numbers are supported.

**internet** – Specifies the entire Internet. Routes with this community attribute are advertised to all internal and external peers.

**local-as** – Specifies the local autonomous system. Routes with this community attribute are advertised only to peers that are part of the local autonomous system or to peers within a sub-autonomous system of a confederation. These routes are not advertised to external peers or to other sub-autonomous systems within a confederation.

**no-advertise** – Routes with this community attribute are not advertised to any internal or external peer.

**no-export** – Routes with this community attribute are advertised only to peers in the same autonomous system or to other sub-autonomous systems within a confederation. These routes are not advertised to external peers.

100-500 – Expanded community list number that identifies one or more groups of communities.

**expanded** *community-list-name* – Name of expanded access list. (Maximum length: 32 characters, no spaces or other special characters)

*regular-expression* – Regular expression indicating the community list number or name<sup>17</sup>.

### Command Mode

Global Configuration

### Default Setting

No community lists are defined.

### Command Usage

- ◆ Standard community lists are used to configure well-known communities or community numbers. Expanded community lists are used to filter communities using a regular expression.
- ◆ When multiple values are entered in the same community list, they form a logical AND condition. When multiple values are configured in separate community lists, they form a logical OR condition, where the first list that matches a condition is processed.
- ◆ If the criteria specified for a community list is matched, then the deny/permit condition is applied to the routing message.
- ◆ If a permit value is applied to a community list, the filter will implicitly deny other community values.
- ◆ By default, the internet community is set with a route if no other communities are defined.
- ◆ Use this command in conjunction with the [neighbor send-community](#) to filter route updates sent to or received from a neighbor, or with the [match community](#) route map command to implement a more comprehensive filter for policy-based routing.

### Example

This example configures a named standard community list LN that permits routes with community value 100:10, denoting that they come from autonomous system 100 and network 10.

```
Console(config)#bgp community-list standard LN permit 100:10
Console(config)#
```

### Related Commands

[neighbor send-community \(1143\)](#)

[match community \(1168\)](#)

**bgp extcommunity-list** This command configures an extended community access list. Use the **no** form with only the access list name to disable its use, or with the relevant parameters to remove a community attribute from the access list.

### Syntax

#### [no] bgp extcommunity-list

```
{1-99 | standard community-list-name {deny | permit}
[{{rt | soo} extended-community-value}] |
{100-500 | expanded community-list-name {deny | permit}
regular-expression}
```

1-99 – Standard community list number that identifies one or more groups of communities.

**standard** *community-list-name* – Name of standard access list. A maximum of 16 extended communities can be configured in a standard community list. (Maximum length: 32 characters, no spaces or other special characters)

**deny** – Denies access to messages with matching extended community attribute.

**permit** – Permits access for messages with matching extended community attribute.

**rt** – The route target extended community attribute.

**soo** – The site of origin extended community attribute.

*extended-community-value* – The route target or site of origin in one of the following formats:

*AAAA:NN* or *AA:NNNN* – Community-number to deny or permit. The community number can either be formatted as a 4-byte autonomous system number and a 2-byte network number, or as a 2-byte autonomous system number and a 4-byte network number, separated by one colon. Each 2-byte number can range from 0 to 65535, and 4-byte numbers from 0 to 4294967295.

*IP:NN* – Community to deny or permit. The community number is composed of a 4-byte IP address (representing the autonomous system

number) and a 2-byte network number, separated by one colon. The 2-byte network number can range from 0 to 65535.

One or more community numbers can be entered, separated by a space. Up to 3 community numbers are supported.

100-500 – Expanded community list number that identifies one or more groups of communities.

**expanded** *community-list-name* – Name of expanded access list. (Maximum length: 32 characters, no spaces or other special characters)

*regular-expression* – Regular expression indicating the community list number or name. Syntax complies with the IEEE POSIX Basic Regular Expressions (BRE) standard.

### Command Mode

Global Configuration

### Default Setting

No extended community lists are defined.

### Command Usage

- ◆ Standard community lists are used to configure well-known communities or community numbers. Expanded community lists are used to filter communities using a regular expression.
- ◆ When multiple values are entered in the same community list, they form a logical AND condition. When multiple values are configured in separate community lists, they form a logical OR condition, where the first list that matches a condition is processed.
- ◆ If the criteria specified for a community list is matched, then the deny/permit condition is applied to the routing message.
- ◆ If a permit value is applied to a community list, the filter will implicitly deny other community values.
- ◆ The route target (RT) attribute is used to identify sites that may receive routes tagged with a specific route target. Using this attribute allows that route to be placed in per-site forwarding tables used for routing traffic received from the corresponding sites.
- ◆ The site of origin (SOO) attribute is used to identify the site from which the provider edge (PE) router learned the route. All routes learned from a particular site are assigned the same site of origin attribute, no matter if a site is connected to a single PE router or multiple PE routers. Filtering based on this extended community attribute can prevent routing loops from occurring when a site is multi-homed.

- ◆ Use this command in conjunction with the [neighbor filter-list](#) to filter route updates sent to or received from a neighbor, or with the [match extcommunity](#) route map command to implement a more comprehensive filter for policy-based routing.

### Example

This example configures a named standard community list LR that permits routes with the route target 100:20, denoting that they destined for the autonomous system 100 and network 20.

```
Console(config)#bgp extcommunity-list standard LP permit soo 100:20
Console(config)#
```

### Related Commands

[neighbor filter-list \(1131\)](#)

[match extcommunity \(1169\)](#)

**ip prefix-list** This command configures an IP address prefix list. Use the **no** form with only the prefix list name to disable its use, or with the relevant parameters to remove an attribute from the prefix list.

### Syntax

```
[no] ip prefix-list prefix-list-name [seq sequence-number]
      {deny | permit} any
```

```
[no] ip prefix-list prefix-list-name [seq sequence-number]
      {deny | permit} {ip-address/mask | any}
      [ge min-prefix-length] [le max-prefix-length]
```

*prefix-list-name* – Name of prefix list. (Maximum length: 128 characters, no spaces or other special characters)

*sequence-number* – Applies a sequence number to the entry. If not specified, the entry is added to the bottom of the list, using a default numbering interval of 5. (Range: 1-429496725)

**deny** – Denies access to messages matching specified criteria.

**permit** – Permits access for messages matching specified criteria.

**any** – Any matching criteria.

*ip-address* – An IPv4 address expressed in dotted decimal notation.

*mask* – Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

**ge** – The minimum prefix length to match. (Range: 0-32)

**le** – The maximum prefix length to match. (Range: 0-32)

### Command Mode

Global Configuration

### Default Setting

No prefix lists are defined.

### Command Usage

- ◆ Prefix filtering can be performed on an IP address expressed as a classful network, a subnet, or a single host route.
- ◆ Prefix lists are checked starting from the lowest sequence number and continues through the list until a match is found. Once an entry is found that covers a network, the permit or deny statement is applied to that network, and the search process stops.
- ◆ At least one “permit” statement should be included when more than one entry is defined. Commonly used “Deny” statements can be included at the top of the list to quickly remove unsuitable routing messages. If a list includes all “Deny” statements, then an entry of “permit 0.0.0.0 255.255.255.255 ge 0 le 32” can be included at the bottom of the list to grant passage for all other routing messages.
- ◆ A prefix list can be applied to inbound or outbound updates for a specific peer by entering the [neighbor prefix-list](#) command, or with the [match ip address prefix-list](#) route map command to implement a more comprehensive filter for policy-based routing.

### Example

This example denies access to routing messages for the specified address.

```
Console(config)#ip prefix-list LS deny 10.0.0.0/8 ge 14 le 22
Console(config)#
```

### Related Commands

[neighbor prefix-list \(1138\)](#)

[match ip address \(1170\)](#)

**aggregate-address** This command configures an aggregate address in the routing table. Use the **no** form to delete an aggregate address.

### Syntax

**[no] aggregate-address** *ip-address netmask* [**as-set**] [**summary-only**]

*ip-address* – An IPv4 address expressed in dotted decimal notation.

*netmask* – Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

**as-set** – Generates autonomous system set information for the AS path attribute, indicating that a route originated in multiple autonomous systems.

**summary-only** – Sends the summary routes only, ignoring more specific routes.

### Command Mode

Router Configuration

### Default Setting

No aggregate routes are defined.

### Command Usage

- ◆ Using this command without any keywords will create an aggregate entry in the routing table if any more specific routes are available in the specified range. The aggregate route does not include any individual route attributes (e.g., AS-Path or Community). It is advertised as coming from this autonomous system and has the atomic aggregate attribute set to indicate that some information may be missing.
- ◆ Using the **as-set** keyword creates an aggregate route where the advertised path is an AS-Set that consists of all elements contained in all of paths being summarized. AS-Set information can be used to avoid routing loops because it records where the route has been. If a router notes its own AS number in the AS-Set of the aggregate update, it will drop the aggregate to prevent a loop. However, when aggregating tens or hundreds of routes, avoid advertising routing information in this manner, since this route may be frequently withdrawn and updated as AS path reachability information for the summarized routes changes.
- ◆ Using the **summary-only** keyword creates the aggregate route, while at the same time suppressing advertisements of more specific routes to all neighbors.

### Example

```

Console(config-router)#aggregate-address 100.1.0.0 255.255.0.0 summary-only
Console(config-router)#aggregate-address 100.2.0.0 255.255.0.0 summary-only
as-set
Console(config-router)#aggregate-address 100.3.0.0 255.255.0.0 as-set
Console(config-router)#end
Console#show ip bgp
BGP table version is 0, local router ID is 192.168.0.4
Status codes: s suppressed, d damped, h history, * valid, > best, i -
              internal,
                r RIB-failure, S Stale, R Removed
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network          Next Hop          Metric LocPrf Weight Path
*>i192.168.0.0/24   0.0.0.0           0         32768  i

```

**bgp always-compare-med** This command allows comparison of the Multi Exit Discriminator (MED) for paths advertised from neighbors in different autonomous systems. Use the **no** form to disable this feature.

#### Syntax

**[no] bgp always-compare-med**

#### Command Mode

Router Configuration

#### Default Setting

Disabled

#### Command Usage

- ◆ The MED is an optional non-transitive<sup>18</sup> attribute used to discriminate among multiple exit points to a neighboring autonomous system. A path with a lower MED is preferred over a path with a higher MED.
- ◆ By default, during best-path selection, the MED is compared only among paths from the same autonomous system. This command allows the comparison of MEDs among different paths regardless of the autonomous system from which the paths are received.
- ◆ The **bgp deterministic-med** command can be used to enforce comparison of the MED value between all paths received from within the same autonomous system.

#### Example

This example assumes that a peer router is advertising the same route prefix through the two ASes (100 and 300) to the same AS (200), each of which carries a different MED.

```
Console(config-router)#bgp always-compare-med
Console(config-router)#
```

**bgp bestpath as-path ignore** This command ignores the AS path length in the selection of a path. Use the **no** form to disable this feature.

#### Syntax

**[no] bgp bestpath as-path ignore**

#### Command Mode

Router Configuration

<sup>18</sup>. If a router does not understand an optional non-transitive attribute, it will be removed.

### Default Setting

Disabled

### Example

```
Console(config-router)#bgp bestpath as-path ignore  
Console(config-router)#
```

**bgp bestpath as-path confed** This command compare confederation AS path length in addition to external AS path length in the selection of a path. Use the no form to disable this feature.

### Syntax

**[no] bgp bestpath as-path confed**

### Command Mode

Router Configuration

### Default Setting

Disabled

### Example

```
Console(config-router)#bgp bestpath as-path confed  
Console(config-router)#
```

**bgp bestpath compare-routerid** This command compares similar routes from external peers, and gives preference to a route with the lowest router identifier. Use the **no** form to restore the default setting.

### Syntax

**[no] bgp bestpath compare-routerid**

### Command Mode

Router Configuration

### Default Setting

When making the best-path selection, the router does not compare identical routes received from different external peers.

### Command Usage

Normally, the first route arriving from different external peers (with other conditions equal) will be chosen as the best route. By using this command, the route with lowest router ID will be selected.

### Example

```
Console(config-router)#bgp bestpath compare-routerid  
Console(config-router)#
```

**bgp bestpath med** This command enables comparison of the Multi Exit Discriminator (MED) attribute for paths learned from confederation peers, and the treatment of a route when the MED is missing. Use the **no** form to disable this feature.

### Syntax

**[no] bgp bestpath med** {[**confed**] [**missing-as-worst**]}

**confed** – Compare MED in confederation path.

**missing-as-worst** – Consider as maximum MED value when missing.

### Command Mode

Router Configuration

### Default Setting

When making the best-path selection, the router does not consider the MED.

### Command Usage

- ◆ The MED for paths learned from confederation peers is compared only if no external autonomous systems (AS) appear in the path. If an external AS is within the path, then the external MED is passed transparently through the confederation, and it is not compared.
- ◆ If the missing-as-worst option is disabled, the missing MED is assigned a value of 0, making a path missing the MED attribute the best path.

### Example

```
Console(config-router)#bgp bestpath med config missing-as-worst  
Console(config-router)#
```

**bgp client-to-client reflection** This command restores route reflection via this router. Use the **no** form to disable route reflection.

### Syntax

**[no] bgp client-to-client reflection**

### Command Mode

Router Configuration

### Default Setting

Enabled

### Command Usage

- ◆ Route reflection from this device is enabled by default, but is only functional if a client has been configured with the [neighbor route-reflector-client](#) command.
- ◆ Route reflection is not required if all of the routers in an AS are fully meshed as normally required by interior BGP. However, to make interior BGP more scalable, route reflection or confederations can be used. Route reflection uses one or more route reflectors to reflect routes between specified clients within a cluster. Clients within a reflector cluster therefore need not be fully meshed, and the exchange of routing information is thereby reduced since the clients need not communicate with any routers outside of the cluster.
- ◆ Routing information from an external BGP router is advertised to all cluster clients and non-client peers. Information from a non-client peer is advertised to all clients. And information from cluster members is reflected to all routing peers, both inside and outside of the cluster. using this model, the local AS can be divided into many clusters.
- ◆ Use the [bgp cluster-id](#) command to designate route reflectors within the same cluster so that route reflectors can recognize updates from other route reflectors in the same cluster.

### Example

```
Console(config-router)#bgp client-to-client reflection
Console(config-router)#
```

### Related Commands

[neighbor route-reflector-client \(1141\)](#)  
[bgp cluster-id \(1109\)](#)

**bgp cluster-id** This command configures the cluster identifier for multiple route reflectors in the same cluster. Use the **no** form to remove the cluster identifier.

### Syntax

**bgp cluster-id** *cluster-identifier*

**no bgp cluster-id**

*cluster-identifier* – The cluster identifier of this router when acting as a route reflector. This identifier can be expressed in the form an IPv4 address or an integer in the range of 1-4294967295.

### Command Mode

Router Configuration

### Default Setting

The router identifier of a lone route reflector in a cluster.

### Command Usage

- ◆ A cluster of clients will usually have a single route reflector (RR). In that case, the cluster can be identified by the BGP Identifier of the RR. However, this represents a single point of failure. This command is used to designate multiple route reflectors used within the same cluster so that they can recognize updates from other peer route reflectors and discard them to prevent loopbacks.
- ◆ All the route reflectors in the same cluster should be fully meshed and all of them configured with identical sets of client and non-client peers.
- ◆ A route reflector uses the non-transitive cluster-list attribute to avoid routing loops. A cluster-list is a sequence of cluster IDs the route has passed through. When a RR reflects a route from its clients to non-client peers, and vice versa, it appends this ID to the cluster list. Using this attribute, an RR can determine if routing information has looped back to the same cluster due to mis-configuration. If the local cluster ID is found in the cluster list, the advertisement is ignored.

### Example

```
Console(config-router)#bgp cluster-id 192.168.0.0  
Console(config-router)#
```

### Related Commands

[bgp client-to-client reflection \(1108\)](#)

**bgp confederation identifier** This command configures the identifier for a confederation containing smaller multiple internal autonomous systems, and declares this router as a member of the confederation. Use the **no** form to remove the confederation identifier.

### Syntax

**bgp confederation identifier** *as-number*

**no bgp confederation identifier**

*as-number* – Autonomous system number which identifies this router as a member of the specified domain, and tags routing messages passed to other BGP routers with this number. (Range: 1-4294967295)

### Command Mode

Router Configuration

### Default Setting

No confederation identifier is configured.

### Command Usage

- ◆ BGP confederations are used to reduce the requirement for fully meshed connections between iBGP peers in the same AS. It works by dividing up a large

AS into several smaller ASes, where only the peers in the same smaller AS are fully meshed, thus reducing the number of required connections and routing traffic.

- ◆ Even though different local confederation peers may have external BGP (eBGP) sessions, they exchange routing information among themselves as if they were iBGP peers. Next hop, Multi Exit Discriminator (MED), and local preference information is preserved. By preserving this information, a single Interior Gateway Protocol (IGP) can be used among the local confederations. When viewed from the outside by external peers, the larger AS is still identified as a single entity or autonomous system.
- ◆ Use the [bgp confederation peers](#) command to specify the autonomous systems within a confederation.

### Example

```
Console(config-router)#bgp confederation identifier 600  
Console(config-router)#
```

### Related Commands

[bgp confederation peers \(1111\)](#)

**bgp confederation peers** This command adds an internal peer autonomous system to a confederation. Use the **no** form to remove an autonomous system from a confederation.

### Syntax

**bgp confederation peers** *as-number*

**no bgp confederation peers** *as-number*

*as-number* – Autonomous system number which identifies this router as a member of the specified domain, and tags routing messages passed to other BGP routers with this number. (Range: 1-4294967295)

### Command Mode

Router Configuration

### Default Setting

No confederation peer is configured.

### Command Usage

- ◆ This command is used to add multiple ASes to a confederation. Each AS is fully meshed within itself, and the AS members are visible internally within the confederation.
- ◆ Use the [bgp confederation identifier](#) command to create a confederation.

### Example

This example divides AS 600 into four smaller ASes 101-104, and assigns a neighboring router as a member of the sub-AS 101.

```
Console(config-router)#bgp confederation identifier 600
Console(config-router)#bgp confederation peer 101
Console(config-router)#bgp confederation peer 102
Console(config-router)#bgp confederation peer 103
Console(config-router)#bgp confederation peer 104
Console(config-router)#neighbor 192.168.0.9 remote-as 101
Console(config-router)#
```

### Related Commands

[bgp confederation identifier \(1110\)](#)

**bgp dampening** This command configures route dampening to reduce the propagation of unstable routes. Use the **no** form to restore the default settings.

### Syntax

**bgp dampening** [*half-life* [*reuse-limit* [*suppress-limit max-suppress-time*]]]

#### **no dampening**

*half-life* – The time after which a penalty is reduced. The penalty value is reduced to half of the previous value after the half-life time expires.  
(Range: 1-45 minutes)

*reuse-limit* – The point at which the penalty for a flapping route must fall before a route is unsuppressed. (Range: 1-2000)

*suppress-limit* – The point at which to start suppressing a route.  
(Range: 1-2000)

*max-suppress-time* – The maximum time a route can be suppressed.  
(Range: 1-255 minutes)

### Command Mode

Router Configuration

### Default Setting

half-life: 15 minutes

reuse-limit: 750

suppress-limit: 2000

max-suppress-time: 60 minutes (4 x half-life)

### Command Usage

- ◆ Route dampening is used to reduce the frequency of routing updates due to unstable routes. Dampened routes are not used in the BGP decision process nor installed in the routing table.

- ◆ Each time a route flaps, the router assigns the route a penalty of 1000. If BGP receives an attribute change, BGP increases the penalty by 500. Penalties are cumulative, and the penalty for the route is stored in the BGP routing table until it exceeds the suppress limit. At that point, the route state changes to damped.
- ◆ Note that route dampening only applies to external BGP routes.

### Example

```
Console(config-router)#bgp dampening 20 1200 20000 220  
Console(config-router)#
```

**bgp default local-preference** This command sets the default local preference used for best path selection among local iBGP peers. Use the **no** form to restore the default setting.

### Syntax

**bgp default local-preference** *preference*

*preference* – Degree of preference iBGP peers give local routes during BGP best path selection. The higher the value, the more the route is to be preferred. (Range: 0-4294967295)

### Command Mode

Router Configuration

### Default Setting

100

### Command Usage

Local preference is a discretionary attribute applied to a route during the BGP best path selection process. It is exchanged only between iBGP peers, and used to determine local policy.

### Example

```
Console(config-router)#bgp default local-preference 100  
Console(config-router)#
```

**bgp deterministic-med** This command enforces deterministic comparison of the MED attribute between all paths received from the same AS, ensuring that selection of the best path will always be the same, regardless of the order in which the paths are received by the local router. Use the **no** form to disable this feature.

### Syntax

**[no] bgp deterministic-med**

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ The MED is compared after BGP attributes weight, local preference, AS-path and origin have been compared and are equal. When deterministic comparison of the MED is enabled, all paths for the same route prefix (received from peers within the same AS) are grouped together and arranged according to their MED value. Based on this comparison, the best path is then chosen.
- ◆ The router immediately groups and sorts all local paths when this command is entered. For correct results, deterministic comparison of the MED must be configured in the same manner (enabled or disabled) on all routers in the local AS.
- ◆ If deterministic comparison of the MED is not enabled, route selection can be affected by the order in which routes are received.
- ◆ This command compares the MED when choosing routes advertised by different peers in the same AS. To compare the MED when choosing routes from neighbors in different ASs, use the [bgp always-compare-med](#) command.

### Example

```
Console(config-router)#bgp deterministic-med  
Console(config-router)#
```

**bgp fast-external-failover** This command resets sessions for any directly connected external peers if the link goes down. Use the **no** form to disable this feature.

### Syntax

**[no] bgp fast-external-failover**

### Command Mode

Router Configuration

### Default Setting

Enabled

### Command Usage

- ◆ This command immediately resets the connection for directly adjacent external peers if the interface goes down for any reason other than TCP timeout.
- ◆ If fast external failover is disabled, the routing process waits until the default hold timer expires to reset the session.

### Example

```
Console(config-router)#bgp fast-external-failover  
Console(config-router)#
```

**bgp log-neighbor-changes** This command enables logging of neighbor resets (that is, up or down status changes). Use the **no** form to disable this feature.

### Syntax

**[no] bgp log-neighbor-changes**

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ This command helps detect network problems by indicating if a neighbor connection is flapping. A high number of neighbor resets might indicate unacceptable error rates or high packet loss in the network.
- ◆ Log messages for neighbor resets are recorded as level 6 messages in the system log file which can be viewed using the [show log ram](#) command.

### Example

```
Console(config-router)#bgp log-neighbor-changes  
Console(config-router)#
```

**bgp network import-check** This command checks for the existence of the next-hop and its accessibility to an Interior Gateway Protocol. Use the no form to disable this feature.

#### Syntax

**[no] bgp network import-check**

#### Command Mode

Router Configuration

#### Default Setting

Disabled

#### Command Usage

By default, BGP will advertise a route regardless of the Interior Gateway Protocol (IGP) in use. This command forces the router to verify the existence of the next hop for an advertised route, and to ensure that the route is accessible to an IGP.

#### Example

```
Console(config-router)#bgp network import-check
Console(config-router)#
```

**bgp router-id** This command sets the router ID for this device. Use the no form to remove this ID.

#### Syntax

**bgp router-id** *router-id*

**no bgp router-id**

*router-id* – Router ID formatted as an IPv4 address.

#### Command Mode

Router Configuration

#### Default Setting

The highest IP address configured for an interface.

#### Command Usage

- ◆ By default, the router ID is automatically set to the highest IP address configured for a Layer 3 interface. This command can be used manually set the router ID to a fixed value.
- ◆ The router ID must be unique for every router in the autonomous system. Using the default setting based on the highest interface address ensures that each router ID is unique.
- ◆ All neighbor sessions will be reset if the router ID is changed.

### Example

```
Console(config-router)#bgp router-id 192.168.0.254  
Console(config-router)#
```

**bgp conditional-advertisement timer** This command sets the interval at which to validate next hop information for BGP routes. Use the **no** form to restore the default setting.

### Syntax

**bgp conditional-advertisement timer** *time*

**no bgp conditional-advertisement timer**

*time* – Next hop validation interval. (Range: 5-240 seconds)

### Command Mode

Router Configuration

### Default Setting

60 seconds

### Command Usage

This command sets the interval at which to check the validity of the next hop for all routes in the routing information database. During the interval between scan cycles, IGP instability or other network problems may cause black holes or routing loops to form.

### Example

```
Console(config-router)#bgp conditional-advertisement timer 30  
Console(config-router)#
```

**clear ip bgp** This command clears connections using hard or soft re-configuration.

### Syntax

**clear ip bgp** [\* | *as-number* | **external** | **peer-group** *group-name* | *neighbor-address*] [**in** [**prefix-list**] | **out** | **soft** [**in** | **out**]]

\* – All BGP peering sessions.

*as-number* – All peering sessions within this autonomous system number. (Range: 1-4294967295)

**external** – All eBGP peering sessions.

**peer-group** *group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*neighbor-address* – IPv4 address of a neighbor.

**in** – Inbound sessions.

**prefix-list** – The outbound route filter (ORF) prefix list. This option triggers a new route refresh or soft re-configuration, which updates the ORF prefix list. This option is ignored unless ORF capabilities have been enabled using the [neighbor capability orf prefix-list](#) command or ORF capability information has been received from a sending peer. If ignored, a normal inbound soft reset is performed.

**out** – Outbound sessions.

**soft** – Uses soft re-configuration for the reset, which does not tear down the session.

### Command Mode

Privileged Exec

### Default Setting

None

### Command Usage

- ◆ Use this command to initiate a hard reset or soft re-configuration. A hard reset clears and rebuilds specified peering sessions and routing tables. Soft re-configuration uses stored information to reconfigure and activate routing tables without clearing existing sessions. It uses stored update information to allow you to apply a new BGP policy without disrupting the network.
- ◆ To generate new inbound updates from stored information without resetting peer sessions, you must preconfigure the local router using the [neighbor capability orf prefix-list](#) command, which causes the router to store all received updates. Note that storing updates is memory intensive and should only be applied to critical links.

Outbound soft configuration requires no memory or preconfiguration.

Outbound re-configuration can be used on the other side of a peering session to make initiate a new inbound policy on the local side.

- ◆ Use this command to clear peering sessions when changes are made to any BGP access lists, weights, or route-maps.
- ◆ Route refresh (RFC 2918) allows a router to reset inbound routing tables dynamically by exchanging route refresh requests with peers. Route refresh relies on the dynamic exchange of information with supporting peers. It is advertised through BGP capability negotiation, and all BGP routers must support this capability.

### Example

This example assumes that soft re-configuration has been set on the neighboring router.

```
Console(config-router)#clear ip bgp 192.168.0.254 soft in
Console(config-router)#
```

**clear ip bgp ipv4** This command clears BGP connections for IPv4 using hard or soft re-configuration.

### Syntax

**clear ip bgp ipv4** [\* | *as-number* | **external** | **peer-group** *group-name* | *neighbor-address*] [**in** [**prefix-list**] | **out** | **soft** [**in** | **out**]]

\* – All BGP IPv4 peering sessions.

*as-number* – All peering sessions within this autonomous system number.  
(Range: 1-4294967295)

**external** – All eBGP peering sessions.

**peer-group** *group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*neighbor-address* – IPv4 address of a neighbor.

**in** – Inbound sessions.

**prefix-list** – The outbound route filter (ORF) prefix list. This option triggers a new route refresh or soft re-configuration, which updates the ORF prefix list. This option is ignored unless ORF capabilities have been enabled using the [neighbor capability orf prefix-list](#) command or ORF capability information has been received from a sending peer. If ignored, a normal inbound soft reset is performed.

**out** – Outbound sessions.

**soft** – Uses soft re-configuration for the reset, which does not tear down the session.

### Command Mode

Privileged Exec

### Default Setting

None

### Command Usage

- ◆ Use this command to initiate a hard reset or soft re-configuration. A hard reset clears and rebuilds specified peering sessions and routing tables. Soft re-configuration uses stored information to reconfigure and activate routing tables without clearing existing sessions. It uses stored update information to allow you to apply a new BGP policy without disrupting the network.
- ◆ To generate new inbound updates from stored information without resetting peer sessions, you must preconfigure the local router using the [neighbor capability orf prefix-list](#) command, which causes the router to store all received

updates. Note that storing updates in memory is intensive and should only be applied to critical links.

Outbound soft configuration requires no memory or preconfiguration. Outbound re-configuration can be used on the other side of a peering session to make initiate a new inbound policy on the local side.

- ◆ Use this command to clear peering sessions when changes are made to any BGP access lists, weights, or route-maps.
- ◆ Route refresh (RFC 2918) allows a router to reset inbound routing tables dynamically by exchanging route refresh requests with peers. Route refresh relies on the dynamic exchange of information with supporting peers. It is advertised through BGP capability negotiation, and all BGP routers must support this capability.

### Example

This example assumes that soft re-configuration has been set on the neighboring router.

```
Console(config-router)#clear ip bgp ipv4 192.168.0.254 soft in
Console(config-router)#
```

**clear ip bgp dampening** This command clears route dampening information and unsuppresses any currently suppressed routes.

### Syntax

**clear ip bgp dampening** [*ip-address* [*netmask*]]

*ip-address* – IP address of network or peer router.

*netmask* – Network mask that identifies the network address bits.

### Command Mode

Privileged Exec

### Default Setting

None

### Example

If no keywords are entered as in this example, route dampening information is cleared for the entire routing table.

```
Console(config-router)#clear ip bgp dampening
Console(config-router)#
```

**distance** This command sets the administrative distance for a specified external BGP (eBGP) routes. Use the **no** form to restore the default setting.

### Syntax

**distance** *distance ip-address netmask [access-list-name]*

**no distance** *ip-address netmask*

*distance* – Administrative distance for an eBGP route. (Range: 1-255)

*ip-address* – IP address of a route entry.

*netmask* – Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

*access-list-name* – Name of standard or extended access list.  
(Maximum length: 16 characters, no spaces or other special characters)

### Command Mode

Router Configuration

### Default Setting

None

### Command Usage

- ◆ The route distance indicates the trustworthiness of a router. The higher the distance the lower the trust rating. A distance of 255 means that the routing source cannot be trusted and should be ignored.
- ◆ This distance set by this command only applies to external BGP paths routes learned from a neighbor outside of the AS. Use the [distance bgp](#) command to configure the global setting for the distance of eBGP, iBGP, and local routes.
- ◆ If an access-list is specified, it will be applied to received routes. If the received routes are not matched in the access-list or the specified list does not exist, the original distance value will be used.

### Example

```
Console(config-router)#distance 90 10.1.1.64 255.255.255.255  
Console(config-router)#
```

### Related Commands

[distance bgp \(1121\)](#)

**distance bgp** This command sets the administrative distance for external BGP, internal BGP, and local routes. Use the **no** form to restore the default settings.

### Syntax

**distance bgp** *ebgp-distance ibgp-distance local-distance*

**no distance bgp**

*ebgp-distance* – Administrative distance for eBGP routes. (Range: 1-255)

*ibgp-distance* – Administrative distance for iBGP routes. (Range: 1-255)

*local-distance* – Administrative distance for local routes. (Range: 1-255)

### Command Mode

Router Configuration

### Default Setting

eBGP: 20

iBGP: 200

local: 200

### Command Usage

- ◆ External routes are learned from an external autonomous system, and internal routes from a peer within the local autonomous system. Local routes are those configured with the [network](#) command as a back door for the router or for the networks being redistributed from another routing process.
- ◆ The route distance indicates the trustworthiness of a router. The higher the distance the lower the trust rating. A distance of 255 means that the routing source cannot be trusted and should be ignored.
- ◆ This command can be used to indicate that another protocol can provide a better route to a node than that learned via eBGP, or to indicate that some internal routes should be preferred by BGP.
- ◆ Changing the administrative distance of iBGP routes is not recommended. It may cause an accumulation of routing table inconsistencies which can break routing to many parts of the network.

### Example

```
Console(config-router)#distance bgp 20 200 20  
Console(config-router)#
```

### Related Commands

[distance \(1121\)](#)

**neighbor activate** This command enables the exchange of routing information with a neighboring router or peer group. Use the **no** form to disable the exchange of routing information.

### Syntax

**[no] neighbor {ip-address | group-name} activate**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the **neighbor peer-group** command.

### Command Mode

Router Configuration

### Default Setting

Enabled

### Command Usage

- ◆ After a connection is opened with a neighboring router, this command is used to enable the exchange of information with the neighbor.
- ◆ The exchange of information is enabled by default for each routing session configured with the **neighbor remote-as** command.

### Example

```
Console(config-router)#neighbor 10.1.1.64 activate  
Console(config-router)#
```

**neighbor advertisement-interval** This command configures the interval between sending update messages to a neighbor. Use the **no** form to restore the default setting.

### Syntax

**neighbor ip-address advertisement-interval interval**

**no neighbor ip-address advertisement-interval**

*ip-address* – IP address of a neighbor.

*interval* – The minimum interval between sending routing updates to the specified neighbor. (Range: 0-600 seconds)

### Command Mode

Router Configuration

### Default Setting

iBGP: 5 seconds

eBGP: 30 seconds

### Command Usage

This command can be used to reduce route flapping. However, the [bgp dampening](#) command can provide more precise control of route flapping.

### Example

```
Console(config-router)#neighbor 10.1.1.64 advertisement-interval 20  
Console(config-router)#
```

**neighbor allowas-in** This command configures the number of times the AS path for a received route can contain the same AS number. Use the **no** form to restore the default setting.

### Syntax

**neighbor** {*ip-address* | *group-name*} **allowas-in** [*count*]

**no neighbor** {*ip-address* | *group-name*} **allowas-in**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*count* – Maximum number of times the same AS number can appear in the AS path of a received route. (Range: 1-10, or 3 if the count is not undefined)

### Command Mode

Router Configuration

### Default Setting

No repeats allowed

### Command Usage

Under standard routing practices, BGP will not accept a route sent from a neighbor if the same AS number appears in the AS path more than once. This could indicate a routing loop, and the route message would therefore be dropped. However, for purposes of traffic engineering (such as degrading the preference for a certain path), this command can be used to configure the number of times the same AS is allowed re-appear in the AS path of a route received from a neighbor.

### Example

```
Console(config-router)#neighbor 10.1.1.64 allowas-in 5  
Console(config-router)#
```

**neighbor attribute-unchanged** This command configures certain route attributes to be kept unchanged for transparent transmission to the specified neighbor. Use the **no** form to disable this feature.

### Syntax

```
[no] neighbor {ip-address | group-name} attribute-unchanged [as-path] [med] [next-hop]
```

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

**as-path** – AS path attribute

**med** – Multi-Exit Discriminator (MED) attribute

**next-hop** – Next hop attribute

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

If this command is entered without specifying any route attributes, then all three optional attributes are used.

### Example

```
Console(config-router)#neighbor 10.1.1.64 attribute-unchanged  
Console(config-router)#
```

**neighbor capability dynamic** This command configures dynamic negotiation of capabilities between neighboring routers. Use the **no** form to disable this feature.

### Syntax

```
[no] neighbor {ip-address | group-name} capability dynamic
```

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ BGP normally requires a router to terminate a peering session if it receives an OPEN message with an unrecognized optional parameter. This command allows new capabilities to be introduced gracefully, without requiring a peering session to be terminated if a negotiated capability is unknown.
- ◆ With dynamic negotiation of capabilities is enabled, the capabilities by both sides are negotiated in OPEN messages, with the partner responding if a capability is supported or sending a NOTIFICATION if not.

### Example

```
Console(config-router)#neighbor 10.1.1.64 capability dynamic
Console(config-router)#
```

**neighbor capability orf prefix-list** This command configures the negotiation of outbound route filter (ORF) capabilities with a neighboring router. Use the **no** form to disable negotiation.

### Syntax

**[no] neighbor {ip-address | group-name} orf prefix-list {both | receive | send}**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

**both** – Capability to send and receive the ORF to/from this neighbor.

**receive** – Capability to receive the ORF from this neighbor.

**send** – Capability to send the ORF to this neighbor.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

When this command is entered, the side configured with inbound prefix-list filter rules will transmit its own rules to the peer, and the peer will then use these rules as its own outbound rules, thereby avoiding sending routes which will be denied by its partner.

### Example

```
Console(config-router)#neighbor 10.1.1.64 orf prefix-list both
Console(config-router)#
```

**neighbor default-originate** This command allows the local router to send a default route to a neighbor. Use the **no** form to disable this feature.

### Syntax

**neighbor** {*ip-address* | *group-name*} **default-originate** [**route-map** *map-name*]

**no neighbor** {*ip-address* | *group-name*} **default-originate**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*map-name* – Name of the route map. The route map can be used to filter the criteria used for sending the default route to a neighbor. (Range: 1-80 characters)

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ This command is used to advertise the local router's default route (0.0.0.0) to a neighbor. This route can be used by the neighbor to reach the local router if no other routes are available.
- ◆ If several neighbors supply a default route to the same partner, the best one will be elected according to the standard path selection process.
- ◆ If a route map is specified, the default route 0.0.0.0 is advertised if the route map contains a [match ip address](#) clause and there is a route that matches an entry in the [ip prefix-list](#).

### Example

```
Console(config-router)#neighbor 10.1.1.64 default-originate
Console(config-router)#
```

**neighbor description** This command configures the description of a neighbor or peer group. Use the **no** form to remove a description.

#### Syntax

**neighbor** {*ip-address* | *group-name*} **description** *description*

**no neighbor** {*ip-address* | *group-name*} **description**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*description* – Descriptive string. (Range: 1-80 characters)

#### Command Mode

Router Configuration

#### Default Setting

No description specified

#### Example

```
Console(config-router)#neighbor 10.1.1.64 description bill's router
Console(config-router)#
```

**neighbor distribute-list** This command filters route updates to/from a neighbor or peer group. Use the **no** form to remove this list.

#### Syntax

**neighbor** {*ip-address* | *group-name*} **distribute-list** *access-list-name* {**in** | **out**}

**no neighbor** {*ip-address* | *group-name*} **distribute-list** {**in** | **out**}

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*access-list-name* – Name of standard or extended access list.  
(Maximum length: 32 characters, no spaces or other special characters)

**in** – Filters inbound routing messages.

**out** – Filters outbound routing messages.

#### Command Mode

Router Configuration

#### Default Setting

None

### Command Usage

- ◆ If the specified access list for input or output mode does not exist, all input or output route updates will be filtered.
- ◆ The [neighbor prefix-list](#) and the [neighbor distribute-list](#) commands are mutually exclusive for a BGP peer. That is, only one of these commands may be applied in the inbound or outbound direction.

### Example

```
Console(config-router)#neighbor 10.1.1.64 distribute-list RD in
Console(config-router)#
```

**neighbor dont-capability-negotiate** This command disables capability negotiation when creating connections. Use the **no** form to restore the default setting.

### Syntax

**[no] neighbor {ip-address | group-name} dont-capability-negotiate**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Capability negotiation is enabled

### Command Usage

Earlier versions of BGPv4 require that when a BGP speaker receives an Open message with one or more unrecognized Optional Parameters, the speaker must terminate BGP peering. This command can be used when connecting to a partner known to use an older BGP version which does not support capabilities negotiation (RFC 2842), thereby allowing the peering session to continue.

### Example

```
Console(config-router)#neighbor 10.1.1.64 dont-capability-negotiate
Console(config-router)#
```

**neighbor ebgp-multihop** This command allows eBGP neighbors to exist in different segments, and configures the maximum hop count (TTL). Use the **no** form to restore the default setting.

#### Syntax

**neighbor** {*ip-address* | *group-name*} **ebgp-multihop** [*count*]

**no neighbor** {*ip-address* | *group-name*} **ebgp-multihop**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the **neighbor peer-group** command.

*count* – Maximum hop count. (Range: 1-255)

#### Command Mode

Router Configuration

#### Default Setting

eBGP neighbors must be located in the same segment.

#### Command Usage

- ◆ This command can be used to allow routers in different network segments to create a BGP neighbor relationship.
- ◆ If this command is entered without specifying a count, the hop limit is set at 255.
- ◆ To avoid creating loops through oscillating routes, a multi-hop session will not be established if the only route to a multi-hop peer is the default route.

#### Example

```
Console(config-router)#neighbor 10.1.1.64 ebgp-multihop 2
Console(config-router)#
```

**neighbor enforce-first-as** This command denies an update received from an external peer that does not list its own autonomous system number at the beginning of the AS path attribute. Use the **no** form to disable this feature.

#### Syntax

**[no] neighbor enforce-first-as**

#### Command Mode

Router Configuration

#### Default Setting

Disabled

### Command Usage

This command can be used to prevent a peer from misdirecting traffic by advertising a route as if sourced from another autonomous system.

### Example

```
Console(config-router)#neighbor enforce-first-as  
Console(config-router)#
```

**neighbor enforce-multihop** This command enforces the requirement for all neighbors to form multi-hop connections. Use the **no** form to disable this requirement.

### Syntax

**[no] neighbor** {*ip-address* | *group-name*} **enforce-multihop**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Not enforced

### Command Usage

By default, the multi-hop check is only performed on iBGP and eBGP non-direct routes. This command can be used to force the router to perform the multi-hop check on directly connected routes as well. In other words, the router will not perform the next-hop direct-connect check the specified neighbor.

### Example

```
Console(config-router)#neighbor 10.1.1.64 enforce-multihop  
Console(config-router)#
```

**neighbor filter-list** This command filters route updates sent to or received from a neighbor based on an AS path access-list. Use the **no** form to disable route filtering.

### Syntax

**neighbor** {*ip-address* | *group-name*} **filter-list** *access-list* {**in** | **out**}

**no neighbor** {*ip-address* | *group-name*} **filter-list** {**in** | **out**}

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*access-list* – Name of an AS-Path access list configured with the `bgp as-path access-list` command.

**in** – Filter inbound routing updates.

**out** – Filter outbound routing updates.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

Use this command in conjunction with the `bgp as-path access-list` command to filter route updates sent to or received from a neighbor.

### Example

In this example, the AS path access list “ASPF” is first configured to deny access to any route passing through AS 100. It then enables route filtering by assigning this list to a peer.

```
Console(config)#ip as-path access-list ASPF deny 100
Console(config)#router bgp 100
Console(config-router)#redistribute static
Console(config-router)#neighbor 10.1.1.66 filter-list ASPF out
Console(config-router)#
```

**neighbor interface** This command specifies the interface to a neighbor. Use the **no** form to remove this configuration setting.

### Syntax

**neighbor *ip-address* interface vlan *vlan-id***

**no neighbor *ip-address* interface**

*ip-address* – IP address of a neighbor.

*vlan-id* - VLAN ID. (Range: 1-4094)

### Command Mode

Router Configuration

### Default Setting

None

### Example

```
Console(config-router)#neighbor 10.1.1.64 interface vlan 1
Console(config-router)#
```

**neighbor maximum-prefix** This command sets the maximum number or route prefixes that can be received from a neighbor. Use the **no** form to restore the default setting.

### Syntax

**neighbor** {*ip-address* | *group-name*} **maximum-prefix** *max-count* [*threshold* [**restart** *interval* | **warning-only**]]

**no neighbor** {*ip-address* | *group-name*} **maximum-prefix**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*max-count* – The maximum number of route prefixes that will be accepted from a neighbor. (Range: 1-4294967295)

*threshold* – The percentage of the maximum number of allowed prefixes at which the router will initiate the specified response. (Range: 1-100)

**restart** – Restarts BGP connection after the threshold is exceeded.

*interval* – Time to wait after a BGP connection has been terminated, before reestablishing the session. (Range: 1-65535 minutes)

**warning-only** – Sends a log message if the threshold is exceeded.

### Command Mode

Router Configuration

### Default Setting

No limit is set

### Command Usage

- ◆ This command is used to control the maximum number of route prefixes that can be sent by a neighbor. It provides a method to reserve resources for other processes, or to prevent malicious attacks.
- ◆ If the threshold is specified, but neither the **restart** nor **warning-only** keywords are used), the connection will be closed until the records are cleared with the [clear ip bgp](#) command.

### Example

In this example, the router warns when the number of route prefixes reaches 6, and the connection will be closed when the prefixes hit 13.

```
Console(config-router)#neighbor 10.1.1.64 maximum-prefix 12 50
Console(config-router)#
```

**neighbor next-hop-self** This command configures the local router as the next hop for a neighbor in all routing messages it sends. Use the **no** form to disable this feature.

### Syntax

**[no] neighbor** {*ip-address* | *group-name*} **next-hop-self**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ iBGP routers only connected to other iBGP routers in same segment will not be able to talk with iBGP routers outside of the segment if they are not directly connected with each other. This command can be used in these kinds of networks (i.e., un-meshed or non-broadcast) where iBGP neighbors may not have direct access to all other neighbors on the same IP subnet.
- ◆ Even when a successful BGP relationship seems to have been established within the local AS, you may not be able to see some routes in the routing table. iBGP routers only connected with other iBGP routers in same AS will not be able to talk with routers outside of the AS if they are not directly connected with each other. The **neighbor next-hop-self** command can be used to configure an iBGP router which is directly connected with an eBGP neighbor so that other iBGP routers in the same AS can talk with eBGP routers outside the AS.

### Example

```
Console(config-router)#neighbor 10.1.1.64 next-hop-self
Console(config-router)#
```

**neighbor override-capability** This command overrides the result of capability negotiations, allowing a session to be formed with a peer that does not support capability negotiation. Use the **no** form to disable this feature.

### Syntax

**[no] neighbor** {*ip-address* | *group-name*} **neighbor override-capability**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Example

```
Console(config-router)#neighbor 10.1.1.64 override-capability  
Console(config-router)#
```

**neighbor passive** This command passively forms a connection with the specified neighbor, not sending a TCP connection request, but waiting a connection request from the specified neighbor. Use the **no** form to disable this feature.

### Syntax

**[no] neighbor {ip-address | group-name} passive**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

This command configures the local router so that it remains in Active state, waiting for an inbound connection request from a neighbor, and not initiating any outbound connections with the neighbor via an Open message.

### Example

```
Console(config-router)#neighbor 10.1.1.64 passive  
Console(config-router)#
```

**neighbor password** This command enables message-digest (MD5) authentication for the specified neighbor and assigns a password (key) to be used. Use the **no** form to remove an existing key.

### Syntax

**neighbor** {*ip-address* | *group-name*} **password** *password*

**no neighbor** {*ip-address* | *group-name*} **password**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*password* - Alphanumeric password used to generate a 128 bit message digest or “fingerprint.” (Range: 1-16 characters)

### Command Mode

Router Configuration

### Default Setting

No authentication

### Command Usage

- ◆ When MD5 authentication is configured on a TCP connection between two peers, neighbor authentication occurs whenever routing updates are exchanged. Authentication must be configured with the same password on both peers; otherwise, the connection between them will not be made.
- ◆ If you configure or change the password used for MD5 authentication between two peers, the local router will not tear down the existing session after you configure the password. It will attempt to maintain the peering session using the new password until the BGP hold timer expires. If the password is not entered or changed on the remote router before the hold timer expires, the session will time out.

### Example

```
Console(config-router)#neighbor 10.1.1.64 password frost
Console(config-router)#
```

**neighbor peer-group (Creating)** This command configures a router peer group which can be easily configured with the same attributes. Use the **no** form to remove a peer group.

### Syntax

[**no**] **neighbor** *group-name* **peer-group**

*group-name* – A BGP peer group. (Range: 1-256 characters)

### Command Mode

Router Configuration

### Default Setting

No peer groups are defined.

### Command Usage

- ◆ Neighbors with the same BGP attributes can be grouped into peer groups. This simplifies the application of various policies, such as filter lists. Other configuration settings can be applied to a peer-group using any of the neighbor commands. Any changes made to the peer group affect all members. Use this command to create a peer-group.
- ◆ To assign members to a peer group, use the `neighbor ip-address peer-group group-name` command.

### Example

```
Console(config-router)#neighbor RD peer-group  
Console(config-router)#
```

**neighbor peer-group** (Group Members) This command assigns routers to a peer group. Use the **no** form to remove a group member.

### Syntax

**[no] neighbor ip-address peer-group group-name**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group.

### Command Mode

Router Configuration

### Default Setting

No group members are defined.

### Command Usage

To create a peer group, use the `neighbor group-name peer-group` command.

### Example

```
Console(config-router)#neighbor 10.1.1.64 peer-group RD  
Console(config-router)#
```

**neighbor port** This command specifies the TCP port number of the partner through which communications are carried. Use the **no** form to restore the default setting.

#### Syntax

**neighbor** *ip-address* **port** *port-number*

**no neighbor** *ip-address* **port**

*ip-address* – IP address of a neighbor.

*port-number* – TCP port number to use for BGP communications.  
(Range: 0-65535)

#### Command Mode

Router Configuration

#### Default Setting

179

#### Example

```
Console(config-router)#neighbor 10.1.1.64 port 1023
Console(config-router)#
```

**neighbor prefix-list** This command configures prefix restrictions applied in inbound/outbound route updates to/from specified neighbors. Use the **no** form to remove the neighbor binding for a prefix list.

#### Syntax

**neighbor** {*ip-address* | *group-name*} **prefix-list** *list-name* {**in** | **out**}

**no neighbor** {*ip-address* | *group-name*} **prefix-list** {**in** | **out**}

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*list-name* – Name of a prefix-list. The prefix list can be used to filter the networks to import or export. (Range: 1-80 characters)

**in** – Filter inbound routing updates.

**out** – Filter outbound routing updates.

#### Command Mode

Router Configuration

#### Default Setting

No prefix list restrictions are configured.

### Command Usage

- ◆ First, configure a prefix list with the `ip prefix-list` command, and then use this command to specify the neighbors to which it applies, and whether it applies to inbound or outbound messages.
- ◆ Filtering routes based on a prefix list searches for entries matching the router specified by this command. If a match is found and the entry is configured to permit the route, the route will be imported or exported as defined by this command. An empty prefix list permits all prefixes. If a prefix does not match any entries in a list, the route is denied. When multiple entries in the list match a prefix, the entry with the smallest sequence number is used.
- ◆ The search starts at the top of the prefix list. Once an entry matches, the router stops searching. To reduce the load on system resources, the most commonly used entries should be placed at the top of the list.

### Example

```
Console(config)#ip prefix-list RD permit 100.1.0.0 255.255.0.0 ge 17 le 18
Console(config)#router bgp 200
Console(config-router)#redistribute static
Console(config-router)#neighbor 10.1.1.66 prefix-list RD out
Console(config-router)#
```

**neighbor remote-as** This command configures a neighbor and its AS number, identifying the neighbor as an iBGP or eBGP peer. Use the **no** form to remove a neighbor.

### Syntax

**neighbor** {*ip-address* | *group-name*} **remote-as** *as-number*

**no neighbor** {*ip-address* | *group-name*} **remote-as**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the `neighbor peer-group` command.

*as-number* – Autonomous system number which identifies this router as a member of the specified domain, and tags routing messages passed to other BGP routers with this number. (Range: 1-4294967295)

### Command Mode

Router Configuration

### Default Setting

No neighbors are configured.

### Command Usage

- ◆ BGP neighbors must be manually configured. A neighbor relationship can only be established if partners are configured on both sides a connection.

- ◆ If the neighbor's AS number is the same as that of the local router, the neighbor is an iBGP peer. If it is different, the neighbor is an eBGP peer.

### Example

```
Console(config-router)#neighbor 10.1.1.64 remote-as 100  
Console(config-router)#
```

**neighbor remove-private-as** This command removes private autonomous system numbers from outbound routing updates to an external neighbor. Use the **no** form to disable this feature.

### Syntax

**neighbor** {*ip-address* | *group-name*} **remove-private-as**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ This command only applies to eBGP neighbors. It is used to avoid passing an internal AS number to an external AS. Internal AS numbers range from 64512-65535, and should not be sent to the Internet since they are not valid external AS numbers.
- ◆ This configuration only takes effect when the AS Path attribute of a route contains only internal AS numbers. If the AS Path attribute for a route contains both internal and external AS numbers, the route will not be processed.
- ◆ This command may be used in BGP confederations provided that the private AS numbers appear after the confederation portion of the AS path.

### Example

```
Console(config-router)#neighbor 10.1.1.64 remove-private-as  
Console(config-router)#
```

**neighbor route-map** This command specifies the route mapping policy for inbound/outbound routing updates for specified neighbors. Use the **no** form to remove this policy binding.

### Syntax

**neighbor** {*ip-address* | *group-name*} **route-map** *map-name* {**in** | **out**}

**no neighbor** {*ip-address* | *group-name*} **route-map** {**in** | **out**}

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*map-name* – Name of the route map. The route map can be used to filter the networks to advertise or receive based on various attributes.  
(Range: 1-128 characters)

**in** – Filter inbound routing updates.

**out** – Filter outbound routing updates.

### Command Mode

Router Configuration

### Default Setting

No route maps are configured nor bound to any neighbor.

### Command Usage

- ◆ First, use [route-map](#) command to create a route map, and the **match** and **set** commands to configure the route attributes to act upon. Then use this command to specify neighbors to which the route map is applied.
- ◆ If the specified route map does not exist, all input/output route updates will be filtered.

### Example

```
Console(config-router)#neighbor 10.1.1.64 route-map RD in
Console(config-router)#
```

**neighbor route-reflector-client** This command configures this router as a route reflector and the specified neighbor as its client. Use the **no** form to disable route reflection for the specified neighbor.

### Syntax

[**no**] **neighbor** {*ip-address* | *group-name*} **route-reflector-client**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ Route reflection from this device is enabled by default, but is only functional if a client has been configured with this command.
- ◆ Under standard configuration rules, all BGP speakers within the same AS must be fully meshed. Route reflection can be used to reduce the number of connections required between peers. Reflector clients exchange messages only with the route reflector, while the reflector handles message exchanges among each client and other iBGP, eBGP, and non-client routers. For more information on configuring route reflection, refer to the Command Usage section under the [bgp client-to-client reflection](#) command.

### Example

```
Console(config-router)#neighbor 10.1.1.64 route-reflector-client
Console(config-router)#
```

**neighbor route-server-client** This command configures this router as a route server and the specified neighbor as its client. Use the **no** form to disable the route server for the specified neighbor.

### Syntax

**[no] neighbor {ip-address | group-name} route-server-client**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

None

### Command Usage

- ◆ A route server is used as a replacement for full mesh eBGP routing in internet exchange points in a manner similar to the way route reflectors are used in iBGP. Instead of maintaining direct eBGP peering sessions with every other service provider, providers can acquire the same routing information through a single connection to a route server at the Internet exchange.

- ◆ Using a route server reduces the configuration complexity required for an eBGP full mesh, limits CPU and memory requirements for the exchange of peering messages, and avoids the need for negotiating a large number of individual peering agreements.

### Example

In the following example, the router 10.1.1.64 (AS100) is configured as the route server for neighbors 10.1.1.66 (AS200) and 10.1.1.68 (AS300).

```
Console(config)#router bgp 100
Console(config-router)#neighbor 10.1.1.66 remote-as 200
Console(config-router)#neighbor 10.1.1.66 route-server-client
Console(config-router)#neighbor 10.1.1.68 remote-as 300
Console(config-router)#neighbor 10.1.1.68 route-server-client
Console(config-router)#
```

**neighbor send-community** This command configures the router to send community attributes to a neighbor in peering messages. Use the **no** form to stop sending this attribute to a neighbor.

### Syntax

```
[no] neighbor {ip-address | group-name} send-community
[both | extended | standard]
```

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

**both** – Sends both extended and standard community attributes.

**extended** – Sends extended community attributes.

**standard** – Standard community attributes.

### Command Mode

Router Configuration

### Default Setting

No community attributes are sent. If community type is not specified, then only standard community attributes are sent.

### Command Usage

Community attributes are used to group destinations into a certain community, and apply routing decisions to the overall community.

### Example

```
Console(config-router)#neighbor 10.1.1.66 send-community extended
Console(config-router)#
```

**Related Commands**  
[set community \(1176\)](#)

**neighbor shutdown** This command closes a neighbor connection without canceling the neighbor configuration. Use the **no** form to restore the connection.

**Syntax**

**[no] neighbor {ip-address | group-name} shutdown**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

**Command Mode**

Router Configuration

**Default Setting**

None

**Command Usage**

- ◆ This command terminates any active sessions for the specified neighbor, and removes any associated routing information.
- ◆ Use the [show ip bgp summary](#) command display the neighbors which have been administratively shut down. Entries with in an Idle (Admin) state have been disabled by the **neighbor shutdown** command.

**Example**

```
Console(config-router)#neighbor 10.1.1.66 shutdown
Console(config-router)#
```

**neighbor soft-reconfiguration inbound** This command configures the switch to store updates in the inbound message buffer, and perform soft re-configuration from this buffer for specified neighbors when required. Use the **no** form to disable this feature.

**Syntax**

**[no] neighbor {ip-address | group-name} soft-reconfiguration inbound**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

**Command Mode**

Router Configuration

### Default Setting

Disabled

### Command Usage

- ◆ Use this command to employ soft reconfiguration for a neighbor. A hard reset clears and rebuilds specified peering sessions and routing tables. Soft reconfiguration uses stored information to reconfigure and activate routing tables without clearing existing sessions. It uses stored update information to allow you to restore a connection or to apply a new BGP policy without disrupting the network. Note that outbound soft reconfiguration does not require inbound soft reconfiguration to be enabled.
- ◆ The command is only available when route refresh capability is not enabled. Route refresh (RFC 2918) allows a router to reset inbound routing tables dynamically by exchanging route refresh requests with peers. Route refresh relies on the dynamic exchange of information with supporting peers. It is advertised through BGP capability negotiation, and all BGP routers must support this capability.
- ◆ To use soft reconfiguration, without preconfiguration, both BGP neighbors must support the soft route refresh capability advertised in open messages sent when a BGP session is established. To see if a BGP router supports this capability, use the [show ip bgp neighbors](#) command.

### Example

```
Console(config-router)#neighbor 11.1.1.120 soft-reconfiguration inbound  
Console(config-router)#
```

**neighbor strict-capability-match** This command forces strict capability matching when establishing connections. Use the **no** form to disable this requirement.

### Syntax

**[no] neighbor {ip-address | group-name} strict-capability-match**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

### Command Mode

Router Configuration

### Default Setting

Disabled

### Command Usage

This command specifies that a connection can only be established when the both sides have perfectly matching capabilities.

### Example

```
Console(config-router)#neighbor 10.1.1.66 strict-capability-match  
Console(config-router)#
```

**neighbor timers** This command sets the Keep Alive time and Hold time used for specified neighbors. Use the **no** form to restore the default settings.

### Syntax

**[no] neighbor** {*ip-address* | *group-name*} **timers** *keepalive-time* *hold-time*

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*keepalive-time* – The frequency at which the local router sends keep-alive messages to its neighbors. (Range: 0-65535 seconds)

*hold-time* – The maximum interval after which a neighbor is declared dead if a keep-alive or update message has not been received. (Range: 0-65535 seconds)

### Command Mode

Router Configuration

### Default Setting

Keep Alive time: 60 seconds

Hold time: 180 seconds

### Command Usage

- ◆ This command sets the Keep Alive time used for maintaining connectivity, and the Hold time to wait for Keep Alive or Update messages before declaring a neighbor down.
- ◆ This command sets timers for monitoring connectivity to specific neighboring routers, which supercede those applied to all neighbors with the global [timers bgp](#) command.

### Example

```
Console(config-router)#neighbor 10.1.1.66 timers 50 200  
Console(config-router)#
```

**neighbor timers connect** This command sets the time to wait before attempting to reconnect to a neighbor whose TCP connection has failed. Use the **no** form to restore the default setting.

### Syntax

**[no] neighbor *ip-address* timers connect *retry-interval***

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*retry-interval* – The amount of time the system waits for the transport protocol connection to complete. If this timer expires, the state remains in Connect state, the timer is reset, and the system tries to initiate a new transport connection. (Range: 0-65535 seconds)

### Command Mode

Router Configuration

### Default Setting

120 seconds

### Command Usage

This command sets the time to wait before attempting to reconnect to a BGP neighbor after having failed to connect. During the idle time specified by the Connect Retry timer, the remote BGP peer can actively establish a BGP session with the local router.

### Example

```
Console(config-router)#neighbor 10.1.1.66 timers connect 100
Console(config-router)#
```

**neighbor unsuppress-map** This command allows routes suppressed by the [aggregate-address](#) (summary-only option) to be advertised to specified neighbors. Use the **no** form to remove this configuration entry.

### Syntax

**[no] neighbor {*ip-address* | *group-name*} unsuppress-map *map-name***

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*map-name* – Name of the route map. The route map can be used to filter the networks to advertise. (Range: 1-80 characters)

### Command Mode

Router Configuration

### Default Setting

No exceptions

### Command Usage

This command is used to leak routes suppressed by the [aggregate-address](#) command (with summary-only option) to specified neighbors. Other routes that meet the route map conditions, but have not been suppressed, will still be sent.

### Example

```
Console(config-router)#neighbor 10.1.1.66 unsuppress-map rmp
Console(config-router)#
```

**neighbor update-source** This command specifies the interface to use for a TCP connection, instead of using the nearest interface. Use the **no** form to use the default interface.

### Syntax

**[no] neighbor** {*ip-address* | *group-name*} **update-source interface** {**vlan** *vlan-id* | **loopback** *loopback-id*}

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*vlan-id* - VLAN ID. (Range: 1-4094)

*loopback-id* - Loopback ID. (Range: 0)

### Command Mode

Router Configuration

### Default Setting

The nearest (best/closest) interface is used.

### Command Usage

By default the nearest interface to the neighbor is used for BGP connections. This command can be used to specify any available interface for a TCP connection.

### Example

```
Console(config-router)#neighbor 10.1.1.66 update-source interface vlan 1
Console(config-router)#
```

**neighbor weight** This command assigns a weight to routes sent from a neighbor. Use the **no** form to restore the default weight.

### Syntax

**neighbor** {*ip-address* | *group-name*} **weight** *weight*

**no neighbor** {*ip-address* | *group-name*} **weight**

*ip-address* – IP address of a neighbor.

*group-name* – A BGP peer group containing a list of neighboring routers configured with the [neighbor peer-group](#) command.

*weight* – The weight to be assigned to routes received from this neighbor. (Range: 0-65535)

### Command Mode

Router Configuration

### Default Setting

Routes learned from a neighbor: 0

Static routes sourced by the local router: 32768

### Command Usage

- ◆ Use this command to specify a weight for all the routes learned from a neighbor. The route with the highest weight gets preference over other routes to the same network.
- ◆ Weights assigned using the [set weight](#) command override those assigned by this command.

### Example

```
Console(config-router)#neighbor 10.1.1.66 weight 500
Console(config-router)#
```

**network** This command specifies a network to advertise. Use the **no** form to stop advertising a network.

### Syntax

**network** *ip-address* [*netmask*] [**route-map** *map-name*] [**backdoor**]

**no network** *ip-address* [*netmask*]

*ip-address* – IP address of a to advertise.

*netmask* – Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

**map-name** – Name of the route map. The route map can be used to filter the networks to advertise. (Range: 1-80 characters)

**backdoor** – Specifies a backdoor route to a BGP border router that provides better information about the network.

### Command Mode

Router Configuration

### Default Setting

No networks are configured.

### Command Usage

- ◆ Use this command to specify the networks to advertise to BGP neighbors. BGP networks can be learned from directly connected routes, dynamic routing, or static route sources.
- ◆ BGP only sends and receives updates on interfaces specified by this command. If a network is not specified, the interfaces in that network will not be advertised in any BGP updates.
- ◆ A backdoor network has an administrative distance of 200, making routes learned through interior gateway protocols (RIP, OSPF, iBGP) preferred. A backdoor network is treated as a local network, except that it not advertised by the local router. A backdoor route should not be sourced at the local router, but should be one that has been learned from external neighbors. However, since these routes are treated as a local network, they are given priority over routes learned through eBGP, even if the distance of the external route is shorter.

### Example

```
Console(config-router)#network 172.16.0.0 255.255.0.0  
Console(config-router)#
```

**redistribute** This command redistributes routes from one routing domain to another. Use the **no** form to stop redistributing an previously configured entry.

### Syntax

```
redistribute {connected | ospf | rip | static} [metric metric-value]  
[route-map map-name]
```

```
no redistribute {connected | ospf | rip | static}  
[metric metric-value] [route-map map-name]
```

**connected** - Imports routes that are established automatically just by enabling IP on an interface.

**ospf** - External routes will be imported from the Open Shortest Path First (OSPF) protocol into this routing domain.

**rip** - External routes will be imported from the Routing Information Protocol (RIP) into this routing domain.

**static** - Static routes will be imported into this routing domain.

*metric-value* - Metric value assigned to all external routes for the specified protocol. (Range: 1-16)

*map-name* - Name of the route map. The route map can be used to filter the networks to advertise, and to modify their weight or other attributes. (Range: 1-80 characters)

### Command Mode

Router Configuration

### Default Setting

No redistribution is configured.

### Command Usage

- ◆ Use this command to advertise routes that are learned by some other means, such as from another routing protocol or static routing entries. Since all internal routes are maintained by interior gateway protocols such as RIP and OSPF, careful filtering should be used to ensure that only routes that need to be advertised reach the Internet.
- ◆ A route metric must be used to resolve the problem of redistributing external routes with incompatible metrics.

### Example

```
Console(config-router)#redistribute static metric 10
Console(config-router)#
```

**timers bgp** This command sets the Keep Alive time used for maintaining connectivity, and the Hold time to wait for Keep Alive or Update messages before declaring a neighbor down. Use the **no** form to restore the default settings.

### Syntax

**timers bgp** *keepalive-time hold-time*

**no timers bgp**

*keepalive-time* - The frequency at which the local router sends keep-alive messages to its neighbors. (Range: 0-65535 seconds)

*hold-time* - The maximum interval after which a neighbor is declared dead if a keep-alive or update message has not been received. (Range: 0-65535 seconds)

### Command Mode

Router Configuration

### Default Setting

Keep Alive time: 60 seconds  
Hold time: 180 seconds

### Command Usage

- ◆ Use this command to set global BGP timers used for monitoring connectivity to neighboring routers. These timers will be applied to all neighbors unless the `neighbor timers` command has been used to explicitly configure other timer settings for a neighbor.
- ◆ When the minimum acceptable hold-time is configured with this command, a remote peer session can be established only if the neighboring router is advertising a hold-time equal to, or greater than, that configured on this device.

### Example

```
Console(config-router)#timers bgp 60 200  
Console(config-router)#
```

**show ip bgp** This command shows entries in the routing table.

### Syntax

**show ip bgp** [*ip-address/mask* | **cidr-only**]

*ip-address* – IP address of a route entry.

*mask* – Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

**cidr-only** – Shows routes that use classless interdomain routing network masks.

### Command Mode

Privileged Exec

### Example

```
Console#show ip bgp  
BGP table version is 14, local router ID is 1.1.1.1, vrf id 0  
Default local pref 100, local AS 100  
Status codes: s suppressed, d damped, h history, * valid, > best, =  
multipath,  
i internal, r RIB-failure, S Stale, R Removed  
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self  
Origin codes: i - IGP, e - EGP, ? - incomplete  
RPKI validation codes: V valid, I invalid, N Not found
```

Network	Next Hop	Metric	LocPrf	Weight	Path
*>i1.1.1.0/24	1.1.1.2	0	100		0 ?
*> 2.2.2.0/24	2.2.2.2	0			0 200 ?
*> 3.3.3.0/24	2.2.2.2	0			0 200 ?
*>i4.4.4.0/24	1.1.1.2	0	100		0 ?
*	2.2.2.2	0			0 200 ?
*>i5.5.5.2/32	1.1.1.2	0	100		0 ?

```
Displayed 5 routes and 6 total paths  
Console#
```

**show ip bgp attribute-info** This command shows internal attribute hash information.

### Syntax

**show ip bgp attribute-info**

### Command Mode

Privileged Exec

### Example

In the following example, Refcnt refers to the number of routes using the indicated next hop.

```
Console#show ip bgp attribute-info  
  
attr[1] nexthop 0.0.0.0  
        flags: 15 distance: 0 med: 0 local_pref: 100 origin: 0 weight: 32768  
        label: 429  
4836223 sid:  
  
Console#
```

**show ip bgp community** This command shows routes that belong to specified BGP communities.

### Syntax

**show ip bgp community** **[[AA:NN] [internet] [local-as] [no-advertise] [no-export]] [exact-match]**

**AA:NN** – Standard community-number to match. The 4-byte community number is composed of a 2-byte autonomous system number and a 2-byte network number, separated by one colon. Each 2-byte number can range from 0 from 65535. One or more communities can be entered, separated by a space. Up to 16 community numbers are supported.

**internet** – Specifies the entire Internet. Routes with this community attribute are advertised to all internal and external peers.

**local-as** – Specifies the local autonomous system. Routes with this community attribute are advertised only to peers that are part of the local autonomous system or to peers within a sub-autonomous system of a confederation. These routes are not advertised to external peers or to other sub-autonomous systems within a confederation.

**no-advertise** – Routes with this community attribute are not advertised to any internal or external peer.

**no-export** – Routes with this community attribute are advertised only to peers in the same autonomous system or to other sub-autonomous systems within a confederation. These routes are not advertised to external peers.

**exact-match** – Displays only routes that match the specified communities exactly.

### Command Mode Privileged Exec

#### Example

```
Console#show ip bgp community
BGP table version is 12, local router ID is 1.1.1.1, vrf id 0
Default local pref 100, local AS 100
Status codes: s suppressed, d damped, h history, * valid, > best, =
               multipath,
                i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
RPKI validation codes: V valid, I invalid, N Not found

      Network          Next Hop           Metric LocPrf Weight Path
*> 10.10.10.0/24      0.0.0.0             0         32768 i

Displayed 1 routes and 3 total paths
Console#
```

### show ip bgp community-info

This command shows community messages permitted by BGP.

#### Syntax

**show ip bgp community-info**

### Command Mode Privileged Exec

#### Example

```
Console#show ip bgp community-info
Address      Refcnt  Community
[0x3312558] (3)    100:50
Console#
```

Table 193: show ip bgp community-info - display description

Field	Description
Address	Internal address in memory where the entry is stored.
Refcnt	The number of routes which refer to this community.
Community	4-byte community number composed of a 2-byte autonomous system number and a 2-byte network number, separated by one colon

**show ip bgp community-list** This command shows the routes matching a community-list.

#### Syntax

**show ip bgp community-list** {*community-list-number* | *community-list-name*}  
[**exact-match**]

*community-list-number* – Standard community list number that identifies one or more groups of communities. (Range: 1-500)

*community-list-name* – Name of standard or expanded access list. (Maximum length: 32 characters, no spaces or other special characters)

**exact-match** – Displays only routes that match the specified communities exactly.

#### Command Mode

Privileged Exec

#### Example

```

Console#show ip bgp community-list rd
BGP table version is 2, local router ID is 1.1.1.1, vrf id 0
Default local pref 100, local AS 100
Status codes: s suppressed, d damped, h history, * valid, > best, =
multipath,
                i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
RPKI validation codes: V valid, I invalid, N Not found

   Network          Next Hop          Metric LocPrf Weight Path
*> 10.10.10.0/24    0.0.0.0           0         32768 i

Displayed 1 routes and 2 total paths
Console#

```

**show ip bgp dampening** This command shows dampened routes.

#### Syntax

**show ip bgp dampening** {**dampened-paths** | **flap-statistics** | **parameters**}

**dampened-paths** – Routes suppressed due to dampening.

**flap-statistics** – Statistics for flapping route prefixes.

**parameters** – Route dampening parameters.

#### Command Mode

Privileged Exec

### Example

In the following example, "From" indicates the peer that advertised this path, while "Reuse" is the time after which the path will be made available.

```
Console#show ip bgp dampening dampened-paths
BGP table version is 2, local router ID is 1.1.1.1, vrf id 0
Default local pref 100, local AS 100
Status codes: s suppressed, d damped, h history, * valid, > best, =
multipath,
                i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
RPKI validation codes: V valid, I invalid, N Not found

   Network          From           Reuse    Path
*d 100.1.3.0/24     10.1.1.64      00:27:40 100 ?

Displayed 1 routes and 3 total paths
Console#
```

**show ip bgp filter-list** This command shows routes matching the specified filter list.

### Syntax

**show ip bgp filter-list** *access-list-name*

*access-list-name* – Name of a list of autonomous system paths as defined by the **bgp as-path access-list** command. (Maximum length: 16 characters, no spaces or other special characters)

### Command Mode

Privileged Exec

### Example

```
Console#show ip bgp filter-list rd
BGP table version is 2, local router ID is 11.1.1.100
Status codes: s suppressed, d damped, h history, * valid, > best, i -
internal,
                S Stale
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network          Next Hop          Metric LocPrf Weight Path
*> 100.1.1.0/24     10.1.1.64         0           0 100 ?

Displayed 1 routes and 3 total paths
Console#
```

**show ip bgp neighbors** This command shows connection information for neighbor sessions.

#### Syntax

**show ip bgp neighbors** [*ip-address* [**advertised-routes** | **received prefix-filter** | **received-routes** | **routes**]]

*ip-address* – IP address of the neighbor.

**advertised-routes** – Shows the routes advertised to a neighbor.

**received prefix-filter** – Shows the prefix-list (outbound route filter) sent from a neighbor.

**received-routes** – Shows all routes, both accepted and rejected, which have been received from a neighbor. To display all received routes from a neighbor, first enable soft reconfiguration with the [neighbor soft-reconfiguration inbound](#) command.

**routes** – Displays all accepted routes learned from a neighbor.

#### Command Mode

Privileged Exec

```
Console#show ip bgp neighbors
BGP neighbor is 10.1.1.66, remote AS 200, local AS 100, external link
BGP version 4, remote router ID 11.1.1.100
BGP state = Established, up for 00:13:43
Last read 00:13:43, hold time is 240, keep alive interval is 60 seconds
Neighbor capabilities:
  Route refresh: advertised and received (old and new)
  Address family IPv4 Unicast: advertised and received
Received 17 messages, 0 notifications, 0 in queue
Sent 17 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast
BGP table version 2, neighbor version 2
Index 1, Offset 0, Mask 0x2
Community attribute sent to this neighbor (both)
0 accepted prefixes
1 announced prefixes

Connections established 7; dropped 6
Console#
```

**show ip bgp paths** This command shows all paths in the database.

#### Syntax

**show ip bgp paths**

#### Command Mode

Privileged Exec

### Example

```
Console#show ip bgp paths
Address      RefCnt  ASpath
0x331dad0:0  1
0x331d850:93  1  600
0x331d8d8:249  2  200 300
Console#
```

**Table 194: show ip bgp paths - display description**

Field	Description
Address	Internal address in memory where the path is stored.
Refcnt	The number of routes using this path.
ASpath	The autonomous system path for this route.

**show ip bgp prefix-list** This command shows routes matching the specified prefix-list.

### Syntax

**show ip bgp prefix-list** *list-name*

*list-name* – Name of a prefix-list. The prefix list can be used to filter the networks to import or export as defined by the [match ip address prefix-list](#) command. (Range: 1-80 characters)

### Command Mode

Privileged Exec

### Example

```
Console#show ip bgp prefix-list rd
BGP table version is 0, local router ID is 192.168.0.2
Status codes: s suppressed, d damped, h history, * valid, > best, i internal,
               r RIB-failure, S Stale, R Removed
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network      Next Hop           Metric LocPrf Weight Path
*  100.1.1.0/24  10.1.1.66          0         0 200 300 ?
*>              10.1.1.100         0         0 32768 ?
Console#
```

**show ip bgp regexp** This command shows routes matching the AS path regular expression.

### Syntax

**show ip bgp regexp** *regular-expression*

*regular-expression* – Regular expression indicating the path attributes to match. Syntax complies with the IEEE POSIX Basic Regular Expressions (BRE) standard.

## Command Mode Privileged Exec

### Example

```

Console#show ip bgp regex 100
BGP table version is 12, local router ID is 1.1.1.1, vrf id 0
Default local pref 100, local AS 100
Status codes: s suppressed, d damped, h history, * valid, > best, =
multipath,
                i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
RPKI validation codes: V valid, I invalid, N Not found

      Network          Next Hop           Metric LocPrf Weight Path
*  100.1.1.0/24       10.1.1.64          0           0 500 100 600 ?

Displayed 1 routes and 3 total paths
Console#

```

**show ip bgp route-map** This command shows routes matching the specified route map.

### Syntax

**show ip bgp route-map** *map-name*

*map-name* – Name of the route map as defined by the [route-map](#) command. The route map can be used to filter the networks to advertise. (Range: 1-80 characters)

## Command Mode Privileged Exec

### Example

```

Console#show ip bgp route-map rd
BGP table version is 5, local router ID is 1.1.1.1, vrf id 0
Default local pref 100, local AS 100
Status codes: s suppressed, d damped, h history, * valid, > best, =
multipath,
                i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
RPKI validation codes: V valid, I invalid, N Not found

      Network          Next Hop           Metric LocPrf Weight Path
*> 5.5.5.1/32         0.0.0.0            0           0 32768 ?

Displayed 1 routes and 5 total paths
Console#

```

**show ip bgp nexthop** This command shows the BGP nexthop table.

### Syntax

**show ip bgp nexthop**

### Command Mode

Privileged Exec

### Example

```
Console#show ip bgp nexthop
Current BGP nexthop cache:
 1.1.1.2 valid [IGP metric 0], #paths 0, peer 1.1.1.2
   if VLAN1
   Last update: Thu Dec  8 06:51:48 2022

 2.2.2.2 valid [IGP metric 0], #paths 0, peer 2.2.2.2
   if VLAN2
   Last update: Thu Dec  8 06:20:22 2022
Console#
```

**show ip bgp summary** This command shows summary information for all connections.

### Syntax

**show ip bgp summary**

### Command Mode

Privileged Exec

### Example

In the following example, “Up/Down” refers to the length of time the session has been in the Established state, or the current status if not in Established state.

```
Console#show ip bgp summary
BGP router identifier 10.1.1.66, local AS number 200
BGP table version is 1
 1 BGP AS-PATH entries
 0 BGP community entries

Neighbor V AS MsgRcvd MsgSent TblVer InQ OutQ Up/Down State/PfxRcd
10.1.1.68 4 300 0 0 0 0 0 never Active

Total number of neighbors 1

Console#
```

**show ip community-list** This command shows routes permitted by a community list.

#### Syntax

**show ip community-list** [*community-list-number* | *community-list-name*]

*community-list-number* – Standard community list number that identifies one or more groups of communities. (Range: 1-500)

*community-list-name* – Name of standard or expanded access list. (Maximum length: 32 characters, no spaces or other special characters)

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip community-list rd
Named Community standard list rd
  permit 100:10
Console#
```

**show ip extcommunity-list** This command shows routes permitted by an extended community list.

#### Syntax

**show ip extcommunity-list** [*community-list-number* | *community-list-name*]

*community-list-number* – Standard community list number that identifies one or more groups of communities. (Range: 1-500)

*community-list-name* – Name of standard or expanded access list. (Maximum length: 32 characters, no spaces or other special characters)

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip extcommunity-list rd
Named extended community standard list rd
  permit RT:192.168.0.0:10
Console#
```

**show ip prefix-list** This command shows the specified prefix list.

### Syntax

**show ip prefix-list** [*prefix-list-name* [*ip-address netmask* [**first-match** | **longer**] | **seq** *sequence-number*]]

*prefix-list-name* – Name of prefix list. (Maximum length: 128 characters, no spaces or other special characters)

*ip-address* – An IPv4 address expressed in dotted decimal notation.

*netmask* – Network mask for the route. This mask identifies the network address bits used for the associated routing entries.

**first-match** – First matched prefix.

**longer** – All entries more specific than the specified network/mask.

*sequence-number* – The sequence number of an entry.  
(Range: 1-429496725)

### Command Mode

Privileged Exec

### Example

```
Console#show ip prefix-list rd
ip prefix-list rd: 1 entries
  seq 5 deny 10.0.0.0/8 ge 14 le 22
Console#
```

**show ip prefix-list detail** This command shows detailed information for the specified prefix list.

### Syntax

**show ip prefix-list detail** [*prefix-list-name*]

*prefix-list-name* – Name of prefix list. (Maximum length: 128 characters, no spaces or other special characters)

### Command Mode

Privileged Exec

### Example

```
Console#show ip prefix-list detail rd
ip prefix-list rd:
  count: 1, range entries: 0, sequences: 5 - 5
  seq 5 deny 10.0.0.0/8 ge 14 le 22 (hit count: 0, refcount: 0)
Console#
```

**show ip prefix-list summary** This command shows summary information for the specified prefix list.

#### Syntax

**show ip prefix-list summary** [*prefix-list-name*]

*prefix-list-name* – Name of prefix list. (Maximum length: 128 characters, no spaces or other special characters)

#### Command Mode

Privileged Exec

#### Example

```
Console#show ip prefix-list summary rd
ip prefix-list rd:
  count: 1, range entries: 0, sequences: 5 - 5
Console#
```

---

## Policy-based Routing for BGP

This section describes commands used to configure policy-based routing (PBR) maps for Border Gateway Protocol (BGP).

Policy-based routing is performed before regular routing. PBR inspects traffic on the interface where the policy is applied and then, based on the policy, makes some decision. First, the traffic is “matched” according to the policy. Second, for each match, there is something “set.” What is set could be that the traffic matches must exit out a different interface, or the traffic could be given a higher priority, or it could choose to just drop that traffic.

Matching of the traffic is usually done with an ACL (access-control list) that is referenced by a route-map. In the route-map, if there is a “match” for the traffic defined in that ACL, then a “set” defines what the administrator wants to happen to that traffic (prioritize it, route it differently, drop it, or other actions). Policies can be based on IP address, port numbers, protocols, or size of packets.

If matching criteria is found and the specified action is to permit the packet, then it will be forwarded to the next hop based on policy-based routing. If the action is to deny the packet, normal unicast routing is used to determine the packet’s next hop, instead of using policy-based routing. If no matching criteria are found in the route map, normal unicast routing is used to determine the packet’s next hop. Although route redistribution is protocol-independent, some of the route-map match and set commands defined in this section are specific to BGP.

Like matches in the same route map subblock are filtered with “or” semantics. If any one match clause is matched in the entire route map subblock, this match is treated as a successful match. Dissimilar match clauses are filtered with “and” semantics. If the first set of conditions is not met, the second match clause is filtered. This process continues until a match occurs or there are no more match clauses.

A route map can have several sequences. A route that does not match at least one match command defined in a route-map will be ignored; that is, the route will not be advertised for outbound route maps nor accepted for inbound route maps.

**Table 195: Policy-based Routing Configuration Commands**

Command	Function	Mode
route-map	Enters route-map configuration mode, allowing route maps to be created or modified	GC
call	Jumps to another route map after match and set commands are executed	RM
continue	Goes to a route-map entry with a higher sequence number after a successful match occurs	RM
description	Creates a description of an entry in the route map	RM
match as-path	Sets an AS path access list to match	RM
match community	Sets a BGP community access list to match	RM
match extcommunity	Sets a BGP extended community access list to match	RM
match ip address	Specifies destination addresses to match in a standard access list, extended access list, or prefix list	RM
match ip next-hop	Specifies next hop addresses to match in a standard access list, extended access list, or prefix list	RM
match ip route-source	Specifies the source of routing messages to match in a standard access list, extended access list, or prefix list	RM
match metric	Sets the metric value to match in routing messages	RM
match origin	Sets the originating protocol to match in routing messages	RM
match peer	Sets the peer address to match in routing messages	RM
on-match	Sets the next entry to go to when this entry matches	RM
set aggregator as	Assigns an AS number and IP address to the aggregator attribute of a route	RM
set as-path	Modifies the AS path by prepending or excluding an AS number	RM
set atomic-aggregate	Indicates the loss of some information in the route aggregation process	RM
set comm-list delete	Removes communities from the community attribute of inbound or outbound routing messages	RM
set community	Sets the community attributes of routing messages	RM
set extcommunity	Sets the extended community attributes of routing messages	RM
set ip next-hop	Sets the next-hop for a routing message	RM
set local-preference	Sets the priority within the local AS for a routing message	RM
set metric	Sets the metric value of a route to external neighbors	RM
set origin	Sets the origin code for the routing protocol which generated this message	RM
set originator-id	Sets the IP address of the routing message's originator	RM

Table 195: Policy-based Routing Configuration Commands (Continued)

Command	Function	Mode
set weight	Sets the weight for routing messages	RM
show route-map	Shows the configuration setting for a route map	PE

**route-map** This command enters route-map configuration mode, allowing route maps to be created or modified. Use the **no** form to remove a route map.

### Syntax

**[no] route-map** *map-name* {**deny** | **permit**} *sequence-number*

*map-name* – Name for the route map. (Range: 1-128 case-sensitive alphanumeric characters)

**deny** – Route-map denies set operations.

**permit** – Route-map permits set operations.

*sequence-number* – Sequence to insert to or delete from existing route-map entry. (Range: 1-65535)

### Command Mode

Global Configuration

### Default Setting

Disabled

### Command Usage

- ◆ This command enters the route map configuration mode. In this mode, a new route map can be created, or an existing route map modified.
- ◆ The match commands specify the conditions under which policy routing occurs, and the set commands specify the routing actions to perform if the criteria enforced by the match commands are met.
- ◆ If the match criteria are met for a route map, and the permit keyword specified, the packet is policy routed based on defined set commands.
- ◆ If the match criteria are not met, and the permit keyword specified, the next route map with the same map-name is tested. If a route passes none of the match criteria for the set of route maps sharing the same name, it is not policy routed by that set.
- ◆ If the match criteria are met for the route map and the deny keyword specified, the packet is not policy routed, and no further route maps sharing the same map-name are examined. If the packet is not policy routed, the normal forwarding process is used.

- ◆ Processing for exceptions include the following results:
  - For a deny route-map, if it does not have a match clause, any routing message is matched, and therefore all routes are denied.
  - For a deny route-map which includes a match clause for an access-list, if the access-list does not exist, no routing message will be matched, and therefore all routes are skipped.
  - For a permit route-map, if it does not have a match clause, any routing message is matched, and therefore all routes are permitted.
  - For a permit route-map which includes a match clause for an access-list, if the access-list does not exist, no routing messages are matched, and therefore all routes are skipped.

### Example

```
Console(config)#route-map r1 permit 1
Console(config-route-map)#match as-path 60
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**call** This command jumps to another route map after match and set commands are executed. Use the **no** form to remove an entry from a route map.

### Syntax

**call** *map-name*

**no call**

*map-name* – Name for the route map. (Range: 1-128 case-sensitive alphanumeric characters)

### Command Mode

Route Map

### Command Usage

Only one call clause is permitted per route map. The call clause executed only after all match and set commands are executed.

### Example

```
Console(config)#route-map r1 permit 1
Console(config-route-map)#match as-path 60
Console(config-route-map)#set weight 30
Console(config-route-map)#call FD
Console(config-route-map)#
```

**continue** This command goes to a route-map entry with a higher sequence number after a successful match occurs. Use the **no** form to remove this entry from a route map.

### Syntax

**continue** [*sequence-number*]

**no continue**

*sequence-number* – Sequence number at which to continue processing.  
(Range: 1-65535)

### Command Mode

Route Map

### Command Usage

If no match statements precede the call entry, the call is automatically executed. If no sequence number is specified by the call entry, the next entry is executed.

### Example

```
Console(config)#route-map RD permit 1
Console(config-route-map)#match as-path 60
Console(config-route-map)#set weight 30
Console(config-route-map)#continue 3
Console(config-route-map)#
```

**description** This command creates a description of an entry in the route map. Use the **no** form to remove the description.

### Syntax

**description** *text*

**no description**

*text* – Comment describing this route-map rule. (Maximum length: 128 characters, no spaces or other special characters)

### Command Mode

Route Map

### Example

```
Console(config)#route-map RD permit 1
Console(config-route-map)#description AS-Path rule
Console(config-route-map)#match as-path 60
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**match as-path** This command sets a BGP autonomous system path access list to match. Use the **no** form to remove this entry from a route map.

#### Syntax

**[no] match as-path** *access-list-name*

*access-list-name* – Name of the access list. (Maximum length: 16 characters, no spaces or other special characters)

#### Command Mode

Route Map

#### Command Usage

The weights assigned by the **match as-path** and **set weight** route-map commands command override the weight assigned using the BGP **neighbor weight** command.

#### Example

```
Console(config)#route-map RD permit 1
Console(config-route-map)#match as-path 60
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

#### Related Commands

[bgp as-path access-list \(1098\)](#)

**match community** This command sets a BGP community access list to match. Use the **no** form to remove this entry from a route map.

#### Syntax

**match community** {1-99 | 100-500 | *community-list-name*} [**exact-match**]

**no match community**

1-99 – Standard community list number that identifies one or more groups of communities.

100-500 – Expanded community list number that identifies one or more groups of communities.

*community-list-name* – Name of standard or expanded community list. (Maximum length: 32 characters, no spaces or other special characters)

**exact-match** – Must exactly match the specified community list. All and only those communities specified must be present.

#### Command Mode

Route Map

### Command Usage

This command matches the community attributes of the BGP routing message following the rules specified with the [bgp community-list](#) command.

### Example

```
Console(config)#route-map RD permit 2
Console(config-route-map)#match community 60
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**match extcommunity** This command sets a BGP extended community access list to match. Use the **no** form to remove this entry from a route map.

### Syntax

**match extcommunity** {1-99 | 100-500}

**no match extcommunity**

1-99 – Standard community list number that identifies one or more groups of communities.

100-500 – Expanded community list number that identifies one or more groups of communities.

### Command Mode

Route Map

### Command Usage

This command matches the extended community attributes of the BGP routing message following the rules specified with the [bgp extcommunity-list](#) command.

### Example

```
Console(config)#route-map RD permit 3
Console(config-route-map)#match extcommunity 160
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**match ip address** This command specifies the destination addresses to be matched in a standard access list, an extended access list, or a prefix list. Use the **no** form to remove this entry from a route map.

#### Syntax

**match ip address** {*access-list-name* | **prefix-list** *prefix-list-name*}

**no match ip address**

*access-list-name* – Name of standard or extended access list.  
(Maximum length: 32 characters, no spaces or other special characters)

*prefix-list-name* – Name of a specific prefix list.

#### Command Mode

Route Map

#### Example

```
Console(config)#route-map RD permit 4
Console(config-route-map)#match ip address rd-addresses
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

#### Related Commands

[ip prefix-list \(1103\)](#)

**match ip next-hop** This command specifies the next-hop addresses to be matched in a standard access list, an extended access list, or a prefix list. Use the **no** form to remove this entry from a route map.

#### Syntax

**match ip next-hop** {*access-list-name* | **prefix-list** *prefix-list-name*}

**no match ip next-hop**

*access-list-name* – Name of standard or extended access list.  
(Maximum length: 32 characters, no spaces or other special characters)

*prefix-list-name* – Name of a specific prefix list.

#### Command Mode

Route Map

#### Command Usage

When inbound update messages are received from a neighbor, next-hop information contained in Network Layer Reachability Information (NLRI) entries is checked against the specified access-list or prefix-list before any routes are learned.

### Example

```
Console(config)#route-map RD permit 5
Console(config-route-map)#match ip next-hop rd-next-hops
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**match ip route-source** This command specifies the source of routing messages advertised by routers and access servers to be matched in a standard access list, an extended access list, or a prefix list. Use the **no** form to remove this entry from a route map.

### Syntax

**match ip route-source** {*access-list-name* | **prefix-list** *prefix-list-name*}

**no match ip route-source** [*access-list-name* | **prefix-list**]

*access-list-name* – Name of standard or extended access list.  
(Maximum length: 32 characters, no spaces or other special characters)

*prefix-list-name* – Name of a specific prefix list.

### Command Mode

Route Map

### Command Usage

Note that there may be situations in which the next hop and source router address of the route are not the same.

### Example

```
Console(config)#route-map RD permit 6
Console(config-route-map)#match ip route-source rd-sources
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**match metric** This command sets the metric value to match in routing messages. Use the **no** form to remove this entry from a route map.

### Syntax

**match metric** *metric-value*

**no match metric**

*metric-value* – The metric value in the routing messages.  
(Range: 0-4294967295)

### Command Mode

Route Map

### Example

```
Console(config)#route-map RD permit 7
Console(config-route-map)#match metric 60
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**match origin** This command sets the originating protocol to match in routing messages. Use the **no** form to remove this entry from a route map.

### Syntax

**match origin {egp | igp | incomplete}**

**no match origin**

**egp** – Routes learned from exterior gateway protocols.

**igp** – Routes learned from internal gateway protocols.

**incomplete** – Routes of uncertain origin.

### Command Mode

Route Map

### Example

```
Console(config)#route-map RD permit 8
Console(config-route-map)#match origin igp
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**match peer** This command sets the peer address to match in routing messages. Use the **no** form to remove this entry from a route map.

### Syntax

**match peer {peer-address | local}**

**no match peer [peer-address | local]**

*peer-address* – IP address of neighboring router sending routing messages.

**local** – Static or redistributed routes.

### Command Mode

Route Map

### Example

```
Console(config)#route-map RD permit 9
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set weight 30
Console(config-route-map)#
```

**on-match** This command sets the next entry to go to when this entry matches. Use the **no** form to remove this entry from a route map.

### Syntax

**on-match** {**goto** *sequence-number* | **next**}

**no on-match** {**goto** | **next**}

**goto** – On match, go to specified entry.

*sequence-number* – Route-map entry. (Range: 1-65535)

**next** – Go to next entry.

### Command Mode

Route Map

### Command Usage

Use this command when no set action is for a match clause.

### Example

```
Console(config)#route-map RD permit 8
Console(config-route-map)#match pathlimit as 5
Console(config-route-map)#on match goto 20
Console(config-route-map)#
```

**set aggregator as** This command assigns an AS number and IP address to the aggregator attribute of a route. Use the **no** form to remove this entry from a route map.

### Syntax

**set aggregator as** *as-number ip-address*

**no set aggregator as** [*as-number ip-address*]

*as-number* – Autonomous system number. (Range: 1-4294967295)

*ip-address* – IP address of aggregator.

### Command Mode

Route Map

### Command Usage

Aggregate routes advertised to a neighbor contain an aggregator attribute. This attribute contains an AS number and IP address. The AS number is the creator's AS number (or confed ID in a confederation) and an IP address which is the creator's router-id. The **set aggregator as** command can be used to overwrite the aggregator attribute in routes created locally with the [aggregate-address](#) command, or in routes learned from a neighbor which already carry an aggregator attribute, or to add a new aggregator attribute to a route which has no aggregator attribute.

### Example

```
Console(config)#route-map RD permit 8
Console(config-route-map)#match pathlimit as 5
Console(config-route-map)#set aggregator 1 192.168.0.0
Console(config-route-map)#
```

**set as-path** This command modifies the AS path by prepending or excluding an AS number. Use the **no** form to remove this entry from a route map.

### Syntax

**set as-path** {**exclude** | **prepend**} *as-number*...

**no set as-path** {**exclude** | **prepend**}

**exclude** – Removes one or more autonomous system numbers from the AS path of the route that is matched.

**prepend** – Appends one or more autonomous system numbers to the AS path of the route that is matched.

*as-number* – Autonomous system number. (Range: 1-4294967295)

### Command Mode

Route Map

### Command Usage

Note that best path selection may be influenced with this command by varying the length of the autonomous system path.

### Example

```
Console(config)#route-map RD permit 8
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set as-path prepend 2
Console(config-route-map)#
```

**set atomic-aggregate** This command indicates the loss of some information in the route aggregation process. Use the **no** form to remove this entry from a route map.

### Syntax

**[no] set atomic-aggregate**

### Command Mode

Route Map

### Command Usage

The purpose of the atomic-aggregate attribute is to alert BGP speakers along the path that some information have been lost due to the route aggregation process and that the aggregate path might not be the best path to the destination. This attribute should be set when the BGP speaker advertises ONLY the less-specific prefix and suppresses more specific ones.

### Example

```
Console(config)#route-map RD permit 9
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set atomic-aggregate
Console(config-route-map)#
```

**set comm-list delete** This command removes communities from the community attribute of inbound or outbound routing messages. Use the **no** form to remove this entry from a route map.

### Syntax

**[no] set comm-list {1-99 | 100-500 | *community-list-name*} delete**

1-99 – Standard community list number that identifies one or more groups of communities.

100-500 – Expanded community list number that identifies one or more groups of communities.

*community-list-name* – Name of standard or expanded community list.  
(Maximum length: 32 characters, no spaces or other special characters)

### Command Mode

Route Map

### Command Usage

When using the [bgp community-list](#) command to configure a community access list, each entry of a standard community list should list only one community. Otherwise, the **set comm-list delete** command will not succeed. For example, in order to be able to delete communities 100 and 200, you must create two separate entries with the [bgp community-list](#) command.

## Example

```
Console(config)#route-map RD permit 10
Console(config-route-map)#match peer 192.168.0.77
Console(config-route-map)#set comm-list 10:01 delete
Console(config-route-map)#exit
Console(config)#route-map RD permit 11
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set comm-list 20:01 delete
Console(config-route-map)#
```

**set community** This command sets the community attributes of routing messages. Use the **no** form to remove this entry from a route map.

## Syntax

### set community

```
[AA:NN...]  
[additive [[AA:NN...] [internet] [local-as] [no-advertise] [no-export]]  
[internet [[AA:NN...] [local-as] [no-advertise] [no-export]]  
[local-as [[AA:NN...] [no-advertise] [no-export]]  
[no-advertise [AA:NN...] [no-export]]  
[no-export [AA:NN...]]  
[none]
```

### no set community

**AA:NN** – Standard community-number. The 4-byte community number is composed of a 2-byte autonomous system number and a 2-byte network number, separated by one colon. Each 2-byte number can range from 0 from 65535. One or more communities can be entered, separated by a space. Up to 16 community numbers are supported.

**additive** – Adds community attributes to already existing community attributes.

**internet** – Specifies the entire Internet. Routes with this community attribute are advertised to all internal and external peers.

**local-as** – Specifies the local autonomous system. Routes with this community attribute are advertised only to peers that are part of the local autonomous system or to peers within a sub-autonomous system of a confederation. These routes are not advertised to external peers or to other sub-autonomous systems within a confederation.

**no-advertise** – Routes with this community attribute are not advertised to any internal or external peer.

**no-export** – Routes with this community attribute are advertised only to peers in the same autonomous system or to other sub-autonomous systems within a confederation. These routes are not advertised to external peers.

**none** – Delete the community attributes from the prefix of this route.

## Command Mode

### Route Map

### Example

```

Console(config)#route-map RD permit 11
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set community 10:01
Console(config-route-map)#exit
Console(config)#route-map RD permit 12
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set community 20:01
Console(config-route-map)#

```

### Related Commands

[set comm-list delete \(1175\)](#)

**set extcommunity** This command sets the extended community attributes of routing messages. Use the **no** form to remove this entry from a route map.

### Syntax

**set extcommunity** {**rt** *extended-community-value* |  
**soo** *extended-community-value*}

**no set extcommunity** [**rt** | **soo**]

**rt** – The route target extended community attribute.

**soo** – The site of origin extended community attribute.

*extended-community-value* – The route target or site of origin in one of the following formats:

*AAAA:NN* or *AA:NNNN* – Community-number to deny or permit. The community number can either be formatted as a 4-byte autonomous system number and a 2-byte network number, or as a 2-byte autonomous system number and a 4-byte network number, separated by one colon. Each 2-byte number can range from 0 to 65535, and 4-byte numbers from 0 to 4294967295.

*IP:NN* – Community to deny or permit. The community number is composed of a 4-byte IP address (representing the autonomous system number) and a 2-byte network number, separated by one colon. The 2-byte network number can range from 0 to 65535.

One or more community numbers can be entered, separated by a space. Up to 3 community numbers are supported.

## Command Mode

### Route Map

### Command Usage

- ◆ Using the **rt** keyword to specify new route targets replaces existing route targets.
- ◆ The route target (RT) attribute is used to identify sites that may receive routes tagged with a specific route target. Using this attribute allows that route to be placed in per-site forwarding tables used for routing traffic received from the corresponding sites.
- ◆ The site of origin (SOO) attribute is used to identify the site from which the provider edge (PE) router learned the route. All routes learned from a particular site are assigned the same site of origin attribute, no matter if a site is connected to a single PE router or multiple PE routers. Filtering based on this extended community attribute can prevent routing loops from occurring when a site is multi-homed.

### Example

```
Console(config)#route-map RD permit 13
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set extcommunity 100:0 192.168.1.1:1
Console(config-route-map)#
```

**set ip next-hop** This command sets the next-hop for a routing message. Use the **no** form to remove this entry from a route map.

### Syntax

**set ip next-hop** {*ip-address* | **peer-address**}

**no set ip next-hop** [*ip-address*]

*ip-address* – An IPv4 address of the next hop, expressed in dotted decimal notation.

**peer-address** – Sets the next hop as the BGP peering address.

### Command Mode

Route Map

### Command Usage

- ◆ The IP address specified as the next hop need not be an adjacent router.
- ◆ When this command is used with the **peer-address** keyword in an inbound route map received from a BGP peer, the next hop of the received matching routes are set to be the neighbor peer address, overriding any other next hops.
- ◆ When this command is used with the **peer-address** keyword in an outbound route map for a BGP peer, the next hop of the advertised matching routes will be set to be the peering address of the local router, thus disabling next hop calculation. This command therefore has finer granularity than the **neighbor**

`next-hop-self` command, because it can set the next hop for some routes, but not others. While the `neighbor next-hop-self` command sets the next hop for all routes sent to the specified neighbor(s).

### Example

```
Console(config)#route-map RD permit 14
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set ip next-hop 192.168.0.254
Console(config-route-map)#
```

**set local-preference** This command sets the priority within the local AS for a routing message. Use the **no** form to remove this entry from a route map.

### Syntax

**set local-preference** *preference*

**no set local-preference**

*preference* – Degree of preference iBGP peers give local routes during BGP best path selection. The higher the value, the more the route is to be preferred. (Range: 1-4294967295)

### Command Mode

Route Map

### Command Usage

- ◆ The preference is sent only to routers in the local autonomous system. To specify the metric for inter-autonomous systems, use the `set metric` command.
- ◆ A route with a higher local priority level when compared with other routes to the same destination will be preferred over other routes.

### Example

```
Console(config)#route-map RD permit 15
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set local-preference 2
Console(config-route-map)#
```

**set metric** This command sets the metric value of a route to external neighbors. Use the **no** form to restore the default value.

#### Syntax

**set metric** [+ | -]*metric-value*

**no set metric**

*metric-value* – Metric value assigned to all external routes for the specified protocol. (Range: 0-4294967295)

#### Default Setting

The dynamically learned metric value.

#### Command Mode

Route Map

#### Command Usage

- ◆ Lower metric values indicate a higher priority.
- ◆ This command can modify the current metric for a route using the “+” or “-” keywords.
- ◆ The metric applies to external routers in the inter-autonomous system. To specify the metric for the local AS, use the [set local-preference](#) command.
- ◆ This path metric is normally only compared with neighbors in the local AS. To extend the comparison to paths advertised from neighbors in different autonomous systems, use the [bgp always-compare-med](#) command.

#### Example

```
Console(config)#route-map RD permit 16
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set metric +1
Console(config-route-map)#
```

**set origin** This command sets the BGP origin code for the routing protocol which generated this message. Use the **no** form to remove this entry from a route map.

#### Syntax

**set origin** {**egp** | **igp** | **incomplete**}

**no set origin**

**egp** – Exterior gateway protocols.

**igp** – Interior gateway protocols.

**incomplete** – Route origin unknown.

### Default Setting

As indicated in main IP routing table

### Command Mode

Route Map

### Command Usage

EGP is an inter-domain routing protocol which has been superceded by BGP. IGP indicates any intra-domain routing protocol such as RIP or OSPF.

### Example

```
Console(config)#route-map RD permit 16
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set origin egp
Console(config-route-map)#
```

**set originator-id** This command sets the IP address of the routing message's originator. Use the **no** form to remove this entry from a route map.

### Syntax

**set originator-id** *ip-address*

**no set originator-id**

*ip-address* – An IPv4 address of the route source, expressed in dotted decimal notation.

### Command Mode

Route Map

### Command Usage

This attribute is commonly used for loop prevention by rejecting updates that contain the receiving router's own router-ID in the originator-ID attribute.

### Example

```
Console(config)#route-map RD permit 17
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set originator-id 192.168.0.254
Console(config-route-map)#
```

**set weight** This command sets the weight for routing messages. Use the **no** form to remove this entry from a route map.

### Syntax

**set weight** *weight*

**no set weight**

*weight* – The weight assigned to this route. (Range: 0-4294967295)

### Command Mode

Route Map

### Command Usage

- ◆ Weights are used to determine the best path available to the local switch. The route with the highest weight gets preference over other routes to the same network.
- ◆ Weights assigned using this command override those assigned by the [neighbor weight](#) command.

### Example

```
Console(config)#route-map RD permit 19
Console(config-route-map)#match peer 192.168.0.99
Console(config-route-map)#set weight 255
Console(config-route-map)#
```

**show route-map** This command shows the configuration setting for a route map.

### Syntax

**show route-map** [*map-name*]

*map-name* – Name for the route map. (Range: 1-128 case-sensitive alphanumeric characters)

### Command Mode

Privileged Exec

### Example

```
Console#show route-map RD
route-map RD, permit, sequence 1
  Match clauses:
    peer 102.168.0.99
  Set clauses:
    comm-list 100 delete
  Call clause:
  Action:
    Exit routemap
Console#
```





## PIM Commands

This section includes commands for Protocol-Independent Multicast (PIM) routing.

This device can route multicast traffic to different subnetworks using Protocol-Independent Multicast - Sparse Mode (PIM-SM) for IPv4. PIM for IPv4 (PIMv4) relies on messages sent from IGMP-enabled Layer 2 switches and hosts to determine when hosts want to join or leave multicast groups.

PIM-SM is designed for networks where the probability of multicast group members is low, such as the Internet. PIM Source Specific Multicast (PIM-SSM) for multicast groups is also supported, which enables clients to receive multicast traffic directly from a source.

**Table 196: PIM-SM and PIM-SSM Multicast Routing Commands**

Command	Function	Mode
<code>router pim</code>	Enables IPv4 PIM globally for the router	GC
<code>ip pim</code>	Enables PIM-SM on the specified interface	IC
<code>ip pim hello-holdtime</code>	Sets the time to wait for hello messages from a neighboring PIM router before declaring it dead	IC
<code>ip pim hello-interval</code>	Sets the interval between sending PIM hello messages	IC
<code>ip pim override-interval</code>	Specifies the time it takes a downstream router to respond to a lan-prune-delay message	IC
<code>ip pim propagation-delay</code>	Configures the propagation delay required for a LAN prune delay message to reach downstream routers	IC
<code>show ip pim interface</code>	Displays information about interfaces configured for PIM	NE, PE
<code>show ip pim neighbor</code>	Displays information about PIM neighbors	NE, PE
<code>ip pim dr-priority</code>	Sets the priority value for a DR candidate	IC
<code>ip pim join-prune-interval</code>	Sets the join/prune timer	IC
<code>ip pim rp-address</code>	Sets a static address for the rendezvous point	GC
<code>ip pim spt-threshold</code>	Prevents the last-hop PIM router from switching to Shortest Path Source Tree (SPT) mode	GC
<code>ip pim ssm range</code>	Configures a PIM-SSM address	GC

**router pim** This command enables IPv4 Protocol-Independent Multicast routing globally on the router. Use the **no** form to disable PIM multicast routing.

### Syntax

**[no] router pim**

### Default Setting

Disabled

### Command Mode

Global Configuration

### Command Usage

This command enables PIM globally for the router. You also need to enable PIM-SM for each interface that will support multicast routing using the [ip pim sparse mode](#) command, and make any changes necessary to the multicast protocol parameters.

### Example

```

Console(config)#router pim
Console(config)#exit
Console#show ip pim interface
PIM is enabled.
VLAN 1 is up.
PIM Mode           : Sparse Mode
IP Address          : 192.168.0.2
Hello Interval     : 30 sec
Hello HoldTime     : 105 sec
Triggered Hello Delay : 5 sec
Join/Prune Holdtime : 210 sec
Lan Prune Delay    : Disabled
Propagation Delay  : 500 ms
Override Interval  : 2500 ms
DR Priority         : 1
Join/Prune Interval : 60 sec

Console#

```

**ip pim** This command enables PIM-SM on the specified interface. Use the **no** form to disable PIM-SM on this interface.

### Syntax

**[no] ip pim {sparse-mode}**

**sparse-mode** - Enables PIM Sparse Mode.

### Default Setting

Disabled

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ To fully enable PIM, you need to enable multicast routing globally for the router with the `ip multicast-routing` command, enable PIM globally for the router with the `router pim` command, and also enable PIM-SM for each interface that will participate in multicast routing with this command.
- ◆ If you enable PIM on an interface, you should also enable IGMP on that interface. PIM mode selection determines how the switch populates the multicast routing table, and how it forwards packets received from directly connected LAN interfaces. Sparse mode interfaces are added only when periodic join messages are received from downstream routers, or a group member is directly connected to the interface.
- ◆ Sparse-mode interfaces forward multicast traffic only if a join message is received from a downstream router or if group members are directly connected to the interface. When routers want to receive a multicast flow, they periodically send join messages to the Rendezvous Point (RP), and are subsequently added to the shared path for the specified flow back up to the RP. If routers want to join the source path up through the Shortest Path Source Tree (SPT), they periodically send join messages toward the source. They also send prune messages toward the RP to prune the shared path if they have already connected to the source through the SPT, or if there are no longer any group members connected to the interface.

### Example

```

Console(config)#interface vlan 1
Console(config-if)#ip pim sparse-mode
Console(config-if)#end
Console#show ip pim interface
PIM is enabled.
VLAN 1 is up.
PIM Mode           : Sparse Mode
IP Address          : 192.168.0.2
Hello Interval     : 30 sec
Hello HoldTime     : 105 sec
Triggered Hello Delay : 5 sec
Join/Prune Holdtime : 210 sec
Lan Prune Delay    : Disabled
Propagation Delay   : 500 ms
Override Interval   : 2500 ms
DR Priority         : 1
Join/Prune Interval : 60 sec

Console#

```

**ip pim hello-holdtime** This command configures the interval to wait for hello messages from a neighboring PIM router before declaring it dead. Use the **no** form to restore the default value.

#### Syntax

**ip pim hello-holdtime** *seconds*

**no ip pim hello-interval**

*seconds* - The hold time for PIM hello messages. (Range: 1-65535)

#### Default Setting

105 seconds

#### Command Mode

Interface Configuration (VLAN)

#### Command Usage

The **ip pim hello-holdtime** should be greater than the value of **ip pim hello-interval**.

#### Example

```
Console(config-if)#ip pim hello-holdtime 210
Console(config-if)#
```

**ip pim hello-interval** This command configures the frequency at which PIM hello messages are transmitted. Use the **no** form to restore the default value.

#### Syntax

**ip pim hello-interval** *seconds*

**no pim hello-interval**

*seconds* - Interval between sending PIM hello messages. (Range: 1-65535)

#### Default Setting

30 seconds

#### Command Mode

Interface Configuration (VLAN)

#### Command Usage

Hello messages are sent to neighboring PIM routers from which this device has received probes, and are used to verify whether or not these neighbors are still active members of the multicast tree.

### Example

```
Console(config-if)#ip pim hello-interval 60
Console(config-if)#
```

**ip pim join-prune-holdtime** This command configures the hold time for the prune state. Use the **no** form to restore the default value.

### Syntax

**ip pim join-prune-holdtime** *seconds*

**no ip pim join-prune-holdtime**

*seconds* - The hold time for the prune state. (Range: 0-65535)

### Default Setting

210 seconds

### Command Mode

Interface Configuration (VLAN)

### Command Usage

The multicast interface that first receives a multicast stream from a particular source forwards this traffic to all other PIM interfaces on the router. If there are no requesting groups on that interface, the leaf node sends a prune message upstream and enters a prune state for this multicast stream. The prune state is maintained until the join-prune-holdtime timer expires or a graft message is received for the forwarding entry.

### Example

```
Console(config-if)#ip pim join-prune-holdtime 60
Console(config-if)#
```

**ip pim override-interval** This command configures the override interval, or the time it takes a downstream router to respond to a lan-prune-delay message. Use the **no** form to restore the default setting.

### Syntax

**ip pim override-interval** *milliseconds*

**no ip pim override-interval**

*milliseconds* - The time required for a downstream router to respond to a lan-prune-delay message by sending back a Join message if it wants to continue receiving the flow referenced in the message. (Range: 500-6000 milliseconds)

#### Default Setting

2500 milliseconds

#### Command Mode

Interface Configuration (VLAN)

#### Command Usage

The override interval configured by this command and the propagation delay configured by the [ip pim propagation-delay](#) command are used to calculate the LAN prune delay. If a downstream router has group members which want to continue receiving the flow referenced in a LAN prune delay message, then the override interval represents the time required for the downstream router to process the message and then respond by sending a Join message back to the upstream router to ensure that the flow is not terminated.

#### Example

```
Console(config-if)#ip pim override-interval 3500
Console(config-if)#
```

#### Related Commands

[ip pim propagation-delay \(1190\)](#)

### **ip pim propagation-delay**

This command configures the propagation delay required for a LAN prune delay message to reach downstream routers. Use the **no** form to restore the default setting.

**ip pim propagation-delay** *milliseconds*

**no ip pim propagation-delay**

*milliseconds* - The time required for a lan-prune-delay message to reach downstream routers attached to the same VLAN interface. (Range: 100-5000 milliseconds)

#### Default Setting

500 milliseconds

#### Command Mode

Interface Configuration (VLAN)

#### Command Usage

The override interval configured by the [ip pim override-interval](#) command and the propagation delay configured by this command are used to calculate the LAN

prune delay. If a downstream router has group members which want to continue receiving the flow referenced in a LAN prune delay message, then the propagation delay represents the time required for the lan-prune-delay message to be propagated down from the upstream router to all downstream routers attached to the same VLAN interface.

### Example

```
Console(config-if)#ip pim propagation-delay 600
Console(config-if)#
```

### Related Commands

[ip pim override-interval \(1189\)](#)

**show ip pim interface** This command displays information about interfaces configured for PIM.

### Syntax

**show ip pim interface** [*vlan* *vlan-id*]

*vlan-id* - VLAN ID (Range: 1-4094)

### Command Mode

Normal Exec, Privileged Exec

### Command Usage

This command displays the PIM settings for the specified interface as described in the preceding pages. It also shows the address of the designated PIM router and the number of neighboring PIM routers.

### Example

```
Console#show ip pim interface vlan 1
PIM is enabled.
VLAN 1 is up.
PIM Mode                : Sparse Mode
IP Address               : 192.168.0.2
Hello Interval          : 30 sec
Hello HoldTime          : 105 sec
Triggered Hello Delay   : 5 sec
Join/Prune Holdtime     : 210 sec
Lan Prune Delay         : Disabled
Propagation Delay       : 500 ms
Override Interval       : 2500 ms
DR Priority              : 1
Join/Prune Interval     : 60 sec

Console#
```

**show ip pim neighbor** This command displays information about PIM neighbors.

### Syntax

**show ip pim neighbor** [**interface vlan** *vlan-id*]  
*vlan-id* - VLAN ID (Range: 1-4094)

### Default Setting

Displays information for all known PIM neighbors.

### Command Mode

Normal Exec, Privileged Exec

### Example

```

Console#show ip pim neighbor
Neighbor Address VLAN Interface Uptime (sec.) Expiration Time (sec) DR
-----
192.168.0.3/32 1 00:00:21 00:01:30
Console#

```

**Table 197: show ip pim neighbor - display description**

Field	Description
Neighbor Address	IP address of the next-hop router.
VLAN Interface	Interface number that is attached to this neighbor.
Uptime	The duration this entry has been active.
Expiration Time	The time before this entry will be removed.
DR	The designated PIM-SM router. If multicast hosts are directly connected to the LAN, then only one of these routers is elected as the DR, and acts on behalf of these hosts, sending periodic Join/Prune messages toward a group-specific RP for each group.

**ip pim dr-priority** This command sets the priority value for a Designated Router (DR) candidate. Use the **no** form to restore the default setting.

### Syntax

**ip pim dr-priority** *priority-value*

**no ip pim dr-priority**

*priority-value* - Priority advertised by a router when bidding to become the DR. (Range: 0-4294967294)

### Default Setting

1

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ More than one PIM-SM router may be connected to an Ethernet or other shared-media LAN. If multicast hosts are directly connected to the LAN, then only one of these routers is elected as the DR, and acts on behalf of these hosts, sending periodic Join/Prune messages toward a group-specific RP for each group. A single DR is elected per interface (LAN or otherwise) using a simple election process.
- ◆ The router with the highest priority configured on an interface is elected as the DR. If more than one router attached to this interface uses the same priority, then the router with the highest IP address is elected to serve as the DR.
- ◆ If a router does not advertise a priority in its hello messages, it is assumed to have the highest priority and is elected as the DR. If more than one router is not advertising its priority, then the router with the highest IP address is elected to serve as the DR.

### Example

This example sets the priority used in the bidding process for the DR.

```

Console(config)#interface vlan 1
Console(config-if)#ip pim dr-priority 20
Console(config-if)#end
Console#show ip pim interface
PIM is enabled.
VLAN 1 is up.
PIM Mode           : Sparse Mode
IP Address          : 192.168.0.2
Hello Interval     : 30 sec
Hello HoldTime     : 105 sec
Triggered Hello Delay : 5 sec
Join/Prune Holdtime : 210 sec
Lan Prune Delay    : Disabled
Propagation Delay  : 500 ms
Override Interval  : 2500 ms
DR Priority         : 20
Join/Prune Interval : 60 sec

```

```
Console#
```

**ip pim join-prune-interval** This command sets the join/prune timer. Use the **no** form to restore the default setting.

### Syntax

**ip pim join-prune-interval** *seconds*

**no ip pim join-prune-interval**

*seconds* - The interval at which join/prune messages are sent.  
(Range: 1-65535 seconds)

### Default Setting

60 seconds

### Command Mode

Interface Configuration (VLAN)

### Command Usage

- ◆ By default, the switch sends join/prune messages every 210 seconds to inform other PIM-SM routers about clients who want to join or leave a multicast group.
- ◆ Use the same join/prune message interval on all the PIM-SM routers in the same PIM-SM domain, otherwise the routing protocol's performance will be adversely affected.
- ◆ The multicast interface that first receives a multicast stream from a particular source forwards this traffic only to those interfaces on the router that have requested to join this group. When there are no longer any requesting groups on that interface, the leaf node sends a prune message upstream and enters a prune state for this multicast stream. The protocol maintains both the current join state and the pending Reverse Path Tree (RPT) prune state for this (source, group) pair until the join/prune-interval timer expires.

### Example

This example sets the priority used in the bidding process for the DR.

```

Console(config)#interface vlan 1
Console(config-if)#ip pim join-prune-interval 210
Console#show ip pim interface
PIM is enabled.
VLAN 1 is up.
PIM Mode           : Sparse Mode
IP Address          : 192.168.0.2
Hello Interval      : 30 sec
Hello HoldTime      : 105 sec
Triggered Hello Delay : 5 sec
Join/Prune Holdtime : 210 sec
Lan Prune Delay     : Disabled
Propagation Delay    : 500 ms
Override Interval    : 2500 ms
DR Priority          : 20
Join/Prune Interval : 80 sec

```

```
Console#
```

**ip pim rp-address** This command sets a static address for the Rendezvous Point (RP) for a particular multicast group. Use the **no** form to remove an RP address or an RP address for a specific group.

### Syntax

```
[no] ip pim rp-address rp-address [group-prefix group-address mask]
```

*rp-address* - Static IP address of the router that will be an RP for the specified multicast group(s).

*group-address* - An IP multicast group address. If a group address is not specified, the RP is used for all multicast groups.

*mask* - Subnet mask that is used for the group address.

### Default Setting

None

### Command Mode

Global Configuration

### Command Usage

- ◆ The router specified by this command will act as an RP for all multicast groups in the local PIM-SM domain if no groups are specified. A static RP can either be configured for the whole multicast group range 224.0.0.0/4, or for specific group ranges.
- ◆ Using this command to configure multiple static RPs with the same RP address is not allowed. If an IP address is specified that was previously used for an RP, then the older entry is replaced.
- ◆ Multiple RPs can be defined for different groups or group ranges. If a group is matched by more than one entry, the router will use the RP associated with the longer group prefix length. If the prefix lengths are the same, then the static RP with the highest IP address is chosen.
- ◆ Static definitions for RP addresses may be used together with RP addresses dynamically learned through the bootstrap router (BSR). If an RP address learned by the BSR and one statically configured using this command are both available for a group range, the RP address learned by the BSR is chosen over the one statically configured with this command.
- ◆ All routers within the same PIM-SM domain must be configured with the same RP(s). Selecting an RP through the dynamic election process is therefore preferable for most situations. Using the dynamic RP election process also

allows a backup RP to automatically take over if the active RP router becomes unavailable.

- ◆ If the **no** form of this command is used without specifying a multicast group, the default 224.0.0.0 (with the mask 240.0.0.0) is removed. In other words, all multicast groups are removed.

### Example

In the following example, the first PIM-SM command just specifies the RP address 192.168.1.1 to indicate that it will be used to service all multicast groups. The second PIM-SM command includes the multicast groups to be serviced by the RP.

```
Console(config)#ip pim rp-address 192.168.1.1
Console(config)#ip pim rp-address 192.168.2.1 group-prefix 224.9.0.0
255.255.0.0
Console(config)#
```

**ip pim spt-threshold** This command prevents the last-hop PIM router from switching to Shortest Path Source Tree (SPT) mode. Use the **no** form to allow the router to switch over to SPT mode.

### Syntax

**ip pim spt-threshold infinity** [**group-prefix** *group-address mask*]

**no ip pim spt-threshold infinity**

*group-address* - An IP multicast group address. If a group address is not specified, the command applies to all multicast groups.

*mask* - Subnet mask that is used for the group address.

### Default Setting

The last-hop PIM router joins the shortest path tree immediately after the first packet arrives from a new source.

### Command Mode

Global Configuration

### Command Usage

- ◆ The default path for packets from a multicast source to a receiver is through the RP. However, the path through the RP is not always the shortest path. Therefore, the router uses the RP to forward only the first packet from a new multicast group to its receivers. Afterwards, it calculates the shortest path tree (SPT) directly between the receiver and source, and then uses the SPT to send all subsequent packets from the source to the receiver instead of using the shared tree. Note that when the SPT threshold is not set by this command, the PIM leaf router will join the shortest path tree immediately after receiving the first packet from a new source.

- ◆ This command forces the router to use the shared tree for all multicast groups, or just for the specified multicast groups.
- ◆ Only one entry is allowed for this command.

### Example

This example prevents the switch from using the SPT for multicast groups 224.1.0.0~224.1.255.255.

```
Console(config-if)#ip pim sparse-mode
Console(config-if)#exit
Console(config)#ip multicast-routing
Console(config)#router pim
Console(config)#ip pim spt-threshold infinity group-prefix 224.1.0.0
0.0.255.255
Console#
```

**ip pim ssm range** This command configures the address of a PIM-SSM for multicast groups. Use the **no** form to remove an SSM address.

### Syntax

**ip pim ssm range** *group-address mask*

**no ip pim ssm**

*group-address* - An IP multicast group address. If a group address is not specified, the command applies to all multicast groups.

*mask* - Subnet mask that is used for the group address.

### Default Setting

None configured

### Command Mode

Global Configuration

### Example

```
Console(config)#ip pim ssm range 225.1.1.1 192.168.1.1

Console(config)#
```



# Multicast Routing Commands

This section describes commands used to configure multicast routing globally on the switch.

**Table 198: General Multicast Routing Commands**

Command	Function	Mode
<code>ip multicast-routing</code>	Enables IPv4 multicast routing	GC
<code>show ip mroute</code>	Shows the IPv4 multicast routing table	PE

**ip multicast-routing** This command enables IPv4 multicast routing. Use the **no** form to disable IP multicast routing.

## Syntax

**[no] ip multicast-routing**

## Default Setting

Disabled

## Command Mode

Global Configuration

## Command Usage

- ◆ This command is used to enable IPv4 multicast routing globally for the router. A specific multicast routing protocol also needs to be enabled on the interfaces that will support multicast routing using the `router pim` command, and then specify the interfaces that will support multicast routing using the `ip pim sparse-mode` commands.

## Example

```
Console(config)#ip multicast-routing
Console(config)#
```

**show ip mroute** This command displays the IPv4 multicast routing table.

### Syntax

**show ip mroute** [*group-address source*] [**summary**]

*group-address* - An IPv4 multicast group address with subscribers directly attached or downstream from this router.

*source* - The IPv4 subnetwork at the root of the multicast delivery tree. This subnetwork contains a known multicast source.

**summary** - Displays summary information for each entry in the IP multicast routing table.

### Command Mode

Privileged Exec

### Command Usage

This command displays information for multicast routing. If no optional parameters are selected, detailed information for each entry in the multicast address table is displayed. If you select a multicast group and source pair, detailed information is displayed only for the specified entry. If the **summary** option is selected, an abbreviated list of information for each entry is displayed on a single line.

### Example

This example shows detailed multicast information for a specified group/source pair

```

Console#show ip mroute 224.0.255.3 192.111.46.8

IP Multicast Forwarding is enabled.

IP Multicast Routing Table
Flags: D - Dense, S - Sparse, s - SSM Channel, C - Connected, P - Pruned,
      F - Register flag, R - RPT-bit set, T - SPT-bit set, J - Join SPT
Interface state: F - Forwarding, P - Pruned, L - Local

(192.168.2.1, 224.0.17.17), uptime 00:00:05
Owner: PIM-DM, Flags: D
Incoming Interface: VLAN2, RPF neighbor: 192.168.2.1
Outgoing Interface List:
VLAN1(F)

Console#

```

Table 199: show ip mroute - display description

Field	Description
Flags	<p>The flags associated with this entry:</p> <ul style="list-style-type: none"> <li>◆ D (Dense) - PIM Dense mode in use.</li> <li>◆ S (Sparse) - PIM Sparse mode in use.</li> <li>◆ s (SSM) - A multicast group with the range of IP addresses used for PIM-SSM.</li> <li>◆ C (Connected) - A member of the multicast group is present on this interface.</li> <li>◆ P (Pruned) - This route has been terminated.</li> <li>◆ F (Register flag) - This device is registering for a multicast source.</li> <li>◆ R (RP-bit set) - The (S,G) entry is pointing to the Rendezvous Point (RP), which normally indicates a pruned state along the shared tree for a particular source.</li> <li>◆ T (SPT-bit set) - Multicast packets have been received from a source on the shortest path tree.</li> <li>◆ J (Join SPT) - The rate of traffic arriving over the shared tree has exceeded the SPT-threshold for this group. If the SPT flag is set for (*,G) entries, the next (S,G) packet received will cause the router to join the shortest path tree. If the SPT flag is set for (S,G), the router immediately joins the shortest path tree.</li> </ul>
Interface state	The multicast state for the displayed interface.
group address	IP multicast group address for a requested service.
source	Subnetwork containing the IP multicast source.
uptime	The time elapsed since this entry was created.
Owner	The associated multicast protocol (PIM).
Incoming Interface	<p>Interface leading to the upstream neighbor.</p> <p>PIM creates a multicast routing tree based on the unicast routing table. If the related unicast routing table does not exist, PIM will still create a multicast routing entry, but displays "Null" for the upstream interface to indicate that the unicast routing table is not valid. This field may also display "Register" to indicate that a pseudo interface is being used to send or receive PIM-SM register packets.</p>
RPF neighbor	IP address of the multicast router immediately upstream for this group.
Outgoing interface list and flags	<p>The interface(s) on which multicast subscribers have been recorded. The flags associated with each interface indicate:</p> <ul style="list-style-type: none"> <li>◆ F (Register flag) - This device is registering for a multicast source.</li> <li>◆ P (Pruned) - This route has been terminated.</li> <li>◆ L (Local) - Downstream interface has received IGMP report message from host in this subnet.</li> </ul>

This example lists all entries in the multicast table in summary form:

```

Console#show ip mroute summary

IP Multicast Forwarding is enabled

IP Multicast Routing Table (Summary)
Flags: F - Forwarding, P - Pruned
  Group                Source                Source Mask           Interface  Owner  Flags
-----
  224.0.0.17.17       192.168.2.1 255.255.255.255     VLAN2      PIM-DM F

```

Total Entry is 1

Console#

---

# Section III

## Appendices

This section provides additional information and includes these items:

- ◆ [“Troubleshooting” on page 1205](#)
- ◆ [“License Information” on page 1207](#)





# Troubleshooting

## Problems Accessing the Management Interface

Table 200: Troubleshooting Chart

Symptom	Action
Cannot connect using Telnet, or SNMP software	<ul style="list-style-type: none"><li>◆ Be sure the switch is powered up.</li><li>◆ Check network cabling between the management station and the switch. Make sure the ends are properly connected and there is no damage to the cable. Test the cable if necessary.</li><li>◆ Check that you have a valid network connection to the switch and that the port you are using has not been disabled.</li><li>◆ Be sure you have configured the VLAN interface through which the management station is connected with a valid IP address, subnet mask and default gateway.</li><li>◆ Be sure the management station has an IP address in the same subnet as the switch's IP interface to which it is connected.</li><li>◆ If you are trying to connect to the switch via the IP address for a tagged VLAN group, your management station, and the ports connecting intermediate switches in the network, must be configured with the appropriate tag.</li><li>◆ If you cannot connect using Telnet, you may have exceeded the maximum number of concurrent Telnet/SSH sessions permitted. Try connecting again at a later time.</li></ul>
Cannot connect using Secure Shell	<ul style="list-style-type: none"><li>◆ If you cannot connect using SSH, you may have exceeded the maximum number of concurrent Telnet/SSH sessions permitted. Try connecting again at a later time.</li><li>◆ Be sure the control parameters for the SSH server are properly configured on the switch, and that the SSH client software is properly configured on the management station.</li><li>◆ Be sure you have generated an RSA public key on the switch, exported this key to the SSH client, and enabled the SSH service. Try using another SSH client or check for updates to your SSH client application.</li><li>◆ Be sure you have set up an account on the switch for each SSH user, including user name, authentication level, and password.</li><li>◆ Be sure you have imported the client's public key to the switch (if public key authentication is used).</li></ul>
Cannot access the on-board configuration program via a serial port connection	<ul style="list-style-type: none"><li>◆ Be sure you have set the terminal emulator program to VT100 compatible, 8 data bits, 1 stop bit, no parity, and the baud rate set to 115200 bps.</li><li>◆ Verify that you are using the RJ-45 to DB-9 null-modem serial cable supplied with the switch. If you use any other cable, be sure that it conforms to the pin-out connections provided in the Installation Guide.</li></ul>
Forgot or lost the password	<ul style="list-style-type: none"><li>◆ Contact your local distributor.</li></ul>

## Using System Logs

If a fault does occur, refer to the Installation Guide to ensure that the problem you encountered is actually caused by the switch. If the problem appears to be caused by the switch, follow these steps:

1. Enable logging.
2. Set the error messages reported to include all categories.
3. Enable SNMP.
4. Enable SNMP traps.
5. Designate the SNMP host that is to receive the error messages.
6. Repeat the sequence of commands or other actions that lead up to the error.
7. Make a list of the commands or circumstances that led to the fault. Also make a list of any error messages displayed.
8. Set up your terminal emulation software so that it can capture all console output to a file. Then enter the “show tech-support” command to record all system settings in this file.
9. Contact your distributor’s service engineer, and send a detailed description of the problem, along with the file used to record your system settings.

For example:

```
Console(config)#logging on
Console(config)#logging history flash 7
Console(config)#snmp-server host 192.168.1.23
:
```



---

# License Information

This product includes copyrighted third-party software subject to the terms of the GNU General Public License (GPL), GNU Lesser General Public License (LGPL), or other related free software licenses. The GPL code used in this product is distributed WITHOUT ANY WARRANTY and is subject to the copyrights of one or more authors. For details, refer to the section "The GNU General Public License" below, or refer to the applicable license as included in the source-code archive.

---

## The GNU General Public License

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.  
59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## **GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION**

1. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

2. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

3. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
  - a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
  - b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
  - c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

4. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
  - a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

- 5. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
- 6. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
- 7. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
- 8. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

9. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
10. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.  
  
Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.
11. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

1. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
2. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

---

# List of Commands

aaa accounting commands 256  
aaa accounting dot1x 257  
aaa accounting exec 258  
aaa accounting update 259  
aaa authorization commands 259  
aaa authorization exec 260  
aaa group server 261  
absolute 189  
access-list arp 414  
access-list ip 396  
access-list ipv6 402  
access-list mac 408  
accounting commands 263  
accounting dot1x 262  
accounting exec 263  
aggregate-address 1104  
alias 424  
area authentication 1036  
area default-cost 1037  
area nssa 1038  
area range 1040  
area range 1074  
area stub 1040  
area stub 1075  
arp 942  
arp timeout 943  
authentication enable 244  
authentication login 245  
authorization commands 264  
authorization exec 264  
auto-cost reference-bandwidth 1042  
auto-traffic-control 499  
auto-traffic-control action 499  
auto-traffic-control alarm-clear-threshold 500  
auto-traffic-control alarm-fire-threshold 501  
auto-traffic-control apply-timer 497  
auto-traffic-control auto-control-release 502  
auto-traffic-control control-release 503  
auto-traffic-control release-timer 498  
backup-port 532  
banner configure 113  
banner configure company 115  
banner configure dc-power-info 115  
banner configure department 116  
banner configure equipment-info 117  
banner configure equipment-location 117  
banner configure ip-lan 118  
banner configure ip-number 119  
banner configure manager-info 119  
banner configure mux 120  
banner configure note 121  
bgp always-compare-med 1106  
bgp as-path access-list 1098  
bgp bestpath as-path confed 1107  
bgp bestpath as-path ignore 1106  
bgp bestpath compare-routerid 1107  
bgp bestpath med 1108  
bgp client-to-client reflection 1108  
bgp cluster-id 1109  
bgp community-list 1099  
bgp conditional-advertisement timer 1117  
bgp confederation identifier 1110  
bgp confederation peers 1111  
bgp dampening 1112  
bgp default local-preference 1113  
bgp deterministic-med 1114  
bgp extcommunity-list 1101  
bgp fast-external-failover 1114  
bgp log-neighbor-changes 1115  
bgp network import-check 1116  
bgp router-id 1116  
boot system 136  
bootfile 921  
bpdu-tcn-notify 634  
bridge-ext gvrp 570  
calendar set 187  
call 1166  
capabilities 424  
channel-group 458  
class 674  
class-map 670  
clear access-list hardware counters 417  
clear arp-cache 944  
clear counters 431  
clear dns cache 897  
clear efm oam counters 884  
clear efm oam event-log 884  
clear erps statistics 647  
clear ethernet cfm ais mpid 849  
clear ethernet cfm errors 861  
clear ethernet cfm linktrace-cache 870  
clear ethernet cfm maintenance-points remote 860

## List of Commands

clear ip bgp 1117  
clear ip bgp dampening 1120  
clear ip bgp ipv4 1119  
clear ip dhcp binding 930  
clear ip dhcp snooping binding 349  
clear ip dhcp snooping database flash 349  
clear ip igmp group 761  
clear ip igmp snooping groups dynamic 709  
clear ip igmp snooping statistics 710  
clear ip ospf process 1059  
clear ip rip route 1030  
clear ip source-guard binding blocked 367  
clear ipv6 dhcp snooping binding 358  
clear ipv6 dhcp snooping statistics 359  
clear ipv6 mld snooping groups dynamic 739  
clear ipv6 mld snooping statistics 739  
clear ipv6 nd snooping binding 992  
clear ipv6 nd snooping prefix 992  
clear ipv6 neighbors 984  
clear ipv6 traffic 968  
clear log 164  
clear mac-address-table dynamic 525  
clear mvr groups dynamic 776  
clear mvr statistics 776  
clear mvr6 groups dynamic 799  
clear mvr6 statistics 799  
clear network-access 328  
clear pppoe intermediate-agent statistics 306  
client-identifier 921  
clock summer-time (date) 180  
clock summer-time (predefined) 181  
clock summer-time (recurring) 182  
clock timezone 183  
clock timezone-predefined 184  
cluster 192  
cluster commander 193  
cluster ip-pool 194  
cluster member 194  
compatible rfc1583 1042  
configure 101  
continue 1167  
control-plane 687  
control-vlan 628  
copy 137  
databits 150  
default-information originate 1016  
default-information originate 1043  
default-metric 1017  
default-metric 1045  
default-metric 1076  
default-router 922  
delete 141  
delete public-key 278  
description 671  
description 1167  
description 425  
dir 141  
disable 102  
discard 426  
disconnect 157  
distance 1018  
distance 1121  
distance bgp 1121  
dns-server 923  
domain-name 923  
dos-protection echo-charge 384  
dos-protection smurf 384  
dos-protection tcp-flooding 385  
dos-protection tcp-null-scan 385  
dos-protection tcp-syn-fin-scan 386  
dos-protection tcp-udp-port-zero 386  
dos-protection tcp-xmas-scan 387  
dos-protection udp-flooding 387  
dos-protection win-nuke 388  
dot1q-tunnel system-tunnel-control 587  
dot1q-tunnel tpid 588  
dot1x default 283  
dot1x eapol-pass-through 284  
dot1x identity profile 292  
dot1x intrusion-action 285  
dot1x max-reauth-req 286  
dot1x max-req 286  
dot1x max-start 292  
dot1x operation-mode 287  
dot1x pae supplicant 293  
dot1x port-control 288  
dot1x re-authenticate 291  
dot1x re-authentication 288  
dot1x system-auth-control 284  
dot1x timeout auth-period 294  
dot1x timeout held-period 294  
dot1x timeout quiet-period 289  
dot1x timeout re-authperiod 289  
dot1x timeout start-period 295  
dot1x timeout supp-timeout 290  
dot1x timeout tx-period 290  
dying-gasp 197  
efm oam 880  
efm oam critical-link-event 880  
efm oam link-monitor frame threshold 882  
efm oam link-monitor frame window 882  
efm oam link-monitor frame 881  
efm oam mode **883**  
efm oam remote-loopback 885  
efm oam remote-loopback test 886  
enable 99  
enable (instance) 627  
enable (ring) 626

enable password 240  
end 103  
erps 621  
erps clear 647  
erps forced-switch 643  
erps instance 624  
erps manual-switch 645  
erps node-id 622  
erps ring 623  
erps vlan-group 623  
ethernet cfm ais level 840  
ethernet cfm ais ma 841  
ethernet cfm ais period 842  
ethernet cfm ais suppress alarm 842  
ethernet cfm cc enable 858  
ethernet cfm cc ma interval 857  
ethernet cfm delay-measure two-way 876  
ethernet cfm domain 843  
ethernet cfm enable 845  
ethernet cfm linktrace 869  
ethernet cfm linktrace cache 866  
ethernet cfm linktrace cache hold-time 867  
ethernet cfm linktrace cache size 868  
ethernet cfm loopback 871  
ethernet cfm mep 848  
ethernet cfm mep crosscheck 865  
ethernet cfm mep crosscheck start-delay 863  
ethernet cfm port-enable 849  
excluded-vlan 616  
exclusion-vlan 626  
exec-timeout 150  
exit 103  
fan-speed force-full 133  
fec 429  
flowcontrol 426  
garp timer 571  
guard-timer 631  
hardware-address 924  
history 427  
holdoff-timer 632  
host 924  
hostname 112  
inclusion-vlan 642  
interface 423  
interface loopback 937  
interface vlan 578  
ip access-group 400  
ip address 934  
ip address (loopback) 937  
ip arp inspection 375  
ip arp inspection filter 376  
ip arp inspection limit 380  
ip arp inspection log-buffer logs 377  
ip arp inspection trust 380  
ip arp inspection validate 378  
ip arp inspection vlan 379  
ip default-gateway 936  
ip dhcp client class-id 903  
ip dhcp dynamic-provision 902  
ip dhcp excluded-address 919  
ip dhcp inform 905  
ip dhcp pool 919  
ip dhcp relay information option 914  
ip dhcp relay information option encode no-subtype 914  
ip dhcp relay information option remote-id 915  
ip dhcp relay information policy 915  
ip dhcp relay server 911  
ip dhcp restart client 906  
ip dhcp restart relay 912  
ip dhcp snooping 338  
ip dhcp snooping max-number 348  
ip dhcp snooping database flash 350  
ip dhcp snooping information option 340  
ip dhcp snooping information option circuit-id 346  
ip dhcp snooping information option encode no-subtype 341  
ip dhcp snooping information option remote-id 342  
ip dhcp snooping information option tr101 board-id 343  
ip dhcp snooping information policy 344  
ip dhcp snooping trust 348  
ip dhcp snooping verify mac-address 344  
ip dhcp snooping vlan 345  
ip domain-list 892  
ip domain-lookup 893  
ip domain-name 894  
ip forward-protocol udp 946  
ip helper 947  
ip helper-address 948  
ip host 894  
ip http authentication 267  
ip http port 268  
ip http secure-port 269  
ip http secure-server 269  
ip http server 268  
ip igmp 756  
ip igmp authentication 720  
ip igmp filter (Global Configuration) 718  
ip igmp filter (Interface Configuration) 722  
ip igmp last-member-query-interval 757  
ip igmp max-groups 723  
ip igmp max-groups action 724  
ip igmp max-resp-interval 758  
ip igmp profile 719  
ip igmp query-drop 724  
ip igmp query-interval 758  
ip igmp snooping 693  
ip igmp snooping mrouter-forward-mode dynamic 694  
ip igmp snooping proxy-reporting 694

## List of Commands

ip igmp snooping querier 696  
ip igmp snooping report-suppression 695  
ip igmp snooping router-alert-option-check 696  
ip igmp snooping router-port-expire-time 697  
ip igmp snooping tcn-flood 697  
ip igmp snooping tcn-query-solicit 699  
ip igmp snooping unregistered-data-flood 699  
ip igmp snooping unsolicited-report-interval 700  
ip igmp snooping version 701  
ip igmp snooping version-exclusive 701  
ip igmp snooping vlan general-query-suppression 702  
ip igmp snooping vlan immediate-leave 703  
ip igmp snooping vlan last-memb-query-count 704  
ip igmp snooping vlan last-memb-query-intvl 704  
ip igmp snooping vlan mrd 705  
ip igmp snooping vlan mrouter 716  
ip igmp snooping vlan proxy-address 706  
ip igmp snooping vlan query-interval 707  
ip igmp snooping vlan query-resp-intvl 708  
ip igmp snooping vlan static 709  
ip igmp static-group 759  
ip igmp version 760  
ip mdns 899  
ip multicast-data-drop 725  
ip multicast-routing 1199  
ip name-server 895  
ip ospf area 1050  
ip ospf authentication 1051  
ip ospf authentication-key 1052  
ip ospf cost 1053  
ip ospf dead-interval 1054  
ip ospf hello-interval 1054  
ip ospf message-digest-key 1055  
ip ospf network 1056  
ip ospf priority 1057  
ip ospf retransmit-interval 1058  
ip ospf transmit-delay 1058  
ip pim 1186  
ip pim dr-priority 1192  
ip pim hello-holdtime 1188  
ip pim hello-interval 1188  
ip pim join-prune-holdtime 1189  
ip pim join-prune-interval 1194  
ip pim override-interval 1189  
ip pim propagation-delay 1190  
ip pim rp-address 1195  
ip pim spt-threshold 1196  
ip pim ssm range 1197  
ip prefix-list 1103  
ip proxy-arp 944  
ip rip authentication mode 1025  
ip rip authentication string 1026  
ip rip receive version 1027  
ip rip receive-packet 1027  
ip rip send version 1028  
ip rip send-packet 1029  
ip rip split-horizon 1030  
ip route 1006  
ip source-guard 363  
ip source-guard binding 361  
ip source-guard max-binding 365  
ip source-guard mode 366  
ip ssh authentication-retries 276  
ip ssh crypto host-key generate 278  
ip ssh crypto zeroize 279  
ip ssh save host-key 280  
ip ssh server 277  
ip ssh timeout 277  
ip telnet max-sessions 271  
ip telnet port 272  
ip telnet server 272  
ip tftp retry 147  
ip tftp timeout 147  
ipv6 access-group 406  
ipv6 address 952  
ipv6 address autoconfig 953  
ipv6 address dhcp 955  
ipv6 address eui-64 956  
ipv6 address link-local 958  
ipv6 default-gateway 951  
ipv6 dhcp client rapid-commit vlan 907  
ipv6 dhcp dynamic-provision 909  
ipv6 dhcp relay destination 916  
ipv6 dhcp restart client vlan 907  
ipv6 dhcp snooping 352  
ipv6 dhcp snooping max-binding 357  
ipv6 dhcp snooping option remote-id 354  
ipv6 dhcp snooping option remote-id policy 355  
ipv6 dhcp snooping trust 357  
ipv6 dhcp snooping vlan 356  
ipv6 enable 959  
ipv6 hop-limit 971  
ipv6 host 896  
ipv6 mld filter (Global Configuration) 747  
ipv6 mld filter (Interface Configuration) 750  
ipv6 mld max-groups 751  
ipv6 mld max-groups action 751  
ipv6 mld profile 748  
ipv6 mld query-drop 752  
ipv6 mld snooping 731  
ipv6 mld snooping proxy-reporting 731  
ipv6 mld snooping querier 732  
ipv6 mld snooping query-interval 732  
ipv6 mld snooping query-max-response-time 733  
ipv6 mld snooping robustness 733  
ipv6 mld snooping router-port-expire-time 734  
ipv6 mld snooping unknown-multicast mode 735  
ipv6 mld snooping unsolicited-report-interval 735

ipv6 mld snooping version 736  
ipv6 mld snooping vlan immediate-leave 736  
ipv6 mld snooping vlan mrouter 737  
ipv6 mld snooping vlan static 738  
ipv6 mtu 960  
ipv6 multicast-data-drop 753  
ipv6 nd dad attempts 973  
ipv6 nd managed-config-flag 975  
ipv6 nd ns-interval 976  
ipv6 nd other-config-flag 975  
ipv6 nd prefix 979  
ipv6 nd ra interval 981  
ipv6 nd ra lifetime 982  
ipv6 nd ra router-preference 982  
ipv6 nd ra suppress 983  
ipv6 nd raguard 977  
ipv6 nd reachable-time 979  
ipv6 nd snooping 987  
ipv6 nd snooping auto-detect 988  
ipv6 nd snooping auto-detect retransmit count 989  
ipv6 nd snooping auto-detect retransmit interval 990  
ipv6 nd snooping max-binding 991  
ipv6 nd snooping prefix timeout 990  
ipv6 nd snooping trust 991  
ipv6 neighbor 972  
ipv6 ospf area 1080  
ipv6 ospf cost 1081  
ipv6 ospf dead-interval 1082  
ipv6 ospf hello-interval 1083  
ipv6 ospf priority 1083  
ipv6 ospf retransmit-interval 1084  
ipv6 ospf transmit-delay 1085  
ipv6 route 1012  
ipv6 source-guard 371  
ipv6 source-guard binding 369  
ipv6 source-guard max-binding 372  
jumbo frame 133  
l2protocol-tunnel tunnel-dmac 594  
lACP 459  
lACP actor/partner mode (Ethernet Interface) 460  
lACP admin-key (Ethernet Interface) 461  
lACP admin-key (Port Channel) 463  
lACP port-priority 462  
lACP system-priority 463  
lACP timeout 464  
lease 926  
line 149  
lldp 813  
lldp admin-status 817  
lldp basic-tlv management-ip-address 817  
lldp basic-tlv management-ipv6-address 818  
lldp basic-tlv port-description 819  
lldp basic-tlv system-capabilities 819  
lldp basic-tlv system-description 820  
lldp basic-tlv system-name 820  
lldp dot1-tlv proto-ident 821  
lldp dot1-tlv proto-vid 821  
lldp dot1-tlv pvid 822  
lldp dot1-tlv vlan-name 822  
lldp dot3-tlv link-agg 823  
lldp dot3-tlv mac-phy 823  
lldp dot3-tlv max-frame 824  
lldp dot3-tlv poe 824  
lldp holdtime-multiplier 813  
lldp med-fast-start-count 814  
lldp med-location civic-addr 825  
lldp med-notification 827  
lldp med-tlv ext-poe 827  
lldp med-tlv inventory 828  
lldp med-tlv location 829  
lldp med-tlv med-cap 829  
lldp med-tlv network-policy 830  
lldp notification 830  
lldp notification-interval 814  
lldp refresh-interval 815  
lldp reinit-delay 815  
lldp tx-delay 816  
logging command 159  
logging facility 160  
logging history 160  
logging host 161  
logging level 162  
logging on 163  
logging sendmail 167  
logging sendmail destination-email 168  
logging sendmail host 168  
logging sendmail level 169  
logging sendmail source-email 170  
logging trap 163  
login 151  
loopback detection trap 512  
loopback-detection 510  
loopback-detection action 510  
loopback-detection recover-time 511  
loopback-detection release 513  
loopback-detection transmit-interval 512  
ma index name 846  
ma index name-format 847  
mac access-group 413  
mac-address-table aging-time 523  
mac-address-table static 524  
mac-authentication intrusion-action 327  
mac-authentication max-mac-count 327  
mac-authentication reauth-time 319  
mac-learning 310  
mac-vlan 607  
major-ring 633  
management 298

## List of Commands

match 672  
match as-path 1168  
match community 1168  
match extcommunity 1169  
match ip address 1170  
match ip next-hop 1170  
match ip route-source 1171  
match metric 1171  
match origin 1172  
match peer 1172  
max-hops 547  
maximum-paths 1007  
maximum-prefix 1019  
media-type 428  
meg-level 627  
memory 220  
mep archive-hold-time 860  
mep crosscheck mpid 864  
mep fault-notify alarm-time 873  
mep fault-notify lowest-priority 873  
mep fault-notify reset-time 875  
mgmt 106  
mgmt loglevel 107  
mgmt property 109  
mgmt setoption 107  
mgmt upgrade 109  
mlag 470  
mlag domain peer-link 470  
mlag group member 471  
mst priority 547  
mst vlan 548  
mvr 766  
mvr associated-profile 766  
mvr domain 767  
mvr immediate-leave 773  
mvr profile 767  
mvr proxy-query-interval 768  
mvr proxy-switching 769  
mvr robustness-value 770  
mvr source-port-mode 771  
mvr type 774  
mvr upstream-source-ip 772  
mvr vlan 772  
mvr vlan group 775  
mvr6 associated-profile 789  
mvr6 domain 789  
mvr6 immediate-leave 796  
mvr6 profile 790  
mvr6 proxy-query-interval 791  
mvr6 proxy-switching 792  
mvr6 robustness-value 793  
mvr6 source-port-mode dynamic 794  
mvr6 type 797  
mvr6 upstream-source-ip 794  
mvr6 vlan 795  
mvr6 vlan group 798  
name 549  
negotiation 429  
neighbor 1019  
neighbor activate 1123  
neighbor advertisement-interval 1123  
neighbor allowas-in 1124  
neighbor attribute-unchanged 1125  
neighbor capability orf prefix-list 1126  
neighbor capability dynamic 1125  
neighbor default-originate 1127  
neighbor description 1128  
neighbor distribute-list 1128  
neighbor dont-capability-negotiate 1129  
neighbor ebgp-multihop 1130  
neighbor enforce-first-as 1130  
neighbor enforce-multihop 1131  
neighbor filter-list 1131  
neighbor interface 1132  
neighbor maximum-prefix 1133  
neighbor next-hop-self 1134  
neighbor override-capability 1134  
neighbor passive 1135  
neighbor password 1136  
neighbor peer-group (Creating) 1136  
neighbor peer-group (Group Members) 1137  
neighbor port 1138  
neighbor prefix-list 1138  
neighbor remote-as 1139  
neighbor remove-private-as 1140  
neighbor route-map 1141  
neighbor route-reflector-client 1141  
neighbor route-server-client 1142  
neighbor send-community 1143  
neighbor shutdown 1144  
neighbor soft-reconfiguration inbound 1144  
neighbor strict-capability-match 1145  
neighbor timers 1146  
neighbor timers connect 1147  
neighbor unsuppress-map 1147  
neighbor update-source 1148  
neighbor weight 1149  
netbios-name-server 926  
netbios-node-type 927  
network 1020  
network 1149  
network 928  
network-access aging 317  
network-access dynamic-qos 319  
network-access dynamic-vlan 320  
network-access guest-vlan 321  
network-access link-detection 322  
network-access link-detection link-down 322

network-access link-detection link-up 323  
network-access link-detection link-up-down 324  
network-access mac-filter 318  
network-access max-mac-count 324  
network-access mode mac-authentication 325  
network-access port-mac-filter 326  
next-server 929  
nlm 217  
no rspan session 489  
non-revertive 634  
ntp authenticate 174  
ntp authentication-key 175  
ntp client 176  
ntp server 177  
on-match 1173  
option 929  
parity 152  
passive-interface 1021  
passive-interface 1045  
passive-interface 1077  
password 153  
password-thresh 153  
periodic 190  
permit, deny 719  
permit, deny 749  
permit, deny (ARP ACL) 415  
permit, deny (Extended IPv4 ACL) 397  
permit, deny (Extended IPv6 ACL) 404  
permit, deny (MAC ACL) 409  
permit, deny (Standard IP ACL) 396  
permit, deny (Standard IPv6 ACL) 403  
physical-ring 643  
ping 940  
ping6 969  
police flow 675  
police srtcm-color 677  
police trtcm-color 679  
policy-map 674  
port monitor 481  
port security 311  
port security mac-address sticky 313  
port security mac-address-as-permanent 313  
port-channel load-balance 457  
power inline 475  
power inline maximum allocation 476  
power inline priority 477  
power-save 453  
pppoe intermediate-agent 301  
pppoe intermediate-agent format-type 301  
pppoe intermediate-agent port-enable 302  
pppoe intermediate-agent port-format-type 303  
pppoe intermediate-agent port-format-type remote-id-delimiter 304  
pppoe intermediate-agent trust 305  
pppoe intermediate-agent vendor-tag strip 305  
primary-port 531  
privilege 242  
process cpu 221  
process cpu guard 222  
prompt 97  
propagate-tc 633  
protocol-vlan protocol-group (Configuring Groups) 602  
protocol-vlan protocol-group (Configuring Interfaces) 603  
qos map cos-dscp 659  
qos map dscp-mutation 661  
qos map ip-prec-dscp 662  
qos map phb-queue 658  
qos map trust-mode 663  
queue mode 654  
queue weight 655  
quit 100  
radius-server acct-port 246  
radius-server auth-port 247  
radius-server encrypted-key 249  
radius-server host 247  
radius-server key 248  
radius-server retransmit 249  
radius-server timeout 250  
range 720  
range 749  
raps-def-mac 638  
raps-without-vc 639  
rate-limit 492  
rcommand 195  
redistribute 1022  
redistribute 1046  
redistribute 1078  
redistribute 1150  
reload (Global Configuration) 98  
reload (Privileged Exec) 102  
rename 673  
revision 549  
ring-port 625  
rmon alarm 226  
rmon collection history 228  
rmon collection rmon1 229  
rmon event 227  
route-map 1165  
router bgp 1097  
router ipv6 ospf 1073  
router ospf 1035  
router pim 1186  
router rip 1016  
router-id 1048  
router-id 1079  
rpl neighbor 630  
rpl owner 629  
rspan destination 487

## List of Commands

rspan remote vlan 488  
rspan source 486  
server 261  
service dhcp 920  
service-policy 684  
service-policy 688  
set aggregator as 1173  
set as-path 1174  
set atomic-aggregate 1175  
set comm-list delete 1175  
set community 1176  
set cos 681  
set extcommunity 1177  
set ip dscp 682  
set ip next-hop 1178  
set local-preference 1179  
set metric 1180  
set origin 1180  
set originator-id 1181  
set phb 683  
set weight 1182  
sflow owner 234  
sflow polling instance 235  
sflow sampling instance 236  
show access-group 418  
show access-list 418  
show access-list arp 416  
show access-list tcam-utilization 123  
show accounting 265  
show arp 945  
show authorization 266  
show auto-traffic-control 507  
show auto-traffic-control interface 508  
show banner 121  
show bridge-ext 573  
show cable-diagnostics 451  
show calendar 187  
show class-map 684  
show cluster 196  
show cluster candidates 196  
show cluster members 196  
show discard 432  
show dns 897  
show dns cache 897  
show dos-protection 388  
show dot1q-tunnel 593  
show dot1q-tunnel service 592  
show dot1x 295  
show dying-gasp packets 198  
show dying-gasp status 198  
show efm oam counters interface 887  
show efm oam event-log interface 887  
show efm oam remote-loopback interface 889  
show efm oam status remote interface 890  
show efm oam status interface 889  
show erps 649  
show erps statistics 648  
show ethernet cfm configuration 850  
show ethernet cfm errors 862  
show ethernet cfm fault-notify-generator 875  
show ethernet cfm linktrace-cache 870  
show ethernet cfm ma 852  
show ethernet cfm maintenance-points local 853  
show ethernet cfm maintenance-points local detail mep 854  
show ethernet cfm maintenance-points remote crosscheck 866  
show ethernet cfm maintenance-points remote detail 855  
show ethernet cfm md 852  
show excluded-vlan 617  
show garp timer 574  
show gvrp configuration 575  
show history 100  
show hosts 898  
show interfaces brief 432  
show interfaces counters 433  
show interfaces history 437  
show interfaces protocol-vlan protocol-group 604  
show interfaces status 439  
show interfaces switchport 440  
show interfaces transceiver 448  
show interfaces transceiver-threshold 449  
show ip access-group 401  
show ip access-list 401  
show ip arp inspection configuration 381  
show ip arp inspection interface 381  
show ip arp inspection log 382  
show ip arp inspection statistics 382  
show ip arp inspection vlan 383  
show ip bgp 1152  
show ip bgp attribute-info 1153  
show ip bgp community 1153  
show ip bgp community-info 1154  
show ip bgp community-list 1155  
show ip bgp dampening 1155  
show ip bgp filter-list 1156  
show ip bgp neighbors 1157  
show ip bgp nexthop 1160  
show ip bgp paths 1157  
show ip bgp prefix-list 1158  
show ip bgp regexp 1158  
show ip bgp route-map 1159  
show ip bgp summary 1160  
show ip community-list 1161  
show ip dhcp 931  
show ip dhcp binding 931  
show ip dhcp dynamic-provision 906  
show ip dhcp pool 931

show ip dhcp relay 913  
show ip dhcp snooping 350  
show ip dhcp snooping binding 351  
show ip extcommunity-list 1161  
show ip helper 949  
show ip host-route 1009  
show ip igmp authentication 725  
show ip igmp filter 726  
show ip igmp groups 761  
show ip igmp interface 763  
show ip igmp profile 727  
show ip igmp query-drop 727  
show ip igmp snooping 710  
show ip igmp snooping group 711  
show ip igmp snooping mrouter 712  
show ip igmp snooping statistics 713  
show ip igmp throttle interface 728  
show ip interface 938  
show ip mdns 899  
show ip mroute 1200  
show ip multicast-data-drop 729  
show ip ospf 1059  
show ip ospf border-routers 1060  
show ip ospf database 1061  
show ip ospf database asbr-summary 1062  
show ip ospf database external 1063  
show ip ospf database network 1064  
show ip ospf database nssa-external 1065  
show ip ospf database router 1066  
show ip ospf database self-originate 1067  
show ip ospf database summary 1068  
show ip ospf interface 1070  
show ip ospf neighbor 1071  
show ip ospf route 1071  
show ip pim interface 1191  
show ip pim neighbor 1191  
show ip prefix-list 1162  
show ip prefix-list detail 1162  
show ip prefix-list summary 1163  
show ip protocols rip 1031  
show ip rip 1032  
show ip route 1007  
show ip route database 1010  
show ip route summary 1010  
show ip source-guard 367  
show ip source-guard binding 368  
show ip ssh 280  
show ip telnet 273  
show ip tftp 148  
show ip traffic 1010  
show ip traffic 938  
show ipv6 access-group 407  
show ipv6 access-list 407  
show ipv6 dhcp duid 909  
show ipv6 dhcp dynamic-provision 910  
show ipv6 dhcp relay destination 918  
show ipv6 dhcp snooping 359  
show ipv6 dhcp snooping binding 360  
show ipv6 dhcp snooping statistics 360  
show ipv6 dhcp vlan 910  
show ipv6 interface 961  
show ipv6 mld filter 753  
show ipv6 mld profile 754  
show ipv6 mld query-drop 754  
show ipv6 mld snooping group 741  
show ipv6 mld snooping group source-list 741  
show ipv6 mld snooping mrouter 742  
show ipv6 mld snooping statistics 743  
show ipv6 mld throttle interface 755  
show ipv6 mld snooping 740  
show ipv6 mtu 963  
show ipv6 nd prefix 985  
show ipv6 nd rguard 978  
show ipv6 nd snooping 993  
show ipv6 nd snooping binding 993  
show ipv6 nd snooping prefix 994  
show ipv6 neighbors 984  
show ipv6 ospf 1086  
show ipv6 ospf database 1086  
show ipv6 ospf database external 1087  
show ipv6 ospf database inter-area-prefix 1088  
show ipv6 ospf database inter-area-router 1088  
show ipv6 ospf database intra-area-router 1089  
show ipv6 ospf database link 1089  
show ipv6 ospf database network 1090  
show ipv6 ospf database router 1090  
show ipv6 ospf database self-originate 1091  
show ipv6 ospf interface 1091  
show ipv6 ospf neighbor 1092  
show ipv6 ospf route 1092  
show ipv6 route 1013  
show ipv6 source-guard 373  
show ipv6 source-guard binding 374  
show ipv6 traffic 964  
show l2protocol-tunnel 598  
show lacp 465  
show line 158  
show lldp config 831  
show lldp info local-device 832  
show lldp info remote-device 833  
show lldp info statistics 835  
show log 164  
show logging 165  
show logging sendmail 170  
show loop internal 452  
show loopback-detection 513  
show mac access-group 413  
show mac access-list 414

## List of Commands

show mac-address-table 526  
show mac-address-table aging-time 527  
show mac-address-table count 527  
show mac-address-table hash-lookup-depth 528  
show mac-vlan 608  
show management 299  
show memory 124  
show mgmt log 110  
show mgmt option 111  
show mgmt status 110  
show mgmt version 110  
show mlag 473  
show mlag domain 473  
show mlag group 473  
show mvr 777  
show mvr associated-profile 778  
show mvr interface 779  
show mvr members 780  
show mvr profile 782  
show mvr statistics 782  
show mvr6 800  
show mvr6 associated-profile 801  
show mvr6 domain 804  
show mvr6 interface 802  
show mvr6 members 802  
show mvr6 profile 805  
show mvr6 statistics 806  
show network-access 328  
show network-access mac-address-table 329  
show network-access mac-filter 330  
show nlm oper-status 220  
show ntp 178  
show ntp peer-status 179  
show ntp statistics peer 178  
show ntp status 178  
show policy-map 685  
show policy-map control-plane 688  
show policy-map interface 686  
show port monitor 483  
show port security 314  
show port-channel load-balance 468  
show power inline status 478  
show power inline time-range 479  
show power mainpower 480  
show power-save 454  
show pppoe intermediate-agent info 306  
show pppoe intermediate-agent statistics 307  
show privilege 243  
show process cpu 124  
show process cpu guard 125  
show process cpu task 126  
show protocol-vlan protocol-group 604  
show public-key 281  
show qos map cos-dscp 664  
show qos map dscp-mutation 665  
show qos map ip-prec-dscp 665  
show qos map phb-queue 666  
show qos map trust-mode 667  
show queue mode 657  
show queue weight 657  
show radius-server 250  
show reload 103  
show rmon alarms 230  
show rmon events 230  
show rmon history 231  
show rmon statistics 231  
show route-map 1182  
show rspan 490  
show running-config 126  
show sflow 237  
show smart-pair 533  
show snmp 203  
show snmp engine-id 214  
show snmp group 215  
show snmp notify-filter 220  
show snmp user 216  
show snmp view 217  
show snmp-server enable port-traps 208  
show snmp 174  
show spanning-tree 564  
show spanning-tree mst configuration 566  
show spanning-tree tc-prop 567  
show ssh 281  
show startup-config 128  
show subnet-vlan 606  
show system 129  
show tacacs-server 255  
show tech-support 130  
show time-range 191  
show traffic-segmentation 393  
show twamp reflector 536  
show udd 520  
show upgrade 146  
show users 131  
show version 131  
show vlan 585  
show vlan-translation 600  
show voice vlan 615  
show vrrp 1000  
show vrrp interface 1002  
show vrrp interface counters 1003  
show vrrp router counters 1004  
show watchdog 132  
show web-auth 335  
show web-auth interface 336  
show web-auth summary 336  
shutdown 430  
silent-time 154

smart-pair 529  
smart-pair restore 530  
snmp-server 201  
snmp-server community 201  
snmp-server contact 202  
snmp-server enable port-traps atc broadcast-alarm-clear 503  
snmp-server enable port-traps atc broadcast-alarm-fire 504  
snmp-server enable port-traps atc broadcast-control-apply 504  
snmp-server enable port-traps atc broadcast-control-release 505  
snmp-server enable port-traps atc multicast-alarm-clear 505  
snmp-server enable port-traps atc multicast-alarm-fire 506  
snmp-server enable port-traps atc multicast-control-apply 506  
snmp-server enable port-traps atc multicast-control-release 507  
snmp-server enable traps ethernet cfm cc 859  
snmp-server enable traps ethernet cfm crosscheck 863  
snmp-server enable port-traps link-up-down 207  
snmp-server enable port-traps mac-notification 208  
snmp-server enable traps 204  
snmp-server engine-id 209  
snmp-server group 210  
snmp-server host 205  
snmp-server location 203  
snmp-server notify-filter 218  
snmp-server user 211  
snmp-server view 213  
snmp client 172  
snmp poll 173  
snmp server 173  
spanning-tree 538  
spanning-tree bpdu-filter 550  
spanning-tree bpdu-guard 551  
spanning-tree cisco-prestandard 539  
spanning-tree cost 552  
spanning-tree edge-port 553  
spanning-tree forward-time 539  
spanning-tree hello-time 540  
spanning-tree link-type 554  
spanning-tree loopback-detection 555  
spanning-tree loopback-detection action 555  
spanning-tree loopback-detection release 563  
spanning-tree loopback-detection release-mode 556  
spanning-tree loopback-detection trap 557  
spanning-tree max-age 541  
spanning-tree mode 541  
spanning-tree mst configuration 543  
spanning-tree mst cost 558  
spanning-tree mst port-priority 559  
spanning-tree pathcost method 543  
spanning-tree port-bpdu-flooding 559  
spanning-tree port-priority 560  
spanning-tree priority 544  
spanning-tree protocol-migration 563  
spanning-tree restricted-tcn 557  
spanning-tree root-guard 561  
spanning-tree spanning-disabled 562  
spanning-tree system-bpdu-flooding 545  
spanning-tree tc-prop 545  
spanning-tree tc-prop-stop 562  
spanning-tree transmission-limit 546  
speed 155  
speed-duplex 430  
stopbits 155  
subnet-vlan 605  
summary-address 1048  
switchport acceptable-frame-types 579  
switchport allowed vlan 580  
switchport dot1q-tunnel mode 589  
switchport dot1q-tunnel priority map 590  
switchport dot1q-tunnel service match cvid 590  
switchport forbidden vlan 572  
switchport gvrp 573  
switchport ingress-filtering 581  
switchport l2protocol-tunnel 597  
switchport mode 582  
switchport native vlan 583  
switchport packet-rate 493  
switchport priority default 656  
switchport vlan-translation 598  
switchport voice vlan 612  
switchport voice vlan priority 613  
switchport voice vlan rule 613  
switchport voice vlan security 614  
tacacs-server encrypted-key 253  
tacacs-server host 251  
tacacs-server key 252  
tacacs-server port 253  
tacacs-server retransmit 254  
tacacs-server timeout 254  
telnet (client) 273  
terminal 157  
test cable-diagnostics 450  
test loop internal 451  
timeout login response 156  
time-range 188  
timers basic 1023  
timers bgp 1151  
timers spf 1049  
timers spf 1080  
traceroute 939  
traceroute6 970  
traffic-segmentation 389

---

## List of Commands

traffic-segmentation session 391  
traffic-segmentation uplink/downlink 391  
traffic-segmentation uplink-to-uplink 392  
transceiver-monitor 442  
transceiver-threshold current 443  
transceiver-threshold rx-power 444  
transceiver-threshold temperature 445  
transceiver-threshold tx-power 446  
transceiver-threshold voltage 447  
transceiver-threshold-auto 443  
twamp reflector 535  
twamp reflector refwait 536  
udld aggressive 518  
udld detection-interval 515  
udld message-interval 516  
udld port 519  
udld recovery 517  
udld recovery-interval 517  
umount usbdisk 142  
upgrade opcode auto 144  
upgrade opcode path 145  
upgrade opcode reload 146  
username 241  
version 1024  
version 641  
vlan 577  
vlan database 576  
vlan-trunking 584  
voice vlan 609  
voice vlan aging 610  
voice vlan mac-address 611  
vrrp authentication 996  
vrrp ip 996  
vrrp preempt 997  
vrrp priority 998  
vrrp timers advertise 999  
watchdog software 132  
web-auth 334  
web-auth login-attempts 332  
web-auth quiet-period 332  
web-auth re-authenticate (IP) 335  
web-auth re-authenticate (Port) 334  
web-auth session-timeout 333  
web-auth system-auth-control 333  
whichboot 143  
wtr-delay 533  
wtr-timer 631



